

Machine Manual: MAN-010

Machine Overview: Heat Exchanger HX01

This manual covers the operating principles and structural limits of the asset.

Specifications: 480V 3-Phase, 5000 RPM Max

Operating Limits: Do not exceed 85C core temperature.

Maintenance Schedule: Weekly lubrication, Monthly alignment check.

Common Faults: Pump vibration, Bearing failure

Troubleshooting: Refer to SOP for step-by-step resolution.

Safety Notes: Follow all plant safety regulations.