

User Guide SHS-3420

Please review all included documentation and use the product as intended. Safety precautions must be followed to avoid personal injury or property damage.

| Table of Contents

Introduction & Helpful Tips · · · · · · · 2
Components & Tools · · · · · · · 3
Door Preparation · · · · · · · · · · · · · · · 4
Installation · · · · · · · · · · · · · · · · · · ·
Basic Lock Operation Overview · · · · · · · · · · 8
Programming Features & Definitions · · · · · · 9-12
Programming · · · · · · · · 13
Miscellaneous Information · · · · · · · · · · · · · · · · · · ·
Troubleshooting · · · · · · · · · · · · · · · · · · ·
Management Number Table · · · · · · · · · · · · 19
Product Specifications · · · · · · 20
Warranty · · · · · · · · 21
Drilling Template

I Introduction

Congratulations on the purchase of your Samsung Smart Door Lock! Your lock has a touch sensitive number display pad and optionally a 13.56MHz Card reader. Up to 70 users can be registered to gain access with unique Codes or Access Cards (supports ISO14443A type).

The touchpad makes it convenient to enter the code and the Randomizer function helps prevent lockpicking using fingerprint traces on the touchpad. Other convenient functions such as Automatic Locking / Sound Setting / Out-of-Home Security, etc. provide advanced security and peace of mind.

You can unlock the door using video intercom's monitor after connecting a Samsung video intercom. (Refer to page 6 for connection diagram to a video intercom).

Helpful Tips

Do not attempt to repair the product yourself.

Change your codes regularly to ensure the security of your codes.

Minimize the lock's exposure to moisture including wet hands and direct contact with liquids.

Do not exert excessive force or use sharp instrument on the touchpad.

Insert the batteries according to correct polarity.

When the low-battery warning sounds, replace all batteries immediately.

Do not mix old batteries with new batteries.

Use soft, dry cloth to clean the lock and avoid cleaning with water, alcohol or other chemicals.

Components and Tools

Components


- Exterior Unit
- Interior Unit
- Interior Mounting Plate
- Turn Shaft
- Strike
- 4 AA Alkaline Batteries

- Key Tag
- User Guide
- Screw Pack (6 types)
- Deadbolt
- Magnet

Parts Drawings









Exterior Unit

Interior Unit

Interior Plate

Rubber Pad









Turn Shaft

Deadbolt

Strike

Magnet

Tools

Door Preparation

- 2-1/8"(54mm) hole saw
- 1"(25mm) hole saw
- 3/8"(10mm) drill bit
- 1/8"(2.5mm) drill bit
- Chisel and hammer

Lock Installation

- Screw driver #2
- Drill

Door Preparation

Step 1. Check Door Status

- 1) This lock supports door thickness of 1-7/32" to 1-9/16" (31 to 40 mm).
- 2) Using the provided lock template, ensure that there are no obstructions that would prevent installing the lock properly.
- 3) Take note of which orientation the deadbolt will need to be installed, left hand or right hand.



Left-Handed Door

When viewed from the Outside. the hinge is on the left.



Right-Handed Door

When viewed from the Outside. the hinge is on the right.








The hand type is not set by default and it is set to the direction where the magnetic is detected.

In order to change the hand type when it is already set, press the [OPEN/CLOSE] button while the magnet is detected from the desired direction.

Step 2. Mark the Door


Check the location and direction of the deadbolt, attach the drilling template (page 23) on the side of the door, and mark on it with a pen.

- 1) Align the horizontal line across the door.
- 2) Align the vertical line over the door.
- 3) Mark the centers of the holes with the drilling template.
- 4) Mark the centerline of the deadbolt by aligning it with the vertical line.







- 1) Drill a 2-1/8" (54 mm) diameter hole through the door, as indicated on the template, using a hole saw.
- 2) Drill a 1" (25 mm) mortise hole using a hole saw.
- 3) Drill strike plate holes using a drill bit (1/8", 2.5 mm).



Step 4. Strike Plate Installation

- Using the template, locate the center horizontal line for the deadbolt hole, which lines up with the center of the 2-1/8" hole, and draw a horizontal line on the door frame to mark where you will make the deadbolt mortise hole.
- 2) Measure half the thickness of the door. Now, measure that distance from where the door stops at the frame when the door is closed toward the the door jamb and mark a straight, vertical line the length of the door strike plate. Draw a horizontal line from the mark you made in Step 1 toward the vertical line. Where both lines cross, make a 1" (25 mm) diameter hole. 1/2" (13 mm) in depth.
- 3) Align the holes of the strike plate with the vertical line. Trace the outline of the strike plate and mortise with a 1/16" (1.6 mm) indentation. Attach the strike plate with the 2 screws provided. (T4 x 15: for wooden door, U10-24 x 9: for metal door)





Procedures

1. Insert the deadbolt.

- 1) Insert the deadbolt from the side of the door.
- 2) Rotate the deadbolt so the center hole is horizontally aligned from the outside.
- Fix the deadbolt using two FH+T4 x 25 screws. (T4x25/T4x15: for wooden door, U10-24x14: for steel door)

2. Insert the Exterior Unit.

(Ensure the Exterior Unit is aligned with the center hole of the deadbolt.)

3. Connect the Interior Mounting Plate.

- Detach the Interior Mounting Plate from the Interior Unit
- 2) First, install the two OH+M4 x 22 screws (3a) 90% of the way.
- 3) Next, fasten the Interior Mounting Plate with three FH+M5 x 20 screws (3b).
- Align the Exterior Unit with the Interior Mounting Plate and then fasten the Interior Mounting Plate using four FH+T4X25 screws (3c).
- 5) Tighten all screws on the Interior Mounting Plate 100%.
- While the deadbolt is in the open position, insert the turn shaft.
- 5. Connect the cable to the Interior Unit.

6. Fix screws for the Interior Unit.

- Align the Interior Unit on to the Interior Mounting Plate, and check that the Manual switchgear operates correctly. (Ensure cables are arranged neatly to prevent them from getting entangled or being compressed.)
- Open the battery cover of the Interior Unit. (There are screw grooves at the upper left and right corners.)

- 3) Using two PH+M4 x 26 screws, fasten the upper portion of the Interior Unit (6a).
- 4) Using two PH+M4 x 26 screws, fasten the lower portion of the Interior Unit (6b).
- Install the magnet after seeing page 23 to 25 for information about the drilling template sheet.

The hand type is not set by default and it is set to the direction where the magnetic is detected.

In order to change the hand type when it is already set, press the [OPEN/CLOSE] button while the magnet is detected from the desired direction.

CAUTION: If the magnet is not detected, automatic lock does not work.

So be sure to install it with the specified gap size.

8. Install 4 Alkaline batteries.

A melody will sound when all 4 batteries are installed correctly.

CAUTION: Press the [OPEN/CLOSE] button to check whether the dead bolt works properly.

Connect the video intercom

Connect the cable of video intercom to the Interior Unit.

SHS-3420 is compatible with SHT-3005 and other Samsung video intercom systems.

Basic Lock Operation Overview

Opening the Door with a PIN Code



Press the [Wake Up] button.



The number pad will illuminate. (If the Random Security function is enabled, press the 2 illuminated numbers.)



Enter the PIN Code and press the [*] button.

Successful:

Ding dong dang dong Failed:

■) Ding dong ding dong



The door opens within one second.

Opening the Door with a Card



Press the **[Wake Up]** button.




Touch the Card reader with an Access Card.

Successful:


Ding dong dang dong
Failed:


Ding dong ding dong



The door opens within one second.

Programming Features





Symbols	Description	Symbols	Description
W	Press the [Wake Up] button on the Exterior Unit. It is used to initiate Pin code or card access or to quit the registration mode.	*	Press the [*] button. It is used to complete number entry.
R	Press the [Registration] button. It is used to change the PIN Code or set other functions. R: Press the [Registration]	Mstr PIN	Enter the Master PIN Code (4~12 digits). Factory Default: 1234
R ₅	button briefly (~1 second) R5: Press the [Registration] button for 5 seconds R10: Press the [Registration] button for 10 seconds	1 ~ 0	Press the Number buttons.

Symbols	Description	Symbols	Description
U PIN	Enter the User PIN Code (4~12 digits).	®	Repeat the process inside the rectangle.
U CARD	Touch the Card reader with the User Card.	OPEN	Press the [OPEN/CLOSE] button.
Mgmt NO	Enter the User/Management Number. Can be set from 1 to 70.		Sound Icon Display.

Sound Indicators

Sound	Description
Fur Elise Tiritiritiririri	Low voltage warning sound accompanied with [OPEN/CLOSE] button flashing red.
Ding	Button input sound
Ding dong ding dong	Error sound
Ding dong dang	Success sound
Ding dong	Input standby sound
Toot~ toot~ (10 seconds)	Malfunction prevention warning
Ti~ ti~ ti~ ti~ (5 minutes)	Intrusion Detection/Out-of-home Security warning
Too~~t, too~~t	Double locking sound

Definitions

Double Authentication Mode: This mode requires both User Card and PIN Code to open the door, ensuring more security. However, Master PIN Code can open the door regardless of mode. This mode is disabled by default.

Double-locking : Double-locking prevents the lock from being unlocked from the outside. You can enable it by using the Double lock lever.

| Double-locking enable | Double-locking disable | Doub

Emergency Power Supply: Continuing to use the lock without replacing batteries when required will lead to the batteries discharging and cause the lock to malfunction. You can open the door by touching the external power contacts on the Exterior Unit with a 9V battery and then touching with the Card or entering the PIN Code.

Indicator Lamp: Indicates the operational status when the Card is being read or the lock is in operation.

Infrared Ray Sensor : This sensor detects movement on the inside with an infrared ray when the door opens by pressing [Open/Close] button. It prevents the door being opened by abnormal methods. You can enable or disable this sensor. This sensor is disabled by default.

Intrusion Detection Function: When the Interior Unit is forcibly detached while the door is locked, it is detected by the magnetic sensor and an alarm is sounded. (The function is not activated when the magnet is not used.) The Intrusion Detection function is a basic function and cannot be enabled or disabled.

Locking Mode (Auto/Manual): You can enable or disable the function for locking the door automatically when it is closed. The factory default is 'Auto mode'.

- Auto: The door is locked automatically 2 seconds after it is closed. However, it does not function if the magnet is not used or the batteries are completely discharged.
- Manual: When the door does not lock automatically when it is closed, pressing the **[Wake-Up]** button or the **[OPEN/CLOSE]** button on the Interior Unit will lock the door.

Low Voltage: Refers to the state when the operating voltage of the lock is lower than the standard voltage, and activates the Low Voltage Alarm ("Fur Elise") to indicate that the batteries need to be replaced. Use the Emergency Power when the batteries are completely discharged.

Magnetic Sensor: Detects the opening and closing of the door.

Malfunction Prevention Function (Mischief Prevention Function): When more than 5 failed authentication attempts with unregistered PIN Codes/Cards occur, a warning sounds for 10 seconds, and the lock stops operating for 3 minutes. While lock operation is stopped, a 'beep' is sounded every 10 seconds and the lock is activated again automatically after 3 minutes. The Malfunction Prevention function is a basic function and cannot be enabled or disabled.

Manual Switchgear: When the batteries are completely discharged, this device is used to mechanically lock or unlock the door from inside.

Master PIN Code: You can enter only one Master PIN (4-12 digits) Code. You can register the User PIN Codes/Cards after authenticating with the Master PIN (4-12 digits) Code. You can open the door with the Master PIN Code, and the factory default is '1234'.

OPEN/CLOSE Button: A one-touch button to open the locked door. (It is also used to lock the door from inside in the Manual locking mode.)

Out-of-Home Security Function: This function prevents intrusions from outside when no one is home. Pressing the [OPEN/CLOSE] button while the Out-of-Home function is enabled sounds an alarm. You can enable this function with either the Master PIN code or the User PIN Codes.

Random Security Function: This mode prevents the disclosure of the PIN Code by entering the PIN Code after authenticating 2 arbitrarily selected numbers. When the buttons for 2 arbitrarily selected numbers are illuminated, pressing the 2 illuminated buttons illuminates the whole number pad. You can enable or disable the Random Security function. This function is **enabled** by default.

Registration Button: This button is used to change Master PIN Code/User PIN Codes/User Cards or the lock settings. It is found below the battery cover of the Interior Unit. The length of time the **[Registration]** button is pressed varies depending on the function.

Resetting: Deletes all registered information and restores the factory default. After resetting, change the Master PIN Code for security.

Restart Button: This button resets the lock when the lock stops functioning. Registered information is not deleted.

Sound Setting: The volume during the input of numbers and opening or locking of the door can be set from Level 0 ~ Level 2. The sound is muted at Level 0 and is at maximum volume at Level 2. The registration mode operates at Level 1 regardless of the sound setting.

User Card: You can register up to 70 User Cards including the User PIN Codes. You can open the door with a User Card.

User/Management Number: It is the same number as the registered user's address and can be set from 1 to 70. The User Number should be managed with caution as it is used to register or delete User PIN Codes/Cards.

User PIN Code: You can register up to 70 User PIN Codes (4-12 digits) including the User Cards. You can open the door with a User PIN Code.

Wake Up Button: Pressing this button activates the number pad. Enter the PIN Code or touch with the Card while the number pad is illuminated. It is also used to quit the registration mode.

Scope of Master, User Settings

Settings	Master	User
Opening the Door	✓	✓
Setting Up the Sound	✓	✓
Changing Master PIN Code	✓	
Registering User PIN Code/Card	✓	
Deletion of User PIN Code/Card	✓	
Setting the Locking Mode	✓	✓
Setting Out-of-home Security	✓	✓
Setting Double-locking	√	✓
Setting Random Security	√	✓
Factory Reset	√	
Setting the Infrared Ray Sensor	✓	✓
Setting the Double Authentication Mode	✓	√

Factory Defaults

Factory Defaults
1234
Level 1
None
Auto
Disabled
Disabled
Enabled
Disabled
Disabled

Programming

Note: Pressing the [Registration] button is only available while the door is open. (Deadbolt must be unlocked.)

Changing the Master PIN Code



Open the battery cover of the Interior Unit and press the [Registration] button briefly.

Ding dong



When the number pad is illuminated, enter the current Master PIN Code (default is '1234') and press the [*] button.

Successful: () Ding dong Failed: ■) Ding dong ding dong



Enter the new Master PIN Code and press the [*] button. Successful: ■ Ding dong dang Failed: Ding dong ding dong Note: Master PIN Code must be



Registering a User PIN Code



Open the battery cover of the Interior Unit and press the [Registration] button briefly.

■) Ding dong

1	2	3	
4	5	6	
7	8	9	
_*	0	#	

When the number pad is illuminated, enter the current Master PIN Code (default is '1234') and press the [*] button.

Successful: Ding dong

Failed: Ding dong ding dong



Enter a User Number (1~70*) to register the User PIN Code and press the [*] button.

*Choose a User Number that has not already been used.

Successful:

Ding dong

Failed: (1) Ding dong ding dong



4~12 digits.


Enter a new User PIN Code and press [x] button. Successful:

Ding dong dang

Failed: Ding dong ding dong Note: User PIN Code must be 4~12 digits.



Enter another User Number or press the [Wake Up1 button to auit.



Registering a User Card



Open the battery cover of the Interior Unit and press the [Registration] button briefly.

|)) Ding dong

1	2	3	
4	5	6	
7	8	9	
*	0	#	

When the number pad is illuminated, enter the current Master PIN Code (default is '1234') and press the [*] button.

Successful: ■

Ding dong

Failed: ■

Ding dong ding dong

1	2	3	
4	5	6	
7	8	9	
*	0	#	

Enter a User Number (1~70*) to register the User Card code and press the [*] button.

* Choose a User Number that has not already been used.

Successful: ■③ Ding dong
Failed: ■③ Ding dong ding dong



Touch the Card reade. the Card to register.

Ding dong dang



Enter another User Number or press the **[Wake Up]** button to quit.



User PIN Code / Card Deletion



Open the battery cover of the Interior Unit and press and hold the **[Registration]** button for 5 seconds.

■)) Ding dong → Ding ding



Enter the Master PIN Code and press the [**] button.

Successful: ■**)Ding dong

Successful: ◄ Ding dong Failed: ◄ Ding dong ding dong


1	2	3	
4	5	6	
7	8	9	
 *	0	#	

Enter the User Number (1 to 70) of the User PIN Code or card to be deleted and press the [*] button.

Successful: ♠ Ding dong dang
Failed: ♠ Ding dong ding dong



Setting the Out-of-Home Security Function



Press and hold the **[Wake** Up] button on the outdoor assembly while the door is locked.

1	2	3	
4	5	6	
7	8	9	
*	0	#	

Press and hold the [#] button on the outdoor assembly for 3 seconds.

■)) Too~~t, too~~t


1	2	3	
4	5	6	
7	8	9	
*	0	#	

Enter the Master PIN Code or User PIN Code and press the [*] button to set the security function.

■⑥ Too~~~t



Additional Functions



Miscellaneous Information

Reset to Factory Default

Resetting the lock will delete all registered information.

Note: After Reset, let the sensor detect the magnet to set the hand type again.

All registered Master and user data will be deleted, and the lock will be reset to default settings. (Refer to the Program section on Page 12 for default values.)



Press the [Registration] button for 10 seconds.


Successful: \blacksquare \gg Ding dong → Ding ding → Ding ding



Enter the current Master PIN Code, and press the [*\frac{1}{2}] button.

Successful: ■ Ding dong dang Failed: ■ Ding dong ding dong

9V Battery Emergency Power




Continuing to use the lock without replacing the batteries when required will lead to lock malfunction. Touching a 9V DC battery to the external power contacts on the under-side of the Exterior Unit will allow for temporary access (continue touching the battery to the contacts until the lock is open).

Restart function

Note: Restarting does not delete registered information.

If there is no response after pressing the **[Wake Up]** button, use a pin to press the **[Restart]** button on the right of the external power contact of the Exterior Unit.



| Troubleshooting

When the lock doesn't function correctly, please check the items below. If you can't resolve the problem, please contact the nearest service center.

Problem	Resolution	Reference	
	Check if the batteries are inserted in the correct polarity.		
There is no power.	Check that the batteries have a full charge.	-	
	Check that the Exterior Unit cable has not come loose.		
I can't change the	There was a delay while changing the PIN Code. The number pad must be illuminated when changing the PIN Code. Also, after entering the first digit, the next digit must be entered within 10 seconds.		
Master PIN Code.	Replace the batteries if they are discharged.	Page 13	
	Refer to the 'Registering/changing the Master PIN Code' section in the user manual and try again. Ensure that the Master PIN Code is 4~12 digits long.		
I can't register the User PIN Code.	The User Number has already been used. Delete the desired User Number and re-register.		
FIN Code.	Ensure that the User PIN Code is 4~12 digits long.		
I can't register the User	The User Number has already been used. Delete the desired User Number and re-register.	Page 14	
Card.	Ensure that the card is touched to the card reader within 10 seconds of entering the User Number.		
	Check that the registered PIN Code was entered correctly.		
I entered the PIN Code and pressed the [*] button, but the door won't open.	If the number pad illumination turns off while entering the PIN Code, the button input was not registered. Press the [Wake Up] button to illuminate the number pad and enter the PIN Code again from the beginning. (The number pad illumination is turned off automatically if there is no input within 5 seconds)	Page 13	
I can't unlock the door	The Card is either unregistered or unrecognized.	Page 14	
with my Card.	The Card must touch the Card reader correctly.		
I can't unlock the door with my PIN Code or Card.	Check if the Double-locking function has been enabled. When this function is enabled, the lock will not open with a PIN Code or Card. Pressing the [Wake Up] button when the Double-locking function is enabled causes the lock to emit a 'Too~~t' sound.		
My PIN Code or Card is authenticated, but the door won't open.	The lock may be malfunctioning. Please contact service center.	-	

	Check if Auto Locking is set. When Manual Locking is set, pressing the [Wake Up] button locks the door.	
The door won't lock automatically when I close it.	If the door doesn't lock automatically when Auto Locking is set, then the lock has been installed incorrectly.	
	The Auto Locking function is not activated when the batteries are completely discharged. Check if the batteries are discharged.	
I hear the "Too~t, too~t" warning sound when I press the [Wake Up] button.	When the Double-Locking function is enabled, pressing the [Wake Up] button issues this warning sound. Check if Double-locking is enabled, disable the function and try again.	Page 15
The lock issues a different melody (Fur Elise) when I activate it.	with new patteries within a week	
There is no response when I press the [Wake Up] button. • Use a pin to press the hole on the right of the external power contact of the Exterior Unit. • If doing the above does nothing, contact the service center.		Page 16

lanagement No.	PIN CODE/CARD	User Name	Management No.	PIN CODE/CARD	User Name

| Product Specifications

Item	Specifications		
Voltage	4 AA Alkaline 1.5V Batteries (LR6) (6V)		
Emergency Power Source	9V Battery (6LF22) (purchased separately)		
Operation Method	Electronic Control Method (PIN Code entry or Card reading)		
Weight	1.8Kg (including both inside and Exterior Unit)		
	Exterior Unit	68.7 mm (W) × 175.1 mm (H) × 21.5 mm (D)	
Draduat Dimanaiana		2.70 inch (W) × 6.89 inch (H) × 0.85 inch (D)	
Product Dimensions	Interior Unit	90 mm (W) × 164.0 mm (H) × 46.65 mm (D)	
		3.54 inch (W) × 6.46 inch (H) × 1.84 inch (D)	

The content of this manual is subject to change without prior notice to the user in order to enhance the performance of the product.



Installation of the product is considered acceptance of warranty conditions

SAMSUNG SNS CO., LTD (SAMSUNG SNS) warrants its products to be free from manufacturing defects in materials and workmanship for 12 months from the date of purchase. SAMSUNG SNS will, within said period, at its option, repair or replace any product failing to operate correctly without charge to the original purchaser or user.

This warranty shall not apply to any equipment, or any part thereof, which has been repaired by others, improperly installed, improperly used, abused, altered, damaged, subjected to acts of God, or on which any serial numbers have been altered, defaced or removed. SAMSUNG SNS does not warrant the performance or sale conditions of the seller/installer.

There are no warranties, express or implied, which extend beyond the description on the face hereof. There is no express or implied warranty of merchantability of a warranty of fitness for a particular purpose. Additionally, this warranty is in lieu of all other obligations or liabilities on the part of SAMSUNG SNS.

Any action for breach of warranty, including but not limited to any implied warranty of merchantability, must be brought within the six months following the end of the warranty period. In no case shall SAMSUNG SNS be liable to anyone for any consequential or incidental damages for breach or this or any other warranty, express or implied, even if the loss or damage is caused by the seller's own negligence or fault.

SAMSUNG SNS shall have no obligation under this warranty, or otherwise, if the product has been repaired by others, improperly installed, improperly used, abused, altered, damaged, subjected to accident, nuisance, flood, fire or acts of God, or on which any serial numbers have been altered, defaced or removed. SAMSUNG SNS and its distributor will not be responsible for any dismantling, reassembly or reinstallation charges. This warranty contains the entire warranty. It is the sole warranty and any prior agreements or representations, whether oral or written, are either merged herein or are expressly cancelled. SAMSUNG SNS neither assumes, nor authorizes any other person purporting to act on its behalf to modify, to change, or to assume for it, any other warranty or liability concerning its products. In no event shall SAMSUNG SNS be liable for an amount in excess of SAMSUNG SNS's original selling price of the product, for any loss or damage, whether direct, indirect, incidental, consequential, or otherwise arising out of any failure of the product. Seller's warranty, as hereinabove set forth, shall not be enlarged, diminished or affected by and no obligation or liability shall arise or grow out of Seller's rendering of technical advice or service in connection with Buyer's order of the goods furnished hereunder. SAMSUNG SNS recommends that the entire system be completely tested weekly.

Warning: Despite frequent testing, and due to, but not limited to, any or all of the following; criminal tampering, electrical or communications disruption, it is possible for the system to fail to perform as expected. SAMSUNG SNS does not represent that the product/system may not be compromised or circumvented; or that the product or system will prevent any personal injury or property loss by burglary, robbery, fire or otherwise; nor that the product or system will in all cases provide adequate warning or protection. A properly installed and maintained alarm may only reduce risk of burglary, robbery, fire or otherwise but it is not insurance or a guarantee that these events will not occur.





Consequently, seller shall have no liability for any personal injury, property damage, or other loss based on a claim the product failed to give warning.

Therefore, the installer should in turn advise the consumer to take any and all precautions for his or her safety including, but not limited to, fleeing the premises and calling police or fire department, in order to mitigate the possibilities of harm and/or damage. SAMSUNG SNS is not an insurer of either the property or safety of the user's family or employees, and limits its liability for any loss or damage including incidental or consequential damages to SAMSUNG SNS's original selling price of the product regardless of the cause of such loss or damage.

Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitation of incidental or consequential damages, or differentiate in their treatment of limitations of liability for ordinary or gross negligence, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

In case of the product defect, contact our U.S. Customer Service Center. In order to exercise the warranty, you must contact our U.S. Customer Service Center and obtain a proper RMA # - the product must be returned to our U.S. Customer Service Center at user's shipping expense and the replacement product will be shipped back at our expense.


For product service, the product in all cases must be accompanied by below warranty form. Customer must ask the reseller or installer to fill out the warranty form indicated below, otherwise the product warranty may be considered void.

Visit our website at www.samsungsns.com and go to Support menu to find the contact information of our worldwide distributors.


Date of Purchase or Installation :	(MM/DD/YY)
Name, telephone and full address of purchaser :	
Stamp or Signature of authorized reseller / installer	Product Code and Serial Number :




Drilling Template Sheet for 60mm Backset



| Drilling Template Sheet for 60mm Magnet



Drilling Template Sheet for 70mm Backset



When installing the 60 mm iron door and 70 mm iron/wood door, a separate magnet sensor is applied.

Product information and customer service contact :
SAMSUNG SNS SAMSUNG SNS Co.,Ltd., reserves the right to change availability of any item in this catalog, its design, construction, and/or its materials. Copyright © 2009, SAMSUNG SNS Co.,Ltd. All right reserved. Reproduction in whole or in part without the express written permission of SAMSUNG SNS is prohibited.