
Procedure to Layout Export as GDS:

To export as GDS please do the following:-

Settings: First make the following settings in the "Preferences". Open Preferences -> I/O -> GDS and set the units/meter as 10^11 (Typically you will need to add two more zeros as it will be set, by default to 10^9). Shown is a screenshot to do the same.



Export: To export the GDS, do the following.

- 1. Open your CSM (8 Bit multiplier) layout in electric.
- 2. Click on File -> Export -> GDSII (Stream) as shown in the screenshot below.
- 3. Specify your group number as the File Name as "**GROUP_NUMBER.gds**". For example: if you belong to group 32, please name your file as "**32.gds**"



