

RACK DESIGNER

User Manual

Version 0.1.17

Stage Tools

stage-tools.github.io/stagetools

Contents

1. Introduction	4
1.1 What Rack Designer Does	4
1.2 System Requirements	4
1.3 Application Layout	4
2. Projects	5
2.1 Creating a New Project	5
2.2 Project Metadata Fields	5
2.3 Saving a Project	5
2.4 Opening an Existing Project	5
2.5 Deleting a Project	5
3. Designer	6
3.1 Racks Tab	6
3.1.1 Adding a Rack	6
3.1.2 Editing a Rack	6
3.1.3 Removing a Rack	6
3.2 Library Tab	6
3.2.1 Adding a Device to a Rack	6
3.2.2 Tray Placement	7
3.3 Custom Slots	7
3.4 The Rack Canvas	7
3.4.1 Selecting a Slot	7
3.4.2 Reordering Slots by Drag	7
3.4.3 Context Menu	7
3.4.4 Stats Bar	7
4. Library Management	8
4.1 Device Fields	8
4.2 Creating a Device	8
4.3 Editing a Device	8
4.4 Duplicating a Device	8
4.5 Deleting a Device	8
4.6 Custom Categories	9
4.7 Importing Devices	9
JSON	9
CSV	9
4.8 Exporting Devices	9
5. PDF Export	10
5.1 Rack Selection	10
5.2 Content Options	10
5.3 Generating the PDF	10

5.4 PDF Structure.....	10
6. Preloaded Device Library.....	11
6.1 Video.....	11
6.2 Audio.....	11
6.3 Lighting.....	11
6.4 Network.....	11
6.5 Power.....	11
7. Keyboard Shortcuts	12
8. Data Storage.....	13
9. Tips & Best Practices	14
9.1 Library Organisation	14
9.2 Rack Layout	14
9.3 PDF Export.....	14
9.4 Project Files.....	14
10. Troubleshooting	15
11. Version History.....	16

1. Introduction

Rack Designer is a rack layout application designed for live events, touring productions, permanent installations, and broadcast environments. It lets you build and document equipment racks, manage a reusable device library, and export rider-ready PDF reports.

1.1 What Rack Designer Does

- Design multi-rack layouts visually by dragging equipment from a library into rack slots.
- Manage a persistent device library with technical specifications (power, weight, dimensions).
- Support tray configurations — place multiple half-width or sub-rack-width devices side by side within a single rack row.
- Export PDF documentation including rack diagrams, device lists, power and weight totals, and project summaries.
- Store multiple projects independently, each with its own metadata and rack configuration.

1.2 System Requirements

Requirement	Details
Operating System	Windows 10 / 11 (64-bit)
Display	1280 × 800 pixels minimum, higher resolution recommended
Storage	~50 MB for the application; additional space for projects and library

1.3 Application Layout

The application is organised into five top-level sections accessible from the navigation bar at the top of the window:

Section	Purpose
PROJECT	Create, open, save, and delete projects. Edit project metadata.
DESIGNER	Visual rack layout editor. Add racks, drag devices, reorder slots.
EXPORT	Configure and generate PDF documentation.
LIBRARY	Manage the device library: add, edit, duplicate, delete, import, export.
ABOUT	Version information and links.

Note: The navigation bar also shows the current project name and a SAVE button. An amber dot (●) next to the project name indicates unsaved changes.

2. Projects

A project is the top-level container for your work. Each project holds metadata and one or more racks. Projects are saved to disk as `.rackproj` files.

2.1 Creating a New Project

Click PROJECT in the navigation bar, then click NEW PROJECT in the sidebar. A blank project is created in memory. Fill in the fields in the main area and click SAVE (or press Ctrl+S) to write it to disk for the first time.

Note: A new project does not appear in the Recent Projects list until it has been saved at least once.

2.2 Project Metadata Fields

Field	Description
Project name	Displayed in the navigation bar, window title, and exported PDFs.
Project number	Free-text reference (e.g. job or commission number). Exported as the Client field in PDFs.
Venue	Location or venue name. Appears in PDF exports.
Date	Free-text date (e.g. 2025-06-01). Appears in PDF exports.
Notes	Free-text notes. Appear in PDF exports when the Notes option is enabled.

2.3 Saving a Project

- Click SAVE in the navigation bar or the Project section footer, or press Ctrl+S.
- The first time a project is saved, a `.rackproj` file is created automatically in the application data directory.
- If a project with the same name already exists on disk, a numeric suffix is appended automatically (e.g. "My Show (2)").
- To save to a specific location, click SAVE AS... in the Project section footer.

2.4 Opening an Existing Project

- Select a project from the Recent Projects list in the left sidebar of the PROJECT section.
- Click Ctrl+O to browse for a `.rackproj` file anywhere on disk.

Note: If the current project has unsaved changes, a dialog will ask whether to save before loading another project. Choose Save, Discard, or Cancel.

2.5 Deleting a Project

Select a project in the Recent Projects list and click DELETE PROJECT (or the DELETE button in the footer). Confirm the action in the dialog. This permanently removes the `.rackproj` file from disk and cannot be undone.

Note: Deleting a project does not affect any library entries — only the project file is removed.

3. Designer

The Designer is the main workspace. It is divided into a resizable sidebar on the left and the rack canvas on the right. The sidebar has two tabs: RACKS and LIBRARY.

3.1 Racks Tab

The Racks tab lists all racks in the current project. Click a rack to select it. The selected rack is the target for the double-click action in the Library tab and for the "Add to selected rack" button in the Custom Slot section.

When a slot is selected on the canvas, a slot information panel appears below the rack list, showing the device name, category, physical dimensions, power draw, weight, and any notes attached to the slot.

3.1.1 Adding a Rack

Click + ADD RACK at the bottom of the Racks tab. In the dialog:

- Enter a name for the rack.
- Optionally select a common size preset (4U to 48U).
- Set the size in U (rack units). Range: 1–60.
- Set the number of bays (1, 2, or 3 side-by-side vertical sections within the same rack enclosure).

Note: Bays allow you to represent multi-bay physical rack cases. Each bay is displayed as an independent column on the canvas at the same U height.

3.1.2 Editing a Rack

Select a rack in the list and click EDIT. You can rename the rack and resize it. If you reduce the rack size, the application checks whether any slots in the rows that would be removed are occupied and refuses the change with a list of the conflicting devices.

Note: When a rack is enlarged, existing slots shift downward to make room at the top. When it is reduced, existing slots shift upward.

3.1.3 Removing a Rack

Select a rack in the list and click REMOVE. Confirm in the dialog. The rack and all its slots are permanently removed from the project. The library is not affected.

3.2 Library Tab

The Library tab lists all devices in your device library. Filter by category using the drop-down and search by name, manufacturer, model, or description using the search field.

3.2.1 Adding a Device to a Rack

There are two ways to place a library device into a rack:

- Drag: Click and hold a device in the library list, drag it onto the rack canvas, and release at the desired row. A highlight shows the target row under the cursor.
- Double-click: Double-click a device in the library list. It is appended to the currently selected rack at the first available position.

Tip: The drag ghost shows the device name with an amber border. Drop it precisely on the target row for accurate placement.

3.2.2 Tray Placement

Devices that are not rack-native (i.e. narrower than a full 19" rack width, 482 mm) can be placed side by side in the same row to form a tray. When you drag such a device onto an existing slot that already contains another sub-width device and there is enough horizontal space remaining, the two devices are automatically combined into a tray.

Note: Tray capacity is checked in millimetres. The standard rack inner width is 482 mm. Rack Designer refuses placement if the combined width of all tray members would exceed this limit.

3.3 Custom Slots

At the bottom of the Library tab is a Custom Slot section. Enter a label, set a height in U, then click "Add to selected rack". A custom slot is created at the first available position. Custom slots are useful for placeholder entries such as cable trays, spare space blocks, or labelled empty slots.

3.4 The Rack Canvas

The canvas displays all project racks side by side. Each rack is a vertical column of U-height rows. U1 is at the top. U number labels are shown to the left of the leftmost bay.

3.4.1 Selecting a Slot

Click a slot to select it. The selected slot is highlighted with an amber border, and the slot information panel in the sidebar updates accordingly. Click on an empty area to deselect.

3.4.2 Reordering Slots by Drag

Click and hold a slot on the canvas, then drag it up or down within the same bay. The slot cannot overlap another slot. Release to confirm the new position.

3.4.3 Context Menu

Right-click any slot on the canvas to open the context menu:

Action	Description
Edit notes...	Open a dialog to enter free-text notes for this slot. Slots with notes display an amber left-edge bar.
Move up ↑	Move the slot one unit upward (if space allows).
Move down ↓	Move the slot one unit downward (if space allows).
Remove from rack	Remove the slot from the rack. The device definition remains in the library.
Remove device from tray...	For tray slots only: a sub-menu lists each device in the tray individually for selective removal.

Right-clicking on an empty row offers:

- Insert blank panel at U[n] — inserts a 1U blank panel at the clicked position (if that row is free).

3.4.4 Stats Bar

Below the canvas a stats bar shows the total used U, free U, number of bays (when more than one), total power draw in watts, and total weight in kg for the entire project.

4. Library Management

The device library is a persistent, project-independent database of equipment definitions. Changes to the library do not retroactively affect devices already placed in racks — each slot stores a snapshot of the device definition at the time of placement.

4.1 Device Fields

Field	Description
Name	Required. Display name of the device.
Manufacturer	Free-text manufacturer name.
Model	Free-text model identifier.
Description	Short description of the device.
Category	Functional category. Used for filtering and colour coding. Built-in categories: Video, Audio, Lighting, Network, Power, Other. Custom categories can be added.
Mounting	Rack-native (standard 19"): the device occupies a declared number of U. Non-rack-native: height in mm is used to compute U automatically.
Height (U)	Number of rack units occupied (rack-native devices only, range 1–20).
Dimensions W/H/D	Physical width, height, and depth in mm. Width below 482 mm marks the device as sub-width, making it eligible for tray placement. Height drives U calculation for non-rack-native devices.
Color	Custom colour swatch for display on the canvas. If left as "auto", the category default colour is used.
Power (W)	Power consumption in watts. Contributes to per-rack and per-project totals.
Weight (kg)	Device weight. Contributes to per-rack and per-project totals.
Notes	Free-text technical notes visible in the device library and optionally in PDF exports.

4.2 Creating a Device

Click + NEW. A blank entry is created and selected. Fill in the fields in the right panel and click SAVE.

4.3 Editing a Device

Select a device in the list. Edit any fields in the right panel. Click SAVE to confirm. Changes apply to the library entry only — existing rack slots are not updated.

4.4 Duplicating a Device

Select a device and click DUPLICATE. A copy is created with " (copy)" appended to the name. Useful for creating variants (e.g. different power configurations of the same chassis).

4.5 Deleting a Device

Select a device and click DELETE. Confirm in the dialog. The device is removed from the library permanently. Projects that already contain this device are not affected.

4.6 Custom Categories

In addition to the six built-in categories, you can define your own. In the Category drop-down within the device form, select "+ Add category..." and enter a name. Custom categories are shared across all devices and projects.

4.7 Importing Devices

Click IMPORT in the Library toolbar. Supported formats:

JSON

A JSON array of device objects in the Rack Designer format (produced by the JSON export). All fields are preserved.

CSV

A semicolon-delimited file (comma is auto-detected if no semicolons are found). Expected column headers:

Column	Notes
Name	Required. If empty, Manufacturer and Model are combined as the name.
Manufacturer	Optional.
Model	Optional.
Description	Optional.
Category	Optional. Auto-capitalised. New categories are created automatically.
Power (W)	Optional. Accepts decimal values with comma or dot separator.
Height (U)	If present and valid, the device is treated as rack-native. If empty, H (mm) is used to compute U height; the device is treated as non-rack-native.
W	Physical width in mm. Optional.
H	Physical height in mm. Optional. Required for non-rack-native U calculation.
D	Physical depth in mm. Optional.
Weight (kg)	Optional.
Notes	Optional.

After parsing, a dialog asks whether to Merge or Replace:

- Merge: adds devices whose (name, category) pair is not already in the library. Duplicates are skipped.
- Replace: discards the existing library entirely and replaces it with the imported set.

4.8 Exporting Devices

Click EXPORT in the Library toolbar. A two-step dialog appears:

- Step 1 — Scope: export the entire library, a specific category, or only the currently selected device.
- Step 2 — Format: JSON (full fidelity) or CSV (semicolon-delimited, for editing in spreadsheet applications).

Note: Exported JSON files can be shared with other Rack Designer users and imported directly.

5. PDF Export

Navigate to the EXPORT section to configure and generate a PDF document for the current project.

5.1 Rack Selection

The left column lists all racks with a checkbox. Only checked racks are included in the export. All racks are checked by default.

5.2 Content Options

Option	Description
Rack diagram	Draws a scaled graphical representation of each rack, showing device positions and colour coding.
Color	When enabled alongside Rack diagram, the diagram prints in colour. Uncheck for greyscale output — useful for monochrome printing.
Device list per rack	Appends a table below each rack listing devices with quantity, name, category, and optional columns.
Include category column	Adds a Category column to the device list table.
Power totals	Adds power consumption (watts) to the rack info line, device list, and project summary.
Weight totals	Adds weight (kg) to the rack info line, device list, and project summary.
Project summary	Appends a summary table at the end of the document covering all selected racks.
Slot notes	Adds a Notes column to the device list, showing any per-slot notes.

5.3 Generating the PDF

Click EXPORT PDF, choose a file path in the save dialog, and confirm. A success message appears when the file is written. Open the file in any PDF viewer to review the output.

Note: Rack diagrams scale automatically to fit the page if their natural height exceeds the available print area.

5.4 PDF Structure

The generated PDF follows this structure:

- Document header: project name, client/project number, venue, date, generation date, and notes.
- Per-rack block: rack name, info line (size, used/free U; optional watts and kg), optional rack diagram, optional device list.
- Optional project summary table.
- Footer on every page: application credit line and page number.

6. Preloaded Device Library

On first launch, Rack Designer seeds the library with a curated set of commonly used professional equipment across five categories.

6.1 Video

- Disguise: GX 1, GX 2, GX 3, GX 3+, VX 4+, 4x4 Pro, 2x2
- AV Stumpfl Pixera: PX Zero, PX One Gen2, PX Two Gen2, PX Four Gen2, PX Four RS Gen2
- Barco: ImagePro-4K, EX, S3, E2, E2 Gen2, Encore 3, PDS 4K
- Analog Way: Aquilon RS1–RS6, Ascender 16, 32, 48
- Novastar: MCTRL 4K, MCTRL R5, VX400/600/1000/2000 Pro, H2, H5, H9, H15, H20
- Pixelhue: 4K ViewPro, P10, P20, P20 DS, P80, P8
- Colorlight: Z3, Z6
- Lightware: MX2 8x8, 16x16, 24x24 HDMI; 16x16 DVI
- Blackmagic Design: Teranex AV; HyperDeck HD Mini, Plus, Pro, 4K; Videohub 10x10 to 80x80 12G; ATEM Constellation HD and 4K/8K series; MultiView 4 and 16; full Teranex Mini converter range

6.2 Audio

- Drawmer: DA6 Distribution Amplifier
- Tascam: US-16x8
- Focusrite: Scarlett 18i20 3rd Gen
- Yamaha: SWP1 Dante switches (SWP1-8MMF, SWP1-16MMF, SWP1-8S)

6.3 Lighting

- Luminex: LumiSplit 2.10, LumiNode 12

6.4 Network

- Luminex: Gigacore 10t, Gigacore 18t
- Netgear M4250 series: multiple PoE+ and PoE++ variants
- Netgear Prosafe: G716T, XS508M, XS708Ev2, XS512EM

6.5 Power

- Eaton UPS: 5PX 1500, 2200, 3000 (Gen1 and Gen2); 5P 1150, 1150 Gen2

Note: The preloaded library is seeded only once, on first launch. All subsequent edits, additions, and deletions are preserved. Reinstalling the application will reseed the library only if it is empty.

7. Keyboard Shortcuts

Shortcut	Action
Ctrl+S	Save the current project.
Ctrl+O	Open a project file from disk.
Ctrl+N	Create a new project.
Click (canvas)	Select a slot; click empty area to deselect.
Click + Drag (canvas slot)	Reorder a slot within its bay.
Right-click (canvas)	Open the context menu for the slot or empty row under the cursor.
Click + Drag (library item)	Drag a device from the library onto the rack canvas.
Double-click (library item)	Append a device to the selected rack at the first available position.

8. Data Storage

Rack Designer stores all persistent data in the application data directory:

`%APPDATA%\RackDesigner\`

File / Folder	Contents
library.json	The complete device library.
custom_categories.json	User-defined custom categories.
projects\	Folder containing all saved .rackproj project files.

Project files (.rackproj) are plain JSON and can be backed up, version-controlled, or shared with other users. A shared .rackproj file contains a full snapshot of all device data and does not require the recipient to have the same library installed.

Note: There is no cloud sync or auto-save. Save your work regularly with Ctrl+S.

9. Tips & Best Practices

9.1 Library Organisation

- Use a consistent naming convention: Manufacturer Model (e.g. "Novastar MCTRL R5").
- Always fill in Watts and Weight for equipment that carries electrical or structural significance — these values drive the power and weight totals in the PDF export.
- Use the Depth field to document rack depth requirements even if it is not visible on the canvas; it is a useful documentation reference.
- For equipment available in multiple configurations, use DUPLICATE and adjust the copy rather than creating from scratch.

9.2 Rack Layout

- Reflect the physical placement in your layout: heavy equipment (UPS, amplifiers) at the bottom, network and processing at the top.
- Use blank panels (right-click on empty rows) to document intentionally empty U spaces.
- Use slot notes (right-click → Edit notes...) to attach cable labels, IP addresses, or configuration reminders directly to slots.
- Multi-bay racks are useful for wide physical cases. Devices do not span bays — each bay is an independent column.

9.3 PDF Export

- For rider and advance documentation: enable Rack diagram, Color, Device list, Power totals, Weight totals, and Project summary.
- For a printed working copy: disable Color to produce a greyscale diagram that reads well on monochrome printers.
- Enable Slot notes to include per-slot annotations in the device list — useful for cabling notes and configuration details.

9.4 Project Files

- Keep a copy of the .rackproj file alongside your production documentation. The file is self-contained.
- Use SAVE AS... to create named revisions (e.g. MyShow_v2_preproduction.rackproj).

10. Troubleshooting

Issue	Solution
A device dragged from the library does not appear in the rack.	Ensure there is at least enough consecutive free U space in the target bay for the device height. The canvas highlights the target row under the cursor on drag.
Cannot reduce rack size — the application shows devices in the way.	Move or remove the listed devices before reducing the rack size.
A sub-width device is not combining into a tray.	Both the existing slot and the dragged device must be non-rack-native with a Width value set. The combined width must not exceed 482 mm.
The PDF rack diagram is very small.	The diagram scales to fit one page. Very large racks produce proportionally smaller diagrams. There is currently no option to split diagrams across multiple pages.
A project file cannot be opened.	Ensure the file ends in .rackproj and has not been corrupted. Use OPEN FILE... to browse for it. The file is plain JSON and can be inspected in a text editor.
Library changes are not reflected in existing rack slots.	This is by design. Slots store a snapshot of the device at placement time. Re-adding the device to the rack will use the current library definition.

11. Version History

Version	Highlights
0.1.17	Initial public release. Project management, visual rack designer, device library with 100+ preloaded devices, PDF export, tray placement, multi-bay rack support, CSV and JSON import/export.

Rack Designer is developed by Riccardo Nessi — Stage Tools
stage-tools.github.io/stagetools