



STEELROCK TECHNOLOGIES

SECONDSIGHT

Client Test & Feedback Guide

STANDALONE CONSOLE

WINDOWS & ANDROID

BUILD 4.0.0

Jamming & detection console for the deployed operator.

Prepared for client evaluation. **Not for onward distribution outside the evaluation team.**

SteelRock Technologies Limited · September 2026

1 About SecondSight

SecondSight is SteelRock's standalone counter-UAS console for the deployed operator: it **detects** drones and their control signals, and **defeats** them through a family of jamming and GNSS-deception effectors — on one screen, on a Windows laptop or an Android phone/tablet.

DETECT

Delta R · Delta+ · Echo

RF detection and direction finding — drones, RID, non-RID and FPV signals, plotted on the map.

DEFEAT — JAM

Foxtrot · Foxtrot 50 · Sierra · Whiskey · X8

Full-band ECM and multi-channel RF jammers, each with its own control page.

DEFEAT — DECEIVE

Echo (GNSS)

GNSS deception — area denial and targeted takedown of a drone's satellite navigation.

ONE PICTURE

Map + control board

A live map beside the controls, so detections and effects share one operating picture.

This evaluation build opens unlocked — you will see a “**DEVELOPMENT BUILD · SIGN-IN SUSPENDED**” banner. That is expected for testing and will not appear in a release build.

2 Getting started

The layout is the same on both platforms: the **map** on one side, the **control board** on the other, and a row of tabs along the bottom — **Home · Detectors · Jammer · Echo · Settings**. On a phone the board stacks so every control stays reachable.

Windows

Launch SecondSight from the desktop shortcut. It opens full-screen with the map and board side by side.

Android (phone & tablet)

Open **SecondSight** from the launcher. Allow **location** when asked (it centres the map on you and draws your own position). Keep the tablet **out of desktop mode** for a true full-screen console.

Map: it works offline from a cached area and fills in online detail over Wi-Fi. If a fresh area looks plain, connect to Wi-Fi once and pan/zoom to cache it.

3 The main screens

Home & Detection

The status strip reads **CLEAR** or shows live tracks. The tiles (**ALL / DRONES / SIGNALS / RID / NON-RID / FPV**) filter what is shown. Press **CONNECT** to start the selected detectors; the **Connected devices** row shows Delta R, Delta+ and Echo status.

Jammer roster

The **Jammer** tab lists the effectors. Open one to reach its control page. The RF jammers now share a two-tab layout:

- **SETUP** — the device gateway (host/port) and **CONNECT / TEST LINK**. Set this first.
- **OPERATE** — the working view: channels, shortcuts and the firing interlock.

FULL-BAND ECM

Foxtrot / Foxtrot 50

Interference bands set in SETUP; load a frequency set and activate channels in OPERATE, then fire.

CHANNEL JAMMERS

Sierra 10 / Sierra 9 / Whiskey

Tap channels to key them, or use a **Shortcut** chip to key several at once. SELECT ALL / CLEAR for the rest.

Shortcuts (Sierra / Whiskey)

A **shortcut** is a one-tap preset that keys several channels together. Tap **+ NEW**, name it, tick the channels it should key, and it appears as a chip. Long-press a chip to edit or delete it. Shortcuts are saved per unit.

Echo (GNSS deception)

- **Constellations** — choose GPS / BDS / GLONASS / Galileo.
- **Output power** — shown in dBm and watts; opens at full power (43 dBm / 20 W) and is adjustable.
- **Operation mode** — **Area modes** (Interfere, No-Fly land, Defense circle, Directional) need no target; **Targeted modes** (Trap point, Static spoof, Circle path) need a fix.
- **Set a target** — pick a targeted mode, then **tap the map** to drop a red target crosshair, or tap a detected drone.

4 Arming & safety

Every effector uses the same firing interlock and opens **SAFE / read-only**. Nothing transmits until you deliberately arm and commit.

SAFE → slide to unlock → **ARM** → **FIRE / ENGAGE** → **CEASE / STOP**

- **SAFE** is the resting state — controls are locked and inert.
- **Slide to unlock**, then **ARM** to permit transmit (the badge turns amber).
- **FIRE / ENGAGE** transmits; **CEASE / STOP** stops immediately and is always available.
- **TEST LINK / PROBE** proves the path to the device and never keys a channel.

Operate responsibly. Jamming and GNSS deception affect real spectrum. Only transmit where you are authorised to do so, on an approved range or enclosure. When in doubt, stay SAFE and use TEST LINK.

5 Reporting bugs & change requests

Please log everything you find in the SteelRock feedback form — a fault to fix (**Bug**) or something you'd like different (**Change request**). One item per entry.

- 1 Open the **feedback form link** (in the covering email) in any browser — phone, tablet or PC.
- 2 Choose **Bug** or **Change**, then fill in the **system**, **platform**, **severity**, a clear **title** and **description**. For a bug, add the **steps to reproduce**, and what you **expected** vs what **actually** happened.
- 3 Attach diagnostics if you can (see §6) — paste a log or attach a log file.
- 4 Press **Add to log**. Entries autosave in your browser as you go.
- 5 When ready, press **Copy all (CSV)** and paste it into an email back to your SteelRock contact. (Attach any binary log bundle to that email.)

Severity — how to grade it

Grade	Use it when...
Critical	Unusable, data loss, or a safety concern (e.g. it transmits when it shouldn't, or won't cease).
High	A main function is broken or a device can't be operated.
Medium	Works but behaves wrongly, is confusing, or needs a workaround.
Low	Cosmetic, wording, or a minor polish item.

Good reports get fixed faster. Name the exact **system** (e.g. “Echo”, “Sierra 10”), the **platform** (Windows / Android), the **build**, and the shortest **steps** that reproduce it. A screenshot or a log helps enormously.

6 Attaching diagnostics / logs

Logs let the team see exactly what the software did at the moment of a fault. The feedback form has an “+ **Attach system logs / diagnostics**” section — paste log text there, or attach a text log file (it's read on your device, nothing is uploaded).

ANDROID

App log or logcat

Export the log bundle from the app (Settings → diagnostics) and open the .txt to copy it; or, on a connected PC, run `adb logcat` and copy the lines around the fault.

WINDOWS

Console log

Copy the console log text, or the message from any error dialog, and paste it into the form.

Big or binary logs: a full .zip log bundle can't be pasted into the form — attach it to your email alongside the CSV, and reference the entry ID (e.g. `SR-004`) so we can match them up.

7 Contact & version

Questions, or anything blocking your testing — reach your SteelRock contact directly. Please quote the **build (4.0.0)** and the **platform** you're on.

Item	Detail
Product	SecondSight standalone console (jamming + detection)

Build	4.0.0 — evaluation
Platforms	Windows · Android (phone & tablet)
Feedback form	Link provided in the covering email