## LCD firmware upgrade for Ender-3 V2

## **LCD Types**

There are reports that some customers who have purchased the Ender-3 V2 from around February 2022 have started receiving the Ender-3 V2 with the new LCD model.

Original DWIN company LCD (DMT48270C043\_04WN): use DWIN\_SET




New DACAI company LCD: use private



## **LCD Firmware Upgrade**

1. Format your microSD card to FAT32 with a 4096 bytes allocation unit size.



- 2. Use DWIN\_SET for old stock LCD or private for DACAI new LCD.
- 3. Copy one of the "DWIN\_SET" or "private" folder to an SD card.
- 4. Power Off Ender-3 V2 and disconnect LCD unit.
- 5. Remove the back cover of the display and insert the card into the microSD slot on the back of the display unit's PCB.



- 6. Connect LCD unit to Ender-3 V2 and Power On Ender-3 V2.
- 7. Wait for the upgrade to complete.
  - $_{\odot}$  When DWIN LCD upgrade is completed, the blue screen changes to orange screen (15  $\sim$  20 seconds)



 $_{\circ}$  DACAI LCD upgrade progress is indicated by %



- 8. Power off Ender-3 V2.
- 9. Remove the microSD card from the back of the LCD's PCB.
- 10. After assembling LCD unit, connect to Ender-3 V2.
- 11. Power on to confirm a successful flash.

## **Troubleshooting**

If flashing is not working (e.g. the blue screen only flashes for a second before the orange screen):

• Reformat the microSD card in FAT32 with 4096 bytes allocations