

RELOOP MIXTOUR PRO

MIDI MAP

MIDI Channel	Category	CH (hex)	Key
	Deck 1 (Transport + Mixer)	00	N
	Deck 2 (Transport + Mixer)	01	N
	Deck 3 (Transport + Mixer)	02	N
	Deck 4 (Transport + Mixer)	03	N
	Deck 1 (Other Functions)	04	P
	Deck 2 (Other Functions)	05	P
	Deck 3 (Other Functions)	06	P
	Deck 4 (Other Functions)	07	P
	FX Unit Deck 1	08	E
	FX Unit Deck 2	09	E
	FX Unit Deck 3	0A	E
	FX Unit Deck 4	0B	E
	Global	0F	G

Section	Item	Type	CH	SHIFT		MODE		SHIFT + MODE		FROM CONTROLLER		TO CONTROLLER		Comment			
				(hex)	LED	CH	LED	(hex)		MIDI 2 IN (hex)	MIDI 2 OUT (hex)						
PADS	MODE	BTN	Note	P	08	08 / HW	P	26	26	-	-	-	-	OFF = 00, ON = 7F	DIM = 00, ON = 7F	Stateful / Toggle on button release Splits Pad Modes into two rows	
	SPLIT	BTN	Note	G	09	09 / HW	G	0A	0A	-	-	-	-	OFF = 00, ON = 7F	DIM = 00, ON = 7F		
	PAD 1	BTN	Note	P	14	14	P	1C	1C	P	00	00	-	-	OFF = 00, ON = 7F	refer to LED map	
	PAD 2	BTN	Note	P	15	15	P	1D	1D	P	01	01	-	-	OFF = 00, ON = 7F	refer to LED map	
	PAD 3	BTN	Note	P	16	16	P	1E	1E	P	02	02	-	-	OFF = 00, ON = 7F	refer to LED map	
	PAD 4	BTN	Note	P	17	17	P	1F	1F	P	03	03	-	-	OFF = 00, ON = 7F	refer to LED map	
	PAD 5	BTN	Note	P	18	18	P	20	20	P	04	04	-	-	OFF = 00, ON = 7F	refer to LED map	
	PAD 6	BTN	Note	P	19	19	P	21	21	P	05	05	-	-	OFF = 00, ON = 7F	refer to LED map	
MIXER	PAD 7	BTN	Note	P	1A	1A	P	22	22	P	06	06	-	-	OFF = 00, ON = 7F	refer to LED map	
	PAD 8	BTN	Note	P	1B	1B	P	23	23	P	07	07	-	-	OFF = 00, ON = 7F	refer to LED map	
	GAIN	VR	CC	N	16	-	-	-	-	-	-	-	-	-	00-7F	-	off when centered otherwise lit
	NEURAL MIX	BTN	Note	P	24	24	P	25	25	-	-	-	-	OFF = 00, ON = 7F	OFF = 00, DIM = 01, ON = 7F		
	HIGH	VR	CC	N	17	-	-	-	-	-	-	-	-	00-7F	-		
	MID	VR	CC	N	18	-	-	-	-	-	-	-	-	00-7F	-		
	LOW	VR	CC	N	19	-	-	-	-	-	-	-	-	00-7F	-		
	FILTER	VR	CC	N	1A	-	-	-	-	-	-	-	-	00-7F	-		
	FILTER LED	LED	-	-	-	HW	-	-	-	-	-	-	-	-	-		
	CHANNEL FADER	VR	CC	N	1C	-	-	-	-	-	-	-	-	00-7F	-		
	CROSSFADER	VR	CC	G	08	-	-	-	-	-	-	-	-	00-7F	-		
	HEADPHONE CUE	BTN	Note	N	1B	1B	N	12	12	-	-	-	-	OFF = 00, ON = 7F	OFF = 00, DIM = 01, ON = 7F		
	CUE MIX	VR	CC	G	0D	-	-	-	-	-	-	-	-	00-7F	-		
	CUE VOL	VR	CC	G	0C	-	-	-	-	-	-	-	-	00-7F	-		
	CH FADER START	VR	Note	-	-	-	N	31	-	-	-	-	-	CUE = 00, PLAY = 7F	-	Shift + Linefader	
	X-FADER START	VR	Note	-	-	-	N	2D	-	-	-	-	-	CUE = 00, PLAY = 7F	-	Shift + Crossfader	
VU-METER CHANNEL	LED	CC	N	-	-	1F	-	-	-	-	-	-	-	-	00 - 06		
EFFECT	STEREO/MONO	SW	Note	G	-	7F / HW	-	-	-	-	-	-	-	STEREO = 00, MONO = 7F	-	when Mode-button is held, MIDI layer will switch for both buttons when Mode-button is held, MIDI layer will switch for both buttons	
	MAIN VOL	VR	CC	G	0A	-	-	-	-	-	-	-	-	00-7F	-		
	FX DRY/WET	VR	CC	G	02	-	-	-	-	E	03	-	-	00-7F	-		
	PARAM <	BTN	Note	G	03	-	E	0A	-	E	0B	-	-	OFF = 00, ON = 7F	-		
	PARAM >	BTN	Note	G	04	-	E	0D	-	E	0C	-	-	OFF = 00, ON = 7F	-		
NAVIGATION	FX ON	SW	Note	E	05	05	E	00	00	-	-	-	-	CENTER = 00 / HOLD/ON = 7F	OFF = 00, DIM = 01, ON = 02, FLASH = 7F		
	BROWSE (turn)	ENC	CC	G	00	-	G	01	-	N	06	-	-	01-7F	-		
	BROWSE (press)	BTN	Note	G	06	-	G	07	-	-	-	-	-	OFF = 00, ON = 7F	-		
	LOAD	BTN	Note	P	0A	-	P	10	-	N	08 / HW	-	-	DECK 1/2 = 00 / DECK 3/4 = 7F	-		
	DECK ACTIVE LED	LED	LED	N	-	08 / HW	-	-	-	-	-	-	-	-	DECK 1/2 = 00 / DECK 3/4 = 7F		
TRANSPORT	SHIFT	BTN	Note	G	00	HW	-	-	-	-	-	-	-	-	-	refer to LED map refer to LED map refer to LED map refer to LED map	
	IN > OUT > EX	BTN	Note	N	03	03	N	40	40	N	2A	2A	N	2C	2C		OFF = 00, ON = 7F
	SYNC	BTN	Note	N	02	02	N	29	29	N	2B	2B	N	2E	2E		OFF = 00, ON = 7F
	CUE	BTN	Note	N	01	01	N	0C	0C	N	27	27	N	2F	2F		OFF = 00, ON = 7F
	PLAY/PAUSE	BTN	Note	N	00	00	N	0B	0B	N	28	28	N	30	30		OFF = 00, ON = 7F

RELOOP MIXTOUR PRO

LED colour coding map

RGB Pads: Dimmed state (25%)						
Color-Binary	MIDI Value		Power: 25%			COLOR
	dec	hex	R	G	B	
00000000	0	0	0%	0%	0%	OFF
00000001	1	1	0%	0%	33%	
00000010	2	2	0%	0%	66%	
00000011	3	3	0%	0%	100%	
00000100	4	4	0%	33%	0%	
00000101	5	5	0%	33%	33%	
00000110	6	6	0%	33%	66%	
00000111	7	7	0%	33%	100%	
00001000	8	8	0%	66%	0%	
00001001	9	9	0%	66%	33%	
00001010	10	A	0%	66%	66%	
00001011	11	B	0%	66%	100%	
00001100	12	C	0%	100%	0%	
00001101	13	D	0%	100%	33%	
00001110	14	E	0%	100%	66%	
00001111	15	F	0%	100%	100%	
00010000	16	10	33%	0%	0%	
00010001	17	11	33%	0%	33%	
00010010	18	12	33%	0%	66%	
00010011	19	13	33%	0%	100%	
00010100	20	14	33%	33%	0%	
00010101	21	15	33%	33%	33%	
00010110	22	16	33%	33%	66%	
00010111	23	17	33%	33%	100%	
00011000	24	18	33%	66%	0%	
00011001	25	19	33%	66%	33%	
00011010	26	1A	33%	66%	66%	
00011011	27	1B	33%	66%	100%	
00011100	28	1C	33%	100%	0%	
00011101	29	1D	33%	100%	33%	
00011110	30	1E	33%	100%	66%	
00011111	31	1F	33%	100%	100%	
00100000	32	20	66%	0%	0%	
00100001	33	21	66%	0%	33%	
00100010	34	22	66%	0%	66%	
00100011	35	23	66%	0%	100%	
00100100	36	24	66%	33%	0%	
00100101	37	25	66%	33%	33%	
00100110	38	26	66%	33%	66%	
00100111	39	27	66%	33%	100%	
00101000	40	28	66%	66%	0%	
00101001	41	29	66%	66%	33%	
00101010	42	2A	66%	66%	66%	
00101011	43	2B	66%	66%	100%	
00101100	44	2C	66%	100%	0%	
00101101	45	2D	66%	100%	33%	
00101110	46	2E	66%	100%	66%	
00101111	47	2F	66%	100%	100%	
00110000	48	30	100%	0%	0%	
00110001	49	31	100%	0%	33%	
00110010	50	32	100%	0%	66%	
00110011	51	33	100%	0%	100%	
00110100	52	34	100%	33%	0%	
00110101	53	35	100%	33%	33%	
00110110	54	36	100%	33%	66%	
00110111	55	37	100%	33%	100%	
00111000	56	38	100%	66%	0%	
00111001	57	39	100%	66%	33%	
00111010	58	3A	100%	66%	66%	
00111011	59	3B	100%	66%	100%	
00111100	60	3C	100%	100%	0%	
00111101	61	3D	100%	100%	33%	
00111110	62	3E	100%	100%	66%	
00111111	63	3F	100%	100%	100%	

RGB Pads: Full state (100%)						
Color-Binary	MIDI Value		Full Power: 100%			COLOR
	dec	hex	R	G	B	
01000000	64	40	0%	0%	0%	OFF
01000001	65	41	0%	0%	33%	
01000010	66	42	0%	0%	66%	
01000011	67	43	0%	0%	100%	
01000100	68	44	0%	33%	0%	
01000101	69	45	0%	33%	33%	
01000110	70	46	0%	33%	66%	
01000111	71	47	0%	33%	100%	
01001000	72	48	0%	66%	0%	
01001001	73	49	0%	66%	33%	
01001010	74	4A	0%	66%	66%	
01001011	75	4B	0%	66%	100%	
01001100	76	4C	0%	100%	0%	
01001101	77	4D	0%	100%	33%	
01001110	78	4E	0%	100%	66%	
01001111	79	4F	0%	100%	100%	
01010000	80	50	33%	0%	0%	
01010001	81	51	33%	0%	33%	
01010010	82	52	33%	0%	66%	
01010011	83	53	33%	0%	100%	
01010100	84	54	33%	33%	0%	
01010101	85	55	33%	33%	33%	
01010110	86	56	33%	33%	66%	
01010111	87	57	33%	33%	100%	
01011000	88	58	33%	66%	0%	
01011001	89	59	33%	66%	33%	
01011010	90	5A	33%	66%	66%	
01011011	91	5B	33%	66%	100%	
01011100	92	5C	33%	100%	0%	
01011101	93	5D	33%	100%	33%	
01011110	94	5E	33%	100%	66%	
01011111	95	5F	33%	100%	100%	
01100000	96	60	66%	0%	0%	
01100001	97	61	66%	0%	33%	
01100010	98	62	66%	0%	66%	
01100011	99	63	66%	0%	100%	
01100100	100	64	66%	33%	0%	
01100101	101	65	66%	33%	33%	
01100110	102	66	66%	33%	66%	
01100111	103	67	66%	33%	100%	
01101000	104	68	66%	66%	0%	
01101001	105	69	66%	66%	33%	
01101010	106	6A	66%	66%	66%	
01101011	107	6B	66%	66%	100%	
01101100	108	6C	66%	100%	0%	
01101101	109	6D	66%	100%	33%	
01101110	110	6E	66%	100%	66%	
01101111	111	6F	66%	100%	100%	
01110000	112	70	100%	0%	0%	
01110001	113	71	100%	0%	33%	
01110010	114	72	100%	0%	66%	
01110011	115	73	100%	0%	100%	
01110100	116	74	100%	33%	0%	
01110101	117	75	100%	33%	33%	
01110110	118	76	100%	33%	66%	
01110111	119	77	100%	33%	100%	
01111000	120	78	100%	66%	0%	
01111001	121	79	100%	66%	33%	
01111010	122	7A	100%	66%	66%	
01111011	123	7B	100%	66%	100%	
01111100	124	7C	100%	100%	0%	
01111101	125	7D	100%	100%	33%	
01111110	126	7E	100%	100%	66%	
01111111	127	7F	100%	100%	100%	

Transport section BiLEDs: Dimmed state (25%)						
Color-Binary	MIDI Value		Power: 25%			COLOR
	dec	hex	R	B		
00000000	0	0	0%	0%		OFF
00000001	1	1	100%	0%		
00000010	2	2	0%	100%		
00000011	3	3	100%	100%		

Transport section BiLEDs: Full state (100%)						
Color-Binary	MIDI Value		Full Power: 100%			COLOR
	dec	hex	R	B		
01000000	64	40	0%	0%		OFF
01111101	125	7D	100%	0%		
01111110	126	7E	0%	100%		
01111111	127	7F	100%	100%		