

forum.pistar.uk

Pi-Star User Forum

Search...

[Quick links](#) [FAQ](#)[Register](#) [Login](#)[Home](#) < [Board index](#) < [Pi-Star Information](#) < [FAQ](#)

Using dstar mode with pi-star

Locked



Search this topic...



2 posts • Page 1 of 1

Using dstar mode with pi-star

 by **M1DNS** » Wed Apr 11, 2018 6:27 pm

Using DStar mode with pi-star.

There are a couple of things to ensure are enabled within the dstar radio to work correctly with the pi-star image with DSTAR mode. All, or some of these following recommendations could help with pi-star not 'seeing' ur DStar RF transmissions.

Set the radio to DUPLEX mode (- or + it does not matter)
Set the duplex OFFSET freq. to 0.00hz
Setup RPT1 and RPT2 fields with callsign and module / gateway
Set UR field to either CQCQCQ, USE REFLECTOR or USE REPEATER

Following the recommendations above will help ensure your radio is set 'correctly' for use the DSTAR mode with pi-star.

Also if the pistar setup is intended to be a multiuser installation such as a repeater or simplex gateway, where it runs under its own club call, or NOV callsign. Be sure to change its use from private to public.

It's also worth mentioning that some of the DSTAR networks require your callsign be registered with them to enable you to talk through their particular installation.

Last edited by **M1DNS** on Thu May 10, 2018 10:25 am, edited 1 time in total.

Andrew M1DNS.
Pi-star Admin Team.

Re: Using dstar mode with pi-star

 by **MW0MWZ** » Thu Apr 12, 2018 7:15 am

Also see this handy video by W1MSG;

**MW0MWZ**
Site Admin

Posts: 1560
Joined: Wed Apr 04, 2018 9:15 pm

Location: Wales, UK
Contact: 



Andy

73 de MW0MWZ
<http://pistar.uk>

Locked



2 posts • Page **1** of **1**

< [Return to "FAQ"](#)

Jump to 

 **Home** < **Board index**

 [Contact us](#)  [Delete cookies](#) All times are UTC

Powered by **phpBB®** Forum Software © phpBB Limited
[Privacy](#) | [Terms](#)