

MIDI Implementation Chart

Function	Transmitted	Recognized	Remarks
Basic Channel	Default Changed	10 1-16, OFF	Memorized
Mode	Default Messages Altered	Mode 4 x *****	
Note Number	: True Voice	*1 *****	
Velocity	Note On Note Off	o 9nH v=80 o 8nH v=00	
After Touch	Key's Channel's	x x	
Pitch Bend		x	
Control Change	2	o	BEAT
	9	o	SHUFFLE
	15	o	MASTER FX
	16	o	DELAY LEVEL
	17	o	DELAY TIME
	18	o	DELAY FEEDBACK
	19	o	MASTER FX CTRL
	20	o	BD TUNE
	23	o	BD DECAY
	24	o	BD LEVEL
	25	o	SD TUNE
	28	o	SD DECAY
	29	o	SD LEVEL
	46	o	LT TUNE
	47	o	LT DECAY
	48	o	LT LEVEL
	58	o	HC TUNE
	59	o	HC DECAY
	60	o	HC LEVEL
	61	o	CH TUNE
	62	o	CH DECAY
	63	o	CH LEVEL
	80	o	OH TUNE
	81	o	OH DECAY
	82	o	OH LEVEL
	70	o *2	FILL IN TRIG
	71	o	ACCENT
	91	o	REVERB LEVEL
	96	o	BD CTRL
	97	o	SD CTRL
	102	o	LT CTRL
	106	o	HC CTRL
	107	o	CH CTRL
	108	o	OH CTRL
Program Change	: True Number	o 0-127	
System Exclusive		x	
System Common	: Song Position	x	
	: Song Select	x	
	: Tune Request	x	
System Real Time	: Clock	o	
	: Start	o	
	: Continue	x	
	: Stop	o	
Aux Message	: All Sound Off	x	
	: Reset All Controllers	x	
	: Local On/Off	x	
	: All Notes Off	x	
	: Omni Mode Off	x	
	: Omni Mode On	x	
	: Mono Mode On	x	
	: Poly Mode On	x	
	: Active Sensing	o	
	: System Reset	x	
*1			
INST		Note Number	Note Number (ALT)
BD		36	35
SD		38	40
LT		43	41
HC		39	54
CH		42	44
OH		46	55
*1 These note numbers are configurable on UTILITY:MIDI:Inst Note.			
*2 Transmitted when the UTILITY:SOUND:LocalSw is SURFACE.			