

## Adapt to ESC and parameters

MOTOR 3

## MAMBA F55\_128K ESC

**CURR** Yes Telemetery Yes 55A **Output Current** Peak Current 65A 3-65 Lipo Input BLheli-32 BLheli 24-128K **PWM** MAMBA F55\_128K Target Dshot 300/600/1200 Protocol 30.5×30.5mm,**Ø** 3 Mounting 44.5×40.0×7.5mm Size Weight 15g

## MAMBA F65\_128K ESC

**CURR** Yes Telemetery Yes 65A **Output Current** 75A Peak Current 3-65 Lipo Input BLheli-32 BLheli **PWM** 24-128K MAMBA F65\_128K Target Dshot 300/600/1200 Protocol 30.5×30.5mm,Ø3 Mounting 44.5×40.0×7.5mm Size

15g

Weight



Correspond USER1 to the AUX

Correspond USER1 to the AUX


VTX power switch channel: USER1 Connected by default, control the power on or off after setting the channel

将 USER1对应到遥控器的AUX通道。(如下图所示)

channel of the remote control.(As shown in the following figure)

将 USER1对应到遥控器的AUX通道。(如下图所示)


channel of the remote control.(As shown in the following figure)




Use VCC for 3-4S Voltage

Use 9V for 6S Voltage

MAMBA F55/F65\_128K



MAMBA F55\_128K ESC Amperage Meter \$ Scale[1/10th mV/A] 0.00A Offset [mA]



Betaflight是开源软件,自行刷写固件将可能导致产品工作不稳定。 为了你的安全,地面站设置必须拆除螺旋桨。