







Serial Rx

Telemetry Output

115200 🔻

115200 🔻

GPS

GPS GPS for navigation and telemetry

Note: Remember to configure a Serial Port (via Ports tab) when using GPS feature.

UART4

✓ Setup

Ports

Configuration

Sensor Input

Disabled ▼ AUTO ▼

Disabled ▼ AUTO ▼

GPS ▼ 57600 ▼

