## AOS 3.5 EVO V1.2

## 机架组装示意图

## Frame Assembly Guide

1. <sup>顶板</sup> Top plate	x1	,, (附赠)/(Additional parts)	
2.底板 Bottom plate	x1	1. M2 尼龙螺母 1. M2 nylon nut	x8
3. 机臂	x4	2. M2*20 内六角螺丝 M2*20 hex screw	x4
4. 中板A Counter plate A	x1	3. M2减震橡胶柱 3. M2 rubber damper balls	x8
5. 中板B Counter plate B	x2	4. M5 nut	x8
6. 摄像头侧板 Camera side plate	x1	5. 集线管 Motor wire protector	x4
7. 脚垫打印件 Arm guard TPU	x4	6. 防尘塞 Dust plug	x2
8. 图传天线座打印件 Antenna TPU	x1	7. 15*150 超纤皮电池扎带 15*150 Battery strap	x1
<b>9.</b> 接收机座打印件 Receiver mount TPU	x1	¦ 8. 15*200 超纤皮电池扎带 15*200 Battery strap	x1
10.TX30固定座打印件 XT30 Mount TPU	x1	9. 通用贴纸 Sticker	x1
11. 摄像头硅胶侧板 Silicone camera side plate	x1	10. 光面硅胶防滑垫 Silicone spacer for 19mm cam	x2
<b>12.</b> M2*23 圆形网纹铝柱 <b>12.</b> M2*23 Al. standoff	x2	11. 电池硅胶防滑垫 Battery pad	x2
<b>13.</b> M2*20 圆形网纹铝柱 <b>13.</b> M2*20 Al. standoff	x8	12. 自锁尼龙扎带 Self-locking nylon zip ties	x5
14. M2*6 沉头内六角螺丝 14. M2*6 countersunk hex screw	x8		
15. M2*12 沉头内六角螺丝 16. M2*12 countersunk hex screw	x10		
16. M2*5 内六角螺丝 16. M2*5 hex screw	х6		
<b>17.</b> M2*6 内六角螺丝 M2*6 hex screw	х6		
18. <sub>M2*7</sub> 内六角螺丝 18. <sub>M2*7</sub> hex screw	x24		
<b>19.</b> M2*16 内六角螺丝 M2*16 hex screw	x4		
20.M1.6*10 杯头内六角螺丝	x4		
21. M2 防松自紧螺母 M2 lock nut	х6		

