AOS 5 V5

机架组装示意图 Frame Assembly Guide

26
2
28
2
,
;
į
10
1
1:
13
_

x1	26. M2 防松自紧螺母 M2 lock nut	x3
x1	27. M3 防松自紧螺母 M3 lock nut	x5
x4	28. M2*3 沉头内六角螺丝 M2*3 countersunk hex screw	x5
x1	29. M2*6 内六角螺丝 M2*6 hex screw	x5
x2	,, (附赠)/(Additional parts)	
x2	1 模拟摄像头固定侧板 - Analog camera side plate M25 河头内六角螺丝	x2
x4	2. M2*5 沉头内六角螺丝 2. M2*5 countersunk hex screw	x5 ¦
x1	3. 内六角扳手 Allen wrench	x1
x1	4. M5法兰螺母 4. M5 nut	x1
x1	5. M5*20 内六角螺丝 5. M5*20 hex screw	x2
x1	集线管 6. Motor wire protecto	x4
x1	7. 15*250 超纤皮电池扎带 15*250 Battery strap	x1
x2	8. 15*200 超纤皮电池扎带 8. 15*200 Battery strap	x1 ¦
x2	9. 电池硅胶防滑垫 Battery pad	x2
x7	10. 自锁尼龙扎带 Self-locking nylon zip ties	х6
x7	11. 通用贴纸 Sticker	x1
x3	12. M2*5 内六角螺丝 12. M2*5 hex screw	x5 ¦
x5	13. 电源线+插头 Power cable + plug	x1
x10	\ \	;

