

Features & Functions Guide



SORENTO

Hybrid / Plug-In Hybrid

WELCOME TO THE KIA FAMILY!

Your new Kia vehicle has been designed, engineered and manufactured to provide you with years of comfortable and dependable driving. Kia is committed to quality, innovation, safety and — above all — your satisfaction.

USING THIS FEATURES & FUNCTIONS GUIDE

The information contained in this guide is a brief overview of the operation and features of your new Kia vehicle.

This Features & Functions Guide and the specific operational and safety information it provides are not a substitute for your Owner's Manual. In the interest of your safety and that of the vehicle's occupants, and to help you avoid risks that may result in death or serious injury, Kia reminds you to carefully read the Owner's Manual in order to fully familiarize yourself with the important information and safety warnings it contains.

While Kia endeavors to ensure that the information contained in this guide is accurate at the time of printing, Kia may change vehicle specifications without notice in advance of or after the fact and assumes no liability in connection with such changes.

VIDEOS AND QR CODES

Kia provides a number of video resources to assist you with becoming familiar with the features and functions found in your Kia vehicle. You can access these resources by snapping the QR Codes with your mobile device using the built-in QR Code Reader or a downloaded QR Code Reader App.

After opening the QR Code Reader App on your mobile device, the app will utilize your device's camera. Center the code in the camera viewing area — with some apps, as soon as the app recognizes the code, it will launch the corresponding video.

With other apps, you will have to snap or "take a picture" of the code. The app will then launch the corresponding video.

For operation specifics, refer to the instructions that come with your QR Code Reader App. You can also view the videos by visiting the following website: www.youtube.com/KiaFeatureVideos

QUICK TIPS

If you're having trouble scanning codes, check the following:

- The code should be centered and focused in your mobile device's camera screen
 - Consider moving your device closer to or farther away from the code
 - The code should be well lit, without significant shadow
 - Avoid scanning from a significant angle
- Confirm that the device's app supports 2D QR Code scanning
- Try another QR Code Reader App; not all apps are created equal
- After scanning, you may experience a "connection error" message or a "connecting" message with no subsequent response. These messages typically indicate that your device is having trouble connecting to the Internet

QR CODES

Getting Started With Your New Kia Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

GETTING STARTED

As you get to know your new Kia, you can explore this booklet to better understand how to operate its many features and systems. You can find the complete Table of Contents on the next two pages, but first, be sure to review the following to better understand some of your Kia's most used features:

① Smart Key with Remote Start	60
② Front Seat Headrest Adjustment / Power Adjustable Driver's Seat* . .	55-56
③ Seat Warmers/Ventilated Seats*	53
④ Folding Rear Seats	56-58
⑤ Windshield Wipers & Washers	39
⑥ Navigation-based Smart Cruise Control (NSCC)	24
⑦ Normal Maintenance Schedules	Back Cover
⑧ User Settings* - Instrument Cluster	09
⑨ Vehicle Settings* - Infotainment System	09
⑩ Bluetooth® Wireless Technology	40
⑪ Kia Connect Activation / Kia Connect Assistance.	43
⑫ Kia Connect with Navigation	45
⑬ Kia Access App Download	44
⑭ Kia Access App Features Guide	44
⑮ Android Auto™ / Apple CarPlay® Setup	42

QR CODES

Getting Started With Your
New Kia Video



Your New Kia Important
Care Tips Video



Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury or death. The driver's primary responsibility is in the safe and legal operation of a vehicle. Handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law, should never be used during operation of the vehicle.

Vehicle Cameras
Important Tips Video



www.kia.com
Consumer Affairs -
Roadside Assistance^{†11}:
1-800-333-4KIA (800-333-4542)

Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

Always check the Owner's Manual for complete
operating information and safety warnings.

TABLE OF CONTENTS

VIDEOS & QR CODES .. Inside Front Cover

INSTRUMENT CLUSTER

Instrument Cluster Overview	03
Hybrid / Plug-In Hybrid Indicators at Startup	04
Indicators & Warning Lights	05
Tire Pressure Monitoring System (TPMS)	06
Fuel Economy / Tips for Economical Driving	06
Drive Mode Integrated Control System*	07

VEHICLE SETTINGS

Trip Modes / Trip Computer	08
Instrument Cluster LCD Modes	08
User Settings - Instrument Cluster	09
Vehicle Settings* - Infotainment System	09
Vehicle Auto Shut-off System*	10
Service Interval Mode	10

HYBRID / PLUG-IN HYBRID SYSTEM

Charging Connector Auto/Lock/Unlock Mode	11
Scheduled Charging* (Plug-In Hybrid only)	11
Charging the Plug-In Hybrid Vehicle	12
Energy Flow - Instrument Cluster LCD	14
Plug-In Hybrid Display - Infotainment System*	16
Plug-In Hybrid Modes (Plug-In Hybrid only)	17

ADVANCED DRIVER ASSISTANCE SYSTEMS (ADAS)

Forward Collision-Avoidance Assist (FCA)	18
Lane Keeping Assist (LKA)	19
Blind-spot Collision-Avoidance Assist (BCA)	20
Intelligent Speed Limit Assist (ISLA)	21
Driver Attention Warning (DAW)	22
Leading Vehicle Departure Alert (LVDA)	23
Safe Exit Assist (SEA)*	23
Navigation-based Smart Cruise Control (NSCC) ..	24
Lane Following Assist (LFA)	26
Highway Driving Assist (HDA)	27
Rear View Monitor (RVM)	28
Blind-spot View Monitor (BVM)*	28
Surround View Monitor (SVM)*	29
Rear Cross-traffic Collision-Avoidance Assist (RCCA)* ..	30

ADAS CONTINUED

Reverse Parking Collision-Avoidance Assist (PCA)* ..	31
Forward/Reverse Parking Distance Warning (PDW) ..	32

DRIVER'S PANEL

Instrument Cluster Illumination Control	33
Electronic Stability Control (ESC)	33
Hill-start Assist Control (HAC)	33
Reverse Parking Aid Function*	34
Engine Start/Stop Button*	34
Power Windows, Window Lock & Central Door Lock / Auto Door Lock/Unlock	35
Electronic Child Safety Lock System	35
Power/Heated Outside Mirrors*	36
Manual Folding Mirrors*	36
Power Folding Outside Mirrors*	36

STEERING WHEEL CONTROLS

Tilt/Telescoping Steering Wheel	37
Headlights & High Beams	38
Daytime Running Lights*	38
High Beam Assist (HBA)	38
Turn Signals & Fog Lights*	39
Windshield Wipers & Washers	39
Rear Wiper & Washer*	39
Lifting Wipers (Wiper Service Mode)	39

INFOTAINMENT SYSTEM

Bluetooth® Wireless Technology	40
Audio Controls	41
Android Auto™ / Apple CarPlay® Setup	42
Kia Connect Activation	43
Kia Connect Assistance	43
Kia Access App Download	44
Kia Access App Features Guide	44
Kia Connect with Navigation	45

CENTER PANEL

Multimedia USB Ports, Power Outlets & USB Charger Ports	46
AC Inverter	46

CENTER PANEL CONTINUED

Digital Clock - Infotainment System	46
Wireless Smartphone Charging System	47
Automatic Climate Control	48
Rotary Dial Shifter Knob - Shift-by-Wire	50
Paddle Shifters	50
AWD (All-Wheel Drive) Lock*	51
Electronic Parking Brake (EPB) / Auto Hold	52
Heated Steering Wheel	53
Seat Warmers/Ventilated Seats*	53

SEATING

Rear Occupant Alert with Ultrasonic Sensors	54
Front Seat Headrest Adjustment	55
Driver Position Memory System*	55
Power Adjustable Driver's Seat / Power Lumbar ..	56
2nd-Row Folding Seat	56
2nd-Row Auto-Folding Seat	57
Unfastening Center Seatbelt	57
One-Touch Slide & Fold 2nd-Row Seats	58
3rd-Row Folding Seat	58


OTHER KEY FEATURES

Sun Visor	59
Double-Turn Lock/Unlock All	59
Smart Key with Remote Start	60
Smart Power Liftgate	61
Map/Room Lamps	63
Panoramic Sunroof with Power Sunshade	63
HomeLink® with Auto-Dimming Rearview Mirror ..	64
Hood Release Lever and Latch	65
Fuel Cap / Malfunction Indicator	65
Fuel Filler Lid Release	65

SAFETY FEATURES

Occupant Detection System (ODS) / Passenger Airbag Off Indicator	66
Child-Protector Rear Door Locks*	66
Seat Belts	67

LEGAL DISCLAIMERS .. Inside Back Cover	
MAINTENANCE CHART .. Back Cover	

INSTRUMENT CLUSTER**Instrument Cluster Overview**

Full LCD cluster (Type B)

- A** Speedometer
- B** Power Gauge
- C** Hybrid Battery SOC (State of Charge) gauge
- D** Indicators & Warning Lights
- E** LCD Display (including Trip Computer)
- F** Fuel Gauge

◀Fuel icon. Arrow direction indicates the side of the vehicle the fuel door is located.

This illustration is for demonstration purposes only. Some indicators and warning lights may not appear in the illustration. On the vehicle, they may appear in the LCD.

Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. Refer to Section 5 in the Owner's Manual for more information.

QR CODE

Plug-In Hybrid Instrument Cluster Overview Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

INSTRUMENT CLUSTER


Hybrid / Plug-In Hybrid Indicators at Startup

- A Power Gauge** - Indicates how economically the vehicle is being driven.
 - **CHARGE B** - Indicates that the energy made by the vehicle is being converted to electrical energy (regenerated energy)
 - **ECO C** - Indicates that the vehicle is being driven in an ECO-friendly manner
 - **POWER D** - Indicates that the vehicle is exceeding the ECO-friendly range
- E EV Mode** - Illuminates when only the electric motor is powering the vehicle
- F Ready** - Illuminates when the Hybrid system is operational. Even if the engine is off, the vehicle can be driven (Plug-In Hybrid indicator location may vary from image shown)
- G Service Indicator** - Illuminates when a malfunction occurs in the vehicle's Hybrid system. Have an authorized Kia dealer address the concern as soon as possible

REMINDER: Avoid starting or driving the vehicle when the fuel tank is empty. As the engine will be incapable of charging the high-voltage Hybrid battery, the battery will lose its charge and may be damaged.

Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. For more information on the instrument cluster, please refer to section 5 in the Owner's Manual.

These illustrations are for demonstration purposes only. Some indicators and warning lights may not appear in illustration. On the vehicle, they may appear in the LCD.



Conventional Cluster (Type A)


QR CODE

Plug-In Hybrid Instrument Cluster Overview Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Indicators & Warning Lights

Conventional cluster
(Type A)

This illustration is for demonstration purposes only. Some indicators and warning lights may not appear in the illustration. On the vehicle, they may appear in the LCD.

Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. Refer to Section 5 in the Owner's Manual for more information.


READY Indicator	All-Wheel Drive (AWD) Lock Indicator Light*	Washer Fluid Warning Light*
EV Mode Indicator	Electronic Power Steering (EPS) Warning Light	Master Warning Light
Hybrid System Warning Light*	Charging System Warning Light*	Electronic Brake Force Distribution (EBD) System Warning Light (two separate indicators on Instrument Cluster lit at same time)
Engine Oil Pressure Warning Light	Airbag Warning Light	Lane Safety Indicator Light
Malfunction Indicator Light	Low Fuel Level Warning Light	LED Headlamp Warning Indicator*
Electric Parking Brake (EPB) Warning Light*	Immobilizer Indicator Light*	Downhill Brake Assist (DBC) Indicator*
Seat Belt Warning Light	Engine Coolant Temperature Warning Light*	SPORT Mode Indicator Light
Light ON Indicator Light	Icy Road Warning Indicator Light*	ECO Mode Indicator Light
High Beam Indicator Light	Low Tire Pressure Light / Tire Pressure Monitoring System (TPMS) Malfunction Indicator Light	SMART Mode Indicator Light
Low Beam Indicator Light	Anti-Lock Braking System (ABS) Warning Light	Charging Cable Connection Indicator (Plug-In Hybrid)*
Front Fog Light Indicator Light*	Electronic Stability Control (ESC) OFF Indicator Light	Regenerative Brake Warning Indicator (Two separate indicators on Instrument Cluster lit at same time)
High Beam Assist Indicator Light	Electronic Stability Control (ESC) Indicator Light	
Parking Brake & Brake Fluid Warning Light	AUTO HOLD Indicator*	
Forward Safety Warning Light*	Cruise Control Indicator Light*	
All-Wheel Drive (AWD) Warning Light*	Cruise Control ON/SET Indicator Light*	

INSTRUMENT CLUSTER

Tire Pressure Monitoring System (TPMS)^{†18}

 The TPMS indicator  functions as both the Low Tire Pressure Light and the TPMS Malfunction Indicator.

The TPMS indicator  is designed to illuminate if it detects one or more tires is significantly underinflated, the vehicle has a spare tire installed without TPMS or the outside temperature becomes significantly lower.



The Low Tire Pressure Position Indicator **A** is displayed on the LCD screen in the Instrument Cluster when the tire(s) is underinflated. Inflate the tire(s) to specifications using an accurate tire pressure gauge to turn off the Low Tire Pressure Indicator . See the front driver's door jamb for PSI specifications.

When there is a problem with the TPMS, the TPMS Malfunction Indicator  will blink for approximately one minute and then illuminate. See the dealer for service.

For illustrative purposes only. Your actual display, buttons and/or features may vary. Refer to Section 7 in the Owner's Manual for more information.

QUICK TIPS

- Even with TPMS, tire pressure should be checked manually at least once a month. Only adjust tire pressure on "cold tires" that have been sitting for 3 hours or more, and tires that are not hot in temperature from direct sunlight or heat
- For proper maintenance and optimal fuel economy, maintain the recommended tire inflation pressures and stay within the load limits and weight distribution recommended for your vehicle
- A significant drop in temperature can cause tire inflation pressures to drop, which may activate the TMPS light. Manually confirm tire pressures after significant changes in temperature or altitude

REMINDERS:

- Check the recommended tire pressure label located on the left side of the driver's door jamb, visible when the door is opened.
- Consult your dealer for service if the Low Tire Pressure Light remains illuminated after inflating your tire(s).
- Personal electronic devices (such as laptops, wireless chargers, remote start systems, etc.) may interfere with the TPMS system, which may cause the Malfunction Warning Indicator (Check Engine Light) to illuminate.

QR CODE

Tire Pressure Monitoring System Video



Tips for Economical Driving Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

For more information on Fuel Economy, you can snap the QR Code above to view a video or refer to section 5 in the Owner's Manual.

Fuel Economy / Tips for Economical Driving

Several factors contribute to your vehicle's fuel economy, such as maintenance of your vehicle, driving style, environmental conditions, vehicle weight and vehicle aerodynamics. Below are some tips on how to help improve fuel economy:

- Use the climate control system less often. Use the Driver Only* setting as much as possible
- Keep your vehicle in good condition with regular maintenance
- Drive at a moderate speed, accelerating smoothly and at a moderate rate
- Keep tires inflated to the recommended pressure
- Travel lightly, without carrying unnecessary weight in your vehicles
- Avoid placing large or heavy items on roof racks
- Avoid hilly, winding or poorly maintained roads

INSTRUMENT CLUSTER

Drive Mode Integrated Control System*


The drive modes may be changed according to the driver's preferences or road conditions. To cycle through the drive modes **A** or deactivate a drive mode, rotate the Drive Mode knob **B**.

When a drive mode is selected, the drive mode indicator will illuminate in the Instrument Cluster and illuminate next to the Drive Mode knob. The system's default mode is ECO mode and when selected, the indicator will not be illuminated.

- **SPORT Mode**
- **ECO Mode**
- **SMART Mode*** - When the SMART mode is activated, the system automatically selects the drive mode best suited to the current driving style (economic, average, spirited). The color of the SMART mode indicator (green, white, red) depends on the current driving style.
- **SNOW Mode*** (All Wheel Drive)

QUICK TIP

When vehicle is shut down while in SPORT Mode, the system will default to NORMAL mode when the engine is turned off. SPORT mode would need to be selected again once the vehicle is restarted.



See section 6 in the Owner's Manual
for more information.

REMINDERS:

- When ECO mode is selected, the following may occur to help improve fuel economy:
 - Acceleration may be slightly reduced even when the accelerator is fully depressed
 - Air conditioner performance may be limited
 - Shift pattern of the automatic transmission may change
 - Engine noise may increase
 - System's power will be limited when driving uphill
- When SPORT mode is selected, fuel economy may decrease
- The system defaults to ECO mode when ignition is in the ON position
- Steering effort may be slightly increased in SPORT mode

QR CODE

Drive Mode Integrated Control Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

VEHICLE SETTINGS


Trip Modes / Trip Computer

The Trip Computer is a driver information system that displays information related to driving on the display when the Engine Start/Stop button is in the ON position.

To cycle through the LCD Instrument Cluster modes **A**, press the Mode button **B**.

To select and enter the Trip Computer mode **C**, press the Move button **C** up/down and then press Set/Reset (OK) **C** to enter. To cycle through and select the different screens (Fuel Economy, Trip A, Trip B), press the Move button **C** up/down again and then press the OK button **C**. When displaying the TRIP A or TRIP B screens, press and hold the OK button **C** to reset the Tripmeter to zero.


Press the OK button **C** to go back to the previous mode/item.



REMINDERS:

- Appearance of the Trip Computer display may differ as equipped
- All stored driving information (except Odometer and Range) is reset if the battery is disconnected

Your vehicle's steering wheel buttons may differ from those in the illustrations.



Instrument Cluster LCD Modes

Press the Mode button **B** to cycle through the different Instrument Cluster LCD Modes:



Trip Computer Mode: Displays driving information for range, fuel economy, accumulated info, drive info, driving style*, energy flow



Driving Assist Mode: Displays information on Lane Keeping Assist*, Lane Following Assist/, Highway Driving Assist, Driver Attention Warning*



Turn-by-Turn Mode*: Displays the route guidance and destination information



User Settings Mode: Change settings of the Driver Assistance, doors, lights, sound, ECO vehicle, convenience and other features



Information/Master Warning Mode: Displays information on Intelligent Speed Limit Assist*, TPMS, drive force distribution*, and warning messages related to the vehicle when one or more systems is not operating normally

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

QR CODE

Instrument Cluster's LCD Display Video



Plug-In Hybrid Instrument Cluster Overview Video



Steering Wheel Controls Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 5 in the Owner's Manual for more information.

User Settings - Instrument Cluster

To enter the User Settings mode in the LCD Instrument Cluster Modes, press the Mode button **A** when the vehicle is at a standstill, shift lever in Park, and with the Engine/Start Stop button in the ON position, select User Settings **②** by pressing the Move (OK) button **B** up/down.



You can navigate the selections on the display by pressing the Move (OK) button **B** up/down, and then selecting the item by pressing the OK button **B**.

Press the OK button **B** up/down to go back to the previous mode/item.

User Settings mode:

Driver Assistance

- Driver attention warning
- Speed limit warning
- Warning timing
- Warning volume
- Haptic Warning
- Forward safety
- Lane safety
- Blind-spot safety
- Parking safety

Door*

- Automatically lock
- Automatically unlock
- Two-press unlock
- Horn feedback
- Power liftgate
- Power liftgate speed
- Power liftgate opening height
- Smart liftgate*

Lights*

- Illumination
- One-touch turn signal
- Ambient light brightness
- Ambient light color
- Headlamp delay
- High-beam assist

Sound*

- Welcome sound*

Convenience*

- Seat easy access
- Rear occupant alert
- Welcome mirror/light
- Wireless charging system
- Auto rear wiper (in R)
- Vehicle auto-shut off
- Icy road warning

Service Interval

- Enable service interval
- Adjust interval
- Reset

Other Features

- Speedometer unit
- Fuel economy unit
- Temperature unit
- Tire pressure unit

ECO Vehicle*

- Coasting guide
- Start coasting

Reset

- Reset the menus in the User Settings mode
- Set the language


Vehicle Settings* - Infotainment System

To enter the Vehicle Settings mode in the Infotainment System **C**, press the SETUP key on the Infotainment System. Then press Vehicle **③**, which will take you to Vehicle Settings. Use the touchscreen to navigate through the menus.

Vehicle Settings:

Driver Assistance:

- Driving Convenience*, Warning Time*, Warning Volume*, Driver Attention Warning*, Forward Safety*, Lane Safety*, Blind-Spot Safety*, Parking Safety*



Drive Mode: Drive Mode Alert*

Climate*: Recirculate Air*, Automatic Ventilation*, Defog/Defrost Options*, Climate Features*

Lights*: Ambient Light*, One Touch Turn Signal*, Headlight Display*, High Beam Assist*

Door*: Auto Lock*, Auto Unlock*, Walk-Away Lock*, Two-Press Unlock*, Smart Trunk*

Cluster*: Service Interval*, Energy Consumption Reset*, Content Selection*, Cluster Voice Guidance Volume*, Welcome Sound*, Theme Selection*

Convenience*: Rear Occupant Alert*, Welcome Mirror Light*, Wireless Charging System*, Vehicle Auto-Shut Off*

Seat*: Seat Position Change Alert*, Smart Posture Care*, Heated/Ventilated Features*, Seat East Access*, Rear Seat Heating Control*

Reset: Reset Vehicle Settings to Factory Defaults

Driving while distracted is dangerous and should be avoided. Do not attempt to change vehicle system settings while driving.

For more information, refer to the Owner's Manual or the Car Infotainment System Quick Reference Guide.

QR CODE

Vehicle & User Settings Video



Ambient, Mood & Theme Lighting Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Vehicle Auto Shut-off System*

The Vehicle Auto Shut-off, when certain conditions are met, will turn the vehicle off automatically after a pre-set time (30 or 60 minutes) in the User Settings **E**.

A warning on the Instrument Cluster LCD will appear stating the "Vehicle will be turned off automatically in..." and a chime will sound when the timer starts **A**.

QUICK TIP

The timer that appears on the Instrument Cluster's LCD can be reset using the OK button on the right side of the Steering Wheel.


When timer ends, a continuous beep sounds for one minute before the vehicle shuts off.

Auto Shut-off Settings - The system is on by default and timer is pre-set to 30 minutes. To change the pre-set time settings, go to User Settings **E** on the Instrument Cluster LCD by pressing the Mode button **B** on right side of the Steering Wheel. Select Convenience, then Vehicle Auto Shut-off. Move through the selections by pressing the OK button **C** on the Steering Wheel. Select 30 minutes, 60 minutes or Disable for off **D**.

REMINDERS:

- When the vehicle is turned off then on again, the system defaults to on (30-minute pre-set time)
- The system will activate when the vehicle is on and these conditions are met:
 - The vehicle is in (P) Park
 - The driver's seat belt is unfastened
 - The driver's door is opened
 - The passenger seat is not occupied

Refer to section 6 in the Owner's Manual for more information.



Service Interval Mode

To enter Service Interval Mode, press the Mode button **B**, go to User Settings **E** and enter by pressing the OK button **C**. Move up/down to Service Interval by pressing the OK button **C**, then press the OK button **C** to enter. System will display the number of miles remaining until the next service is due, as well as the type of service due.

When service is required, the following will be displayed:
Service Required.

To reset the Service Interval Mode system, press and hold the OK button **C** for more than 1 second.

Press the OK button **C** up/down to go back to the previous mode/item.

To turn **Service Interval OFF**, go to User Settings.

Service Interval Setting **E**

To set the service interval in User Settings mode:

- Press the Mode button **B** to go to User Settings and press the OK button **C** to enter
- If Service Interval is OFF, press the OK button **C** to turn ON
- Press the OK button **C** up/down to select/change the interval setting
- Press the OK button **C** to select the interval

QUICK TIP

An "Engine Oil Change Due Soon" message appears on the Instrument Cluster LCD when the engine oil needs to be changed. After oil change, reset the oil change reminder in User Settings*. Go to Convenience, then Oil Change.

QR CODE

Vehicle Auto Shut-off Video



Kia Full Synthetic Oil Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

See section 5 in the Owner's Manual for more information.

E



Service Interval
900mi/30day

(Images are for illustration purposes only and may vary.)

Charging Connector Auto/Lock/Unlock Mode (Plug-In Hybrid Only)

The charging connector automatically locks when the connector is plugged into the charging inlet.

When in Auto/Lock Mode and the vehicle is unlocked but charging cable is not disconnected within 15 seconds, the connector will be automatically locked again.

If charging connector is unlocked but all doors are locked again, immediately, the connector will be automatically locked again.

If charging does not work, disconnect the connector and try charging again.

If the connector cannot be locked/unlocked, pull the emergency release lever in the trunk.

Removing the Charging Connector

To prevent charging cable theft, the charging connector cannot be disconnected from the inlet when the doors are locked or the charging connector is in the LOCK mode. Unlock all doors to disconnect the charging connector from the inlet. If the release button does not work even after the all doors are unlocked, pull the emergency lift cable in the engine room.

REMINDERS:

- If charging does not work, disconnect the connector and try charging again
- If the connector cannot be locked/unlocked, pull the emergency release lever in the trunk. See section 1 of the Owner's Manual for more information
- In unlock mode, there may be a risk of theft because the connector is not locked during charging and after completion of charging

Scheduled Charging* (Plug-In Hybrid Only)

Charging time can be set in the Plug-In Hybrid audio system home screen, under charge management, or using the Kia Access app.

Charging with the Kia Access App:

The Kia Access app can help you find the nearest charging station and displays charging status and the Scheduled Charging information. On your Smartphone, go to an app store or marketplace to download the Kia Access app.

REMINDER: When Scheduled Charging is set and the charger is plugged in, charging will not begin until the set time & date are met to complete the charging. The green charge indicator on top of the dash will temporary flash ON/OFF to show that scheduled/reserve charging is set.

Deactivate Scheduled Charging - Press the Deactivate Scheduled Charging button **A** OFF for more than two seconds to disable the scheduled charging feature when immediate charging is required.

QUICK TIP

When you press the Deactivate Scheduled Charging button* **A** OFF the reserved charging setting will temporarily disable, and start immediate charging mode. If you need to completely deactivate the scheduled charge setting, change the setting from the Infotainment System.

REMINDERS:

- For more detail and/or subsequent steps in charging your vehicle, please see section 1 of the Owner's Manual
- Reservation charging may not be available at public chargers
- Distance to empty may depend on many factors such as the charge amount of the high voltage battery, weather, temperature, durability of the battery, geographical features, and driving style
- If you operate the air conditioner / heater too much, the distance to empty will be reduced
- If you select "Charge ONLY during Off-peak" it will charge only during off-peak time, and then stop. The vehicle may not charge to 100%


Screens, images and buttons may vary by model.

QR CODE

Plug-In Hybrid Charging Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos



Charging the Plug-In Hybrid Vehicle (Plug-In Hybrid Only)

AC Level 1 Charger - "Trickle" Charge

A Level 1 or "trickle" charger is the most common type of charging system for a Plug-In Hybrid. This type of charger uses 120 volts of household electricity and takes up to 10.5 hours for a full charge.

Trickle Charger Indicators:

- A** ICCB plug to a 120VAC outlet
- B** Power - When the charger and AC plug is plugged in and functioning normally, the indicator will turn green. Indicator is red if plug temperature sensor warning is present
- C** Charge - Indicates that the vehicle is charging

REMINDERS:

- Do not use an extension cord. Plug trickle charger directly into wall socket. Do not charge to a receptacle that is old, damaged, corroded or cracked
- When using outdoors, be careful not to expose it to external environments such as rain, snow, and high temperatures
- When part A lights up in red, check if it is exposed to the external environment and then charge it again

- D** Fault - Indicates charge failure

- E** Charge Level - Indicates the level of charge: L (8A), M (10A), or H (12A)

- F** ICCB - In-Cable Control Box

AC Level 2 Charger - "Normal" Charge

A Level 2 or "normal" 240-volt charger is the recommended charging system for the Plug-In Hybrid. This type of charger uses 240 volts of electricity and takes approximately 3.5+ hours for a full charge (Based on Kia Motors Corporation testing with SAE J1772 charger performed at 3.3kW). This charger may be able to be installed at your home or found at a public charging station.

REMINDER: Shape of charger and how to use the charger may be different for each manufacturer.

Please see Owner's Manual for more information.

QUICK TIP

A Level 2 or "normal" 240-volt charger is recommended for regular charging of the vehicle.


REMINDER: For more detail and/or subsequent steps in charging your vehicle, please see section 1 of the Owner's Manual.

QR CODE

Plug-In Hybrid Charging Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos



Charging the Plug-In Hybrid Vehicle (Continued)

To charge the Plug-In Hybrid vehicle using a Level 1 or 2 charger:

1. Connect the ICCB plug **A** to an electrical outlet
2. Check if the power light (green) **B** on the ICCB turns on
3. Press the brake pedal and engage the parking brake
4. Turn off all switches, put the shift lever in P (Park), and turn off the vehicle
5. Open the charging door **G** by pressing the rear center edge of charging door (Ensure doors are unlocked)
6. Remove any dust or water on the charging connector and charging inlet **H**
7. Hold the charging connector handle **I** and connect it to the vehicle's charging inlet **H** by pushing the connector until you hear a clicking sound
8. Charging begins automatically (Ensure the charge indicator light **S** is illuminated on your instrument cluster, indicating the vehicle is charging)

Checking the Charging Status

The charging status can be checked by viewing the charging status indicator **J** near the charging inlet (bottom indicator). The charging indicator will blink yellow when charging, and the charge is from 0-65%. The charging indicator will blink green when charging and the charge is from 65-100%. The indicator will turn off within 5 seconds when charging is completed.


The remaining charging time will be displayed in the Instrument Cluster **K** for one minute, or when a driver's door is opened during charging.

Removing the Charging Connector

To prevent charging cable theft, the charging connector cannot be disconnected from the inlet when the doors are locked or the charging connector is in the LOCK mode. Unlock all doors to disconnect the charging connector from the inlet. If the release button does not work even after the all doors are unlocked, pull the emergency lift cable in the engine room.

REMINDERS:

- When indicator is blinking red, there's an error while trying to charge
- When the charging connector is connected and the reserved charging is in standby mode, the charging indicator is turned off and the scheduled charge release button indicator is turned on. The scheduled charge release button indicator will turn off after 3 minutes
- For more detail and/or subsequent steps in charging your vehicle, please see section 1 of the Owner's Manual





QR CODE

Plug-In Hybrid Charging Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

(Located on rear passenger side of vehicle)




(Message on Cluster Display)


Energy Flow - Instrument Cluster LCD

Hybrid/Plug-In's instrument cluster LCD screen displays the following Hybrid/Plug-In system modes to inform the driver of its status. To change modes, go to User Settings in the Instrument Cluster modes.

EV Propulsion - The electric motor is moving the vehicle.




Power Assist - Both the electric motor AND the engine are moving the vehicle.




Your vehicle's instrument cluster display locations may differ from those in the illustrations. For more information on the instrument cluster, please refer to section 1 of the Owner's Manual. These illustrations are for demonstration purposes only.

Engine-Only Propulsion - The engine is moving the vehicle.



Engine Generation - While the vehicle is stopped, the engine is charging the Hybrid/Plug-In battery.



QR CODE

Plug-In Hybrid Instrument Cluster Overview Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


Energy Flow - Instrument Cluster LCD (continued)

Optima Hybrid/Plug-In's instrument cluster LCD screen displays the following Hybrid/Plug-In system modes to inform the driver of its status. To change modes, go to User Settings in the LCD Instrument Cluster modes.

Power Reserve - While the engine powers the vehicle, it is also recharging the Hybrid/Plug-In battery.



Vehicle Stop - The vehicle's Hybrid/Plug-In system is standing by.



Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. For more information on the instrument cluster, please refer to section 1 of the Owner's Manual.

Illustrations are for demonstration purposes only. Some indicators and warning lights may not appear in illustration. On the vehicle, they may appear in the LCD.


QR CODE

Plug-In Hybrid Instrument Cluster Overview Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Engine Brake/Regeneration - The regenerative braking system is recharging the Hybrid/Plug-In battery.






Engine Generation/Regeneration - The engine and the regenerative braking system are both recharging the Hybrid/Plug-In battery.



Plug-In Hybrid Display (Infotainment System)*

The Infotainment System screen provides information on economical operation and Plug-In Hybrid* system modes. To enter the Plug-In Hybrid display mode, press the ALL MENUS button on the Infotainment System home screen. Then select one of the menus: EV Range, Energy Information, Charge Management, ECO Driving, Energy Flow. Some examples are below:

- **Plug-In Hybrid System Home Screen** - Range, Energy Info, Charge Management, ECO Driving, Energy Flow
- **ECO Level** - The more economically you drive, the more the ECO Level increases
- **Energy Flow** - Displays the current flow of power between the main powertrain components
- **Fuel Economy** - Displays the average fuel economy over the duration of a trip



Eco Driving				
Fuel Economy	05-06-2022	27 mi	13.2 mpg	
Fuel Economy History	05-04-2022	22 mi	12.9 mpg	
	05-03-2022	14 mi	13.6 mpg	Driving dates, distances and fuel economy for the past 30 drives in the History are displayed.
	05-02-2022	7 mi	12.3 mpg	
	05-01-2022	18 mi	13.6 mpg	

The images shown are for illustration purposes only. Not all available displays are shown. Screens may vary.


For more information, refer to the Owner's Manual or the Car Infotainment System Quick Reference Guide.

Plug-In Hybrid Modes (Plug-In Hybrid only)

To change the Plug-In Hybrid Mode, press the EV/HEV button **A** (PHEV only); switch between Automatic mode, Electric (EV) mode and Hybrid (HEV) mode each time the button is pressed.

The LCD on the Instrument Cluster will display the mode selected:

- **Automatic Mode** - AUTO will be displayed on the instrument cluster and the vehicle will operate in Hybrid or Electric vehicle mode as needed
- **Electric Mode** - EV will display on the instrument cluster and the vehicle operates on the EV battery until the power is low, then it switches to HYBRID mode
- **Hybrid mode** - HEV will display on the instrument cluster and the high-voltage



(Located on button panel
below Gear Shift)*

QR CODE

Plug-In Hybrid Modes -
Automatic, EV and HEV
Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

For more information, refer to
sections 1 and 5 of the Owner's
Manual.

Forward Collision-Avoidance Assist (FCA)^{†3}

FCA is designed to detect and monitor a vehicle ahead or detect a pedestrian in the roadway through front view camera recognition and front radar signals to warn the driver that a collision is imminent, and if necessary, temporarily apply emergency braking. Initially, FCA provides Collision Warning **A** when it detects a potential collision with a vehicle, pedestrian, or cyclist, emitting an audible warning and visual alert on the instrument cluster.

If FCA detects that the collision risk has increased, FCA automatically applies the brakes to reduce your speed, potentially helping to reduce the effects of a possible collision **B**.

With the turn signal on, if it detects a potential collision, Junction Turning **E** may help to avoid the collision with an oncoming vehicle in an adjacent lane when turning left by applying emergency braking.

FCA Settings:





- FCA is on by default in most Kia models. FCA can be turned on/off by going to the User Settings* in the Instrument Cluster or the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- To access User settings*  in the Instrument Cluster - Press the Mode button  **C** on the Steering Wheel to toggle to User Settings . Press the **OK D** up/down to toggle to Driver Assistance and select an FCA mode
- To access Vehicle settings* in the Infotainment System - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select DRIVER ASSISTANCE and select an FCA mode
- **FCA Modes** - Select one of the following:
 - **Active Assist**: Vehicle will provide a warning (audible & visual) and apply the brakes if needed
 - **Warning Only**: Vehicle will provide a warning only (audible & visual)
 - **Off**: System is off, no warnings or braking provided
- **Warning Timing** - When in the DRIVER ASSISTANCE menu, select WARNING TIMING and one of the following:
 - **Standard**: Maximizes the amount of distance between the vehicles before the initial warning occurs
 - **Later**: Reduces the amount of distance between the vehicles before the initial warning occurs

FCA will become active when the:

- Ignition is on or the Engine Start/Stop button* is ON
- Vehicle is traveling faster than 6 mph
- Electronic Stability Control (ESC) is ON

When engaged, Forward Collision-Avoidance Assist (FCA) is not a substitute for safe driving and may not detect all objects in front of the vehicle or alert the driver when the vehicle is approaching another vehicle. Always drive safely and use caution.

Actual User Settings steps may vary by model. For illustrative purposes only. Your actual display, buttons and/or features may vary. Refer to section 6 in the Owner's Manual for more information.



(Junction Turning)

QR CODE

Forward Collision-Avoidance Assist (FCA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

QUICK TIP

The Warning Volume can be adjusted in the User Settings  in the Instrument Cluster (Go to Driver Assistance, then Warning Volume) or the Vehicle Settings* in the Infotainment System. Go to Driver Assistance* Warning Method, then Warning Volume.

REMINDERS:

- FCA will be activated by default when the ignition is cycled ON, even when previous setting was OFF
- If FCA is operating and the ESC (Electronic Stability Control) is turned off, FCA is automatically turned off
- When FCA is off, the Forward Safety warning indicator is on in the Instrument Cluster 

Blind-spot Collision-Avoidance Assist (BCA)^{†3}

BCA uses rear corner radar sensors in the rear bumper to monitor and warn the driver in certain situations if it detects an approaching vehicle in the driver's blind spot area and before changing lanes. Initially, BCA provides a Collision Warning when it detects a potential collision with a vehicle, emitting an audible warning and visual alert on the outside rearview mirrors. If BCA detects that the collision risk has increased, BCA automatically applies the opposite side front brake to try and mitigate a potential collision.




Vehicle detection: When another vehicle is detected within BCW warning boundary **A**, an indicator will illuminate on the outside rearview mirrors **B**.

Collision warning: When vehicle detection warning is on and the driver activates a turn signal, a flashing indicator will illuminate on the outside rearview mirrors and BCA will sound a warning.

Collision-Avoidance Assist: When collision warning has already occurred, and the collision risk has increased, braking is applied to the opposite side front wheel and a visual warning occurs. When you are driving forward out of a parking space, if BCA determines that there is a collision risk with an approaching vehicle in the blind spot, BCA will help avoid a collision by applying the brake.

BCA Settings:

- BCA can be turned on/off by going to the User Settings* in the Instrument Cluster or the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- **To access User settings***  **in the Instrument Cluster** - Press the Mode button  **C** on the Steering Wheel to toggle to User Settings . Press the **OK** **D** up/down to toggle to DRIVER ASSISTANCE, then BLIND-SPOT SAFETY and select a BCA mode
- **To access Vehicle settings*** **in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select DRIVER ASSISTANCE, then BLIND-SPOT SAFETY and select a BCA mode
- **BCA Modes** - Select one of the following:
 - **Active Assist:** BCA will provide a warning (audible & visual) and may activate Electronic Stability Control (ESC) and temporarily apply braking power
 - **Warning Only:** Vehicle will provide a warning only (audible & visual)
 - **Off:** BCA is off, no warnings provided
- **Warning Timing** - When in the DRIVER ASSISTANCE menu, select WARNING TIMING and one of the following:
 - **Standard:** Maximizes the amount of distance between the vehicles before the initial warning occurs
 - **Late:** Reduces the amount of distance between the vehicles before the initial warning occurs



QR CODE

Blind-spot Collision-Avoidance Assist Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

When engaged, BCA is a supplemental system. Do not solely rely on this system and always pay attention to the road and its conditions.

The images on this page are for illustrative purposes only and may not reflect actual feature or operation.

QUICK TIPS

- The Warning Volume can be adjusted in the User Settings  in the Instrument Cluster (Go to Driver Assistance, then Warning Volume) or the Vehicle Settings* on the Infotainment System. Go to Driver Assistance, Warning Method, then Warning Volume
- BCA will activate when:
 - BCA is turned on
 - Other vehicles are detected on the rear sides of the vehicle
 - Collision Warning is above approximately 12 mph; Collision Avoidance Assist is above approximately 40 mph

Refer to section 6 in the Owner's Manual for more information.

REMINDERS:

- When BCA is ON and the ignition is cycled, BCA returns to its previous state
- BCA may sound when making a left turn. Maintain a proper distance from oncoming vehicles

Lane Keeping Assist (LKA)^{*†‡}

Lane Keeping Assist (LKA) is designed to detect the lane markers on the road with a front view camera on the windshield, and may assist the driver's steering to potentially help keep the vehicle in the lane. When turned on, the instrument cluster indicator  will initially illuminate white or green. It will remain white when the vehicle is traveling slower than 40 mph or when the system does not detect the lane markers. When LKA detects the lane markers and can assist the steering, the Lane Safety icon will illuminate green.

If LKA detects that you are moving outside of your lane, LKA may give an audible warning and display Lane Departure Warning on the instrument cluster, or, LKA may provide steering inputs, trying to prevent the vehicle from moving outside its lane.

Hands-off Warning - If the driver takes their hands off the Steering Wheel for several seconds, a warning message will appear on the Instrument Cluster.

There are three available modes:


- **Off** - LKA will turn off
- **Lane Keeping Assist** - LKA will automatically assist the driver's steering when lane departure is detected to help prevent the vehicle from moving out of its lane
- **Lane Departure Warning** - LKA will warn the driver with an audible warning when lane departure is detected. The driver must steer the vehicle

LKA will operate under the following conditions:

- The vehicle speed exceeds approximately 40 mph
- LKA recognizes both sides of the lane markers the vehicle is traveling in
- The vehicle is between the lane markers




When LKA detects the lane markers, both lanes are displayed white



When LKA does not detect the lane markers, the lanes are displayed gray



When LKA detects the vehicle moving outside of the lane being traveled in, a yellow indicator will illuminate either on the left or right lane (shown in both images above)



(Located on Driver's Panel to the left of the steering wheel)

QR CODE

Lane Keeping Assist (LKA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

QUICK TIP

The Warning Volume can be adjusted in the User Settings  in the Instrument Cluster (Go to Driver Assistance, then Warning Volume) or the Vehicle Settings* on the Infotainment System. Go to Driver Assistance, Warning Method, then Warning Volume

REMINDERS:

- LKA will not issue a warning if the turn signals or hazard lights are activated
- When the ignition is cycled, LKA will return to the previously set state

Lane Keeping Assist is not a substitute for safe driving and may not always alert the driver if the vehicle is driven outside of its lane. Always drive safely and use caution.

Actual User Settings steps may vary by model. Refer to section 6 in the Owner's Manual for more information.

For illustrative purposes only. Your actual display, buttons and/or features may vary.

Lane Keeping Assist (LKA)^{†3} (continued)


LKA Settings:

- Press and hold the Lane Driving Assist button **A** to turn LKA on or off, when it is first enabled in the User Settings* in the Instrument Cluster or Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- To access User settings* in the Instrument Cluster -** Press the Mode button **B** on the Steering Wheel to toggle to User Settings . Press the **OK** button **C** up/down to toggle to DRIVER ASSISTANCE and then LANE SAFETY
- To access Vehicle settings* in the Infotainment System**
 - Press the **SETUP** key or the onscreen **SETUP** button.
 - Press **VEHICLE** to enter Vehicle Settings. Select DRIVER ASSISTANCE and then LANE SAFETY

REMINDERS:

- Some models access settings through the Vehicle Settings in the audio head unit. Press the Setup hard key on the infotainment system, then **VEHICLE** on the screen to enter Vehicle Settings

Refer to section 6 in the Owner's Manual for more information.



Intelligent Speed Limit Assist (ISLA)^{†3}

Intelligent Speed Limit Assist is designed to use the information from the posted speed limit **D** and the navigation system to inform the driver of the speed limit.


When ISLA is on and active, the system will display an alert on the Instrument Cluster LCD of the detected speed limit. If the vehicle's current speed exceeds the detected speed limit, the speed limit information will illuminate red on the LCD.

ISLA User Settings:

To enable ISLA on, press the **SETUP** key/button on the Infotainment System. Select the **VEHICLE** button to enter the Vehicle Settings. Select DRIVER ASSISTANCE, then SPEED LIMIT.

Select one of the three modes:

- Speed Limit Assist:** Informs the driver of the detected speed limit, display a message to change the set speed of the MSLA or SCC to help the driver stay within the posted speed limit. In addition, ISLA will inform the driver to change set speed of Manual Speed Limit Assist or Smart Cruise Control to help the driver stay within the speed limit
- Speed Limit Warning:** Informs the driver of the detected speed limit **D** and warn the driver when the vehicle is traveling faster than the posted speed limit
- Off:** ISLA is disabled



Refer to section 6 in the Owner's Manual for more information.

QR CODE

Intelligent Speed Limit Assist (ISLA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

ADAS

QUICK TIP

You can set a speed limit offset to the posted speed limit by going to User Settings, Driver Assistance, Speed Limit, then Speed Limit Offset. Set the offset to "0" if you want the vehicle to travel at the detected speed limit, when ISLA is on.

REMINDERS:



- Vehicle must be parked and in a safe location to change the speed settings
- Additional information may be displayed if additional road sign information is detected

Driver Attention Warning (DAW)^{*†‡}

Driver Attention Warning is designed to alert the driver if it detects inattentive driving practices and, in certain situations, can give a warning signal to take a break from driving. If DAW is activated, the DAW information **A** will appear on the Instrument Cluster LCD when you select the Assist mode in the Instrument Cluster User Settings . A message, "Consider taking a break," **B** appears on the LCD and a warning sounds to suggest the driver take a break when the driver's attention level becomes low.

DAW Settings:

- DAW can be turned on/off by going to the User Settings* in the Instrument Cluster or the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- To access User settings* in the Instrument Cluster** - Press the Mode button **C** on the Steering Wheel to toggle to User Settings . Press the **OK** **D** up/down to toggle to DRIVER ASSISTANCE, then DRIVER ATTENTION WARNING and select INATTENTIVE DRIVING
- To access Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select DRIVER ASSISTANCE, then DRIVER ATTENTION WARNING and select INATTENTIVE DRIVING



REMINDERS:

- The setup of DAW will be maintained, as selected, when the ignition is cycled
- When activated, DAW does not display "Consider taking a break" message when the total trip driving time is less than 10 minutes

QR CODE

Driver Attention Warning (DAW) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Driver Attention Warning is not a substitute for safe driving and may not detect all instances of inattentive driving practices. Failure to pay attention to travel conditions and vehicle operation could result in loss of vehicle control. Always drive safely and use caution.

See section 6 in the Owner's Manual for more information.

Leading Vehicle Departure Alert (LVDA)^{†‡}

Leading Vehicle Departure Alert is designed to inform the driver when the vehicle in front starts moving or departs from a stop. When LVDA is on, your vehicle is stopped and detects that the leading vehicle is driving away, LVDA sounds an alert to let you know you can start driving. If no action is taken after the vehicle in front drives away, then a message **A** will appear on the Instrument Cluster LCD.


LVDA User Settings:

- To turn LVDA on, press the Mode **B** button on the Steering Wheel, and go to User Settings ***** in the Instrument Cluster. Press the **OK** button **C** up/down and select DRIVER ASSISTANCE, then press the **OK** button **C** to select. Go to DRIVER ATTENTION WARNING and then LEADING VEHICLE DEPARTURE ALERT
- Some models access settings through the Vehicle Settings in the infotainment system. Press the **SETUP** hard key on the infotainment system, then press **VEHICLE**  on the screen to enter Vehicle Settings

The Leading Vehicle Departure Alert system is not a substitute for safe and proper driving. Always drive safely and use caution.

Images are for illustrative purposes only and may not reflect actual feature or operation.

See section 6 in the Owner's Manual for more information.



REMINDERS:


- When the ignition is cycled, the system returns to its previous state, on or off
- Always check the front of the vehicle and road conditions before departure

Safe Exit Assist (SEA)^{*†‡}

Safe Exit Assist (SEA) can help prevent passengers from opening their door by displaying a warning message on the Instrument Cluster and sounding an audible warning when a vehicle is detected, approaching from behind, and after your vehicle has stopped. In addition, when the electronic child safety lock button is in the LOCK position and an approaching vehicle from the rear area is detected, the electronic child safety lock button will not unlock even if the driver presses the button to prevent the rear doors from opening.

To turn on SEA, go to User Settings* in the Instrument cluster or the Vehicle Settings* in the infotainment system, select DRIVER ASSISTANCE, then BLIND-SPOT SAFETY, and select SAFE EXIT WARNING, and ACTIVE ASSIST.

See section 6 in the Owner's Manual for more information.



QUICK TIP

The Warning Volume can be adjusted in the User Settings* in the Instrument Cluster (Go to Driver Assistance, then Warning Volume) or the Vehicle Settings* on the infotainment system. Go to Driver Assistance, Warning Method, then Warning Volume.

QR CODE

Leading Vehicle
Departure Alert (LVDA)
Video



Safe Exit Assist (SEA)
Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

REMINDER: SEA may not detect all objects and the occupants should always be mindful of their surroundings.

Navigation-based Smart Cruise Control (NSCC)^{*†3,8}

Navigation-based Smart Cruise Control will help automatically adjust vehicle speed when driving on highways with posted speed limits by using road information from the navigation system, while Smart Cruise Control (SCC) is operating.

Smart Cruise Control (SCC) is designed to maintain a predetermined distance from vehicles detected ahead by automatically adjusting the driving speed as needed. When traffic is detected, the vehicle will slow down to maintain a set distance behind traffic without depressing the accelerator or brake pedal.

Highway Curve Zone Auto Slowdown: NSCC can automatically adjust the vehicle speed when it detects a curved road ahead and when it receives road information from the navigation system. When NSCC detects a curve ahead, NSCC activates and reduces the vehicle speed, and the NAV icon changes to AUTO and turns green **A** in the NSCC indicator. When the vehicle passes the curved road, the vehicle may return to its previously set speed.

Highway Auto Speed Change: If the set speed is set to the current posted speed limit on the highway during NSCC operation, the set speed is changed automatically whenever the posted speed limit changes and when it receives information from the navigation system.

SCC Operation: With SCC turned on and activated, the vehicle distance set, and the system detects a vehicle slowing or stopping, the system can bring the vehicle to a complete stop. When the vehicle ahead starts to move forward, SCC re-engages. If the vehicle ahead stops for more than 3 seconds, the accelerator pedal or the **+/-** button **B** must be pressed to start moving the vehicle.

SCC will adjust acceleration based on the drive mode selected in the Drive Mode Integrated Control system.

NSCC/SCC Settings:

- NSCC can be turned on/off by going to the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- **To access Vehicle settings* in the Infotainment System** - Press the SETUP key or the onscreen SETUP button. Press VEHICLE to enter Vehicle Settings. Select Driver Assistance > Driving Convenience > Highway Auto Speed Change
- **To turn on/set/adjust the SCC speed** - Press the Driving Assist button **C** on the Steering Wheel to activate SCC and the speed will be set to the current vehicle speed. SCC may decrease the speed to maintain the distance with the vehicle in front. The CRUISE indicator will illuminate on the instrument cluster. Press the **+/-** button **B** up/down to accelerate/decelerate to the desired speed. Press the button **B** to set the speed

NSCC is a supplemental system and is not a substitute for safe driving. It is the responsibility of the driver to always check the speed and distance to the vehicle ahead.

See section 6 in the Owner's Manual for more information. Images are for illustrative purposes only and may not reflect actual feature or operation.



SCC may decelerate if surrounding vehicle intervenes in front of my vehicle. Smart Cruise Control may not recognize unexpected and sudden situations or complex driving situations, so always pay attention to driving conditions and control your vehicle speed.

QR CODES

Navigation-based Smart Cruise Control (NSCC)
Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos



Navigation-based Smart Cruise Control (NSCC)^{*†3,8} (continued)

NSCC/SCC Settings (continued):

To set the vehicle distance: Press the Vehicle Distance button **D** on the steering wheel. Each time you press the button, the vehicle distance will change **E**, indicated by the number of bars that appear on the display **A**.

To pause/resume SCC operation: Depress the brake pedal or press the Pause/Resume button **II** – **B**. The cruise indicator on the instrument cluster will change.

To turn SCC OFF: Press the Driving Assist button **⑨** **C**. The CRUISE indicator on the instrument cluster will turn OFF.

To adjust the sensitivity of SCC: Press the mode button **¶** **F** on the Steering Wheel.

With the **OK** button **G**, select DRIVE ASSISTANCE, then SCC RESPONSE. Then select FAST, NORMAL or SLOW.



(Distances are approximate and vary depending on vehicle speed)

QUICK TIPS

- If your vehicle speed is between 0-20 mph when you press the Driving Assist button to turn NSCC on, the set speed will be set to 20 mph
- When following a vehicle, the system can automatically adjust your cruise speed based on the vehicle detected in front. It will even bring the vehicle to a complete stop if necessary. If the vehicle remains at a standstill for more than 3 seconds, you must depress the accelerator pedal or press the +/- switch up/down to start the vehicle
- NSCC is designed to function above approximately 20 mph only
- NSCC will not activate until the brake pedal has been depressed at least once after ignition ON or engine start
- The navigation part of Smart Cruise Control does not function when a destination is not set on the infotainment navigation system

REMINDERS:

- CRUISE indicator must be ON in order to operate SCC
- The speed setting will need to be reset when ignition is cycled
- The distance settings are approximations and may vary depending on vehicle speed. See the owner's manual for more information
- SCC is also canceled when the driver's door is opened, gear shift is changed out of D (Drive), Electronic Parking Brake (EPB) is activated and various other conditions. See owner's manual for other conditions
- If SCC is left on, it can be activated inadvertently. Keep the system off when not in use to avoid setting a speed which the driver is not aware of
- The navigation part of NSCC does not function when a destination is not set on the infotainment navigation system.
- NSCC requires an active navigation subscription
- NSCC is only available on controlled access roads and highways

QR CODES

Smart Cruise Control (SCC) with Overtaking Acceleration Assist Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Lane Following Assist (LFA)^{*†3}

Lane Following Assist (LFA) is designed to help ensure that the vehicle stays centered in its lane **A** by monitoring the detected lane markings ahead and adjusting the steering. The instrument cluster indicator will initially illuminate white or green **B** when turned ON. It will remain white when LFA does not detect the lane markers. When LFA detects the lane markers and can assist the steering, the LFA icon will illuminate green **B**.

Hands-off Warning - If the driver takes their hands off the Steering Wheel for several seconds, a warning message will appear on the Instrument Cluster. If hands on the Steering Wheel are not detected continually, LFA will be turned off with additional emergency warning.

LFA Settings:

Press the Lane Driving Assist button **C** to turn LFA on or off



LFA will operate only when these conditions are met:

- LKA recognizes both side lane markers the vehicle is traveling in
- The vehicle is traveling slower than 120 mph

QUICK TIP

The Warning Volume can be adjusted in the User Settings* in the Instrument Cluster (Go to Driver Assistance, then Warning Volume) or the Vehicle Settings* on the infotainment system. Go to Driver Assistance, Warning Method, then Warning Volume.

REMINDER: LFA is not a substitute for safe and proper driving. Always drive safely and use caution.



(Buttons located on steering wheel)

QR CODE

Lane Following Assist (LFA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Images are for illustrative purposes only and may not reflect actual feature or operation.

LFA is supplemental. Do not solely rely on this system and always pay attention to the road and its conditions.

Actual User Settings steps may vary by model. See section 6 in the Owner's Manual for more detailed information, limitations and conditions.

Highway Driving Assist (HDA)^{*†³}

Highway Driving Assist (HDA) is designed to help detect vehicles and lanes ahead, and help maintain distance from the vehicle ahead, maintain the set speed, and keep the vehicle between lanes while driving on the highway (or motorway).

When HDA is activated and the conditions are met, the Instrument Cluster indicator **A** will illuminate green. If the conditions are not met, HDA will be in standby mode and the indicator light **A** will illuminate white. When in operation, and if both lanes are recognized, the Instrument Cluster will show the lanes illuminated white and the HDA indicator illuminated green **A**.

Hands-off Warning - If the driver takes their hands off the Steering Wheel for several seconds, a warning message will appear on the Instrument Cluster, and an audible warning will sound. If hands on the Steering Wheel is not detected, HDA will cancel.

HDA settings:

- HDA can be turned on/off by going to the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- **To access Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select DRIVER ASSISTANCE, then DRIVER CONVENIENCE. Select HIGHWAY DRIVING ASSIST to activate

REMINDERS:

- Current highway speeds and controlled or limited access roads information may vary. Future navigation updates may change this information. See owner's manual for more information
- When the ignition is cycled, HDA returns to its previous state, on or off


When engaged, Highway Driving Assist is not a substitute for safe driving, may not detect all objects around the vehicle, and only functions on certain federal highways. Always drive safely and use caution. Refer to section 6 in the Owner's Manual for more detailed information, limitations and conditions.

QR CODE

Highway Driving Assist (HDA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos




Rear View Monitor (RVM)^{†‡}

Rear View Monitor is a supplemental system that displays the view behind the vehicle through the infotainment system screen.

RVM activates when the:

- Ignition or the Engine Start/Stop button* (Green Light) is in the ON position
- Gear Shift Lever is in the R (Reverse) position



REMINDER: Through normal use and after inclement weather or washing, the rear camera may become dirty. Use a clean, microfiber cloth to remove any dirt, debris or spots that may have accumulated on the lens.

Rear View Monitor is not a substitute for proper and safe backing-up procedures. Rear View Monitor may not display every object behind the vehicle. Always drive safely and use caution when backing up.

See section 5 in the Owner's Manual for more information. Images are for illustrative purposes only and may not reflect actual feature or operation.

Blind-spot View Monitor (BVM)^{*†‡}

Blind-spot View Monitor (BVM) displays the rear blind spot area of the vehicle in the cluster when the turn signal is turned on to help safely change lanes.

BVM Settings:

- Enable BVM in the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- **To access Vehicle settings* in the Infotainment System -**
Press the **SETUP** key or the onscreen **SETUP** button.
Press **VEHICLE** to enter Vehicle Settings. Select **DRIVER ASSISTANCE**, **BLIND-SPOT SAFETY** and then **BLIND-SPOT VIEW**

BVM will operate when the Engine Start/Stop button is on and the turn signal is activated.

BVM will not operate when the Engine Start/Stop button is off, a turn signal is deactivated or another warning screen comes up on the Instrument Cluster LCD.



(Display showing left side of vehicle)

QR CODE

Blind-spot View Monitor (BVM) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

See section 6 in the Owner's Manual for more information.

Images are for illustrative purposes only and may not reflect actual feature or operation.

Surround View Monitor (SVM)*†³

Surround View Monitor (SVM) is a parking support system that shows the areas around the front, rear, left and right sides of the vehicle via four wide-view cameras displayed onto the infotainment system screen.

Press **A** to turn SVM ON/OFF.

SVM will operate when:

- The Parking/View button **A** is pressed with the gear in D (Drive) or N (Neutral) when vehicle speed is below 9 mph (15 km/h)
- Parking/View button **A** is pressed with the gear in P (Park)
- The gear shift is in R (Reverse). When the gear is in R (Reverse), Surround View Monitor will turn ON regardless of vehicle speed or button status
- The gear shift is changed from R (Reverse) to N (Neutral) or D (Drive) when vehicle speed is below 9 mph (15 km/h)


Off Conditions:

- Parking/View button **A** is depressed
- When vehicle speed is above 9 mph (15 km/h), SVM will turn off and the screen will change back to the previous infotainment system screen
- One of the infotainment system buttons is pressed without the gear in R (Reverse). The screen will change back to the previous infotainment system screen


QUICK TIP

The Front wide-view camera will turn off when the gear shift is moved into Park or Reverse or the Parking View button is pressed.

To change the SVM settings, press the onscreen settings icon **B**, while SVM is operating.



(Located below gear shift knob)



The Surround View Monitoring (SVM) is only a supplemental device. Drivers should not rely solely on the SVM information when parking and backing up. Drivers should always pay attention and directly check the left/right and rear.

Images are for illustrative purposes only and may not reflect actual feature or operation.

See section 5 in the Owner's Manual for more information.

QR CODE

Surround View Monitor (SVM) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Rear Cross-traffic Collision - Avoidance Assist (RCCA)*†³

Rear Cross-traffic Collision-Avoidance Assist (RCCA) is designed to warn the driver, under certain conditions, may temporarily apply braking if it detects cross traffic approaching the vehicle, when vehicle is in reverse **A**.

RCCA will sound a warning, the warning indicators on the outside rearview mirror will illuminate and a message will appear on the Instrument Cluster LCD **B**. If RCCA detects that the collision risk has increased, the system automatically applies the brakes to reduce your speed, potentially helping to minimize the effects of a possible collision.

RCCA is designed to operate under the following conditions:



- When the gear shift is in Reverse
- When the vehicle is moving slower than 7.5 mph

RCCA Settings:

- RCCA can be turned on/off by going to the User Settings*  in the Instrument Cluster or the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- To access User settings*  in the Instrument Cluster** - Press the Mode button  **C** on the Steering Wheel to toggle to User Settings . Press the **OK** **D** up/down to toggle to DRIVER ASSISTANCE, then PARKING SAFETY. Select REAR CROSS TRAFFIC SAFETY and press the **OK** button **D**
- To access Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select DRIVER ASSISTANCE, then PARKING SAFETY and select REAR CROSS TRAFFIC SAFETY
- To set the initial warning activation time, go to User Settings , press the **OK** button **D** up/down, then go to DRIVER ASSISTANCE, WARNING TIME and press the **OK** button.

There are two settings:

- Standard:** This setting allows for a nominal amount of distance between the vehicles before the initial warning occurs
- Late:** Reduces the amount of distance between the vehicles before the initial warning occurs



(Buttons located on steering wheel)

QUICK TIP

The Warning Volume can be adjusted in the User Settings*  in the Instrument Cluster (Go to Driver Assistance, then Warning Volume) or the Vehicle Settings* on the infotainment system. Go to Driver Assistance, Warning Method, then Warning Volume.

QR CODE

Rear Cross-traffic
Collision - Avoidance
Assist (RCCA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 6 in the Owner's Manual for more information.

REMINDERS:

- When vehicle power is cycled, RCCA will remain in the previous state
- When a vehicle is approaching within the sensing range, and traveling faster than 3 mph, the RCCA system will show a warning
- RCCA is a supplemental system. Do not solely rely on this system and always pay attention to the road and its conditions

Reverse Parking Collision-Avoidance Assist (PCA)*†³

Reverse Parking Collision-Avoidance Assist is a supplemental system that is designed to assist the driver when the vehicle is in reverse by sounding a warning and temporarily braking, if a pedestrian or any object is detected within the sensing area of the rear of the vehicle, or to help reduce the possibility of a collision.

PCA Settings:

- PCA can be turned on/off by going to the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- **To access Vehicle settings in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select DRIVER ASSISTANCE, then PARKING SAFETY
- There are three modes:
 - **Rear Active Assist** - PCA will warn the driver with an audible alert and may apply temporary braking
 - **Rear Warning Only** - PCA will warn the driver with an audible alert
 - **Off** - PCA is disabled



To set the initial warning activation time, go to User Settings, press the **OK** button A up/down, then go to DRIVER ASSISTANCE, WARNING TIME and press the **OK** button A.

There are two settings:

- **Normal:** This setting allows for a nominal amount of distance between the vehicles before the initial warning occurs
- **Late:** Reduces the amount of distance between the vehicles before the initial warning occurs

QUICK TIP

The Warning Volume can be adjusted in the User Settings* in the Instrument Cluster (Go to Driver Assistance, then Warning Volume) or the Vehicle Settings* on the infotainment system. Go to Driver Assistance, Warning Method, then Warning Volume.



(Buttons located on right side of the steering wheel)

QR CODE

Reverse Parking Collision-Avoidance Assist (PCA)
Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Reverse Parking Collision-Avoidance Assist (PCA)* is not a substitute for proper and safe backing-up procedures. Always drive safely and use caution when backing up. Reverse Parking Collision-Avoidance Assist (PCA) may not detect every object around the vehicle. See section 6 in the Owner's Manual for more information.

Forward/Reverse Parking Distance Warning (PDW)^{†3}

Forward/Reverse Parking Distance Warning (PDW) is a supplemental system that is designed to assist the driver by chiming if any object is detected within the sensing area to the front, rear and side of the vehicle when backing up.

To turn PDW on, press the Parking Safety button **A** (LED illuminated). To turn PDW off, press again **A** (LED not illuminated).

PDW will activate when the ignition is on/ready and the vehicle is in D (Drive) or R (Reverse).

Parking Distance Warning Auto On - To set the parking distance warning to be on at low speeds, enable it in the User Settings* in the Instrument Cluster or the Vehicle Settings* in the infotainment system.

To enable in User settings* in the Instrument Cluster - Press the Mode button  **B** on the Steering Wheel to toggle to User Settings. Press the **OK** button **C** up/down to toggle to DRIVER ASSISTANCE, then PARKING SAFETY, and select PARKING DISTANCE WARNING AUTO ON

To enable in Vehicle settings* in the Infotainment System - Press the **SETUP** key or the onscreen **SETUP** button. Press VEHICLE to enter Vehicle Settings. Select DRIVER ASSISTANCE, then PARKING SAFETY and select PARKING DISTANCE WARNING AUTO ON

QUICK TIP

The Warning Volume can be adjusted in the User Settings* in the Instrument Cluster (Go to Driver Assistance, then Warning Volume) or the Vehicle Settings* on the infotainment system. Go to Driver Assistance, Warning Method, then Warning Volume.

REMINDERS:

- If the vehicle is moving at speeds over 3 mph, the system may not activate correctly
- When more than two objects are sensed at the same time, the closest one will be recognized first

Forward/Reverse Parking Distance Warning (PDW) is not a substitute for proper and safe backing-up procedures. Always drive safely and use caution when backing up. Forward/Reverse Parking Distance Warning (PDW) may not detect every object around the vehicle.

See section 5 in the Owner's Manual for more information.


Images are for illustrative purposes only and may not reflect actual feature or operation.

QR CODE

Forward/Reverse Parking Distance Warning (PDW) Video



(Located below gear shift knob)




(Buttons located on right side of the steering wheel)

Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Instrument Cluster Illumination Control

With the parking lights/headlights ON, press the button A (+) or (-) to adjust the brightness of the instrument panel illumination.

REMINDER: The Instrument Cluster illumination Control does not adjust brightness on the infotainment system screens. Use the display settings in the Setup menu to adjust the brightness on the screen.



See section 5 in the Owner's Manual for more information.

Electronic Stability Control (ESC)^{†5}

The ESC system is designed to help stabilize the vehicle during certain cornering maneuvers. It is a good idea to keep the ESC turned on for daily driving whenever possible.

Press the ESC OFF button B to turn Traction Control OFF/ON.

To turn OFF both the Traction Control and Stability Control, press and hold for more than 3 seconds. Press it again to turn ON.

REMINDERS:

- ESC is active by default at vehicle startup. When the ignition is cycled, ESC will turn ON again
- The ESC Indicator Light in the instrument cluster will illuminate whenever the ESC is in operation

See section 6 in the Owner's Manual for more information.

Hill-start Assist Control (HAC)^{†5}

HAC helps prevent the vehicle from rolling backwards when accelerating from a stop while on a steep incline. The HAC automatically activates whether the ESC is OFF or ON but does NOT activate when the ESC has malfunctioned.

QUICK TIPS

- When HAC is active (e.g., during initial acceleration from a stop on an incline), you may notice that the brakes will momentarily remain engaged after you depress the accelerator - this is normal HAC operation.
- HAC provides a two-second delay before the vehicle may start rolling backwards

REMINDERS:

- HAC does not operate when the gear shift is in the P (Park) or the N (Neutral) position.
- In the event of HAC system malfunction, see an Authorized Kia Dealer for service
- HAC does not replace the need to apply brakes while the vehicle is stopped on an incline

See section 6 in the Owner's Manual for more information.

Reverse Parking Aid Function*


When the gear shift lever is moved into R (Reverse) and while the vehicle is moving backward, the outside rearview mirrors **A** will rotate downward to aid in reverse parking.

When the left or right mirror buttons **B** are depressed, the Reverse Parking Aid Function will operate (LED lit).

To turn OFF the function, press the buttons to the center position.

The outside rearview mirrors will automatically return to their original positions when:

- The Engine Start/Stop Button is in the OFF position
- The gear shift lever is moved to any position except R (Reverse)
- Outside rearview mirror buttons are not depressed



(Button/switch panel located on Driver's Door)

REMINDER: When one of the outside rearview mirror switches are not depressed (LED lit), the Reverse Parking Aid Function will not operate and the outside rearview mirrors will not rotate downward.

See section 5 in the Owner's Manual for more information.

DRIVER'S PANEL


Engine Start/Stop Button*^{†6}

To start the engine:

1. Depress the brake pedal
2. Press the Engine Start/Stop button while gear shift is in P (Park) or N (Neutral)

To turn the engine OFF: Press the Engine Start/Stop button.

To use the Engine Start/Stop button, you must have the Smart Key fob inside the vehicle.



QUICK TIPS

To use electrical accessories:

ACC position

- When in the OFF position and without depressing the brake pedal, press the Engine Start/Stop button once (amber light)

ON position

- When already in the ACC position (amber light) and without depressing the brake pedal, press the Engine Start/Stop button (red light)
- When in the OFF position and without depressing the brake pedal, press the Engine Start/Stop button twice (red light)

Keeping the vehicle in the ACC or ON position for extended periods of time without turning the engine on may discharge the vehicle's battery.

REMINDERS:

- In an emergency situation while the vehicle is in motion, you are able to turn the engine off and to the ACC position by pressing the Engine Start/Stop button for more than 2 seconds or 3 times successively within 3 seconds
- If the Smart Key battery is weak or not working properly, hold the Smart Key fob up to the Engine Start/Stop button (Lock button side closest) and press to start engine

QR CODE

Start/Stop Button Video



Kia Smart & Folding Key Fobs Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

With the engine off, hydraulic power assist for steering and braking will be disabled and the vehicle will be more difficult to control.

See section 6 in the Owner's Manual for more information.

Power Windows, Window Lock & Central Door Lock

- A** Pull/Press to operate Front Windows Auto Up/Down*

QUICK TIP

Press button again to stop Auto Up/Down function.

- B** Press to Unlock/Lock All Doors

- C** Press to disable Rear Passenger Windows

REMINDERS:

- When pressed **C**, window controls for the Rear Passenger Windows are disabled
- When closing, be mindful of any objects or persons

QUICK TIPS


While driving with the rear windows down or with the sunroof* in an open or partially open position, a wind buffeting or pulsation noise may be heard. This noise is a normal occurrence and can be reduced or eliminated by the following:

- If the noise occurs with one or both of the rear windows down, partially lower both front windows approximately 1 inch
- If the noise occurs with the sunroof open, slightly reduce the size of the sunroof opening

Automatic Door Lock/Unlock

Auto Door Lock/Unlock will engage when the gear shift is moved into or out of the P (Park) position. Refer to the User Settings mode in the LCD Instrument Cluster or the infotainment system on how to turn Auto Door Lock/Unlock ON/OFF.

Button configuration may vary depending on vehicle model. Refer to section 5 in the Owner's Manual for more information.



(Button/switch panel located on
Driver's Door)

Electronic Child Safety Lock System

Press button **C** to lock the rear passenger doors. An indicator will illuminate showing the system is active. This system is on by default, and then activated once the button **C** is pressed. To deactivate, press the button again.

See section 5 in the Owner's Manual for more information.

QR CODE

Electronic Child Safety Lock System Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

DRIVER'S PANEL

Power/Heated Outside Mirrors*

Mirror heaters are activated when the Rear Defroster is turned on **A**.

Refer to section 5 in the Owner's Manual for more information.



Manual Folding Mirrors*


To fold the mirrors in manually, pull the mirror towards the window.

QUICK TIP

If needed, pull the mirror firmly until it folds.


Refer to section 5 in the Owner's Manual for more information.

Images are for illustrative purposes only and may not reflect actual feature or operation.



Power Folding Outside Mirrors*

- B** Press the L or R buttons to select the mirror to adjust
- C** Press button arrows left/right or up/down to adjust mirror position
- D** Toggle button left/right to unfold/fold the outside rearview mirrors
- B** Toggle button to center to automatically fold/unfold mirrors when:
 - The Smart Key* Lock/Unlock buttons are pressed
 - The door outside handle button* is pressed



QUICK TIP

The mirrors will automatically unfold when the Smart Key* is within close proximity to the vehicle.

REMINDERS:

- When the mirror button **B** is in the center, press the Lock button on the Smart Key to automatically fold the mirrors
- To lock the position of mirrors, toggle switch to the neutral (center) position

Tilt/Telescoping Steering Wheel^{†17}

To adjust the Steering Wheel, press the Lock-Release Lever **A** down and adjust the desired angle **B** and distance **C**.


When finished, pull the Lock-Release Lever **A** up to lock the Steering Wheel in place.

QUICK TIP

To adjust the steering wheel angle, it may be helpful to first adjust the steering wheel's distance from the driver.

Do not attempt to adjust steering wheel position when vehicle is in motion as this may cause you to lose control of the vehicle.

For illustrative purposes only. Your steering wheel may vary. See section 5 in the Owner's Manual for more information.



QR CODE

Tilt/Telescoping/Heated Steering Wheel Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Turn Signals & Fog Lights*

To operate:

- Slightly move lever up/down to activate One-Touch Lane Change Signal **D**
- Turn Signals - Move lever Up/Down for Right/Left Turn Signal **E**
- Fog Lights - Press toggle switch **F** to turn Fog Lights ON/OFF

REMINDER: Headlights must be ON for Fog Light operation.



One-Touch Lane Change Signal is activated by briefly pressing the Turn Signal Lever up/down slightly for less than 1 second and then releasing **D**. The lane change signal will blink 3 times.

To turn the One-Touch Lane Change Signal off/on, go to User Settings Mode in the LCD Instrument Cluster or the infotainment system.

Refer to section 5 in the Owner's Manual for more information.


For illustrative purposes only. Your actual display, buttons and/or features may vary.

Headlights & High Beams

To operate:

- Rotate the switch to change the Headlight function **A**
- Push the lever to turn the High Beams ON **B**
- Pull the lever to flash the Headlights/High Beams **C**

AUTO Light position* - When the light switch is in the AUTO Light position, the tail lights and headlights will turn ON/OFF automatically depending on the amount of light outside the vehicle.



Daytime Running Lights (DRL)* - DRL may help others to see the front of your vehicle during the day. The lights will turn on automatically when the ignition or Engine Start/Stop button is ON and the headlight switch is in the AUTO position, unless one of the following occurs:

- Headlights are on
- Parking brake is applied
- Engine is turned off
- Headlight switch is in the OFF position

REMINDER: DRL only operates during the daytime.

High Beam Assist (HBA)

High Beam Assist is designed to automatically adjust the headlight range by switching between high and low beams based on light detected from other vehicles and road conditions.

To enable HBA, toggle the light switch to the AUTO Light position and push the lever away from you. The High Beam Assist indicator will illuminate.

REMINDERS:

- High Beam Assist does not operate below certain speeds, or in some lighting and driving conditions. Please be aware of your surroundings and exercise proper road etiquette when operating a vehicle using the high beams
- HBA will operate when vehicle speed exceeds 25 mph
- If the lever is pushed away from you while HBA is operational, HBA will turn off and the high beams will be on continuously. If the lever is pulled toward you when the high beam is off, the high beam will turn on without High Beam Assist canceled. If the lever is pulled towards you when the high beam is on by High Beam Assist, low beam will be on and the High Beam Assist will turn off
- If the light switch is switched to the headlight position, HBA will turn off and low beams will be on continuously
- When HBA is not working properly, the 'Check High Beam Assist system' warning message will appear and warning light will appear on the cluster. See an authorized Kia dealer for service

See section 5 in the Owner's Manual for more information.

QR CODE

High Beam Assist (HBA)
Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

Windshield Wipers & Washers

To operate:

- Move lever Up/Down **A** to change Wiper modes
- Push switch **B** to adjust Intermittent Wipe Speed
- Pull lever to spray and wipe **C**

Rain Sensing* (Auto Control Wipe):

The rain sensor located on the upper end of the windshield glass senses the amount of rainfall and controls the wiping cycle for the interval selected. The more it rains, the faster the wiper operates. When the rain stops, the wiper stops.


To vary the speed setting, press the Wiper Switch **B** up/down.

If the wiper lever is set in AUTO mode when the Power button is ON, the wiper will operate once to perform a self-check of the system.

Rear Wiper & Washer*


To operate:

- Rotate Rear Wiper switch to change Wiper modes **D**
- Push to spray and wipe **E**



QUICK TIP

On Rear Wipers, the intermittent wipe function is not adjustable. LO and HI sets wiper speed.



QUICK TIPS


- Moving switch **B** up increases intermittent wipe frequency and wipe speed. Moving switch down decreases frequency of wipes
- Set the wiper to the OFF position when the wiper is not in use

Lifting Wipers (Wiper Service Mode)

To lift the windshield wipers to clean windshield, inspect or replace wiper blades or raise wipers in snow/ice conditions without damaging the hood, the blades need to be moved to the service position **F** to prevent damaging the hood.

With the ignition ON, turn the ignition OFF, and within 20 seconds move the wiper switch **B** to the MIST position and hold the switch for more than two seconds until the wiper blade is in the fully up position.

To return wipers to normal position, turn the ignition ON, then activate MIST.



Refer to section 7 in the Owner's Manual for more information.

QR CODE

Wipers and Wipers Stalk Video



Lifting Wipers (Wiper Service Mode) Video



Bluetooth® Wireless Technology^{†2,15}

- A Talk button:** Press to activate voice recognition/bring up menus/place calls with minimal voice command prompts from the system. Press and hold to exit voice recognition
- Kia Connect with Navigation*** - When enrolled with a Kia Connect subscription, press this button to activate the Kia Connect Voice Assist to use navigation guidance and search destinations
- B Volume button:** Press up/down to raise/lower speaker volume
Mute button: Press to mute the microphone during a call
- C Receive/Place Call button:** Press to place/answer calls. If no phone is paired, press the button to pair a phone
- D End Call button:** Press to end a call, reject an incoming call or cancel a function


QUICK TIPS

- When using the voice command feature, wait for the system BEEP before speaking the command
- Phone book transfer upload time varies by phone model and with number of phone book entries
- Because of differences in phone quality, service providers and Bluetooth® Wireless Technology chip programming, functionality may differ from one phone to another
- The system may register or pair multiple Bluetooth® devices

For more information, refer to the Car Infotainment System Quick Reference Guide or the Owner's Manual. For Bluetooth® Wireless Technology FAQs, go to www.kia.com, or call Consumer Information for Bluetooth® Technology at (800) 333-4KIA. Refer to your Owner's Manual for more specific Bluetooth® Wireless Technology phone pairing and operation instructions.

Your vehicle's steering wheel buttons may differ from those in the illustrations.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.



Pairing a Phone

For instructions on how to pair a phone, refer to the Car Infotainment System Quick Reference Guide or your vehicle's Quick Start Guide.

QUICK TIP

During the pairing process, be sure to accept the connection requests on the phone for phone book download and to allow acceptance of all future Bluetooth® connection requests.

How to Place a Call

When using the voice command feature, wait for the system BEEP before speaking the command.

There are two options for placing a call:

- **Option 1:** Press the Receive/Place Call button **C** (displays the phone screen with call history)
- **Option 2:** Press the Talk button* **A**. Then say the command "Call {name}" or "Dial {number}", followed by contact name or number

REMINDER: Bluetooth® Wireless Technology audio and calling functions are supported when connected to a Bluetooth® enabled device

Bluetooth® Wireless Technology^{†2,15} (continued)

Voice Recognition* and Phone Contact Tips

The system may have difficulty understanding some accents or uncommon names. Improve the performance by making a few simple changes to your phone contacts, listed below. To help optimize the Bluetooth® Wireless Technology Voice Recognition system, see other tips and reminders under Quick Tips.

- Use full names (first and last names) vs. short or single-syllable names ("John Smith" vs. "Dad," "Smith Residence" vs. "Home")
- Avoid using special characters, emojis or hyphenated names (@, &, #, /, -, *, +, etc.)
- Avoid using acronyms ("In Case of Emergency" vs. "ICE") or words with all capital letters
- Spell words completely, no abbreviations ("Doctor Smith" vs. "Dr. Smith")

QUICK TIPS


- *Bluetooth® Music Streaming* - If the *Bluetooth®* music is inaudible or too low, you may need to turn up the volume on the connected phone
- When placing a call, speak in a natural, moderate tone, with clear pronunciation. The system may have trouble recognizing commands if you speak too softly or too loudly
- Always wait for the beep before speaking any commands
- Close windows and sunroof and turn off A/C - Open windows, sunroof, weather (wind/rain), or an A/C fan operating at higher speeds can interfere with Voice Recognition
- Press the talk button and say "Help" to get a list of available commands
- The system may register or pair multiple *Bluetooth®* devices. See the Car Infotainment System Quick Reference Guide for more information on setup and limitations.

Audio Controls^{†15}

- A Audio MODE button:** Press to cycle through FM/AM/SiriusXM®*/Media modes
- B Seek/Preset buttons:** FM/AM/SiriusXM® Modes: Press to advance through Preset Stations. Press and hold to auto seek
- Media Modes:** Press up/down to move track up/down. Press and hold to fast forward/rewind (except for *Bluetooth®* Audio)
- C Volume button:** Press up/down to raise/lower volume
- Mute button:** Press to mute all audio (Media pauses in some Media modes when pressed)

For other audio system information, refer to pages 40-45.

For more information, refer to the Owner's Manual or the Car Infotainment System Quick Reference Guide.



(Controls on left side of Steering Wheel)

QR CODE

Voice Recognition
Tips Video



Star, Favorite & Radio
Presets Buttons Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

Android Auto™^{†2} / Apple CarPlay®^{†2} Setup

Android Auto™ compatible smartphone setup - Download the Android Auto™ app from the Google Play™ Store^{†2}. Open the Android Auto™ app and proceed with the onscreen instructions to complete setup on the mobile device.

Wireless Connection setup for Android Auto™ & Apple CarPlay® (Standard Audio System-Value):

1. Press the **SETUP** key on the infotainment system
2. Press **DEVICE CONNECTION SETTINGS**
3. Press **PHONE PROJECTION**, then **ADD NEW**

Cable Connection setup for Android Auto™ (Standard Audio System, Standard Audio System-Value & Kia Connect with Navigation):

1. Press the **SETUP** key on the infotainment system
2. Press **DEVICE CONNECTION**, select **Android Auto™** and then select **ENABLE ANDROID AUTO**. Review all terms, conditions and requests on the head unit and phone, and, if you agree, accept them in order to use **Android Auto™**
3. Connect the **Android™** device with the vehicle's USB port using the manufacturer's cable provided with your phone
4. From the vehicle's home screen, select the **Android Auto™** button, where you'll see all the **Android Auto™** supported apps

QUICK TIPS

- If **Android Auto™ / Apple CarPlay®** randomly disconnects:
 - Ensure the USB cable is certified by the phone manufacturer for both power and data
 - Clean the phone's port, which the USB cable connects to, as instructed by the phone's manufacturer
 - The Phone should not be disturbed while driving as this can cause a disconnection at the phone's USB port
 - Visit the phone manufacturer's website for **Android Auto™ / Apple CarPlay®** app concerns

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and any handheld devices, other equipment, or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or which are not permissible by law should never be used during operation of the vehicle.

QR CODE

Wireless Apple CarPlay® &
Android™ Auto Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to the Car Infotainment System Quick Reference Guide for more information.

Cable Connection setup for Apple CarPlay® (Kia Connect with Navigation only):

1. Connect the Apple CarPlay® compatible iPhone^{†2} with the vehicle's USB port using the manufacturer's cable provided with your iPhone^{†2}
2. Press the **SETUP** key on the infotainment system
3. Press **DEVICE CONNECTION** on the screen and select **Apple CarPlay®**
4. Select **ENABLE APPLE CARPLAY**. Review all terms, conditions and requests on the head unit and phone, and, if you agree, accept them in order to use Apple CarPlay®
4. From the infotainment system home screen, select the **Apple CarPlay®** button, where you'll see all the Apple CarPlay® supported apps

REMINDERS:

- **Android Auto™** compatibility requirements for connection:
 - Kia Connect with Navigation (USB cable connection only): OS **Android™ 5.0** or higher, phone manufacturer's USB cable and data plan for applicable feature(s)
 - Standard Audio System-Value (USB cable & wireless connection):
 - USB cable connection - OS **Android™ 5.0** or higher, phone manufacturer's USB cable and data plan for applicable feature(s)
 - Wireless connection - OS **Android™ 9.0** or higher with data plan for applicable feature(s)
- **Apple CarPlay®** compatibility requirements for connection:
 - Kia Connect with Navigation (USB cable connection only): iOS software **8.0** or higher, phone manufacturer's USB cable and data plan for applicable feature(s)
 - Standard Audio System-Value (Wireless connection only): iOS software **10.0** and higher with data plan for applicable feature(s)
- It is recommended to always update your phone to the latest operating system release
- Wireless **Android Auto™** system only works for certain **Android™** models. Use the manufacturer's USB cable when wireless feature is not available

Kia Connect Activation^{†1} (Systems equipped with Kia Connect only):

Follow these steps to activate your Kia Connect system:

1. Enter the activation screen on your vehicle's head unit:
 - a. Press SETUP key
 - b. Press Kia Connect icon
 - c. Press Activate
2. Read and agree to Terms of Service and Privacy Policy and press SUBMIT
3. Enter phone number or email address to receive a verification code, then press SUBMIT
4. Follow these steps to receive your verification code using your phone text message or email:
 - a. Check your phone text message or email for verification code
 - b. Open the link in your text or email. A page will open requesting that you create your account

Note: If you already have a Kia Owners Portal account using the email or phone number as your login ID, you will need to provide your password prior to receiving the verification code

REMINDER: This vehicle is not equipped with over-the-air system updates.

Kia Connect Assistance^{†1}

Virtual Assistant  **A** - Press to connect to a virtual assistant to hear information about the Kia Connect features

Kia Connect Voice Local Search **B** (systems with navigation) - Press to connect to the search function to find points of interest or other locations, like "cafe"

Kia Connect Voice Local Search **B** (non-navigation systems) - Press to activate phone projection with Android Auto™ or Apple CarPlay® (smartphone must be connected via wireless or USB cable — see previous page for availability and setup)

Roadside Assist  **C** - Press to connect to a Roadside Assistant where you can request vehicle towing services


REMINDER: These buttons may be located in the rearview mirror or the overhead console.

ALWAYS CHECK THE OWNER'S MANUAL FOR COMPLETE OPERATING INFORMATION AND SAFETY WARNINGS.

- c. Enter your first name, last name, email, phone number, an account password, and click CREATE ACCOUNT. A page will open displaying your verification code
- d. Enter the code in the head unit and press ACTIVATE
- e. Go back to the page with your verification code and press "I have entered my verification code." A link will be provided to download the Kia Access app from your app store. After installing the app, log in and enjoy

Kia Connect may be unavailable for model year 2022 vehicles sold or purchased in Massachusetts. See Kia Connect Terms of Service at owners.kia.com for more information.

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and any handheld devices, other equipment, or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or which are not permissible by law should never be used during operation of the vehicle.



(Buttons on overhead console*)

For more information, refer to the Car Infotainment System Quick Reference Guide. On certain models, UVO Assistance buttons are located on the Rearview Mirror.

QR CODE

Kia Connect Activation Video



Kia Access App Video



Kia Connect Assistance Video



*Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos*

Kia Access App Download

Go to an app marketplace to download the Kia Access App. Once you download the app, make sure you register your vehicle and start an account (refer to Kia Connect Activation page). Get to know your new Kia and the available convenient features on the app.

QUICK TIPS

- The smartphone and vehicle need to be connected to a cellular network with a good wireless signal strength in order to use Kia Connect. If these conditions are not met, remote command may not execute or may take a long time. It will also effect voice commands such as navigation POI or address search
- To use Remote Start or Remote Start with Climate Control feature, all doors, hood and trunk/liftgate must be closed and locked
- When Remote Start is activated, if the driver does not enter the vehicle within 10 minutes, the Remote Start will turn the engine off
- When using Remote Start with Climate Control, turn on for at least a few minutes before getting into the vehicle, allowing the vehicle interior to reach your desired temperature
- The quickest way to obtain accurate vehicle status through the app is by pressing the refresh button on the app or refreshing the web page when using the customer web portal
- In order to preserve the vehicle battery, Kia Connect will not turn on seven days after the last ignition was on. You will need to restart the vehicle with a key fob in order to use Kia Connect again



Kia Access App Features Guide

The Kia Access App Features Guide is a step-by-step guide that helps you utilize the app to its full potential by detailing how to use each feature and adjust various settings. Below are some of the topics included:

- Remote Commands
- Set Climate
- Schedule Remote Start/Climate
- Schedule Charge
- Schedule Service
- Dealer Settings
- Manage Vehicles and Profiles

Do not use remote climate control or remote start if vehicle is in an enclosed area (e.g., closed garage) or a partially enclosed area without ventilation. Close all doors leading from adjacent living areas to the vehicle area before executing a remote climate control or remote start command.

Kia Access App Screen for illustrative purposes only. Actual App screen and functionality may vary. For further Kia Connect operations, refer to the Car Infotainment System Quick Reference Guide.

Kia Connect may be unavailable for model year 2022 vehicles sold or purchased in Massachusetts. See Kia Connect Terms of Service at [owners.kia.com](#) for more information.

QR CODES


Download the Kia Access App by clicking this dynamic QR code. Some phone's operating systems may need to be updated to scan dynamic QR codes.



Kia Access App Features Guide. Click this dynamic QR code to access the guide. Some phone's operating systems may need to be updated to scan dynamic QR codes.



Kia Connect^{†1} w/ Navigation^{†8} - FM/AM/SiriusXM^{®†14}/ Media (USB, Bluetooth^{®†2} Audio)



A programmable key to provide quick access to one of several available system features

Press to display SETUP/Settings mode

Press briefly to do the following:

- FM/AM mode: Play the previous/next frequency.
- SiriusXM® mode: Change the channel.
- MEDIA mode: Change the track, file or title (except for AUX).

Press and hold to do the following (over 0.8 seconds):

- FM/AM mode: Move quickly through all of the frequencies. When released, the system seeks the next available frequency.
- MEDIA mode: Rewinds or fast forwards the track or file (except for AUX and Bluetooth® Audio).

Sound Settings: To adjust the sound settings from any audio mode, press the SETUP button on the infotainment system, then select the onscreen SOUND button. Select the menu item to change settings, and use the onscreen buttons to adjust settings.

Radio Presets: To save a preset, press the STAR button next to or below the Radio Station display. This saves the current station as a preset.

SiriusXM® Smart Favorites: In Radio mode, choose SiriusXM®, then select any of the first ten favorites. During song or program play, tap the Skip Backward icon to start from the beginning of the song or program. Tap the Play Live icon to return to the live broadcast.

Custom Key : To program the Custom Key, press; select an available feature you would like the Custom Key to open.

QUICK TIPS

- Volume level between different audio modes:
 - When switching between audio modes (AM, FM, Bluetooth® Audio, etc.), the audio system saves the previous volume level you were listening to. For example, if you were listening to FM radio at volume level 20 then switched to Bluetooth® Audio and adjusted the volume level to 30, the volume level will be at 20 when you switch back to FM radio
 - When using Bluetooth® Audio, the overall volume is dependent on your device's volume. If the volume is turned down low on your device it will remain low even if the system volume is turned up
- When connected to Android Auto™ or Apple CarPlay® on your smartphone, the smartphone's navigation system may also be available
- This system supports Android Auto™ and Apple CarPlay® (USB connection only)
- A warning screen may appear periodically to remind users that the navigation system should be operated when the engine is running to prevent battery discharge
- At any time, you can interrupt UVO link Command Feedback by pressing the TALK button on the steering wheel

REMINDERS:

- To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park.
- Prolonged use of the infotainment system in ACC mode may drain the vehicle's battery
- **Map/software updates:** To keep your map and software up to date, free of charge, visit the official Kia update webpage at <https://update.kia.com/US/EN/Main>. Note, visiting a dealer for software update may include an additional charge.

Kia Connect may be currently unavailable for model year 2022 or later vehicles sold or purchased in Massachusetts. See Kia Connect Terms of Service at owners.kia.com for more information.

For further Kia Connect with Navigation operations, refer to the Car Infotainment System Quick Reference Guide. For other audio system information, see pages 40-44.

QR CODE

Kia Connect with Navigation Video



Navigation System Important Tips Video



Navigation System Updates Video



Refer to the inside front cover for more information on QR codes. www.youtube.com/KiaFeatureVideos

Multimedia USB Ports, Power Outlets, & USB Charger Ports*

Multimedia USB Port*

A Use the Multimedia USB port to connect USB audio devices and smartphones

USB Charger Ports*

B USB charger ports* are located in the Center Panel, inside and on the back of the Center Console

Power Outlets


C Use the power outlets for mobile phones and other devices designed to operate on a 12V (180W max) power outlet

QUICK TIP


The power outlets are inactive when the Engine Start/Stop button is OFF.

REMINDERS:

- Using the Power Outlet (accessory plug) and USB charger for prolonged periods of time with the Engine Start/Stop button in the ACC position (Engine OFF) for prolonged period time could cause the battery to discharge
- Use only the charging cables that your device manufacturer supplied. Third party cables may cause damage to device
- The USB data port (Multimedia USB port) is located next to the Power Outlets. The USB Charger ports do not support data transfer



(Located on Center Console below Climate Controls)



QR CODE

Multimedia USB Port, Power Outlets & USB Charger Port Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 5 in the Owner's Manual for more information.

For illustrative purposes only. Your actual display, buttons and/or features may vary.


AC Inverter*

The AC inverter supplies 115V/150W electric power to operate accessories or devices.

To use the AC inverter, open the AC inverter cover and connect a plug to it.

The AC inverter is ON when the vehicle is on.

Refer to section 5 in the Owner's Manual for more information.



(Located on Back of Center Console)

Digital Clock - Infotainment System

Press SETUP, then select General, scroll down and select Date/Time from the menu to adjust. Then use the onscreen buttons to navigate through setup and return to exit.

QUICK TIPS

- When needed, Daylight Savings must be enabled in the Clock Settings screen
- To access manual date and time setting, turn GPS time OFF in the Clock Settings (Kia Connect with Navigation*)

Refer to the Car Infotainment System Quick Reference Guide for more information.

Wireless Smartphone Charging System^{†19}

Charge a compatible Qi Certified smartphone wirelessly by placing it on the tray **A** at the front of the console, near the Multimedia USB ports and the charging indicator, while the ignition is on.


1. Enable Wireless Charging in the User Settings in the Instrument Cluster LCD or the Vehicle Settings* in the infotainment system, select Convenience, then Wireless Charging System
2. Slide open cover **B**. Place the smartphone on the center of the charging pad **A**
3. Indicator light **C** may change to amber once wireless charging begins
4. Once charging is complete, the amber light may change to green

QUICK TIPS

- Wireless charging must be enabled in user settings
- If wireless charging does not work, move the smartphone around the pad until the charging indicator turns amber. Avoid placing other metal items in the bin while charging as to not impede the charging area
- For wireless charging to occur, all doors (excluding the rear hatch) must be closed & the Smart Key Fob must be detected inside the vehicle

REMINDERS:

- The smartphone must be a compatible Qi certified phone with Qi function available. Some smartphone models are not Qi certified, which may affect the availability, speed or performance of the wireless charging
- If the driver door is opened, charging will be disabled
- Wireless charging technology allows for a device to be charged using inductive charging. See your Owner's Manual for more detailed information and the back page for legal disclaimers
- Inductive charging systems are less efficient than conventional charging through a cable. As a result, higher device operating temperatures may be experienced during use
- Charging Performance - Device position on the wireless charging system can affect charging performance. Other factor that may affect the charging rate includes foreign objects, such as coins or pens, and phone case thickness
- Avoid placing other metal items in the bin while charging as to not impede the charging area



QR CODE

Wireless Charging Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 5 in the Owner's Manual for more information.


For illustrative purposes only. Your actual display, buttons and/or features may vary.

Automatic Climate Control

Front Climate Control*



3rd Row Climate Control*



Climate Control Auto Function

1. Press AUTO **B** to select Full Auto Operation. Press once for the air flow high setting, twice for medium setting and once more for the lower setting. The Auto setting automatically controls the airflow modes, fan speeds, air intake and air conditioning according to the temperature setting selected
2. Set desired driver's Temperature **A**
3. Press SYNC* **M** to select Sync Temperature Control Operation*, which synchronizes the passenger's temperature to the driver's setting

A Driver's temperature control

B AUTO (automatic control) button (High, Medium, Low)

C AUTO (automatic control) button (High, Medium, Low)

D Turn the Auto Climate Control system OFF button

E Front windshield defroster button

F Rear window defroster button

G Fan speed control button

H Mode Selection button

I Climate information screen

J A/C Rear Control ON/OFF button

K Air intake control button

L Passenger's temperature control knob

M SYNC temperature control selection button*

N 3rd Row air conditioning ON/OFF button

O 3rd Row fan speed control knob

Defrost Outside and/or Inside Windshield::

1. Set Front Fan Speed **G** to the highest position
2. Set Temperature **A** to Hot
3. Press the Front Defrost button **E**


Automatic Climate Control (continued)

Air Flow Modes

To select Air Flow Modes, press the mode button  to cycle through to the desired mode:



Face-Level



Floor-Level



Bi-Level



Floor/Defrost-Level

QUICK TIPS

- Defrost Mode  activates A/C and opens Fresh Air Vent to help dehumidify the air and improve Defroster performance
- During Auto Operation, the A/C indicator will NOT illuminate. The fan speed, air intake, air flow and air conditioning may automatically be engaged at any time to reach desired temperature and reduce humidity
- Keep inside glass as clean as possible to reduce window fogging

REMINDERS:

- Pressing any button during AUTO operation will deactivate the AUTO function and switch to manual mode, except for Temperature Control
- When in AUTO mode, Air Flow Mode and Fan Speed do not display on the Climate Control Display
- Warm air may flow in through the vents if the Recirculated Air button is not pressed ON (LED lit)
- Continuous use of the climate control system in the recirculated air position may allow humidity to increase inside the vehicle which may fog the glass and obscure visibility and/or cause smell/odor
- Your Automatic Climate Control system may differ from those in the illustrations. Refer to section 5 in the Owner's Manual for more information.
- For illustrative purposes only. Your actual display, buttons and/or features may vary.

Auto Defogging System (ADS)

Auto defogging is designed to reduce the fogging up of the inside of the windshield by automatically sensing the moisture of the inside of the windshield. The system will automatically change to defrost mode when needed.

Auto Defogging is set ON by default. To cancel Auto Defogging, press the Front Defrost button  for three seconds, when the ignition is on (ADS OFF icon will illuminate). To turn Auto Defogging on again, press the Front Defrost button  for three seconds.

QR CODE

Automatic Climate Control Operation Video



Auto Defogging System (ADS) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Rotary Dial Shifter Knob - Shift-by-Wire (SWB)

P: Park - To shift into Park from any gear, press the Park (P) button **A** on the Rotary Dial Shifter Knob while the vehicle is stationary and the brake pedal is depressed

Rotate the Rotary Dial Shifter Knob for the following:


P: Park - Press to place in Park

R: Reverse

N: Neutral

D: Drive

Refer to section 6 in the Owner's Manual for additional information on Automatic Gear Shift operation or call Kia Consumer Affairs for additional information.



QR CODE

Rotary Dial Shifter Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


Paddle Shifters

Paddle Shifters are operable when the shift lever is moved into the Drive (D) position.

Paddle Shifting: The system changes from automatic mode to manual mode when you pull the [+] or [-] paddle shifter **B** once to shift up or down one gear.

For illustrative purposes only. Your actual steering wheel and/or paddle shifters may vary.

Refer to section 6 in the Owner's Manual for more information.




See section 6 in the Owner's Manual for more information.

AWD (All-Wheel Drive) Lock*

When you select AWD Lock mode by pressing the AWD LOCK button **A**, the AWD LOCK mode increases the drive power when driving on wet pavement, snow covered roads and/or off-road.

- This mode is used for climbing or descending sharp grades, off-road driving, driving on sandy and muddy roads, etc., to improve traction
- This mode automatically shifts back to AWD AUTO mode at speed above 19 mph. If the vehicle decelerates to speeds below approximate 25 mph, however, the transfer mode is shifted into AWD LOCK mode again

When the AWD LOCK mode is deactivated, a shock may be felt as the drive power is delivered entirely to the front wheels. This shock is not a mechanical failure.



(Button on center console below gear shift)

QR CODE

All Wheel Drive System
and AWD Lock Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

See section 6 in the Owner's
Manual for more information.

Electronic Parking Brake (EPB)

The Electronic Parking Brake (EPB) system utilizes an electric motor to engage the parking brake.

Applying the Parking Brake

Depress the brake pedal and pull up the EPB switch **A**. Ensure that the indicator light is illuminated  on the instrument cluster.

Releasing the Parking Brake*

The EPB will automatically release when the brake pedal is engaged and shifter is shifted out of P (Park) to R (Reverse) or shifted out of N (Neutral) to Reverse or D (Drive).

To release EPB manually, depress the brake pedal, then press the EPB switch **A**, with the ignition switch in the ON position. Ensure that the indicator light is OFF.

QUICK TIPS

- When leaving your keys with parking lot attendants or valet, make sure to inform them how to operate the EPB
- If parked on a steep incline/decline, pull up the EPB switch for more than 3 seconds for a firmer EPB application
- Pull up and hold EPB switch a second time to increase brake pressure if parked on a decline or incline

REMINDERS:

- As a bulb check, the EPB malfunction indicator will illuminate for approximately 3 seconds when the ignition switch is turned ON
- If the warning light does not illuminate temporarily, or continues to remain lit, take your vehicle to an authorized Kia dealer and have the system checked
- The EPB should not be operated while the vehicle is moving
- A click or electric brake motor sound may be heard while operating or releasing the EPB, but these conditions are normal and indicate that the EPB is functioning properly

Auto Hold

Auto Hold temporarily maintains the vehicle at a standstill even though the brake pedal is not depressed after the driver brings the vehicle to a complete stop by depressing the brake pedal. Auto Hold can be turned On/Off using the AUTO HOLD button **B** on the center panel below the gear shift. Before Auto Hold will operate, the driver's door, engine hood and liftgate must be closed, and the driver's seat belt must be fastened.

The Auto Hold indicator on the Instrument Cluster has four states:

White: Standby - When vehicle is in Park and at a standstill, and AUTO HOLD button **B** is pressed On, the indicator will illuminate white. While driving the vehicle (vehicle is not at a standstill), the Auto Hold indicator will remain white.

Green: Engaged - When coming to a complete stop by pressing the brake pedal, the Auto Hold indicator changes from white to green.

Off (not illuminated) - The indicator will turn Off when the AUTO HOLD button **B** is manually pressed Off or when the EPB is manually turned On.

Yellow: Malfunction - When the indicator is illuminated yellow, there may be a system malfunction. Take your vehicle to a local Kia dealer.

Image is for illustrative purposes only and may not reflect actual feature or operation.

QR CODE

Electric Parking Brake /
Auto Hold Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 6 in the Owner's Manual for more information.

Refer to page 4 for location of Instrument Cluster indicators.

REMINDERS:


- Auto Hold only operates when vehicle is in Drive, Neutral or Reverse
- To reduce the risk of an accident, do not activate Auto Hold while driving downhill, backing up or parking your vehicle
- Do not solely rely on the Auto Hold system to keep the vehicle stopped. Always pay attention to traffic and road conditions, and be prepared to depress the brakes



(Button on center console below gear shift;
Button location may vary by model)

Heated Steering Wheel*

Press Heated Steering Wheel button **A** to turn the Steering Wheel Heater on/off while the Engine Start/Stop button is in the ON position. The Steering Wheel Heater will turn off automatically in 30 minutes, or when button **A** is pressed again to deactivate.



(Located below gear shift knob)


QUICK TIPS

- If ignition is turned OFF, then ON again within 30 minutes of the Steering Wheel Heater being turned ON, the system will return to its previous state
- The system returns to ON when ignition is cycled. To turn OFF system, press the Heated Steering Wheel button **A**
- With the heated steering switch in the ON position, the heating system in the steering wheel turns OFF or ON automatically depending on the steering wheel temperature

REMINDER: If the steering wheel becomes too warm, turn the system off. The heated steering wheel may cause burns even at low temperatures, especially if used for long periods of time.

Image is for illustrative purposes only and may not reflect actual feature or operation.

Seat Warmers / Ventilated Seats*†¹²



(Buttons located on top sides of center console)

B Seat Warmers

- Press the button up once for high setting (3 LEDs lit)
- Press the button twice for medium setting (2 LEDs lit)
- Press a third time for low setting (1 LED lit) and again to turn OFF

C Ventilated Seats

- Press the button down once for high setting (3 LEDs lit)
- Press twice for medium setting (2 LEDs lit)
- Press a third time for low setting (1 LED lit) and again to turn OFF

QUICK TIPS

- With the seat warmer switch in the ON position, the heating system in the seat turns OFF or ON automatically depending on the seat temperature
- System is OFF by default

REMINDER: Use extreme caution when using the seat warmers to avoid burns. Refer to the Owner's Manual for more information.

Refer to section 5 in the Owner's Manual for more information.

QR CODE

Seat Warmers and Ventilated Seats Video



Tilt/Telescoping/Heated Steering Wheel Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Rear Occupant Alert (ROA) with Ultrasonic Sensors^{†3}

Rear Occupant Alert (ROA) with Ultrasonic Sensors can help alert the driver when rear passenger(s) are left in the rear seats using the ultrasonic sensors and door monitoring. The system is designed to provide three separate alerts:

- The 1st alert is a message on the Instrument Cluster, "Check Rear Seats" **A**, and a chime will sound. After the 1st alert, when the doors are locked and there is movement detected in the rear seats, the horn will sound for about 25 seconds. This alert may activate up to eight times within 24 hours, if movement is still detected and system has not been disabled.
- If you have installed the Kia Access app on your smartphone, logged in and activated the Rear Occupant Alert notification, a third alert (notification) will be sent to your phone.

To turn the system on or off, in the Instrument Cluster or infotainment system, go to Settings, select Convenience, and then Rear Occupant Alert.

Rear Occupant with Ultrasonic Sensors activates under the following conditions:

- A rear passenger door is opened and closed
- The ignition has been turned off
- The driver's door has been opened, then closed
- The doors are locked with the Smart Key or the door lock button on the door handle

QUICK TIPS

- The 1st alert message will not display on Instrument Cluster if the rear doors are never opened. Either rear doors must be opened after unlocking the vehicle before the system will activate.
- To temporarily disable alerts, press the OK button **B** on the Steering Wheel while the message is displayed.
- To turn the alert off while sounding, press the unlock button on the Smart Key or press the door lock button on the door handle.
- Must be enrolled in Kia Connect services and Kia Access app installed on the phone to receive ROA alert notifications on your smartphone.

See section 5 in the Owner's Manual for more information.


Images are for illustrative purposes only and may not reflect actual feature or operation.

QR CODE

Rear Occupant Alert (ROA) with Ultrasonic Sensors Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos



REMINDERS:

- To avoid false alerts, make sure the vehicle's windows are rolled up.
- If objects such as boxes are stacked in front of the ultrasonic sensors, the system may not detect any movement.
- The ultrasonic sensors may occasionally detect movement in the vehicle and cause false alerts, when there are no rear occupants present. False alerts can occur due to:
 - The presence of insects near the system sensor
 - Rushing air from a window that is rolled down
 - Movement around the exterior of the vehicle
 - Surrounding noise or vibration
 - Vehicle passing through a car wash
 - Movement in the driver or front passenger seat is detected
- The Rear Occupant Alert with Ultrasonic Sensors system may fail to detect movement and activate an alarm if:
 - Movement is subtle or does not continue
 - A small child sits directly in a seat without a car seat
 - A rear passenger is covered with an object such as a blanket, obstructing the sensor's view

Rear Occupant Alert is not a substitute for one's attention and may not detect all movement within the vehicle. Always check the vehicle's interior before exiting.


Front Seat Headrest Adjustment^{†‡}

Up/down adjustment:


- To raise the headrest, pull headrest up **A** to the desired position
- To lower the headrest, press the button **B**, then press the headrest down **C**

Forward/backward adjustment*:

- Pull the headrest forward/backward **D** to one of three positions
- When forward, to move the headrest to the furthest backward position, pull it fully forward then release



(Type A)



(Type A)

QUICK TIP

For easy adjustments, hold a headrest post with one hand while using the other hand to pull the headrest from underneath.

REMINDERS:

- The headrest only moves up and down as described above. It does not adjust forward or backward
- Do not operate the vehicle with the headrests removed. Headrests can provide critical neck and head support in an accident


Refer to section 4 in the Owner's Manual for more information.

Driver Position Memory System^{*†‡}

The integrated system stores into memory the position of the Driver's Seat and the Outside Rearview Mirrors.

To store positions into memory, first place the Gear Shift into P (Park) while the Engine Start/Stop button is in the ON position. Then:

- Adjust the Driver's Seat and the Outside Mirrors
- Press the SET button **E** on the control panel. System will beep once
- Press one of the memory buttons **F** within 5 seconds. The system will beep twice when memory has been stored



(Buttons located on Driver's Door Panel)

REMINDER: Do not attempt to operate the driver position memory system while the vehicle is moving. This could result in loss of control of the vehicle.

Refer to section 5 in the Owner's Manual for more information.

QR CODE


Power Adjustable Driver's Seat with Memory Settings Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Power Adjustable Driver's Seat^{†12} / Power Lumbar^{†12}

Move/Press the controls to adjust the Seat forward/backward, the Seat Cushion height, the Seatback recline, the Lumbar forward/backward or the Seat Cushion Extension*.



REMINDER: Do not attempt to adjust the seat while the vehicle is moving. This could result in loss of control of the vehicle.

Images are for illustrative purposes only and may not reflect actual feature or operation. Your seat controls may differ from those in the illustrations.

Do not attempt to adjust the seat while the vehicle is moving. This could result in loss of control of the vehicle.

Refer to section 4 in the Owner's Manual for more information.

2nd-Row Folding Seat^{†12}


Folding 2nd-Row Seat

Lower the 2nd-Row Seat Headrest to the lowest position.

Pull up on the Seatback folding lever **E** or strap* and fold the Seatback down.

Unfolding 2nd-Row Seat

Lift the folding Seatback lever **E** and move the Seatback backward to the desired position **F**.



QUICK TIPS

- When you return the Seatback to its original position, ensure it locks (clicks) into place
- It may be necessary to slide the front Seat forward and adjust the front Seatbacks to fully lower rear seats
- Lower Rear Headrests to the lowest position

REMINDER: The lever must return to its original position for the Seatback to lock.

Refer to section 4 in the Owner's Manual for more information.

QR CODE

Power Adjustable Driver's Seat with Memory Settings Video



2nd-Row Seats Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

2nd-Row Auto-Folding Seat^{*†12}

Press buttons **A** to release and automatically fold 2nd-Row Seatback down.

For more information on 2nd-Row Auto Folding Seat operation, refer to the Owner's Manual.




(Located on rear quarter-trim panels)

Refer to section 4 in the Owner's Manual for more information.

Unfastening Center Seat Belt^{†13}

1. If Seat Belt is buckled, press the release button on the buckle
2. To retract the 2nd-Row Center Seatbelt **B** into the headliner, press the "release button" on the buckle by inserting the seat belt tongue plate **C** in the small slot on the center buckle **D**



Refer to section 4 in the Owner's Manual for more information.

QR CODE

2nd-Row Seats Video



Unfastening Center Seatbelt Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


One-Touch Slide & Fold 2nd-Row Seats^{†‡}

To get in and out of the 3rd Row Seat, adjust the 2nd Row Seat by pressing the One-Touch Slide & Fold 2nd Row Seats (located on top **A** and side **B** of the 2nd-row seatback):

1. Set the front seatback to the most upright position, and slide the seat forward, if needed
2. Lower the 2nd Row Seat Headrest to the lowest position
3. Insert the seatbelt buckle into the pocket between the rear seatback and the cushion
4. Press the One-Touch Slide & Fold buttons to slide the Seat forward

QUICK TIPS

The strap can be used in the back of the 2nd Row Seat to slide and fold the 2nd Row Seats.



REMINDER: Do not use the One-Touch Slide & Fold buttons while the 2nd-row passenger seat is occupied.

QR CODE

One-Touch Slide & Fold
2nd-Row Seats Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


Refer to section 4 in the Owner's Manual for more information.

3rd-Row Folding Seat^{*†‡}

Folding 3rd-Row Seat


1. Fully lower the headrest **C**
2. Pull the Seat folding strap **D** located on the Seatback
3. Fold the Seat down

Refer to section 4 in the Owner's Manual for more information.



Sun Visor^{†16}

Use the Sun Visor to shield from direct light through the front or side windows. Slide or swing the Sun Visor out and adjust as needed.



REMINDERS:


- Sun Visor may not shield from all direct light
- The Sun Visor may impair visibility if not adjusted properly
- Do not operate the vehicle if the Sun Visor is impairing your visibility
- Be aware of the seating position when adjusting or swinging Sun Visor around to and from the front or side windows

Refer to section 5 in the Owner's Manual for more information.

Double-Turn Lock/Unlock All

- Turn clockwise once to unlock the Driver's Door
- Turn clockwise again within 4 seconds to unlock All Doors
- Turn counterclockwise once to lock All Doors

Refer to section 5 in the Owner's Manual for more information.



Smart Key with Remote Start^{†6}

- A** Press to lock All Doors
- B** Press to unlock the Driver's Door. Press twice within 4 seconds to unlock All Doors and the Liftgate
- C Manual Liftgate***: Press and hold for more than 1 second to unlock the Liftgate. Then lift by the handle to manually open the Liftgate

REMINDERS:

- The Liftgate does not automatically open when the **C** button is pressed
- The Liftgate unlocks when the Smart Key fob is within close proximity of the vehicle

Power Liftgate*: Press and hold for the Power Liftgate to open automatically.

Press again at any time to stop. Press and hold again to automatically close

- D Remote Start***: Lock the doors by pressing the door lock button **A** within 32 feet distance from the vehicle. Within four (4) seconds of pressing the door lock button **A**, press and hold the Remote Start button **D** for more than two (2) seconds to start the vehicle. To stop the Remote Start operation, press the button again. If driver does enter vehicle within ten minutes of starting the vehicle, the engine will automatically turn off

- E** Press and hold for more than a half second for the Panic Alarm.

To turn off the Alarm, press any button

- F** Press to release Mechanical Key


- G Mechanical Key**

Driver's Door Lock/Unlock button **H**:



- Press button once to unlock the Driver's Door
- Press again within 4 seconds to unlock all doors
- Press again to lock all doors

Mechanical Key **G**:

- Press the button **F** on the back of the key fob to release the Mechanical Key
- Remove the key cover, using the mechanical key
- Use to lock/unlock the Driver's Door **I**
- Use to lock the glove box



Remote button configuration may vary depending on vehicle options.



QUICK TIPS

- The Smart Key's signal can be blocked by the normal operation of a cellular phone or smartphone. To help prevent this, store each device separately
- If the Smart Key battery is weak or not working properly, hold the Smart Key fob up to the Engine Start/Stop button (Lock button side closest) and press to start the engine

QR CODE

Remote Start - Smart Key Video



Kia Smart & Folding Key Fobs Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Remote button configuration may vary depending on vehicle options.

Refer to section 5 in the Owner's Manual for more information.

REMINDER: When reinserting the mechanical key, make sure it is pushed all the way in until there is a click sound.

Smart Power Liftgate^{†10}

Opening from Inside the Vehicle:

Press and hold the Smart Power Liftgate Open/Close button **A** to automatically open/close the Liftgate.

Smart Key:

To open the Smart Power Liftgate, press and hold the Liftgate button **B** until the Liftgate begins to open. Press and hold again to automatically close.

REMINDER: Pulling the Liftgate upward by the handle or pressing the button a second time will interrupt the automatic opening of the Power Liftgate.

Opening from Outside the Vehicle:

To open the Smart Power Liftgate automatically, press the Rear Hatch Release button **C** on the exterior of the Liftgate.

Automatically close by pressing the Power Liftgate Close button **D**.

Power Liftgate Opening Height Adjustment




The height setting of a fully opened liftgate (tailgate) can be adjusted by the following steps:

1. Position the liftgate manually to the preferred height
2. Press the Smart Power Liftgate Close button **D** more than 3 seconds
3. A system beep will sound twice indicating the height setting has been saved

The liftgate will then open to the set height. To change setting again, repeat steps 1-3.

REMINDER: When closing, be mindful of any objects or persons.

See section 5 in the Owner's Manual for more information.



QR CODE

Smart Liftgate Operation,
Opening Height/Speed
Adjustment Video



Kia Smart & Folding Key Fobs Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Smart Power Liftgate^{†10} (continued)

The Smart Power Liftgate with Auto Open can be operated from several controls to either open, close or lock the Liftgate. The Smart Power Liftgate will close the Liftgate, lock all doors and Liftgate and then arm the vehicle.

When the Smart Key fob is on your person and you are near the back of the vehicle, within close proximity, the hazard lights will blink and a chime will sound for about 3 seconds as an alert that the Smart Power Liftgate is about to open. Then the alert system will blink and chime two additional times before opening the Smart Power Liftgate.


The Smart Power Liftgate feature is off by default. To enable the Smart Power Liftgate, go to User Settings mode in the LCD Instrument Cluster or the Vehicle Settings* in the Infotainment System.

QUICK TIPS

- During the Smart Liftgate open alert, the Smart Liftgate can be deactivated with the Smart Key by pressing any button on the key fob or moving away from the detection area
- The open height and speed can be adjusted. For information on how to set the open height and speed, see your owner's manual

REMINDERS:

- All doors are closed and locked after about 15 seconds
- The Smart Power Liftgate feature will not operate when:
 - The doors are recently closed and locked, and the Smart Key is still detected after 15 seconds near the vehicle or within 60 inches of the door handles
 - A door is not locked or closed
 - The Smart Key is in the vehicle
- Press any button on the Smart Key fob during the Detect and Alert stage, or move out of the detection area, to deactivate the Smart Power Liftgate function
- When the ignition is on, the Smart Power Liftgate will only operate with the gear shift in the Park (P) position
- The Smart Key must be outside of the vehicle for the Smart Liftgate with Auto Open to operate
- Ensure obstacles and people are out of the way of the Liftgate
- When closing, be mindful of any objects or persons



QR CODE

Smart Liftgate Operation,
Opening Height/Speed
Adjustment Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

See section 5 in the Owner's
Manual for more information.

Map/Room Lamps

Automatic turn off function*

The interior lights automatically turn off approximately 30 seconds after the Engine Start/Stop button is OFF.

Map/Room Lamp Operation

- Press lens **A** to turn the Driver's/Passenger's Map Lamps ON/OFF. This light produces a spot beam for convenient use as a map lamp or as a personal lamp for the driver or the front passenger.
- Press button **B** to turn all the Map/Room Lamps ON/OFF
- Press button **C** to turn the Map/Room Lamp ON, for 30 seconds, when a door is opened, unlocked from Smart Key or the ignition is turned OFF. When pressed and a door is opened, or doors are unlocked from the Smart Key, the Map and Room Lamps turn ON for approximately 30 seconds.
- Press button **D** to turn the Room Lamp ON/OFF

QUICK TIPS

- When doors are unlocked by the Smart Key*, the lamp turns ON for approximately 30 seconds
- If your vehicle is equipped with the theft alarm system, the interior lights automatically turn off approximately 5 seconds after the system is in the armed stage
- Using interior lights for an extended period of time may cause battery discharge

See section 5 in the Owner's Manual for more information.

Panoramic Sunroof with Power Sunshade*

The Sunroof and Sunshade operation is controlled through a multidirectional switch **E**. The ignition needs to be ON to operate the sunroof / power sunshade.

QUICK TIP

To stop the Sunroof/Sunshade at any position, push or pull the Sunroof control switch in any direction.

REMINDER: The sunroof can be operated for approximately 30 seconds after the ignition is turned off. If the front doors are opened, the sunroof cannot be operated even within the 30-second period.

To slide the power sunshade and sunroof:

- Auto Open - Push the switch **E** backward to the second detent position and release
- Auto Close - Push the switch **E** forward to the second detent position and release

To slide the power sunshade only:


- Auto Open - Push the switch **E** backward to the first detent position and release.
- Auto Close - Push the switch **E** forward to the first detent position and release.

Slide the sunroof (with sunshade open):


- Auto Open - Push the switch **E** backward to the first detent position and release.
- Auto Close - Push the switch **E** forward to the first detent position and release to close sunroof glass only. Push the switch **E** forward to the second detent position and release to close sunroof glass and power sunshade.

To tilt the sunroof:

- Raise: Push and release switch **E** upward
- Lower: Push and release switch **E** upward
- Auto-close sunroof and power sunshade: Push the switch **E** forward to the second detent position



(Front overhead console. Buttons may vary)



(Center of cabin)

QR CODE

Sunroof Operation Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

See section 5 in the Owner's Manual for more information.


REMINDERS:

- The Sunshade needs to remain OPEN while sunroof is open
- Do not adjust the sunroof or sunshade while driving. This could result in loss of control of the vehicle
- When closing, be mindful of any objects or persons
- If the ignition/vehicle is turned off, and the driver's door is opened, with the sunroof not fully closed, the Instrument Cluster LCD will display a warning message and a chime will sound for a few seconds

HomeLink®^{†2} with Auto-Dimming Rearview Mirror*

The HomeLink® / Auto-Dimming Rearview Mirror* is designed to reduce glare from a vehicle's headlights located in the rear and also connect up to three electronic transmitters into one location.

- | | |
|---|---|
| A HomeLink® Channel 1 | E HomeLink® Operation Indicator |
| B HomeLink® Channel 2 | F Garage Door Opener Status Indicator: Opening or Open |
| C HomeLink® Channel 3 | G HomeLink® User Interface Indicator |
| D Garage Door Opener Status Indicator: Closing or Closed | |



QUICK TIPS

- You can reprogram a single HomeLink® button by repeating Step 2
- Erasing the programmed buttons will delete all trained transmitters

How to Sync Transmitter with HomeLink®*

If programming for the first time, begin with Step 1 (repeating this step will delete all information).

To program non-rolling and rolling code garage door openers and other devices:

1. Press and hold the left **A** and **C** buttons simultaneously until the indicator light **G** begins to flash (to reprogram buttons, skip this step)
2. Press and hold the desired button **A** **B** or **C** and hold the button on the transmitter while it is approximately 1 to 3 inches away from the mirror. The HomeLink® Indicator light **E** will flash rapidly once the frequency signal has been successfully programmed

To finish programming rolling code garage door openers, complete these steps:

3. Locate the "learn" or "smart" button on the garage door's motor head unit. Press and release the button and complete Step 4 within 30 seconds
4. Firmly press and release the programmed HomeLink® button up to three times

Operating HomeLink®:

Press one of the programmed HomeLink® buttons.

Erasing programmed buttons:

Press and hold the **A** and **C** buttons simultaneously for approximately 20 seconds, and then release both buttons within 30 seconds.

If your garage door opener was manufactured in 2011 or later, and you're unable to program your vehicle's HomeLink® system, you may need to purchase a HomeLink Repeater Kit. For more information, go to www.HomeLink.com or call (800) 355-3515.

QR CODE

Homelink® Support Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


OTHER KEY FEATURES

Hood Release Lever and Latch


Opening the Hood:

1. Pull the Hood Release Lever **A** to unlatch the Hood
2. In the front of the vehicle, lift the Hood slightly, push the secondary Latch **B** to the left inside of the Hood's center and lift the Hood
3. It will open by itself after it has been raised about half way

REMINDER: Open the Hood only after turning the engine off, on a flat surface, with the gear shift in P (Park) position and setting the parking brake.



(Lever located near floor below
Driver's Panel)



(Latch located inside hood)

Closing the Hood:


Lower the Hood about halfway and then press down to securely lock in place.

Images are for illustrative purposes only and may not reflect actual feature or operation.

See section 5 in the Owner's Manual for more information.

Fuel Cap / Malfunction Indicator (Check Engine Light)

Ensure the Fuel Cap is securely tightened (one-click on the Plug-In Hybrid) to prevent the Check Engine light / Malfunction Indicator from illuminating.




See section 4 in the Owner's
Manual for more information.

Images are for illustrative purposes only and may not reflect actual feature or operation.

Fuel Filler Lid Release

To open the Fuel Filler lid:

1. **Hybrid** - Press the right center edge of the Fuel Filler lid **C**
Plug-In Hybrid - Press the Fuel Filler Lid Release button **D**, located on Driver's Panel, left of Steering Wheel
2. Pull the Fuel Filler lid out to fully open and place the Fuel Cap in the holder **E**
3. To open the Fuel Cap, turn it counterclockwise **F**



(Button located on Driver's Panel, left of
Steering Wheel - Hybrid only)

REMINDERS:

- **Hybrid:** The Fuel Filler Lid lock will unlock/open only when the unlock button on the Smart Key is pressed, central door unlock button is pressed or the driver's side door is unlocked
- To lock the Fuel Filler Lid, press the lock button on the Smart Key or lock central door lock button
- All doors and Fuel Filler Lid will automatically lock after the vehicle speed exceeds 9 mph

QR CODE

Kia Fuel Cap Video



Fuel Filler Lid Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

Occupant Detection System (ODS)^{†9} / Passenger Airbag^{†13} Off Indicator

ODS is designed to detect the presence and position of the front passenger and adjusts or turns off airbag deployment accordingly.


Depending on the situation and type of accident, the system may:

- Deploy airbag (Adult)
- Not deploy the airbag (Unoccupied)

If the system determines that the airbag should not be deployed, the "PASSENGER AIR BAG OFF" light will illuminate.

REMINDER: Do not allow an adult passenger to ride in the front seat when the Passenger Airbag Indicator is illuminated OFF because the airbag will not deploy in the event of a crash. The driver must instruct the passenger to reposition her/himself in the seat.

See section 4 in the Owner's Manual for more information.




(ODS light is located on map/room lamp ceiling console)

Child-Protector Rear Door Locks*

Located on the rear edge of the rear passenger doors. Use the mechanical ignition key to the Child-Protector Rear Door Lock to the lock position  to disable the inner door handles from opening the rear doors.

REMINDER: Child-Protector Rear Door Locks are located on the rear passenger's door jamb.

See section 5 in the Owner's Manual for more information.



(Lock located on rear passenger inside door jamb)

Seat Belts^{†13}

To properly fasten your seat belts:

1. Insert the belt tongue plate **A** into the buckle **B** until it clicks
2. Position the lap portion of the belt across your lap as LOW ON THE HIPS as possible **C**.
Adjust the belt to a SNUG FIT by pulling up on the shoulder portion **D**

Seat Belt Retractor Locks



Retractor locks allow lap/shoulder safety belts to remain unlocked during normal vehicle operation for freedom of movement and increased comfort.

During a STRONG STOP, SUDDEN TURN OR CERTAIN COLLISIONS, seatbelt retractors will automatically lock the belts to reduce the risk of injury.

QUICK TIP

The seat belt warning chime operates for the driver's seat only.

REMINDER: For maximum protection, always wear your seat belt.



QR CODE

Latch Anchors for the Child Restraint System Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

LEGAL DISCLAIMERS

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury or death. The driver's primary responsibility is in the safe and legal operation of a vehicle. Handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law, should never be used during operation of the vehicle.

Safety Features: No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive safely.

1. Kia Connect: Purchase/lease of certain 2022 and newer Kia vehicles with Kia Connect includes a complimentary 1-year subscription starting from new vehicle retail sale/lease date as recorded by the dealer. After your complimentary 1-year Kia Connect subscription expires, continued access to the full suite of Kia Connect services available on your Kia will require a paid subscription at the then-current subscription rate or your use of certain Kia Connect features may immediately terminate. Use of Kia Connect is subject to agreement to the Kia Connect Privacy Policy (available at owners.kia.com/us/en/privacy-policy.html) and Terms of Service (available at owners.kia.com/us/en/terms-of-service.html). Complimentary Kia Connect subscription is transferable to subsequent owner during the original Kia Connect service term. Only use Kia Connect when safe to do so. Kia Connect may currently be unavailable for Model Year 2022 and newer vehicles sold or purchased in Massachusetts; please see the Kia Owners Portal for updates on availability. Kia Access app is available from the Apple® App Store® or Google Play Store®. Kia America, Inc. reserves the right to change or discontinue Kia Connect at any time without prior notification or incurring any future obligation. Message and data rates may apply. Cellular and GPS coverage is required to use most features. Kia Connect features may vary by model, model year, and trim level. Features, specifications, and fees are subject to change. For more on details and limitations, visit www.kia.com or your authorized Kia dealer. Apple® and App Store® are registered trademarks of Apple Inc. Google® and its logos are trademarks of Google LLC.

2. Android Auto™, Apple CarPlay®, Bluetooth® Wireless Technology, Google Play™ Store, iPhone®, SiriusXM®, Sportmatic®, HomeLink®: Fair Use of Trademark - The commentary reference to trademarked material is for educational purposes only and not an endorsement by or of the holder of the mark.

3. Driver Assist Features - Forward Collision-Avoidance Assist (FCA), Lane Keeping Assist (LKA), Blind-spot Collision-Avoidance Assist (BCA), Blind-spot View Monitor (BVM), Safe Exit Assist (SEA), Leading Vehicle Departure Alert (LVDA), Intelligent Speed Limit Assist (ISLA), Navigation-based Smart Cruise Control (NSCC), Lane Following Assist (LFA), Highway Driving Assist (HDA), Rear View Monitor (RVM), Surround View Monitor (SVM), Rear Cross-traffic Collision Avoidance Assist (RCCA), Reverse Parking Collision-Avoidance Assist (PCA), Forward/Reverse Parking Distance Warning (PDW), Rear Occupant Alert (ROA) with Ultrasonic Sensors: These features are not substitutes for safe driving, and may not detect all objects surrounding vehicle. Always drive safely and use caution.

4. Driver Attention Warning (DAW): Driver Attention Warning is not a substitute for safe driving and may not detect all instances of inattentive driving practices. Failure to pay attention to travel conditions and vehicle operation could result in loss of vehicle control. Always drive safely and use caution.

5. Electronic Stability Control (ESC) / Traction Control System (TCS) / Hill-start Assist Control (HAC): No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive safely.

6. Engine Start/Stop Button / Smart Key with Remote Start: Always come to a complete stop before turning the engine on or off. However, if you have an emergency while the vehicle is in motion and must turn the engine off, you can turn the engine off to the ACC position by pressing the Start/Stop button for more than 3 seconds or 3 times in succession. If the vehicle is still moving, you can restart the engine by pressing the Start/Stop button with the shift lever in Neutral (N). With the engine off, hydraulic power assist for steering and braking will be disabled and the vehicle will be more difficult to control.

7. Front Seat Headrest Adjustment: Never attempt to adjust headrests when vehicle is in motion.

8. Navigation: Distracted driving can result in a loss of vehicle control. When operating a vehicle, never use a vehicle system that takes your focus away from safe vehicle operation. Navigation is for information purposes only, and Kia does not make any warranties about the accuracy of the information.

9. Occupant Detection System (ODS): Kia vehicles use a number of different ODS types that vary by model. Children age 12 and under should always be seated in the REAR seats. ODS is not a substitute for one's attention and may not detect all occupants within the vehicle. Always check the vehicle interior when exiting the vehicle.

10. Power Liftgate / Smart Power Liftgate: Driving with the liftgate open may be unlawful and can draw dangerous exhaust fumes into your vehicle; if you choose to do so, keep air vents and all windows open for proper ventilation.

11. Roadside Assist: 24-hour Enhanced Roadside Assistance is a service plan provided by Kia America, Inc. Certain limitations apply. Coverage details are available in the Kia Warranty and Consumer Information Manual. For access to Enhanced Roadside Assistance*, a connected mobile phone via Bluetooth® within the cellular service coverage area is required.

12. Seat adjustments: Reclining the passenger seats can reduce the effectiveness of the safety restraint system and may lead to additional injury in an accident.

13. Seat belts/airbags: For maximum protection, always wear your seatbelt.

14. SiriusXM®: SiriusXM Satellite Radio, SiriusXM Traffic and SiriusXM Travel Link each require a subscription sold separately, or as a package, by SiriusXM Radio Inc. If you decide to continue your service at the end of your trial subscription, the plan you choose will automatically renew and bill at then-current rates until you call 1-866-635-2349 to cancel. See SiriusXM Customer Agreement for complete terms at www.siriusxm.com. Other fees and taxes will apply. All fees and programming are subject to change. Not all vehicles or devices are capable of receiving all services offered by SiriusXM. Data displays and individual product availability vary by vehicle hardware. Current information and features may not be available in all locations, or on all receivers. Weather Forecast, Current Conditions may not be available in all locations. Images above are for representational purposes only and are not real products. For actual features and images of real products, consult the vehicle manufacturer. SiriusXM is not responsible for any errors or inaccuracies in the data services or their use in the vehicle. Travel Link Stocks displays current price and daily delta of around 7,000 actively reported securities traded on the NYSE®, NASDAQ® and AMEX®. The service is delayed approximately 20 minutes. SiriusXM satellite service is available only to those at least 18 years of age in the 48 contiguous USA, DC, and Puerto Rico (with coverage limitations). SiriusXM Internet Radio service is available throughout our satellite service area and in AK and HI. © 2022 SiriusXM Radio Inc. Sirius, XM and all related marks and logos are trademarks of SiriusXM Radio Inc.

15. Steering-wheel-mounted controls: Driving while distracted is dangerous and should be avoided. Remain attentive to driving and be cautious when using steering-wheel-mounted controls while driving.

16. Sun Visors: Sun Visor may not shield all direct light. Do not operate the vehicle if sun visor is impairing your visibility.

17. Tilt/Telescoping Steering Wheel: Never attempt to adjust steering wheel position when vehicle is in motion.

18. Tire Pressure Monitoring System (TPMS): Even with Tire Pressure Monitoring System, check tire pressure on a regular basis.

19. The myQ logo is a registered trademark of The Chamberlain Group, Inc.



SORENTO HYBRID/PLUG-IN HYBRID NORMAL MAINTENANCE SCHEDULE

(up to 64,000 miles)^a

MAINTENANCE ITEMS	MAINTENANCE INTERVALS (MILES)							
	8,000	16,000	24,000	32,000	40,000	48,000	56,000	64,000
Add fuel additive ^c	P	P	P	P	P	P	P	P
Rotate tires	P	P	P	P	P	P	P	P
Engine Oil & Oil Filter (Full Synthetic Oil)	R	R	R	R	R	R	R	R
Climate control air filter	I	R	I	R	I	R	I	R
Air cleaner filter (engine)	I	I	R	I	I	R	I	I
Brake fluid	I	I	I	I	I	R	I	I
HSG (Hybrid starter and generator) belt ^f	I	I	I	I	I	I	I	R
Battery condition	I	I	I	I	I	I	I	I
Brake lines, hoses and connections	I	I	I	I	I	I	I	I
Brake discs and pads	I	I	I	I	I	I	I	I
Steering gear rack, linkage & boots	I	I	I	I	I	I	I	I
Suspension ball joints	I	I	I	I	I	I	I	I
Air conditioner compressor/refrigerant	I	I	I	I	I	I	I	I
Exhaust system	I	I	I	I	I	I	I	I
Cooling System	I	I	I	I	I	I	I	I
Intercooler, in/out hose, air intake hose	I		I		I		I	
Fuel lines, hoses and connections		I		I		I		I
Propeller Shaft (AWD)		I		I		I		I
Driveshaft and boots		I		I		I		I
Fuel tank air filter/fuel tank, and fuel caps ^{†D}		I		I		I		I
Rear Differential / Transfer case oil (AWD) ^E					I			
Spark Plugs (Every 48,000 miles)						R		

P=Perform R=Replace I=Inspect^b

QUICK TIP

Check your Maintenance Schedule or schedule an appointment with a dealer using your Kia Connect account by logging into your Kia Access App or your account on <https://owners.kia.com>

^a If equipped[†] LEGAL DISCLAIMERS ON BACK INSIDE COVER

- A. See the Owner's Manual for complete maintenance schedule. These are approximate estimated intervals. Refer to vehicle mileage for maintenance item schedule.
- B. And, if necessary, adjust, correct, clean or replace.
- C. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.
- D. Both the fuel filter & fuel tank air filter are generally considered to be maintenance free, depending on fuel quality being used. However, periodic inspection is recommended. If your vehicle is having issues like fuel flow restriction, power

surging, loss of power, difficulty starting, etc., replace the fuel filter immediately and consult an authorized Kia dealer for service.

E. Transfer case oil and rear differential oil should be changed anytime they have been submerged in water.

F. Inspect HSG belt for evidence of cuts, cracks, excessive wear or oil saturation and replace if necessary

See your Owner's Manual for more details and complete maintenance information, including severe maintenance schedule. Warranty may be voided if maintenance schedule is not followed.

QR CODES

Kia Full Synthetic Oil Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

© 2022 Kia America, Inc.
All rights reserved.

Consumer - Roadside Assistance^{††}:
1-800-333-4KIA (4542)

Part Number: MQHEV230-PS-004