

AquaFlow AF-200 Submersible Pump

User Manual & Technical Reference

This manual covers installation, operation, maintenance, troubleshooting, and warranty terms for the AquaFlow AF-200 submersible water pump.

1. Warranty Information

The AquaFlow AF-200 is covered by a limited warranty period of 12 months from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover damage caused by improper installation, unauthorized repairs, or use with fluids other than clean fresh water. To make a warranty claim, contact AquaFlow customer support with your original purchase receipt and the product serial number.

Extended warranty coverage of up to 36 months is available for purchase separately within 90 days of the original purchase date.

2. Installation Instructions

2.1 Site Preparation

Select a mounting location with a firm, level base. The pump must be fully submerged in water at all times during operation. Never run the pump dry, as this will damage the internal seals within seconds.

2.2 Electrical Connection

The AF-200 requires a dedicated 230V AC, 50Hz power supply protected by a residual current device (RCD) rated at 30mA or less. Do not connect the pump to an extension cord rated below 10 amps.

2.3 Priming and First Start

Lower the pump slowly into the water, allowing air to escape from the intake housing. Once fully submerged, connect the power supply. The pump will begin operating automatically when the integrated float switch rises above the low-water cutoff level.

3. Maintenance Schedule

Regular maintenance extends the service life of the AF-200 and keeps it operating at peak efficiency.

Interval	Task
Weekly	Inspect intake screen for debris and clean if blocked
Monthly	Check power cable and plug for wear or damage
Every 6 months	Remove pump and inspect impeller for wear
Annually	Replace shaft seal regardless of visible wear

Never use abrasive cleaners on the pump housing. Use only a soft cloth with mild soap and clean water for exterior cleaning.

4. Troubleshooting

4.1 Pump Does Not Start

Check that the float switch moves freely and is not obstructed. Confirm the power supply is active and the RCD has not tripped. If the motor hums but does not turn, the impeller may be jammed with debris.

4.2 Reduced Water Flow

A partially blocked intake screen is the most common cause of reduced flow. Low voltage supply or a worn impeller can also cause this symptom. Clean the intake screen first before investigating further.

4.3 Unusual Noise or Vibration

Grinding or rattling noises usually indicate a damaged impeller or debris caught inside the pump housing. Disconnect power immediately and inspect the impeller chamber.

5. Technical Specifications

Specification	Value
Model	AquaFlow AF-200
Max flow rate	200 liters per minute
Max head height	8 meters
Power rating	750 watts
Voltage	230V AC, 50Hz
Cable length	10 meters
Max water temperature	35 degrees Celsius
Housing material	Stainless steel and reinforced polymer
Weight	6.2 kg

6. Safety Precautions

Always disconnect power before performing any maintenance or inspection. Do not touch the pump, power cable, or plug with wet hands. This product is not intended for use in swimming pools or with flammable liquids.

Keep the pump out of reach of children. The AF-200 is not designed to be operated by persons with reduced physical or sensory capabilities without supervision.