

SkyBrew Coffee Maker

Model SB-450 — User Manual

1. Introduction

Thank you for purchasing the SkyBrew SB-450 automatic coffee maker. This manual explains how to set up, operate, and maintain your device safely. Please read all instructions carefully before first use. The SB-450 supports drip brewing, a programmable timer, and a built-in grinder for whole bean coffee.

2. Safety Precautions

Do not immerse the power cord, plug, or base unit in water or any other liquid. Always unplug the unit before cleaning or when not in use for an extended period. Keep the appliance out of reach of children. Do not operate the coffee maker if the power cord or plug is damaged, or after the appliance malfunctions.

3. Setup Instructions

Remove all packaging material and stickers from the coffee maker. Rinse the removable water reservoir and carafe with warm water before first use. Place the unit on a flat, dry, heat-resistant surface at least 6 inches away from the wall.

3.1 Filling the Water Reservoir

Open the reservoir lid on the back of the unit. Fill with fresh, cold water up to the desired line, not exceeding the MAX marking of 12 cups. Close the lid firmly before brewing.

3.2 Loading Coffee Beans or Grounds

For whole beans, open the bean hopper and add up to 90 grams of beans. For pre-ground coffee, remove the hopper insert and add 1 tablespoon of grounds per cup directly into the filter basket.

4. Technical Specifications

Specification	Value
Model	SB-450
Power	1000W, 120V AC
Water Capacity	1.8 Liters (12 cups)
Bean Hopper Capacity	90 grams
Dimensions (W x D x H)	22cm x 30cm x 38cm
Weight	3.4 kg
Warranty Period	24 months

5. Warranty Information

SkyBrew warrants this product against defects in materials and workmanship for a period of 24 months from the date of purchase. This warranty covers manufacturing defects only. Coverage does not extend to damage caused by unauthorized repairs, misuse, or normal wear and tear such as descaling deposits. To make a warranty claim, contact SkyBrew customer support with your proof of purchase.

6. Troubleshooting

6.1 Coffee Maker Will Not Turn On

Check that the unit is plugged into a working outlet. Ensure the power switch on the base is set to ON. If the unit still does not power on, contact customer support.

6.2 Coffee Tastes Weak or Bitter

Weak coffee is often caused by using too little coffee or grounds that are too coarse. Bitter coffee can result from over-extraction; try a coarser grind setting or reduce brew strength using the STRENGTH dial on the control panel.

6.3 Descaling

Descale the SB-450 every 60 brew cycles using a 1:3 mixture of white vinegar and water, or a commercial descaling solution. Run one full brew cycle with the solution, followed by two full cycles of plain water to rinse.