

Document Title	Specification of Vehicle-2-X Geo Networking
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	793

Document Status	published
Part of AUTOSAR Standard	Classic Platform
Part of Standard Release	R24-11

Document Change History			
Date	Release	Changed by	Description
2024-11-27	R24-11	AUTOSAR Release Management	Adaptation to new lower interface through L-SDU router
2023-11-23	R23-11	AUTOSAR Release Management	Removal of Tx confirmation and transaction ID
2022-11-24	R22-11	AUTOSAR Release Management	Editorial changes to reflect the introduction of V2xDM
2021-11-25	R21-11	AUTOSAR Release Management	 Correction in V2xGn_TxConfirmation prototype Scrubbing and editorial Changes
2020-11-30	R20-11	AUTOSAR Release Management	Editorial Changes
		AUTOSAR	Added support for C2CCC BSP 1.3
2019-11-28	R19-11	Release Management	Changed Document Status from Final to published
			Update ETSI EN 302 636-4-1 v1.3.1
2018-10-31	4.4.0	AUTOSAR Release Management	Corrections on init and configurationCorrections in Tx and Rx flows
			Editorial Changes

 ∇



\triangle

2017-12-08	4.3.1	AUTOSAR Release Management	Editorial Changes
2016-11-30	4.3.0	AUTOSAR Release Management	• Initial Release



Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.



Contents

1	Introduction and functional overview	7
	1.1 Architectural overview	
2	Acronyms and Abbreviations	9
3	Related documentation	10
	3.1 Input documents & related standards and norms	
4	Constraints and assumptions	12
	 4.1 Limitations 4.2 Applicability to car domains 4.3 Authorisation Tickets and Pseudonyms 	12
5	Dependencies to other modules	13
	5.1 AUTOSAR DET (Default Error Tracer) 5.2 AUTOSAR EcuM (Ecu State Manager) 5.3 AUTOSAR Ethernet Interface (EthIf) 5.4 AUTOSAR Linklayer Sdu Routing Module (LSduR) 5.5 AUTOSAR Vehicle-2-X Basic Transport Protocol (V2xBtp) 5.6 AUTOSAR Vehicle-2-X Management (V2xM) 5.7 File structure 5.7.1 Code file structure	13 13 13 13 13 14
6	Requirements Tracing	15
7	Functional specification	16
	7.1 General Functionality 7.2 GeoNetworking Packet Structure and Format 7.3 GeoNetworking Protocol Operations 7.3.1 Network Management 7.3.2 Security Mechanisms 7.4 Message Forwarding 7.5 Message Transmission 7.6 Message Reception 7.7 State handling of PDUs 7.8 Error Classification 7.8.1 Development Errors 7.8.2 Runtime Errors 7.8.3 Production Errors 7.8.4 Extended Production Errors	16 17 17 17 18 19 23 24 25 25 26 26
8	API specification	27
	8.1 Imported types	27



	8.2	Type defi	initions	28
		8.2.1	V2xGn_TxParamsType	
	8.3	Function	definitions	
		8.3.1	V2xGn_Init	
		8.3.2	V2xGn_GetVersionInfo	
		8.3.3	V2xGn_V2xM_PreparePseudonymChange	
		8.3.4	V2xGn_V2xM_CommitPseudonymChange	
		8.3.5	V2xGn_V2xM_AbortPseudonymChange	
		8.3.6	V2xGn_Transmit	
	8.4		notifications	
		8.4.1	V2xGn_V2xM_EncapConfirmation	
		8.4.2	V2xGn_V2xM_DecapConfirmation	
		8.4.3	V2xGn_RxIndication	
		8.4.4	V2xGn_TxConfirmation	
	8.5		ed functions	
		8.5.1	V2xGn_MainFunction	
	8.6	•	d interfaces	
		8.6.1	Mandatory Interfaces	
		8.6.2	Optional Interfaces	39
9	Sequ	ience diagi	rams	41
	9.1	V2xGn F	RxIndication	41
	9.2	V2xGn_1		
	9.3	V2xGn_\	V2xM_UpdatePseudonym	42
	9.4		MainFunction	
10	Conf	iguration s	pecification	44
	10.1	Containe	ers and configuration parameters	44
		10.1.1	Variants	
		10.1.2	V2xGn	
		10.1.3	V2xGnGeneral	
		10.1.4	V2xGnBeaconService	
		10.1.5	V2xGnPacketForwarding	
		10.1.6	V2xGnConfig	62
		10.1.7	V2xGnRxPdu	
		10.1.8	V2xGnTxPdu	64
	10.2	Publishe	d Information	
Α	Not a	applicable r	requirements	66
В	Histo	ory of Spec	ification Items	67
	B.1	Specifica	ation Item History of this document compared to AUTOSAR	
		R24-11.		67
		B.1.1	Added Specification Items in R24-11	
		B.1.2	Changed Specification Items in R24-11	
		B.1.3	Deleted Specification Items in R24-11	
	B.2		nt Item History of this document compared to AUTOSAR R24-11	



	B.2.1	Added Constraints in R24-11 69
	B.2.2	Changed Constraints in R24-11 69
	B.2.3	Deleted Constraints in R24-11 69
B.3	Specifica	tion Item History of this document compared to AUTOSAR
	R23-11.	
	B.3.1	Added Specification Items in R23-11 69
	B.3.2	Changed Specification Items in R23-11
	B.3.3	Deleted Specification Items in R23-11
B.4	Specifica	tion Item History of this document compared to AUTOSAR
	R22-11.	
	B.4.1	Added Specification Items in R22-11
	B.4.2	Changed Specification Items in R22-11
	B.4.3	Deleted Specification Items in R22-11
B.5	Constrair	nt Item History of this document compared to AUTOSAR R22-11.75
	B.5.1	Added Constraints in R22-11
	B.5.2	Changed Constraints in R22-11
	B.5.3	Deleted Constraints in R22-11



1 Introduction and functional overview

This specification specifies the functionality, API and the configuration of the AUTOSAR Basic Software module Vehicle-2-X GeoNetworking (V2xGn).

V2xGn together with Vehicle-2-X Facilities (V2xFac) [1], Vehicle-2-X Basic Transport (V2xBtp) [2], Vehicle-2-X Management (V2xM) [3], Vehicle-2-X Data Manager [4] and AUTOSAR BSW modules Ethernet Interface (EthIf) [5], Linklayer Sdu Routing Module (LSduR) [6], Wireless Ethernet Driver (WEth) [7] and Wireless Ethernet Transceiver Driver (WEthTrcv) [8] forms the V2X stack within the AUTOSAR architecture.

The base for this document is the GeoNetworking specification [9] [10]. It is assumed that the reader is familiar with this specification.

1.1 Architectural overview

V2xGn provides services to and is dependent on the upper V2xBtp module and uses the services of and gets services from the lower EthIf module to realize its functions explained in section 1.2 and chapter 7 of this document.

Positioning of the V2xGn module within the AUTOSAR BSW and the Layered Software architecture is shown in the figure below.




Figure 1.1: AUTOSAR BSW software architecture - V2xGn module scope



1.2 Functional overview

The internal functionality of the V2xGn module should comply to the medium independent specification of the GeoNetworking protocol [9] and the medium dependent specification of the GeoNetworking protocol [10], relying on ETSI ITS-G5 technology as medium. The module provides services to the upper V2xBtp module specified in [2] and in order to provide its packet transport services, it relies on the lower EthIf module [5]. Vehicle-2-X specific data is also exchanged with the V2xM module.

GeoNetworking protocol is a set of network layer functionalities that enables ad hoc communication without infrastructure support using geographical positions of the communicating entities. It supports communication among individual Intelligent Transport System (ITS) station and distribution of packets in geographical areas. As GeoNetworking can be executed over different ITS technologies such as ITS-G5 and infrared, GeoNetworking specification consists of a standard for media-independent functionality [9] which specifies all functions that are common to all ITS access technologies and one or more media-dependent specifications [10] which includes extensions for a specific ITS technology.



2 Acronyms and Abbreviations

The glossary below includes acronyms and abbreviations relevant to the V2xGeoNetworking module that are not included in the AUTOSAR glossary [11].

Abbreviation / Acronym:	Description:	
ВТР	Basic Transport Protocol	
CBF	Contention-Based Forwarding	
DET	Default Error Tracer	
GAC	GeoAnycast	
GBC	GeoBroadcast	
GN	GeoNetworking	
GN-SDU	GeoNetworking Service Data Unit	
ITS	Intelligent Transport System	
MAC	Medium Access Control	
SHB	Single Hop Broadcast	
TC	Traffic Class	
TSB	Topologically Scoped Broadcast	

Table 2.1: Acronyms and abbreviations used in the scope of this Document



3 Related documentation

3.1 Input documents & related standards and norms

- [1] Specification of Vehicle-2-X Facilities AUTOSAR_CP_SWS_V2XFacilities
- [2] Specification of Vehicle-2-X Basic Transport AUTOSAR CP SWS V2XBasicTransport
- [3] Specification of Vehicle-2-X Management AUTOSAR CP SWS V2XManagement
- [4] Specification of Vehicle-2-X Data Manager AUTOSAR_CP_SWS_V2XDataManager
- [5] Specification of Ethernet Interface AUTOSAR CP SWS EthernetInterface
- [6] Specification of Linklayer Sdu Routing Module AUTOSAR CP SWS LSduRouter
- [7] Specification of Wireless Ethernet Driver AUTOSAR_CP_SWS_WirelessEthernetDriver
- [8] Specification of Wireless Ethernet Transceiver Driver AUTOSAR_CP_SWS_WirelessEthernetTransceiverDriver
- [9] EN 302 636-4-1 V1.3.1: Vehicular Communication; Geonetworking; Part 4 Geographical addressing and forwarding for point-to-point and point-to-multipoint communications; Sub-part 1: Media-Independent Functionality
- [10] TS 102 636-4-2 V1.1.1: Intelligent Transport Systems (ITS); GeoNetworking; Part 4: Geographical addressing and forwarding for point-to-point and point-to-multipoint communications; Sub-part 2: Media-dependent functionalities for ITS-G5
- [11] Glossary
 AUTOSAR_FO_TR_Glossary
- [12] General Specification of Basic Software Modules AUTOSAR_CP_SWS_BSWGeneral
- [13] IEEE Part 11: Wireless LAN Medium Access Control (MAC) and Physical Layer (PHY) Specification. Amendment 6: Wireless Access in Vehicular Environments (IEEE STD 802.11p-2010).
- [14] Car 2 Car Communication Consortium; Basic System Profile release 1.3
- [15] Specification of Default Error Tracer
 AUTOSAR CP SWS DefaultErrorTracer



- [16] Specification of ECU State Manager AUTOSAR_CP_SWS_ECUStateManager
- [17] General Requirements on Basic Software Modules AUTOSAR_CP_RS_BSWGeneral
- [18] Requirements on Vehicle-2-X Communication AUTOSAR_CP_RS_V2XCommunication
- [19] TS 102 724 V1.1.1: Intelligent Transport Systems (ITS); Harmonized Channel Specifications for Intelligent Transport Systems operating in the 5 GHz frequency band
- [20] List of EtherTypes by IEEE http://standards.ieee.org/develop/regauth/ethertype/eth.txt

3.2 Related specification

AUTOSAR provides a General Specification on Basic Software modules [12], which is also valid for V2xGn.

Thus, the specification SWS BSW General shall be considered as additional and required specification for V2xGn.



4 Constraints and assumptions

4.1 Limitations

- The GeoNetworking protocol and therefore the V2xGn module requires a broadcast capable access layer in order to provide transmit services.
- Wireless Communication supports IEEE 802.11p only [13]. Other 802.11 standards (e.g. for infrastructure networks and integration with TCP/IP) can be extended in future releases of the AUTOSAR standard.
- The V2X modules follow the guidance regarding the Day-1 scenarios defined by the Basic System Standards Profile from Car-2-Car-Consortium [14].

4.2 Applicability to car domains

This specification is applicable to all car domains.

4.3 Authorisation Tickets and Pseudonyms

The Authorisation Ticket (AT) is referred to as Pseudonym in this document.



5 Dependencies to other modules

This section describes the relations of the V2xGn module to other modules within the AUTOSAR basic software architecture. It outlines the modules that are required or optional for the realization of the V2xGn module and the V2xGn services that these modules use.

5.1 AUTOSAR DET (Default Error Tracer)

In development mode, the V2xGn module reports errors through DET [15].

5.2 AUTOSAR EcuM (Ecu State Manager)

The EcuM [16] is responsible for the initialization of V2xGn.

5.3 AUTOSAR Ethernet Interface (Ethlf)

The Ethernet Interface is the lower layer module of the V2xGn module.

5.4 AUTOSAR Linklayer Sdu Routing Module (LSduR)

The Linklayer Sdu Routing Module is the lower layer module of the V2xGn module for the data flow.

5.5 AUTOSAR Vehicle-2-X Basic Transport Protocol (V2xBtp)

The V2xBtp is the upper layer module of the V2xGn module.

5.6 AUTOSAR Vehicle-2-X Management (V2xM)

V2xM is used for interchange of Data with other V2X-Modules. Security mechanisms are configured by the V2xM and are used by V2xGn.



5.7 File structure

5.7.1 Code file structure

For details refer to the chapter 5.1.6 "Code file structure" in "General Specification of Basic Software Modules" [12].



6 Requirements Tracing

The following tables reference the requirements specified in [17] and [18] and links to the fulfillment of these. Please note that if column "Satisfied by" is empty for a specific requirement this means that this requirement is not fulfilled by this document.

Requirement	Description	Satisfied by
[SRS_BSW_00345]	BSW Modules shall support pre-compile configuration	[SWS_V2xGn_00078]
[SRS_V2X_00010] The implementation of the V system shall follow additiona guidance given by C2C-CC requirements		[SWS_V2xGn_00269] [SWS_V2xGn_20169] [SWS_V2xGn_20181] [SWS_V2xGn_20260] [SWS_V2xGn_20262] [SWS_V2xGn_20263] [SWS_V2xGn_20264] [SWS_V2xGn_20265] [SWS_V2xGn_20266] [SWS_V2xGn_20267] [SWS_V2xGn_20268] [SWS_V2xGn_20270] [SWS_V2xGn_20401]
[SRS_V2X_00160]	The V2X system shall use end-to-end security for communication to external entities	[SWS_V2xGn_00026] [SWS_V2xGn_20251]
[SRS_V2X_00161]	The V2X system shall employ the security envelope on its Network layer	[SWS_V2xGn_00012] [SWS_V2xGn_20251]
[SRS_V2X_00164]	The V2X system shall only forward verified messages	[SWS_V2xGn_00026]
[SRS_V2X_00176]	The V2X system shall change pseudonyms	[SWS_V2xGn_00028] [SWS_V2xGn_00091] [SWS_V2xGn_00112] [SWS_V2xGn_00115]
[SRS_V2X_00259]	The V2X system shall manage the life time of all DENM packets	[SWS_V2xGn_20259]
[SRS_V2X_00279]	The V2X system shall support circular, rectangular and ellipsoidal geographical areas	[SWS_V2xGn_20266]
[SRS_V2X_00391]	The V2X system's access layer shall be ITS-G5 compliant	[SWS_V2xGn_20414]
[SRS_V2X_00531]	The V2X system's Networking Layer shall support addressing based on geographic coordinates	[SWS_V2xGn_20250] [SWS_V2xGn_20251] [SWS_V2xGn_20252] [SWS_V2xGn_20255] [SWS_V2xGn_20258] [SWS_V2xGn_20414] [SWS_V2xGn_20416]
[SRS_V2X_26011]	The V2X Geo Networking shall support PDU based communication	[SWS_V2xGn_00136] [SWS_V2xGn_00137] [SWS_V2xGn_00138] [SWS_V2xGn_00139] [SWS_V2xGn_00140] [SWS_V2xGn_00141] [SWS_V2xGn_00143] [SWS_V2xGn_00144] [SWS_V2xGn_00145] [SWS_V2xGn_00146] [SWS_V2xGn_00147] [SWS_V2xGn_00148] [SWS_V2xGn_00149] [SWS_V2xGn_00150]

Table 6.1: Requirements Tracing



7 Functional specification

7.1 General Functionality

[SWS V2xGn 00012]

Upstream requirements: SRS_V2X_00161

[The V2xGn Module shall implement the GeoNetworking Protocol as defined in [9], [10], and [14] unless specified otherwise in this document.]

[SWS_V2xGn_00013] [The GeoNetworking Protocol shall support the GeoNetworking related requirements specified in [14].|

[SWS_V2xGn_20250]

Upstream requirements: SRS_V2X_00531

[All default constants and parameters of the V2xGn module not defined or overwritten in the current document shall be set as specified in Annex H of [9].]

[SWS_V2xGn_20251]

Upstream requirements: SRS_V2X_00531, SRS_V2X_00160, SRS_V2X_00161

The V2xGn module shall be implemented assuming the ETSI parameter itsGnSecurity is constantly set to ENABLED.

[SWS V2xGn 20252]

Upstream requirements: SRS_V2X_00531

The V2xGn module shall only support anonymous address configuration mode.

[SWS_V2xGn_20255]

Upstream requirements: SRS V2X 00531

[The V2xGn module shall support geo-areas areas of up to 80 km2. In consequence, the itsGnMaxGeoAreaSize shall have a value of 80. It is configurable by the configuration option V2xGnItsGnMaxGeoAreaSize.]

[SWS_V2xGn_20414]

Upstream requirements: SRS_V2X_00531, SRS_V2X_00391

The V2xGn module shall be implemented with respect to the ETSI parameter itsGnIfType constantly set to ITS-G5.

[SWS_V2xGn_00130] [The V2xGn module shall get the pointer to the current time information via V2xM_GetRefTimePtr() within the $V2xGn_Init()$.]



[SWS V2xGn 20416]

Upstream requirements: SRS_V2X_00531

[Packet repetition shall not be performed by V2xGn module and the corresponding steps in the packet handling procedures in [9] clause 10.3 shall not be executed.

The parameter 'Maximum repetition time' of the service primitive GN-DATA.request is not applicable. Also, the GN protocol constant itsGnMinPacketRepetitionInterval is not applicable.

7.2 GeoNetworking Packet Structure and Format

[SWS_V2xGn_00020] [The GeoNetworking protocol shall only support the packet header types Single Hop Broadcast packet header, GeoBroadcast packet headers and Beacon packet header.]

[SWS V2xGn 20258]

Upstream requirements: SRS_V2X_00531

[The V2xGn module shall set the LifeTime field of all SHB packets to 1 second. Consequently, the multiplier bit of the LT field shall be set to 1 and the base bit of the LT field shall be set to 1.]

[SWS V2xGn 20259]

Upstream requirements: SRS_V2X_00259

[The V2xGn module shall set the LifeTime field of all GBC packets to the value of the maxPacketLifetime from the transmit parameters TxParams. The value of the LifeTime field shall not exceed the itsGnMaxPacketLifetime, specified in [9], Annex H.

7.3 GeoNetworking Protocol Operations

7.3.1 Network Management

[SWS_V2xGn_00022] [The V2xGn module shall update the local position and time information. The minimum update frequency is configured by the configuration parameter V2xGnItsGnMinUpdateFrequencyEPV. The scheduled function $V2xGn_-MainFunction$ () shall be used for the cyclic update.



[SWS_V2xGn_00023] [The V2xGn module shall support GeoNetworking beaconing. The scheduled function $V2xGn_MainFunction$ () shall be used for the cyclic beaconing.]

[SWS_V2xGn_00269]

Upstream requirements: SRS V2X 00010

The V2xGn module shall only send beacons if ego position is accurate enough to set the Position Accuracy Indicator (PAI) to 1.

[SWS_V2xGn_00081] [The V2xGn module shall support Location Table Maintainance. The scheduled function $V2xGn_MainFunction$ () shall be used for the cyclic maintainance of the Location Table.

[SWS_V2xGn_00129] [The V2xGn module shall get the current position and time information via V2xM GetPositionAndTime() within the MainFunction.

7.3.2 Security Mechanisms

[SWS V2xGn 00026]

Upstream requirements: SRS V2X 00160, SRS V2X 00164

[The V2xGn module shall use security services provided by V2xM V2xM_V2xGn_ReqEncap() and V2xM_V2xGn_ReqDecap().]

[SWS V2xGn 00028]

Upstream requirements: SRS_V2X_00176

The V2xGn shall suspend transmission of messages and clear transmit buffers when a pseudonym changes is in preparation.

Note: The V2xM will notify the V2xGn about pseudonym changes via V2xGn_V2xM_-PreparePseudonymChange(), V2xGn_V2xM_CommitPseudonymChange() and V2xGn_V2xM_AbortPseudonymChange().



7.4 Message Forwarding

[SWS_V2xGn_20266]

Upstream requirements: SRS_V2X_00010, SRS_V2X_00279

[The V2xGn module shall only support Area forwarding algorithms specified in [9] Annex E.3.|

[SWS V2xGn 20267]

Upstream requirements: SRS_V2X_00010

[When forwarding packets, the V2xGn module shall use the DCC profile DP3 as defined in [19].|

[SWS V2xGn 20169]

Upstream requirements: SRS V2X 00010

[The V2xGn module shall check the distance from the sender position - in the security envelope, if available - and forward only messages with a distance from the sender of equal or less than 6 km.]

7.5 Message Transmission

[SWS_V2xGn_00034] [The V2xGn module shall provide the API V2xGn_Transmit () to enable transmit requests from the V2xBtp Module.]

[SWS V2xGn 00082]

Status: OBSOLETE

[The V2xGn module shall use EthIf_ProvideTxBuffer() to aquire a buffer within the Wireless Ethernet Driver for a V2X Packet to be transmitted. This has to be done during the V2xGn_Transmit() context.]

[SWS_V2xGn_00083] [The V2xGn module shall provide transmission parameters to the Wireless Ethernet Driver for a V2X Packet to be transmitted via an API call to EthIf_SetBufWTxParams(). This has to be done during the V2xGn_Transmit() context.



[SWS V2xGn 00035]

Status: OBSOLETE

Use instead: SWS_V2xGn_00136

[The V2xGn module shall transmits packets using the Ethlf_Transmit() API provided by the Ethlf Module. This has to be done during the V2xGn_Transmit() context.

[SWS_V2xGn_00136] Usage of LSduR_V2xGnTransmit() in context of V2xGn_-Transmit()

Status: DRAFT

Replaces: SWS_V2xGn_00082, SWS_V2xGn_00035

Upstream requirements: SRS V2X 26011

[The V2xGn module shall transmit packets using the $LSduR_V2xGnTransmit()$ API provided by the LSduR Module. This has to be done during the $V2xGn_Transmit()$ context.

[SWS_V2xGn_00135] [The V2xGn module shall create a unique EncapReqId for each packet to be transmitted. This EncapReqId is used to track the result of each encapsulation request during which the packet to be transmitted is signed to authenticate the transmitting ITS station.]

[SWS_V2xGn_20260]

Upstream requirements: SRS V2X 00010

[The V2xGn module shall buffer GBC packets when no neighbours are available (store-carry-forward) if the SCF bit of the TC (Traffic Class) field of GBC packets is set to 1.|

[SWS V2xGn 20262]

Upstream requirements: SRS_V2X_00010

[The V2xGn module is not required to offload packets to another channel. Consequently, the channel offload bit of the TC (Traffic Class) field in the BTP frames to be sent should be set to 0. Value 1 will be ignored anyway.

[SWS_V2xGn_20263]

Upstream requirements: SRS V2X 00010

[The V2xGn module shall only use the DCC profiles specified in [SWS_WEth_20235]. Consequently, the DCC Profile ID bits of the TC (Traffic Class) field shall only use the DPID values defined in [SWS_WEth_20235].

[SWS V2xGn 20264]

Upstream requirements: SRS_V2X_00010

The V2xGn shall set the itsGnIsMobile bit of the Flags field to 1.



[SWS V2xGn 20265]

Upstream requirements: SRS_V2X_00010

The V2xGn shall set the Maximum Hop Limit (MHL) field to 10.

[SWS V2xGn 20270]

Upstream requirements: SRS V2X 00010

[All GeoNetworking frames sent by the V2xGn module shall use the EtherType value 0x8947 as listed by the IEEE Registration Authority at [20].

[SWS V2xGn 20401]

Upstream requirements: SRS_V2X_00010

The GN Source Address shall be constructed as follows:

- Set the field M (bit 0) to 0.
- Set the field ST (bits 1 to 5) to the station type of the ITS-S. The station type in the GN source address shall be identical to the station type in CAMs/DENMs.
- Set reserved bits 6 to 15 to 0.
- Set the field MID (bits 16 to 63) to the value of the MAC address.

[SWS_V2xGn_00128] [The V2xGn module shall call V2xM_GetGlobalTxParams() that delivers own channel CBR information set in the GeoNetworking header to be transmitted.]

The transmission request towards the LSduR is performed with direct data provision. With direct data provision, the data for transmission is forwarded in one single call via the LSduR to the lower layer. The lower layer is responsible to transfer the data to a transmit buffer.

[SWS_V2xGn_00137] Transmission request with direct data provision

Status: DRAFT

Upstream requirements: SRS V2X 26011

[If a transmission request need to be performed, then the V2xGn module shall call LSduR V2XGnTransmit() with the following arguments:

- TxPduId equal to the PDU id that is referenced by the used V2xGnTxPdu
- PduInfoPtr.SduDataPtr equal to the data pointer
- PduInfoPtr.SduLength equal to the data length



• PduInfoPtr.MetaDataPtr equal to the pointer of the created MetaDataItem configured at the V2xGnTxPdu that corresponds to the given TxPduId.

[SWS_V2xGn_00138] Meta data handling while containing headers

Status: DRAFT

Upstream requirements: SRS V2X 26011

[If the V2xGn module provides headers necessary for the transmission through PduInfoPtr.MetaDataPtr then MetaDataItem shall be set in the following order:

- ETHERNET_MAC_64 equal to the destination MAC address
- LISTELEM_PTR equal to the pointer of the created instance of type ListElem—StructType in the following order:
 - create an instance of type ListElemStructType and set NextListElemPtr to NULL_PTR
 - set DataPtr to address of the created header and DataLength to the length of the created header
- PRIORITY_8 equal to the priority value used for this packet

[SWS_V2xGn_00139] Meta data handling while not containing headers

Status: DRAFT

Upstream requirements: SRS V2X 26011

[If the V2xGn module provides headers necessary for the transmission through PduInfoPtr.SduDataPtr then MetaDataItem shall be set in the following order:

- ETHERNET_MAC_64 equal to the Physical destination address (MAC address in network byte order)
- LISTELEM_PTR equal to NULL_PTR
- PRIORITY_8 equal to the priority value used for this packet



7.6 Message Reception

[SWS_V2xGn_00140] Reception parameters derived from PDU

Status: DRAFT

Upstream requirements: SRS_V2X_26011

[If a packet is received, the V2xGn module shall derive the frame type (EthIfFrameType) and the EthIfCtrl (EthIfController) configured in EthIf via the PDU that is referenced by the V2xGnRxPdu which is identified by the given RxPduId.

[SWS V2xGn 00141] Reception parameters derived from meta data items

Status: DRAFT

Upstream requirements: SRS_V2X_26011

[If a packet is received, the V2xGn module shall consume meta data items PduInfoPtr.MetaDataPtr configured at the V2xGnRxPdu that corresponds to the given RxPduId in the following order:

- ETHERNET_MAC_64 indicating the Physical source address (MAC address in network byte order)
- BROADCAST_8 indicating a broadcast frame

[SWS_V2xGn_CONSTR_00142] Reception PDU constraint for keeping the local buffer

Status: DRAFT

[Each V2xGnRxPdu shall refer to global PDU that has KeepLocalPduBuffer set to FALSE.]

[SWS_V2xGn_00038] [The V2xGn module shall create a unique DecapReqld for each received packet. This DecapReqld is used to track the result of each decapsulation request during which the signature of the received packet is verified.]

[SWS_V2xGn_00039] The V2xGn module shall indicate received packets via the V2xBtp_RxIndication() callback to the BTP module.

[SWS_V2xGn_00084] [The V2xGn module shall get the reception status of a received packet during the $V2xGn_RxIndication()$ from the EthIf module with a call to EthIf_GetBufWRxParams().|



[SWS V2xGn 20268]

Upstream requirements: SRS_V2X_00010

[The V2xGn module shall only use duplicate packet detection as specified in [9] Annex A.2 and A.3.]

[SWS_V2xGn_20181]

Upstream requirements: SRS_V2X_00010

[If the V2xGn module detects a collision of the least significant 32 bit of the "Certificate digest" / "hashedId8" with the "Certificate digest" / "hashedId8" of another ITS station, it shall initiate a change of its authorization ticket (pseudonym) only if the certificate corresponding to the other "Certificate digest" / "hashedId8" is valid, and the current authorization ticket was selected according to rules defined in [SWS_V2xM_-00201] (that is to say no such collision has already triggered the change to the current authorization ticket).]

[SWS_V2xGn_00127] [The V2xGn module shall call V2xM_SetGlobalRxParams() with CBR information extracted from the GeoNetworking header.]

[SWS_V2xGn_00131] [The V2xGn module shall use V2xM_CalcDistance() when calculations of geographical distances are necessary for the V2xGn protocol operations.]

7.7 State handling of PDUs

PDUs are used to transfer data across the layers in the AUTOSAR communication stack. The V2xGnConfig references one V2xGnRxPdu and one V2xGnTxPdu to interchange data with the lower layer. The V2xGn module request data transmission via the configured V2xGnTxPdu, and the module is indicated for data reception via the configured V2xGnRxPdu.

[SWS_V2xGn_00143] Transmission PDU states

Status: DRAFT

Upstream requirements: SRS_V2X_26011

The V2xGn module shall maintain a separate state for each transmission PDU used by the V2xGn module (V2xGnTxPdu) and distinguish at least the following states:

- PDU_AVAILABLE: The PDU for a specific transmission is available and ready to be used (PDU resources are released)
- PDU_IN_USE: The PDU for a specific transmission is not available and is already used (PDU resources are valid)



[SWS_V2xGn_00144] Starting transmission request

Status: DRAFT

Upstream requirements: SRS V2X 26011

[The V2xGn module shall request transmission only on PDU in state PDU_AVAILABLE, allocate PDU resources and necessary buffer depending on the transmission type (see [SWS_V2xGn_00137], [SWS_V2xGn_00138], [SWS_V2xGn_00139]), enter the state PDU_IN_USE and call LSduR_-V2XGnTransmit().|

[SWS_V2xGn_00145] Finishing transmission request

Status: DRAFT

Upstream requirements: SRS_V2X_26011

[If the transmission confirmation V2xGn_TxConfirmation() is called on PDU in state PDU_IN_USE, the V2xGn module shall release all PDU resources and enter the state PDU_AVAILABLE.

[SWS V2xGn 00146] Aborting transmission request

Status: DRAFT

Upstream requirements: SRS V2X 26011

[If the V2xGn module requested to transmit data and the LSduR_V2XGnTransmit() returned E_NOT_OK, then the V2xGn module shall release all PDU resources and set the state of the affected PDU back to PDU_AVAILABLE.

7.8 Error Classification

Section "Error Handling" of the document [12] "General Specification of Basic Software Modules" describes the error handling of the Basic Software in detail. Above all, it constitutes a classification scheme consisting of five error types which may occur in BSW modules.

Based on this foundation, the following section specifies particular errors arranged in the respective subsections below.

7.8.1 Development Errors

[SWS_V2xGn_00134] In case development error detection is enabled for the V2xGn module, the V2xGn module shall check API parameters for validity and report detected errors to the DET.



[SWS_V2xGn_00041] Definiton of development errors in module V2xGn [

Type of error	Related error code	Error value
API service called with invalid parameter	V2XGN_E_PARAM	0x01
API service called with invalid pointer	V2XGN_E_PARAM_POINTER	0x02
API service used without module initialization	V2XGN_E_UNINIT	0x03
API service called with invalid configuration pointer	V2XGN_E_INIT_FAILED	0x04

1

7.8.2 Runtime Errors

[SWS_V2xGn_91000] Definiton of runtime errors in module V2xGn

Status: DRAFT

Type of error	Related error code	Error value
Internal transmission processing aborted	V2XGN_E_TX_INTERNAL_PROCESSING_ FAILED	0x01

1

[SWS_V2xGn_00147] Error report for aborting the transmission request

Status: DRAFT

Upstream requirements: SRS_V2X_26011

[The V2xGn shall report the runtime error by calling Det_ReportRuntimeError(V2XGN_E_TX_INTERNAL_PROCESSING_FAILED) if one of the following conditions applies:

• A transmission processing is requested from LSduR_V2xGnTransmit() and then aborted.

7.8.3 Production Errors

There are no production errors.

7.8.4 Extended Production Errors

There are no extended production errors.



8 API specification

8.1 Imported types

In this chapter all types included from the following modules are listed:

[SWS_V2xGn_00042] Definition of imported datatypes of module V2xGn [

Module	Header File	Imported Type
Comtype	ComStack_Types.h	PduldType
	ComStack_Types.h	PduInfoType
	ComStack_Types.h	PduLengthType
Std	Std_Types.h	Std_ReturnType
	Std_Types.h	Std_VersionInfoType
V2x GeneralTypes	Rte_V2xM_Type.h	V2xM_PositionAndTimeType
vzx_denerarrypes	V2x_GeneralTypes.h	V2x_ChanType
	V2x_GeneralTypes.h	V2x_GnAddressType
	V2x_GeneralTypes.h	V2x_GnAreaShapeType
	V2x_GeneralTypes.h	V2x_GnDestinationAreaType
	V2x_GeneralTypes.h	V2x_GnDestinationType
	V2x_GeneralTypes.h	V2x_GnLongPositionVectorType
	V2x_GeneralTypes.h	V2x_GnPacketTransportType
	V2x_GeneralTypes.h	V2x_GnTxResultType
	V2x_GeneralTypes.h	V2x_GnUpperProtocolType
	V2x_GeneralTypes.h	V2x_PseudonymType
	V2x_GeneralTypes.h	V2x_SecProfileType
	V2x_GeneralTypes.h	V2x_SecReportType
	V2x_GeneralTypes.h	V2x_SecReturnType
	V2x_GeneralTypes.h	V2x_TrafficClassIdType
V2xBtp	V2xBtp.h	V2xBtp_RxParamsType
WEth	WEth_GeneralTypes.h	WEth_BufWRxParamIdType
	WEth_GeneralTypes.h	WEth_BufWTxParamIdType



8.2 Type definitions

8.2.1 V2xGn_TxParamsType

[SWS_V2xGn_00063] Definition of datatype V2xGn_TxParamsType [

Name	V2xGn_TxParamsT	V2xGn_TxParamsType		
Kind	Structure	Structure		
	upperProtocol	upperProtocol		
Elements	Туре	V2x_GnUpperProtocolType		
	Comment	The protocol which triggered the request. (e.g. BTP-A or BTP-B)		
	transportType			
	Туре	V2x_GnPacketTransportType		
	Comment	Specifies the packet transportation type		
	destinationAddress			
	Туре	V2x_GnAddressType		
	Comment	Destination address for GeoUnicast packet		
	destinationArea			
	Туре	V2x_GnDestinationAreaType		
	Comment	Destination area for GeoBroadcast/GeoAnycast packet.		
	destinationType			
	Туре	V2x_GnDestinationType		
	Comment	Select which destination type (destinationAddress or destinationArea is used for this packet).		
	secProfile			
	Туре	V2x_SecProfileType		
	Comment	Parameters depending on the security service.		
	maxPacketLifetime			
	Туре	uint16		
	Comment	Time a packet can be buffered until it reaches the destination.		
	trafficClassId			
	Туре	V2x_TrafficClassIdType		
	Comment	Set of parameter specifying the traffic class for the message.		
Description	Structure containing	Structure containing parameters for the V2xGn_Transmit() API.		
Available via	V2xGn.h	V2xGn.h		



8.3 Function definitions

8.3.1 V2xGn_Init

[SWS_V2xGn_00068] Definition of API function V2xGn_Init [

Service Name	V2xGn_Init		
Syntax	<pre>void V2xGn_Init (void* CfgPtr)</pre>		
Service ID [hex]	0x01		
Sync/Async	Synchronous		
Reentrancy	Non Reentrant	Non Reentrant	
Parameters (in)	CfgPtr Pointer to configuration set		
Parameters (inout)	None		
Parameters (out)	None		
Return value	None		
Description	Initializes the V2xGn module.		
Available via	V2xGn.h		

[SWS_V2xGn_00133] [If development error detection is enabled: The function shall check the parameter CfgPtr for containing a valid configuration. If the check fails, the function shall raise the development error V2XGN_E_INIT_FAILED.|

8.3.2 V2xGn_GetVersionInfo

[SWS_V2xGn_00069] Definition of API function V2xGn_GetVersionInfo

Service Name	V2xGn_GetVersionInfo	
Syntax	void V2xGn_GetVersionInfo (Std_VersionInfoType* VersionInfoPtr)	
Service ID [hex]	0x02	
Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (in)	None	
Parameters (inout)	None	
Parameters (out)	VersionInfoPtr	Pointer to where to store the version information of this module.
Return value	None	
Description	Returns the version information of this module.	
Available via	V2xGn.h	



[SWS_V2xGn_00090] [If development error detection is enabled: the function shall check the parameter VersionInfoPtr for being valid. If the check fails, the function shall raise the development error V2XGN_E_PARAM_POINTER.]

8.3.3 V2xGn_V2xM_PreparePseudonymChange

[SWS_V2xGn_00072] Definition of API function V2xGn_V2xM_Prepare PseudonymChange

Service Name	V2xGn_V2xM_PreparePseudonymChange		
Syntax	Std_ReturnType V2xGn_V2xM_PreparePseudonymChange (const V2x_PseudonymType* PseudonymPtr)		
Service ID [hex]	0x05	0x05	
Sync/Async	Synchronous		
Reentrancy	Non Reentrant		
Parameters (in)	PseudonymPtr	The Pseudonym provided by V2xM	
Parameters (inout)	None		
Parameters (out)	None		
Return value	Std_ReturnType	E_OK: operation successful E_NOT_OK: operation failed	
Description	This function is called by the V2xM when a Pseudonym Change occurs to prepare the change in every module using it.		
Available via	V2xGn_V2xM.h		

[SWS V2xGn 00091]

Upstream requirements: SRS_V2X_00176

[The function V2xGn_V2xM_PreparePseudonymChange() shall prepare the setting of the pseudonym specific part of the GeoNetworking Address being used for packet transmission.]

[SWS_V2xGn_00092] [If development error detection is enabled: the function shall check that the service $V2xGn_{init}$ () was previously called. If the check fails, the function shall raise the development error $V2xGn_{E_UNINIT}$.

[SWS_V2xGn_00093] [If development error detection is enabled: the function shall check the parameter PseudonymPtr for being valid. If the check fails, the function shall raise the development error V2XGN E PARAM POINTER.]

Note: This starts a module internal transaction for the pseudonym change. The actual pseudonym change becomes effective only after an API call to $V2xGn_V2xM_CommitPseudonymChange()$.



8.3.4 V2xGn V2xM CommitPseudonymChange

[SWS_V2xGn_00111] Definition of API function V2xGn_V2xM_Commit PseudonymChange \lceil

Service Name	V2xGn_V2xM_CommitPseudonymChange		
Syntax	<pre>Std_ReturnType V2xGn_V2xM_CommitPseudonymChange (void)</pre>		
Service ID [hex]	0x09		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Non Reentrant		
Parameters (in)	None		
Parameters (inout)	None		
Parameters (out)	None		
Return value	Std_ReturnType	E_OK: operation successful E_NOT_OK: operation failed	
Description	This function is called by the V2xM when all modules are OK with the pseudonym change and the change is to be committed.		
Available via	V2xGn_V2xM.h		

[SWS_V2xGn_00112]

Upstream requirements: SRS_V2X_00176

[The function V2xGn_V2xM_CommitPseudonymChange() shall update the pseudonym specific part of the module's GeoNetworking Address.]

[SWS_V2xGn_00113] [If development error detection is enabled: the function shall check that the service $V2xGn_{init}$ () was previously called. If the check fails, the function shall raise the development error $V2xGn_{em}$.

Note: The function requires previous preparation of the pseudonym via an API call to V2xGn V2xM PreparePseudonymChange().



8.3.5 V2xGn V2xM AbortPseudonymChange

[SWS_V2xGn_00126] Definition of API function V2xGn_V2xM_AbortPseudonym Change [

Service Name	V2xGn_V2xM_AbortPseudonymChange	
Syntax	Std_ReturnType V2xGn_V2xM_AbortPseudonymChange (void)	
Service ID [hex]	0x0a	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	None	
Parameters (inout)	None	
Parameters (out)	None	
Return value	Std_ReturnType	E_OK: operation successful E_NOT_OK: operation failed
Description	This function is called by the V2xM when not all modules are OK with the pseudonym change and the change is to be rolled back.	
Available via	V2xGn_V2xM.h	

[SWS_V2xGn_00115]

Upstream requirements: SRS_V2X_00176

[The function V2xGn_V2xM_AbortPseudonymChange() shall set the state of the module to the state before the pseudonym change has been prepared.]

[SWS_V2xGn_00116] [If development error detection is enabled: the function shall check that the service $V2xGn_{init}$ () was previously called. If the check fails, the function shall raise the development error $V2xGn_{E_{init}}$

Note: The function requires previous preparation of the pseudonym via an API call to V2xGn V2xM PreparePseudonymChange().



8.3.6 V2xGn_Transmit

[SWS_V2xGn_00070] Definition of API function V2xGn_Transmit [

Service Name	V2xGn_Transmit		
Syntax	<pre>V2x_GnTxResultType V2xGn_Transmit (const V2xGn_TxParamsType* TxParams, uint16 Length)</pre>		
Service ID [hex]	0x03		
Sync/Async	Asynchronous		
Reentrancy	Non Reentrant	Non Reentrant	
Parameters (in)	TxParams	Additional transmission parameters	
	Length	Length of the user data	
Parameters (inout)	None		
Parameters (out)	None		
Return value	V2x_GnTxResultType	Values specified in the Type could be returned. V2X_GNTX_ACCEPTED if no error occurred. V2X_GNTX_ACCEPTED transmit has been accepted V2X_GNTX_E_MAXSDUSIZEOVFL transmit has been rejected due to maximum length exceedance V2X_GNTX_E_MAXPACKETLIFETIME transmit has been rejected due to maximum lifetime exceedance V2X_GNTX_E_TCID transmit has been rejected due to unsupported Traffic Class ID V2X_GNTX_E_MAXGEOAREASIZE transmit has been rejected due to GeoArea exceeds max size V2X_GNTX_E_UNSPECIFIED transmit has been rejected due to unspecified reasons	
Description	Is called by V2x_Btp to send a message.		
Available via	V2xGn.h		

[SWS_V2xGn_00095] [The function $V2xGn_Transmit()$ shall transmit a V2X Packet.]

[SWS_V2xGn_00096] [If development error detection is enabled: the function shall check that the service $V2xGn_{init}$ () was previously called. If the check fails, the function shall raise the development error $V2xGn_{E_UNINIT}$.

[SWS V2xGn 00098]

Status: OBSOLETE

[The function shall return $V2X_GNTX_E_MAXSDUSIZEOVFL$ if the call to EthIf_ProvideTxBuffer returns BUFREQ_E_OVFL.]



[SWS_V2xGn_00148] Return value if LSduR_V2xGnTransmit() reports E NOT OK

Status: DRAFT

Replaces: SWS_V2xGn_00098
Upstream requirements: SRS_V2X_26011

[The function shall return V2X_GNTX_E_UNSPECIFIED if the call to LSduR_- V2xGnTransmit() returns E_NOT_OK.|

[SWS_V2xGn_00099] [The function shall return V2X_GNTX_E_MAXPACKETLIFE-TIME if the parameter TxParams.maxPacketLifetime is invalid.|

[SWS_V2xGn_00100] [The function shall return V2X_GNTX_E_TCID if the parameter TxParams.trafficClassId is invalid.]

[SWS_V2xGn_00101] [The function shall return V2X_GNTX_E_MAXGEOAREASIZE if the parameter TxParams.destinationType is V2X_GNDESTINATION_AREA and the parameter TxParams.destinationArea is invalid.]

8.4 Callback notifications

8.4.1 V2xGn_V2xM_EncapConfirmation

[SWS_V2xGn_00118] Definition of callback function V2xGn_V2xM_EncapConfirmation [

Service Name	V2xGn_V2xM_EncapConfirmation	
Syntax	<pre>void V2xGn_V2xM_EncapConfirmation (uint16 EncapReqId)</pre>	
Service ID [hex]	0x0b	
Sync/Async	Asynchronous	
Reentrancy	Non Reentrant	
Parameters (in)	EncapReqId	Unique Id of the packet which has been encapsulated with the signature of the transmitting ITS station
Parameters (inout)	None	
Parameters (out)	None	
Return value	None	
Description	This function is called by the V2xM when an encapsulation has been finished.	
Available via	V2xGn_V2xM.h	



[SWS_V2xGn_00119] [The function $V2xGn_V2xM_EncapConfirmation()$ shall finalize the packet transmission by transmitting the packet to the lower layer.]

[SWS_V2xGn_00120] [If development error detection is enabled: the function shall check that the service $V2xGn_{init}$ () was previously called. If the check fails, the function shall raise the development error $V2xGn_{E_UNINIT}$.

Note: The function requires previous successful transmission request via the API V2xGn_Transmit().

8.4.2 V2xGn_V2xM_DecapConfirmation

[SWS_V2xGn_00122] Definition of callback function V2xGn_V2xM_DecapConfirmation \lceil

Service Name	V2xGn_V2xM_DecapConfirmation	
Syntax	<pre>void V2xGn_V2xM_DecapConfirmation (uint32 DecapReqId, V2x_SecReportType SecReport, uint64 CertificateId, uint32 ItsAid, uint8 SspLength, uint8 SspBits)</pre>	
Service ID [hex]	0x0c	
Sync/Async	Asynchronous	
Reentrancy	Non Reentrant	
Parameters (in)	DecapReqId Unique Id of the received packet which has been decapsulated and which signature has been verified	
	SecReport The security report.	
	CertificateId The identification of the used for verification (by certificate hash)	
	ItsAid The numerical value of the ITS-AID	
	SspLength The length (in octets, up to 31) of the SSP bits	
	SspBits The SSP bits	
Parameters (inout)	None	
Parameters (out)	None	
Return value	None	
Description	This function is called by the V2xM when a decapsulation has been finished.	
Available via	V2xGn_V2xM.h	

[SWS_V2xGn_00123] [The function $V2xGn_V2xM_DecapConfirmation()$ shall continue the processing of a received packet by proceeding with V2xGn protocol operations.]



[SWS_V2xGn_00124] [If development error detection is enabled: the function shall check that the service $V2xGn_{init}$ () was previously called. If the check fails, the function shall raise the development error $V2xGn_{E_UNINIT}$.

Note: The function requires previous successful reception of a packet via the API $V2xGn_RxIndication()$.

8.4.3 V2xGn_RxIndication

[SWS_V2xGn_91001] Definition of callback function V2xGn_RxIndication

Status: DRAFT

ſ

Service Name	V2xGn_RxIndication (draft)	
Syntax	<pre>void V2xGn_RxIndication (PduIdType RxPduId, const PduInfoType* PduInfoPtr)</pre>	
Service ID [hex]	0x42	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different Pdulds. Non reentrant for the same Pduld.	
Parameters (in)	RxPduld ID of the received PDU.	
	PduInfoPtr	Contains the length (SduLength) of the received PDU, a pointer to a buffer (SduDataPtr) containing the PDU, and the MetaData related to this PDU.
Parameters (inout)	None	
Parameters (out)	None	
Return value	None	
Description	Indication of a received PDU from a lower layer communication interface module.	
	Tags: atp.Status=draft	
Available via	V2xGn.h	

[SWS_V2xGn_00103] [The function $V2xGn_RxIndication()$ shall get reception parameters of the Wireless Ethernet Driver for a V2X Packet received via an API call to EthIf_GetBufWRxParams.]

This is done to get access to the wireless specific reception parameters of the packet that is not available through the V2xGn_RxIndication() API.

[SWS_V2xGn_00104] [If development error detection is enabled: the function shall check that the service $V2xGn_{init}$ () was previously called. If the check fails, the function shall raise the development error $V2xGn_{emun}$ []



[SWS_V2xGn_00105]

Status: OBSOLETE

[If development error detection is enabled: the function shall check the parameter <code>DataPtr</code> for being valid. If the check fails, the function shall raise the development error <code>V2XGN_E_PARAM_POINTER</code>.

[SWS_V2xGn_00149] Development error handling for invalid PduInfoPtr

Status: DRAFT

Replaces: SWS_V2xGn_00105 Upstream requirements: SRS_V2X_26011

[If development error detection is enabled: the function shall check the parameter PduInfoPtr for being valid. If the check fails, the function shall raise the development error V2XGN_E_PARAM_POINTER.]

8.4.4 V2xGn_TxConfirmation

[SWS_V2xGn_91002] Definition of callback function V2xGn_TxConfirmation

Status: DRAFT

Γ

Service Name	V2xGn_TxConfirmation (dra	V2xGn_TxConfirmation (draft)		
Syntax	PduIdType TxPduId,	<pre>void V2xGn_TxConfirmation (PduIdType TxPduId, Std_ReturnType result)</pre>		
Service ID [hex]	0x40			
Sync/Async	Synchronous	Synchronous		
Reentrancy	Reentrant for different Pdul	Reentrant for different Pdulds. Non reentrant for the same Pduld.		
Parameters (in)	TxPduld ID of the PDU that has been transmitted.			
	result E_OK: The PDU was transmitted. E_NOT_OK: Transmission of the PDU failed.			
Parameters (inout)	None	None		
Parameters (out)	None	None		
Return value	None			
Description	The lower layer communication interface module confirms the transmission of a PDU, or the failure to transmit a PDU.			
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Available via	V2xGn.h			



[SWS_V2xGn_00150] Development Error handling if V2xGn_TxConfirmation() is indicated while V2XGn module is in uninitialized state

Status: DRAFT

Upstream requirements: SRS_V2X_26011

[If development error detection is enabled: the function shall check that the service V2xGn_Init was previously called. If the check fails, the function shall raise the development error V2XGN_E_UNINIT.]

8.5 Scheduled functions

8.5.1 V2xGn_MainFunction

[SWS_V2xGn_00075] Definition of scheduled function V2xGn_MainFunction [

Service Name	V2xGn_MainFunction	
Syntax	void V2xGn_MainFunction (
	void	
Service ID [hex]	0x08	
Description	Main function of the V2xGn module for periodical execution of protocol operations.	
Available via	SchM_V2xGn.h	

8.6 Expected interfaces

In this chapter all external interfaces required from other modules are listed.

8.6.1 Mandatory Interfaces

This chapter defines all external interfaces which are required to fulfill the core functionality of the module.



[SWS_V2xGn_00076] Definition of mandatory interfaces required by module V2x Gn \lceil

API Function	Header File	Description
Ethlf_GetBufWRxParams	Ethlf.h	Read out values related to the receive direction of the transceiver for a received packet. For example, this could be RSSI or Channel belonging to one single packet.
EthIf_GetBufWTxParams	Ethlf.h	Read out values related to the transmit direction of the transceiver for a transmitted packet.
Ethlf_SetBufWTxParams	Ethlf.h	Set values related to the transmit direction of the transceiver for a specific buffer (packet to be sent). For example, this can be the desired transmit power or the channel belonging to one single packet.
LSduR_V2xGnTransmit (draft)	LSduR_V2xGn.h	Requests transmission of a PDU.
V2xBtp_CopyTxData	V2xBtp.h	This API is called by the V2xGn module to request the V2xBtp module to copy the transmission data to a specific location.
V2xBtp_RxIndication	V2xBtp.h	Via this API, the V2xBtp module gets the data (BTP-PDU) and the GeoNetworking parameters of a received GeoNetworking packet.
V2xM_CalcDistance	V2xM.h	Calculates the distance between two geographical points on earth with the assumption that they are on elevation 0.
V2xM_GetPositionAndTime	V2xM.h	Provides the instantaneous position information.
V2xM_GetRefTimePtr	V2xM.h	Provides a pointer to the time reference of the V2X-Stack.
V2xM_TriggerPseudonymChange	V2xM.h	This function is called by the V2xFac, V2xGn or another entity to change the Pseudonym used by the V2X-Stack, e.g. due to a GeoNetworking address conflict.
V2xM_V2xGn_GetGlobalTxParams	V2xM_V2xGn.h	This function is called by V2xGn to get the current channel busy percentage for the specified channel
V2xM_V2xGn_ReqDecap	V2xM_V2xGn.h	This function is called by the V2xGn to decrypt and verify a message. An asynchronous V2xGn_V2xM_DecapConfirmation call will be used to notify V2xGn of the result.
V2xM_V2xGn_ReqEncap	V2xM_V2xGn.h	This function is called by the V2xGn to sign and/or encrypt a message. An asynchronous V2xGn_V2x M_EncapConfirmation call will be used to notify V2x Gn of the result.
V2xM_V2xGn_SetGlobalRxParams	V2xM_V2xGn.h	This function is called by V2xGn to set the current channel busy percentage for the specified channel

8.6.2 Optional Interfaces

This chapter defines all external interfaces which are required to fulfill an optional functionality of the module.



[SWS_V2xGn_00077] Definition of optional interfaces requested by module V2x Gn \lceil

API Function	Header File	Description
Det_ReportError	Det.h	Service to report development errors.



9 Sequence diagrams

The following sequence diagrams show the interactions between the V2xGn module and its adjacent modules.

Please note that the sequence diagrams are an extension for illustrational purposes to ease understanding of the specification and to support the functional specification described in chapter 7 and API specification described in chapter 8.

Note that all parameters and return types are left out to make the diagrams easier to read and understand.

9.1 V2xGn_RxIndication




Figure 9.1: GeoNetworking Packet Reception

Note: Verification on demand is not anymore supported. The verification of each received packet is mandatory.



9.2 V2xGn_Transmit




Figure 9.2: GeoNetworking Packet Transmission

9.3 V2xGn_V2xM_UpdatePseudonym




Figure 9.3: V2x Pseudonym Update



9.4 V2xGn_MainFunction




Figure 9.4: V2xGn Main Function



10 Configuration specification

Chapter 10.1 specifies the structure (containers) and the parameters of the module V2xGn.

Chapter 10.2 specifies additionally published information of the module V2xGn.

10.1 Containers and configuration parameters

The following chapters summarize all configuration parameters. The detailed meanings of the parameters describe Chapter 7 and Chapter 8.

10.1.1 Variants

[SWS_V2xGn_00078]

Upstream requirements: SRS_BSW_00345

[The V2xGn module only supports VARIANT-PRE-COMPILE.]

10.1.2 V2xGn

[ECUC_V2xGn_00001] Definition of EcucModuleDef V2xGn [

Module Name	V2xGn
Description	Configuration of the V2xGn (Vehicle-2-X Geo Networking) module.
Post-Build Variant Support	false
Supported Config Variants	VARIANT-PRE-COMPILE

Included Containers			
Container Name Multiplicity Scope / Dependency		Scope / Dependency	
V2xGnBeaconService	1	This container contains the GeoNetworking configuration parameters related to the beacon service.	
V2xGnConfig	1	This container contains the configuration parameters and sub containers of the V2xGn module.	
		Tags: atp.Status=draft	
V2xGnGeneral	1	This container specifies the general configuration parameters of the V2xGn module.	
V2xGnPacketForwarding	1	This container contains the GeoNetworking configuration parameters related to packet forwarding.	






Figure 10.1: V2xGeoNetworking

10.1.3 V2xGnGeneral

[ECUC_V2xGn_00002] Definition of EcucParamConfContainerDef V2xGnGeneral

Container Name	V2xGnGeneral
Parent Container	V2xGn
Description	This container specifies the general configuration parameters of the V2xGn module.
Configuration Parameters	



Included Parameters				
Parameter Name	Multiplicity	ECUC ID		
V2xGnDevErrorDetect	1	[ECUC_V2xGn_00006]		
V2xGnltsGnLifetimeLocTE	1	[ECUC_V2xGn_00016]		
V2xGnltsGnLocalGnAddr	1	[ECUC_V2xGn_00009]		
V2xGnltsGnMaxGeoNetworkingHeaderSize	1	[ECUC_V2xGn_00014]		
V2xGnltsGnMaxSduSize	1	[ECUC_V2xGn_00013]		
V2xGnItsGnMinUpdateFrequencyEPV	1	[ECUC_V2xGn_00011]		
V2xGnltsGnPaiInterval	1	[ECUC_V2xGn_00012]		
V2xGnItsGnProtocolVersion	1	[ECUC_V2xGn_00008]		
V2xGnltsGnSnDecapResultHandling	1	[ECUC_V2xGn_00017]		
V2xGnltsGnStationType	1	[ECUC_V2xGn_00015]		
V2xGnMainFunctionPeriod	1	[ECUC_V2xGn_00018]		
V2xGnVersionInfoApi	1	[ECUC_V2xGn_00005]		

		ntainers	

١

[ECUC_V2xGn_00006] Definition of EcucBooleanParamDef V2xGnDevErrorDetect \lceil

Parameter Name	V2xGnDevErrorDetect			
Parent Container	V2xGnGeneral			
Description	Switches the Default Error Tracer (I	Switches the Default Error Tracer (Det) detection and notification ON or OFF.		
	• true: enabled (ON)			
	• false: disabled (OFF)			
Multiplicity	1			
Туре	EcucBooleanParamDef			
Default value	false			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

[ECUC_V2xGn_00016] Definition of EcucFloatParamDef V2xGnItsGnLifetimeLoc TE \cref{TE}

Parameter Name	V2xGnltsGnLifetimeLocTE
Parent Container	V2xGnGeneral
Description	Location table maintenance: Lifetime of an entry in the location table in [s]
Multiplicity	1
Туре	EcucFloatParamDef





Range	[0 65535]		
Default value	20		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time X All Variants		
	Link time -		
	Post-build time –		
Scope / Dependency	scope: local		
	dependency: shall be a multiple of the V2xGnMainFunctionPeriod		

I

[ECUC_V2xGn_00009] Definition of EcucIntegerParamDef V2xGnItsGnLocalGn Addr \lceil

Parameter Name	V2xGnltsGnLocalGnAddr			
Parent Container	V2xGnGeneral	V2xGnGeneral		
Description	64bit GeoNetworking Address.	64bit GeoNetworking Address.		
Multiplicity	1			
Туре	EcucIntegerParamDef			
Range	0 18446744073709551615			
Default value	1			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	-		
	Post-build time	-		
Scope / Dependency	scope: local			

[ECUC_V2xGn_00014] Definition of EcucIntegerParamDef V2xGnItsGnMaxGeo NetworkingHeaderSize \lceil

Parameter Name	V2xGnltsGnMaxGeoNetwor	V2xGnltsGnMaxGeoNetworkingHeaderSize		
Parent Container	V2xGnGeneral	V2xGnGeneral		
Description	Maximum size of GeoNetwo	Maximum size of GeoNetworking header in [Byte].		
Multiplicity	1	1		
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	0 65535	0 65535		
Default value	88	88		
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			



[ECUC_V2xGn_00013] Definition of EcucIntegerParamDef V2xGnItsGnMaxSdu Size \lceil

Parameter Name	V2xGnltsGnMaxSduSize			
Parent Container	V2xGnGeneral			
Description	Maximum size of GN-SDU in [Byte]			
Multiplicity	1			
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	0 65535			
Default value	1398			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	-		
	Post-build time	-		
Scope / Dependency	scope: local			

Ī

[ECUC_V2xGn_00011] Definition of EcucFloatParamDef V2xGnltsGnMinUpdate FrequencyEPV \lceil

Parameter Name	V2xGnItsGnMinUpdateFrequencyEPV			
Parent Container	V2xGnGeneral	V2xGnGeneral		
Description	Minimum update frequency of ego p	Minimum update frequency of ego position vector (EPV) in [s].		
Multiplicity	1	1		
Туре	EcucFloatParamDef			
Range	[0 65535]			
Default value	-			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			
	dependency: shall be a multiple of the V2xGnMainFunctionPeriod			

[ECUC_V2xGn_00012] Definition of EcucIntegerParamDef V2xGnItsGnPaiInterval \lceil

Parameter Name	V2xGnltsGnPaiInterval	
Parent Container	V2xGnGeneral	
Description	Distance related to the confidence interval for latitude and longitude [m]. Used to determine the PAI.	
Multiplicity	1	
Туре	EcucIntegerParamDef	
Range	0 100	





Default value	80		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

1

[ECUC_V2xGn_00008] Definition of EcucIntegerParamDef V2xGnItsGnProtocol Version \lceil

Parameter Name	V2xGnltsGnProtocolVersion		
Parent Container	V2xGnGeneral		
Description	GeoNetworking protocol version as defined in Annex H of [14]		
Multiplicity	1		
Туре	EcucIntegerParamDef		
Range	0 255		
Default value	1		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	-	
	Post-build time	_	
Scope / Dependency	scope: local		

1

[ECUC_V2xGn_00017] Definition of EcucEnumerationParamDef V2xGnItsGnSn DecapResultHandling \lceil

Parameter Name	V2xGnltsGnSnDecapResultHandling		
Parent Container	V2xGnGeneral		
Description	Indicates the handling of the V2xM_ReqDecap result code.		
Multiplicity	1		
Туре	EcucEnumerationParamDef		
Range	V2XGN_NON_STRICT_SEC_ HANDLING	GN packets that are not correctly verified and decrypted can be passed to the upper protocol entity for further processing.	
	V2XGN_STRICT_SEC_ HANDLING	Received GN packets that are not correctly verified and decrypted are always dropped.	
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

ı



[ECUC_V2xGn_00015] Definition of EcucEnumerationParamDef V2xGnltsGnStationType \lceil

Parameter Name	V2xGnltsGnStationType			
Parent Container	V2xGnGeneral			
Description	Station Type used in GeoNetworking protocol, RoadSideUnit (15) not supported by AUTOSAR.			
Multiplicity	1	1		
Туре	EcucEnumerationParamDef	EcucEnumerationParamDef		
Range	V2XFAC_ST_BUS	V2XFAC_ST_BUS –		
	V2XFAC_ST_CYCLIST	-		
	V2XFAC_ST_HEAVYTRUCK	-		
	V2XFAC_ST_LIGHTTRUCK	-		
	V2XFAC_ST_MOPED	-		
	V2XFAC_ST_MOTORCYCLE	-		
	V2XFAC_ST_PASSENGERCAR	-		
	V2XFAC_ST_PEDESTRIAN	-		
	V2XFAC_ST_ SPECIALVEHICLES	-		
	V2XFAC_ST_TRAILER	-		
	V2XFAC_ST_TRAM	-		
	V2XFAC_ST_UNKNOWN	-		
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	-		
Scope / Dependency	scope: local			

1

[ECUC_V2xGn_00018] Definition of EcucFloatParamDef V2xGnMainFunctionPeriod \lceil

Parameter Name	V2xGnMainFunctionPeriod			
Parent Container	V2xGnGeneral			
Description	Specifies the period of main function V2xGn_MainFunction in seconds. V2xGn does not require this information but the BSW scheduler.			
Multiplicity	1	1		
Туре	EcucFloatParamDef			
Range]0 INF[
Default value	0.001			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local		·	



[ECUC_V2xGn_00005] Definition of EcucBooleanParamDef V2xGnVersionInfo Api \lceil

Parameter Name	V2xGnVersionInfoApi			
Parent Container	V2xGnGeneral			
Description	Enable/disables the API for reading the version information of the V2xGn Module.			
	• true: enabled (ON)	• true: enabled (ON)		
	• false: disabled (OFF)	• false: disabled (OFF)		
Multiplicity	1			
Туре	EcucBooleanParamDef			
Default value	false			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			






Figure 10.2: V2XGn_General

10.1.4 V2xGnBeaconService

[ECUC_V2xGn_00003] Definition of EcucParamConfContainerDef V2xGnBeacon Service [

Container Name	V2xGnBeaconService
Parent Container	V2xGn
Description	This container contains the GeoNetworking configuration parameters related to the beacon service.
Configuration Parameters	



Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
V2xGnltsGnBeaconServiceMaxJitter	1	[ECUC_V2xGn_00021]	
V2xGnItsGnBeaconServiceRetransmitTimer	1	[ECUC_V2xGn_00020]	

No Included Containers	
No included containers	

1

[ECUC_V2xGn_00021] Definition of EcucFloatParamDef V2xGnItsGnBeaconServiceMaxJitter \lceil

Parameter Name	V2xGnltsGnBeaconServiceMaxJitter			
Parent Container	V2xGnBeaconService	V2xGnBeaconService		
Description	Maximum beacon jitter [s]. The Jitter is used for the beacon retransmission. The actual jitter value is a random number between 0 and V2xGnltsGnBeaconServiceMaxJitter. The function introduces a random component for the timer to avoid synchronization issues among GeoAdhoc routers.			
Multiplicity	1			
Туре	EcucFloatParamDef			
Range	[0.001 INF]			
Default value	0.75	0.75		
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: local			

1

[ECUC_V2xGn_00020] Definition of EcucFloatParamDef V2xGnItsGnBeaconServiceRetransmitTimer $\ \lceil$

Parameter Name	V2xGnltsGnBeaconServiceRetransmitTimer			
Parent Container	V2xGnBeaconService	V2xGnBeaconService		
Description	Duration of Beacon service retrans	Duration of Beacon service retransmit timer [s].		
Multiplicity	1			
Туре	EcucFloatParamDef			
Range	[0.001 INF]			
Default value	3			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			
	dependency: shall be a multiple of the V2xGnMainFunctionPeriod.			






Figure 10.3: V2xGn_BeaconService

10.1.5 V2xGnPacketForwarding

[ECUC_V2xGn_00004] Definition of EcucParamConfContainerDef V2xGnPacket Forwarding \lceil

Container Name	V2xGnPacketForwarding
Parent Container	V2xGn
Description	This container contains the GeoNetworking configuration parameters related to packet forwarding.
Configuration Parameters	

Included Parameters			
Parameter Name	Multiplicity	ECUC ID	
V2xGnltsGnBcForwardingPacketBufferSize	1	[ECUC_V2xGn_00032]	
V2xGnltsGnCbfMaxTime	1	[ECUC_V2xGn_00029]	
V2xGnltsGnCbfMinTime	1	[ECUC_V2xGn_00028]	
V2xGnltsGnCbfPacketBufferSize	1	[ECUC_V2xGn_00033]	
V2xGnltsGnDefaultHopLimit	1	[ECUC_V2xGn_00022]	
V2xGnltsGnDefaultMaxCommunicationRange	1	[ECUC_V2xGn_00030]	
V2xGnltsGnDefaultPacketLifetime	1	[ECUC_V2xGn_00024]	
V2xGnltsGnDefaultTrafficClass	1	[ECUC_V2xGn_00034]	
V2xGnltsGnDplLength	1	[ECUC_V2xGn_00035]	
V2xGnltsGnGeoAreaLineForwardingUsed	1	[ECUC_V2xGn_00031]	
V2xGnltsGnMaxGeoAreaSize	1	[ECUC_V2xGn_00027]	
V2xGnltsGnMaxPacketDataRate	1	[ECUC_V2xGn_00025]	
V2xGnItsGnMaxPacketDataRateEmaBeta	1	[ECUC_V2xGn_00026]	
V2xGnltsGnMaxPacketLifetime	1	[ECUC_V2xGn_00023]	

No Included Containers



[ECUC_V2xGn_00032] Definition of EcucIntegerParamDef V2xGnItsGnBcForwardingPacketBufferSize \lceil

Parameter Name	V2xGnItsGnBcForwardingPacketBufferSize			
Parent Container	V2xGnPacketForwarding			
Description	Size of BC forwarding packet buffer	Size of BC forwarding packet buffer [Byte].		
Multiplicity	1			
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	0 18446744073709551615	0 18446744073709551615		
Default value	1024000			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

[ECUC_V2xGn_00029] Definition of EcucFloatParamDef V2xGnltsGnCbfMax Time \lceil

Parameter Name	V2xGnltsGnCbfMaxTime			
Parent Container	V2xGnPacketForwarding	V2xGnPacketForwarding		
Description	Maximum duration a GeoNetworking packet shall be buffered in the CBF packet buffer [s]			
Multiplicity	1			
Туре	EcucFloatParamDef			
Range]0 INF[
Default value	0.001			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: local			

1

[ECUC_V2xGn_00028] Definition of EcucFloatParamDef V2xGnItsGnCbfMinTime

Parameter Name	V2xGnltsGnCbfMinTime	
Parent Container	V2xGnPacketForwarding	
Description	Minimum duration a GeoNetworking packet shall be buffered in the CBF packet buffer [s]	
Multiplicity	1	
Туре	EcucFloatParamDef	
Range]0 INF[





Default value	0.001		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

1

[ECUC_V2xGn_00033] Definition of EcucIntegerParamDef V2xGnItsGnCbfPacket BufferSize \lceil

Parameter Name	V2xGnltsGnCbfPacketBufferSize			
Parent Container	V2xGnPacketForwarding			
Description	Size of CBF packet buffer [Byte]			
Multiplicity	1			
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	0 18446744073709551615			
Default value	256000			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

[ECUC_V2xGn_00022] Definition of EcucIntegerParamDef V2xGnItsGnDefault HopLimit \lceil

Parameter Name	V2xGnItsGnDefaultHopLimit			
Parent Container	V2xGnPacketForwarding			
Description	Default hop limit indicating the maximum number of hops a packet travels.			
Multiplicity	1	1		
Туре	EcucIntegerParamDef			
Range	0 255			
Default value	10			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

Ī



[ECUC_V2xGn_00030] Definition of EcucIntegerParamDef V2xGnItsGnDefault MaxCommunicationRange \lceil

Parameter Name	V2xGnItsGnDefaultMaxCommunicationRange			
Parent Container	V2xGnPacketForwarding	V2xGnPacketForwarding		
Description	Default theoretical maximum comm	Default theoretical maximum communication range [m]		
Multiplicity	1	1		
Туре	EcucIntegerParamDef			
Range	0 65535			
Default value	1000			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

1

$[ECUC_V2xGn_00024] \quad Definition \ of \ EcucFloatParamDef \ V2xGnItsGnDefault \\ PacketLifetime \ \lceil$

Parameter Name	V2xGnItsGnDefaultPacketLifeti	V2xGnltsGnDefaultPacketLifetime		
Parent Container	V2xGnPacketForwarding			
Description	Default packet lifetime [s].			
Multiplicity	1	1		
Туре	EcucFloatParamDef	EcucFloatParamDef		
Range	[0 6300]	[0 6300]		
Default value	60	60		
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

١

[ECUC_V2xGn_00034] Definition of EcucIntegerParamDef V2xGnItsGnDefault TrafficClass \lceil

Parameter Name	V2xGnltsGnDefaultTrafficClass
Parent Container	V2xGnPacketForwarding
Description	Forwarding: Default traffic class
Multiplicity	1
Туре	EcucIntegerParamDef
Range	0 255
Default value	0





Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		-

$[ECUC_V2xGn_00035] \ Definition \ of \ EcucInteger Param Def \ V2xGnItsGnDplLength$

Parameter Name	V2xGnltsGnDplLength	V2xGnltsGnDplLength		
Parent Container	V2xGnPacketForwarding	V2xGnPacketForwarding		
Description	Length of Duplicate Packet L	Length of Duplicate Packet List (DPL) per source (clause A.2 of [18])		
Multiplicity	1	1		
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	0 65535	0 65535		
Default value	8	8		
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X		All Variants
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

1

[ECUC_V2xGn_00031] Definition of EcucBooleanParamDef V2xGnltsGnGeoArea LineForwardingUsed \lceil

Parameter Name	V2xGnItsGnGeoAreaLineForwardingUsed			
Parent Container	V2xGnPacketForwarding			
Description	Forwarding of GBC/GAC packet if GeoAdhoc router is located outside the destination GeoArea.			
	• true: enabled (ON)			
	• false: disabled (OFF)	• false: disabled (OFF)		
Multiplicity	1	1		
Туре	EcucBooleanParamDef	EcucBooleanParamDef		
Default value	false			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			



[ECUC_V2xGn_00027] Definition of EcucIntegerParamDef V2xGnItsGnMaxGeo AreaSize \lceil

Parameter Name	V2xGnltsGnMaxGeoAreaSize			
Parent Container	V2xGnPacketForwarding	V2xGnPacketForwarding		
Description	Maximum size of the geographical area for a GBC and GAC packet [km2]. If the geographical area size exceeds the maximum value, the GeoNetworking packet shall not be sent (source) and not be forwarded (forwarder).			
Multiplicity	1			
Туре	EcucIntegerParamDef			
Range	0 18446744073709551615			
Default value	80			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: local			

I

$\begin{tabular}{lll} [ECUC_V2xGn_00025] & Definition & of EcucIntegerParamDef & V2xGnItsGnMax \\ PacketDataRate & \cite{Action} & \cite{Acti$

Parameter Name	V2xGnltsGnMaxPacketDataRate			
Parent Container	V2xGnPacketForwarding			
Description	Maximum packet data rate for a GeoAdhoc router [Byte/s]. If the mean (EMA) packet data rate a of a GeoAdhoc router exceeds the value, packets from this GeoAdhoc router (source or sender) are not forwarded.			
Multiplicity	1			
Туре	EcucIntegerParamDef			
Range	0 4294967295	0 4294967295		
Default value	100000			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: local			

[ECUC_V2xGn_00026] Definition of EcucFloatParamDef V2xGnItsGnMaxPacket DataRateEmaBeta \lceil

Parameter Name	V2xGnltsGnMaxPacketDataRateEmaBeta
Parent Container	V2xGnPacketForwarding
Description	Weight factor for the Exponential Moving Average of the packet data rate PDR in percent.
Multiplicity	1





Туре	EcucFloatParamDef		
Range]0 1]		
Default value	0.9		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

[ECUC_V2xGn_00023] Definition of EcucFloatParamDef V2xGnItsGnMaxPacket Lifetime \lceil

Parameter Name	V2xGnltsGnMaxPacketLifeti	V2xGnItsGnMaxPacketLifetime		
Parent Container	V2xGnPacketForwarding	V2xGnPacketForwarding		
Description	Upper limit of the maximum	lifetime [s]		
Multiplicity	1	1		
Туре	EcucFloatParamDef	EcucFloatParamDef		
Range	[0 6300]	[06300]		
Default value	600	600		
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local	•		

⅃






Figure 10.4: V2xGn_PacketForwarding



10.1.6 V2xGnConfig

[ECUC_V2xGn_00036] Definition of EcucParamConfContainerDef V2xGnConfig

Status: DRAFT

Γ

Container Name	V2xGnConfig
Parent Container	V2xGn
Description	This container contains the configuration parameters and sub containers of the V2xGn module.
	Tags: atp.Status=draft
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
V2xGnEthIfRef	1	[ECUC_V2xGn_00019]

Included Containers		
Container Name	Multiplicity	Scope / Dependency
V2xGnRxPdu	1	Represents the received PDU. This PDU is usually linked to the EthIf via LSduR. It consumes meta data items of the types BROADCAST_8 and ETHERNET_MAC_64. Tags: atp.Status=draft
V2xGnTxPdu	1	Represents the transmitted PDU. This PDU is usually linked to the Ethlf via LSduR. It produces meta data items of the type ETHERNET_MAC_64. Tags: atp.Status=draft

[ECUC_V2xGn_00019] Definition of EcucReferenceDef V2xGnEthIfRef

5 · N				
Parameter Name	V2xGnEthIfRef	V2xGnEthlfRef		
Parent Container	V2xGnConfig	V2xGnConfig		
Description	This represents the referenc V2X-Packets to.	This represents the reference to the Ethernet interface taken to transmit the V2X-Packets to.		
Multiplicity	1	1		
Туре	Symbolic name reference to EthIfController			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: local			



10.1.7 V2xGnRxPdu

[ECUC_V2xGn_00037] Definition of EcucParamConfContainerDef V2xGnRxPdu

Status: DRAFT

Γ

Container Name	V2xGnRxPdu
Parent Container	V2xGnConfig
Description	Represents the received PDU. This PDU is usually linked to the Ethlf via LSduR. It consumes meta data items of the types BROADCAST_8 and ETHERNET_MAC_64.
	Tags: atp.Status=draft
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
V2xGnRxPduId	1	[ECUC_V2xGn_00039]
V2xGnRxPduRef	1	[ECUC_V2xGn_00038]

No Included Containers	
NO Included Containers	

1

[ECUC_V2xGn_00039] Definition of EcucIntegerParamDef V2xGnRxPduId

Status: DRAFT

ſ

Parameter Name	V2xGnRxPduld	V2xGnRxPduId		
Parent Container	V2xGnRxPdu	V2xGnRxPdu		
Description	PDU identifier used for RxIndication	on from L	SduR.	
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	EcucIntegerParamDef (Symbolic I	EcucIntegerParamDef (Symbolic Name generated for this parameter)		
Range	0 65535	0 65535		
Default value	-			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	-		
Scope / Dependency	scope: ECU			
	withAuto = true			



[ECUC_V2xGn_00038] Definition of EcucReferenceDef V2xGnRxPduRef

Status: DRAFT

Parameter Name	V2xGnRxPduRef			
Parent Container	V2xGnRxPdu			
Description	Reference to the global PDU.			
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	Reference to Pdu	Reference to Pdu		
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: ECU			

١

10.1.8 V2xGnTxPdu

[ECUC_V2xGn_00040] Definition of EcucParamConfContainerDef V2xGnTxPdu

Status: DRAFT

Γ

Container Name	V2xGnTxPdu
Parent Container	V2xGnConfig
Description	Represents the transmitted PDU. This PDU is usually linked to the EthIf via LSduR. It produces meta data items of the type ETHERNET_MAC_64.
	Tags: atp.Status=draft
Configuration Parameters	

Included Parameters		
Parameter Name	Multiplicity	ECUC ID
V2xGnTxPduld	1	[ECUC_V2xGn_00041]
V2xGnTxPduRef	1	[ECUC_V2xGn_00042]

No Included Containers	
------------------------	--



[ECUC_V2xGn_00041] Definition of EcucIntegerParamDef V2xGnTxPduId

Status: DRAFT

ı

Parameter Name	V2xGnTxPduId	V2xGnTxPduId		
Parent Container	V2xGnTxPdu	V2xGnTxPdu		
Description	PDU identifier used for TxConfirm	nation fror	n LSduR.	
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	EcucIntegerParamDef (Symbolic	EcucIntegerParamDef (Symbolic Name generated for this parameter)		
Range	0 65535	0 65535		
Default value	-			
Post-Build Variant Value	false	false		
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: ECU			
	withAuto = true			

[ECUC_V2xGn_00042] Definition of EcucReferenceDef V2xGnTxPduRef

Status: DRAFT

Γ

Parameter Name	V2xGnTxPduRef		
Parent Container	V2xGnTxPdu		
Description	Reference to the global PDU.		
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	Reference to Pdu		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	–	
Scope / Dependency	scope: ECU		

١

10.2 Published Information

For details refer to the chapter 10.3 "Published Information" in the General Specification on Basic Software modules [12].



A Not applicable requirements

[SWS_V2xGn_NA_00001]

Upstream requirements: SRS_V2X_00451, SRS_V2X_00322, SRS_V2X_00242, SRS_V2X_-00391, SRS_V2X_00232, SRS_V2X_00245

This requirement references all not applicable access layer requirements

[SWS V2xGn NA 00002]

Upstream requirements: SRS_V2X_00711, SRS_V2X_00291, SRS_V2X_00318, SRS_V2X_00741, SRS_V2X_00301

[This requirement references all not applicable facility layer requirements]

[SWS V2xGn NA 00003]

Upstream requirements: SRS_V2X_00405, SRS_V2X_00413, SRS_V2X_00163, SRS_V2X_00412, SRS_V2X_00407, SRS_V2X_00406, SRS_V2X_00184, SRS_V2X_00174

This requirement references all not applicable security requirements

[SWS_V2xGn_NA_00004]

Upstream requirements: SRS_V2X_00190, SRS_V2X_00193, SRS_V2X_00207, SRS_V2X_00214, SRS_V2X_00693, SRS_V2X_00189, SRS_V2X_00323, SRS_V2X_00511

This requirement references all not applicable other requirements from SRS V2X



B History of Specification Items

Please note that the lists in this chapter also include specification items that have been removed from the specification in a later version. These specification items do not appear as hyperlinks in the document.

B.1 Specification Item History of this document compared to AU-TOSAR R24-11.

B.1.1 Added Specification Items in R24-11

Number	Heading
[ECUC_V2xGn 00036]	Definition of EcucParamConfContainerDef V2xGnConfig
[ECUC_V2xGn 00037]	Definition of EcucParamConfContainerDef V2xGnRxPdu
[ECUC_V2xGn 00038]	Definition of EcucReferenceDef V2xGnRxPduRef
[ECUC_V2xGn 00039]	Definition of EcucIntegerParamDef V2xGnRxPduId
[ECUC_V2xGn 00040]	Definition of EcucParamConfContainerDef V2xGnTxPdu
[ECUC_V2xGn 00041]	Definition of EcucIntegerParamDef V2xGnTxPduId
[ECUC_V2xGn 00042]	Definition of EcucReferenceDef V2xGnTxPduRef
[SWS_V2xGn_00136]	Usage of LSduR_V2xGnTransmit() in context of V2xGn_Transmit()
[SWS_V2xGn_00137]	Transmission request with direct data provision
[SWS_V2xGn_00138]	Meta data handling while containing headers
[SWS_V2xGn_00139]	Meta data handling while not containing headers
[SWS_V2xGn_00140]	Reception parameters derived from PDU
[SWS_V2xGn_00141]	Reception parameters derived from meta data items
[SWS_V2xGn_00143]	Transmission PDU states
[SWS_V2xGn_00144]	Starting transmission request
[SWS_V2xGn_00145]	Finishing transmission request
[SWS_V2xGn_00146]	Aborting transmission request
[SWS_V2xGn_00147]	Error report for aborting the transmission request
[SWS_V2xGn_00148]	Return value if LSduR_V2xGnTransmit() reports E_NOT_OK
[SWS_V2xGn_00149]	Development error handling for invalid PduInfoPtr
[SWS_V2xGn_00150]	Development Error handling if V2xGn_TxConfirmation() is indicated while V2XGn module is in uninitialized state





Number	Heading
[SWS_V2xGn_91000]	Definiton of runtime errors in module V2xGn
[SWS_V2xGn_91001]	Definition of callback function V2xGn_RxIndication
[SWS_V2xGn_91002]	Definition of callback function V2xGn_TxConfirmation

Table B.1: Added Specification Items in R24-11

B.1.2 Changed Specification Items in R24-11

Number	Heading
[ECUC_V2xGn 00001]	Definition of EcucModuleDef V2xGn
[ECUC_V2xGn 00002]	Definition of EcucParamConfContainerDef V2xGnGeneral
[ECUC_V2xGn 00019]	Definition of EcucReferenceDef V2xGnEthIfRef
[SWS_V2xGn_00035]	
[SWS_V2xGn_00042]	Definition of imported datatypes of module V2xGn
[SWS_V2xGn_00076]	Definition of mandatory interfaces required by module V2xGn
[SWS_V2xGn_00082]	
[SWS_V2xGn_00098]	
[SWS_V2xGn_00105]	

Table B.2: Changed Specification Items in R24-11

B.1.3 Deleted Specification Items in R24-11

Number	Heading
[SWS_V2xGn_00071]	Definition of callback function V2xGn_RxIndication

Table B.3: Deleted Specification Items in R24-11



B.2 Constraint Item History of this document compared to AU-TOSAR R24-11.

B.2.1 Added Constraints in R24-11

Number	Heading
[SWS V2xGn CONSTR 00142]	Reception PDU constraint for keeping the local buffer

Table B.4: Added Constraints in R24-11

B.2.2 Changed Constraints in R24-11

none

B.2.3 Deleted Constraints in R24-11

none

B.3 Specification Item History of this document compared to AUTOSAR R23-11.

B.3.1 Added Specification Items in R23-11

Number	Heading
[SWS_V2xGn_00012]	
[SWS_V2xGn_00013]	
[SWS_V2xGn_00020]	
[SWS_V2xGn_00022]	
[SWS_V2xGn_00023]	
[SWS_V2xGn_00026]	
[SWS_V2xGn_00028]	
[SWS_V2xGn_00034]	
[SWS_V2xGn_00035]	
[SWS_V2xGn_00038]	
[SWS_V2xGn_00039]	



Number	Heading
[SWS_V2xGn_00041]	Definiton of development errors in module V2xGn
[SWS_V2xGn_00042]	Definition of imported datatypes of module V2xGn
[SWS_V2xGn_00063]	Definition of datatype V2xGn_TxParamsType
[SWS_V2xGn_00068]	Definition of API function V2xGn_Init
[SWS_V2xGn_00069]	Definition of API function V2xGn_GetVersionInfo
[SWS_V2xGn_00070]	Definition of API function V2xGn_Transmit
[SWS_V2xGn_00071]	Definition of callback function V2xGn_RxIndication
[SWS_V2xGn_00072]	Definition of API function V2xGn_V2xM_PreparePseudonymChange
[SWS_V2xGn_00075]	Definition of scheduled function V2xGn_MainFunction
[SWS_V2xGn_00076]	Definition of mandatory interfaces in module V2xGn
[SWS_V2xGn_00077]	Definition of optional interfaces in module V2xGn
[SWS_V2xGn_00078]	
[SWS_V2xGn_00081]	
[SWS_V2xGn_00082]	
[SWS_V2xGn_00083]	
[SWS_V2xGn_00084]	
[SWS_V2xGn_00090]	
[SWS_V2xGn_00091]	
[SWS_V2xGn_00092]	
[SWS_V2xGn_00093]	
[SWS_V2xGn_00095]	
[SWS_V2xGn_00096]	
[SWS_V2xGn_00098]	
[SWS_V2xGn_00099]	
[SWS_V2xGn_00100]	
[SWS_V2xGn_00101]	
[SWS_V2xGn_00103]	
[SWS_V2xGn_00104]	
[SWS_V2xGn_00105]	
[SWS_V2xGn_00111]	Definition of API function V2xGn_V2xM_CommitPseudonymChange
[SWS_V2xGn_00112]	
[SWS_V2xGn_00113]	
[SWS_V2xGn_00115]	
[SWS_V2xGn_00116]	
[SWS_V2xGn_00118]	Definition of callback function V2xGn_V2xM_EncapConfirmation
[SWS_V2xGn_00119]	
[SWS_V2xGn_00120]	
[SWS_V2xGn_00122]	Definition of callback function V2xGn_V2xM_DecapConfirmation
[SWS_V2xGn_00123]	





Number	Heading
[SWS_V2xGn_00124]	
[SWS_V2xGn_00126]	Definition of API function V2xGn_V2xM_AbortPseudonymChange
[SWS_V2xGn_00127]	
[SWS_V2xGn_00128]	
[SWS_V2xGn_00129]	
[SWS_V2xGn_00130]	
[SWS_V2xGn_00131]	
[SWS_V2xGn_00133]	
[SWS_V2xGn_00134]	
[SWS_V2xGn_00135]	
[SWS_V2xGn_00269]	
[SWS_V2xGn_20169]	
[SWS_V2xGn_20181]	
[SWS_V2xGn_20250]	
[SWS_V2xGn_20251]	
[SWS_V2xGn_20252]	
[SWS_V2xGn_20255]	
[SWS_V2xGn_20258]	
[SWS_V2xGn_20259]	
[SWS_V2xGn_20260]	
[SWS_V2xGn_20262]	
[SWS_V2xGn_20263]	
[SWS_V2xGn_20264]	
[SWS_V2xGn_20265]	
[SWS_V2xGn_20266]	
[SWS_V2xGn_20267]	
[SWS_V2xGn_20268]	
[SWS_V2xGn_20270]	
[SWS_V2xGn_20401]	
[SWS_V2xGn_20414]	
[SWS_V2xGn_20416]	
[SWS_V2xGn_NA 00001]	
[SWS_V2xGn_NA 00002]	
[SWS_V2xGn_NA 00003]	





Number	Heading
[SWS_V2xGn_NA 00004]	

Table B.5: Added Specification Items in R23-11

B.3.2 Changed Specification Items in R23-11

none

B.3.3 Deleted Specification Items in R23-11

none

B.4 Specification Item History of this document compared to AU-TOSAR R22-11.

B.4.1 Added Specification Items in R22-11

Number	Heading
[SWS_V2xGn_00012]	
[SWS_V2xGn_00013]	
[SWS_V2xGn_00020]	
[SWS_V2xGn_00022]	
[SWS_V2xGn_00023]	
[SWS_V2xGn_00026]	
[SWS_V2xGn_00028]	
[SWS_V2xGn_00034]	
[SWS_V2xGn_00035]	
[SWS_V2xGn_00036]	
[SWS_V2xGn_00038]	
[SWS_V2xGn_00039]	
[SWS_V2xGn_00041]	
[SWS_V2xGn_00042]	
[SWS_V2xGn_00063]	
[SWS_V2xGn_00068]	
[SWS_V2xGn_00069]	





Number	Heading
[SWS_V2xGn_00070]	
[SWS_V2xGn_00071]	
[SWS_V2xGn_00072]	
[SWS_V2xGn_00074]	
[SWS_V2xGn_00075]	
[SWS_V2xGn_00076]	
[SWS_V2xGn_00077]	
[SWS_V2xGn_00078]	
[SWS_V2xGn_00081]	
[SWS_V2xGn_00082]	
[SWS_V2xGn_00083]	
[SWS_V2xGn_00084]	
[SWS_V2xGn_00090]	
[SWS_V2xGn_00091]	
[SWS_V2xGn_00092]	
[SWS_V2xGn_00093]	
[SWS_V2xGn_00095]	
[SWS_V2xGn_00096]	
[SWS_V2xGn_00098]	
[SWS_V2xGn_00099]	
[SWS_V2xGn_00100]	
[SWS_V2xGn_00101]	
[SWS_V2xGn_00103]	
[SWS_V2xGn_00104]	
[SWS_V2xGn_00105]	
[SWS_V2xGn_00107]	
[SWS_V2xGn_00111]	
[SWS_V2xGn_00112]	
[SWS_V2xGn_00113]	
[SWS_V2xGn_00115]	
[SWS_V2xGn_00116]	
[SWS_V2xGn_00118]	
[SWS_V2xGn_00119]	
[SWS_V2xGn_00120]	
[SWS_V2xGn_00122]	
[SWS_V2xGn_00123]	
[SWS_V2xGn_00124]	
[SWS_V2xGn_00126]	
[SWS_V2xGn_00127]	





Number	Heading
[SWS_V2xGn_00128]	
[SWS_V2xGn_00129]	
[SWS_V2xGn_00130]	
[SWS_V2xGn_00131]	
[SWS_V2xGn_00133]	
[SWS_V2xGn_00134]	
[SWS_V2xGn_00269]	
[SWS_V2xGn_20169]	
[SWS_V2xGn_20181]	
[SWS_V2xGn_20250]	
[SWS_V2xGn_20251]	
[SWS_V2xGn_20252]	
[SWS_V2xGn_20255]	
[SWS_V2xGn_20258]	
[SWS_V2xGn_20259]	
[SWS_V2xGn_20260]	
[SWS_V2xGn_20262]	
[SWS_V2xGn_20263]	
[SWS_V2xGn_20264]	
[SWS_V2xGn_20265]	
[SWS_V2xGn_20266]	
[SWS_V2xGn_20267]	
[SWS_V2xGn_20268]	
[SWS_V2xGn_20270]	
[SWS_V2xGn_20401]	
[SWS_V2xGn_20414]	
[SWS_V2xGn_20416]	
[SWS_V2xGn_NA 00001]	
[SWS_V2xGn_NA 00002]	
[SWS_V2xGn_NA 00003]	
[SWS_V2xGn_NA 00004]	

Table B.6: Added Specification Items in R22-11

B.4.2 Changed Specification Items in R22-11

none



B.4.3	Deleted	Specification	Items in	R22-11
-------	---------	---------------	----------	--------

none

- B.5 Constraint Item History of this document compared to AU-TOSAR R22-11.
- **B.5.1 Added Constraints in R22-11**

none

B.5.2 Changed Constraints in R22-11

none

B.5.3 Deleted Constraints in R22-11

none