# Understanding Heat Map Colors

## PROBLEM

I'm having trouble understanding the Heat Map colors.

## SOLUTION

Metric Alerts can be defined by the Administrator on the Settings > Metric Alerts page. Here you can enter thresholds for Good, Caution, and Warning for certain metrics. Values below Warning are considered Critical. Heat Map colors for Metrics are shown using the logic below.

- The point at which Caution transitions to Good is assigned the color Green.
- The range of Caution (really Caution to Good) is assigned the range of colors from Amber to Green.
- The point at which Warning transitions to Caution is assigned the color Amber.
- The point at which Critical transitions to Warning is assigned the color Red.

Metric alert values are interpolated within these colors. To be able to fully interpolate colors for the four metric alert ranges, five base colors are needed. It is easiest to understand this by looking at an example of metric alerts:

| Metric Alert | OEE Range | Color Range |
|---|---|---|
| **Good** | 85% and above | Green to Deep Green |
| **Caution** | 65% to 85% | Amber to Green |
| **Warning** | 40% to 65% | Red to Amber |
| **Critical** | 0 to 40% | Deep Red to Red |

The Heat Map below shows the color change for Efficiency if Critical is set to < 40%, Warning is set 40%, Caution is set to 65%, and Good is set to 90%.




## NEED FURTHER ASSISTANCE?

We hope this tech note has fully resolved your questions. If not, call us at +1.630.875.3600 and press "2" for technical support or email us at support@vorne.com.