Technical Publication SC-1100R22

Schematics

Mobile X-Ray Unit

REVISION HISTORY

REVISION	DATE	REASON FOR CHANGE						
Refer to each schematic								

This Document is the english original version, edited and supplied by the manufacturer.

The Revision state of this Document is indicated in the code number shown at the bottom of this page.

ADVISORY SYMBOLS

The following advisory symbols will be used throughout this manual. Their application and meaning are described below.



DANGERS ADVISE OF CONDITIONS OR SITUATIONS THAT IF NOT HEEDED OR AVOIDED WILL CAUSE SERIOUS PERSONAL INJURY OR DEATH.



ADVISE OF CONDITIONS OR SITUATIONS THAT IF NOT HEEDED OR AVOIDED COULD CAUSE SERIOUS PERSONAL INJURY, OR CATASTROPHIC DAMAGE OF EQUIPMENT OR DATA.



Advise of conditions or situations that if not heeded or avoided could cause personal injury or damage to equipment or data.

Note 🕼

Alert readers to pertinent facts and conditions. Notes represent information that is important to know but which do not necessarily relate to possible injury or damage to equipment.

TABLE OF CONTENTS


SCHEMATICS								
GENERATOR								
54302246	BATTERY MOBILE DX-D100 THALES EZ - INNOLUX							
54302206	BATTERY MOBILE DX-D100 VW							
54302244	BATTERY MOBILE DX-D100 CANON							
54302245	BATTERY MOBILE DX-D100 VARIAN							
A3096-02	LF-RAC PCB							
A3000-81	HT Controller PCB (12 bits)							
A3004-09/10/11/12	Filament Control PCB							
A3009-09/10/11/12/15	Interface Control PCB							
A3063-06	IPM Driver PCB							
A3212-01	Charge / Discharge Monitor PCB							
A3024-121	ATP Console CPU PCB							
A3567-04	Brake Board PCB							
A3580-1X_2X	Battery Monitor PCB							
A3580-12	Battery Monitor PCB							
A3580-15	Battery Monitor PCB							
A3179-05	Auto ON/OFF Mobile							
A3179-09/10/11	Low Profile Auto ON/OFF Mobile							
A9504-02	Battery Test PCB							
A9504-03	Battery Test PCB							
A9524-02	Varistor Board PCB							
A3610-03	Interface Varian PCB							
A40122-01	Parking Interface PBA							
ESM (ENERGY STORAGE MODULE) (EMC	C Kit)							
A3578-41	PFC 1000							
A3533-16 (compatible with A3533-06)	Inverter Battery Charger-1 PCB (includes Charger)							
A3534-16 (compatible with A3534-06)	Inverter Battery Charger-2 PCB (includes Charger)							
A3138-03	Isolated Stand-Alone Control PCB							
ESM (ENERGY STORAGE MODULE) (Non	-EMC Kit) (until August 2019)							
A3578-31	PFC 1000							
A3533-04	Inverter Battery Charger-1 PCB (includes Charger)							
A3534-04	Inverter Battery Charger-2 PCB (includes Charger)							
A3138-01	Isolated Stand-Alone Control PCB							
MOBILE SERVO MOVEMENTS								
A3532-16 (compatible with A3532-06)	Motors Battery Charger PCB (includes Charger and DC-DC)							
A3539-01	Digital Motion Control PCB							
OPTIONS								
A3170-01	Radiation Meter Board							
A3653-01	Remote Col Board							
A3709-01	PBA Warning Lights							


SC-1100R22


Mobile X-Ray Unit


Schematics


ii SC-1100R22







































































Note:

The LF-RAC shown in the Generator schematic (543020XX) is a basic documentation, only for interconnection purposes.

Follow this schematic for detailed component information of the LF-RAC board.

																061109
					NAME	DATE	SHEET / OF	DWG:		A3096-02						
1				DRAWING	F. GARCIA	21/09/97			A3090-02							
				REVISED	A. DIAZ	21/09/97	1/1								В	← REV
					Ω		i i				LF	- R/	AC Bo	oard		
В	CN 03/004	F. García	13/01/03	Г	- SE	EDECAL		/	l ina F	Freque	ncv	Rotal	tory A	\node	Cont	roller)
REV	DESCRIPTION	ISSUED BY	DATE					('	Lille	reque	псу	riotai	lory A	inoue	COIII	ionei)

