

SAMPLE MODE 1st layer

	Pad 1-8	Pad 1-8 (Shift)	Pad 1-8 + Trax (move)	MODE + PAD 1-8	REPEAT + PAD 1-8	SYNC + PAD 1-8	BANK button	BANK button (Shift)
Bank A	97,00-07,pp	97,20-27,pp	BB,00-07,pp	9B,48-4f,pp	9B,50-57,pp	9B,58-5f,pp	93,00,pp	93,45,pp
Bank B	97,00-07,pp	97,20-27,pp	BB,00-07,pp	9B,48-4f,pp	9B,50-57,pp	9B,58-5f,pp	94,00,pp	94,45,pp
Bank C	97,00-07,pp	97,20-27,pp	BB,00-07,pp	9B,48-4f,pp	9B,50-57,pp	9B,58-5f,pp	95,00,pp	95,45,pp
Bank D	97,00-07,pp	97,20-27,pp	BB,00-07,pp	9B,48-4f,pp	9B,50-57,pp	9B,58-5f,pp	96,00,pp	96,45,pp
Bank C+D								96,49,pp

	MODE	MODE (Shift)	REPEAT	REPEAT (Shift)	SYNC	SYNC (Shift)	Velocity ON	After Touch ON
Bank A	96,0D,pp	96,52,pp	96,0E,pp	96,53,pp	96,0F,pp	96,54,pp	B7,00-07,pp	A7,00-07,pp
Bank B	96,0D,pp	96,52,pp	96,0E,pp	96,53,pp	96,0F,pp	96,54,pp	B7,00-07,pp	A7,00-07,pp
Bank C	96,0D,pp	96,52,pp	96,0E,pp	96,53,pp	96,0F,pp	96,54,pp	B7,00-07,pp	A7,00-07,pp
Bank D	96,0D,pp	96,52,pp	96,0E,pp	96,53,pp	96,0F,pp	96,54,pp	B7,00-07,pp	A7,00-07,pp
Bank C+D								

	LED 1-5 PAD 1	LED 1-5 PAD 2	LED 1-5 PAD 3	LED 1-5 PAD 4	LED 1-5 PAD 5	LED 1-5 PAD 6	LED 1-5 PAD 7	LED 1-5 PAD 8
Bank A	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank B	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank C	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank D	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp

TRAX-encoder	CC	Note	CC (Shift)	Note (Shift)	Pad 1-8 + Trax (move)
Deck A	B6,00,pp	96,*,pp	B6,45,pp	96,5F,pp	BB,00-07,pp
Deck B	B6,00,pp	96,*,pp	B6,45,pp	96,5F,pp	BB,00-07,pp
Deck C	B6,00,pp	96,*,pp	B6,45,pp	96,5F,pp	BB,00-07,pp
Deck D	B6,00,pp	96,*,pp	B6,45,pp	96,5F,pp	BB,00-07,pp

When switched from any Deck mode to Sampler Mode, the following Note must be adopted for Bank A-D

*: From Deck A	96,20,pp
*: From Deck B	96,21,pp
*: From Deck C	96,22,pp
*: From Deck D	96,23,pp

LOOP-encoder	CC	Note	CC (Shift)	Note (Shift)
Bank A	B6,*,pp	96,*1,pp	B6,*2,pp	96,*3,pp
Bank B	B6,*,pp	96,*1,pp	B6,*2,pp	96,*3,pp
Bank C	B6,*,pp	96,*1,pp	B6,*2,pp	96,*3,pp
Bank D	B6,*,pp	96,*1,pp	B6,*2,pp	96,*3,pp

When switched from any Deck mode to Sampler Mode, the following Note must be adopted for Bank A-D

*: From Deck A	B6,04,pp	*1: From Deck A	96,24,pp	*2: From Deck A	B6,49,pp	*3: From Deck A	96,63,pp
*: From Deck B	B6,05,pp	*1: From Deck B	96,25,pp	*2: From Deck B	B6,4A,pp	*3: From Deck B	96,64,pp
*: From Deck C	B6,06,pp	*1: From Deck C	96,26,pp	*2: From Deck C	B6,4B,pp	*3: From Deck C	96,65,pp
*: From Deck D	B6,07,pp	*1: From Deck D	96,27,pp	*2: From Deck D	B6,4C,pp	*3: From Deck D	96,66,pp

SAMPLE MODE 2st layer

	Pad 1-8	Pad 1-8 (Shift)	Pad 1-8 + Trax (move)	CENSOR + PAD 1-8	SLIP + PAD 1-8	DECK SYNC + PAD 1-8	DECK button	DECK button (Shift)
Deck A	97,60-67,pp	97,40-47,pp	B6,00,pp	97,60-67,pp	97,60-67,pp	97,60-67,pp	93,01,pp	93,47,pp
Deck B	98,60-67,pp	98,40-47,pp	B6,00,pp	98,60-67,pp	98,60-67,pp	98,60-67,pp	94,01,pp	94,47,pp
Deck C	99,60-67,pp	99,40-47,pp	B6,00,pp	99,60-67,pp	99,60-67,pp	99,60-67,pp	95,01,pp	95,47,pp
Deck D	9A,60-67,pp	9A,40-47,pp	B6,00,pp	9A,60-67,pp	9A,60-67,pp	9A,60-67,pp	96,01,pp	96,47,pp
Deck C+D								---*

	CENSOR	CENSOR (Shift)	SLIP	SLIP (Shift)	DECK SYNC	DECK SYNC (Shift)	Velocity ON	Velocity ON (Shift)
Deck A	93,10,pp	93,55,pp	93,11,pp	93,56,pp	93,12,pp	93,57,pp	B7,60-67,pp	B7,40-47,pp
Deck B	94,10,pp	94,55,pp	94,11,pp	94,56,pp	94,12,pp	94,57,pp	B8,60-67,pp	B8,40-47,pp
Deck C	95,10,pp	95,55,pp	95,11,pp	95,56,pp	95,11,pp	95,57,pp	B9,60-67,pp	B9,40-47,pp
Deck D	96,10,pp	96,55,pp	96,11,pp	96,56,pp	96,11,pp	96,57,pp	BA,60-67,pp	BA,40-47,pp
Deck C+D								

	After Touch ON	After Touch ON (Shift)
Deck A	A7,60-67,pp	A7,40-47,pp
Deck B	A8,60-67,pp	A8,40-47,pp
Deck C	A9,60-67,pp	A9,40-47,pp
Deck D	AA,60-67,pp	AA,40-47,pp
Deck C+D		

	LED 1-5 PAD 1	LED 1-5 PAD 2	LED 1-5 PAD 3	LED 1-5 PAD 4	LED 1-5 PAD 5	LED 1-5 PAD 6	LED 1-5 PAD 7	LED 1-5 PAD 8
Bank A	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank B	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank C	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank D	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp

TRAX-encoder	CC	Note	CC (Shift)	Note (Shift)	Pad 1-8 + Trax (move)
Deck A	B6,00,pp	96,20,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck B	B6,00,pp	96,21,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck C	B6,00,pp	96,22,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck D	B6,00,pp	96,23,pp	B6,45,pp	96,5F,pp	B6,00,pp

LOOP-encoder	CC	Note	CC (Shift)	Note (Shift)
Deck A	B6,04,pp	96,24,pp	B6,49,pp	96,63,pp
Deck B	B6,05,pp	96,25,pp	B6,4A,pp	96,64,pp
Deck C	B6,06,pp	96,26,pp	B6,4B,pp	96,65,pp
Deck D	B6,07,pp	96,27,pp	B6,4C,pp	96,66,pp

SLICER MODE 1st layer

	Pad 1-8	Pad 1-8 (Shift)	Pad 1-8 + Trax (move)	CENSOR + PAD 1-8	SLIP + PAD 1-8	DECK SYNC + PAD 1-8	DECK button	DECK button (Shift)
Deck A	97,08-0F,pp	97,28-2F,pp	B6,00,pp	97,08-0F,pp	97,08-0F,pp	97,08-0F,pp	93,01,pp	93,48,pp
Deck B	98,08-0F,pp	98,28-2F,pp	B6,00,pp	98,08-0F,pp	98,08-0F,pp	98,08-0F,pp	94,01,pp	94,48,pp
Deck C	99,08-0F,pp	99,28-2F,pp	B6,00,pp	99,08-0F,pp	99,08-0F,pp	99,08-0F,pp	95,01,pp	95,48,pp
Deck D	9A,08-0F,pp	9A,28-2F,pp	B6,00,pp	9A,08-0F,pp	9A,08-0F,pp	9A,08-0F,pp	96,01,pp	96,48,pp
Deck C+D								---*

	CENSOR	CENSOR (Shift)	SLIP	SLIP (Shift)	DECK SYNC	DECK SYNC (Shift)	Velocity ON	Velocity ON (Shift)
Deck A	93,10,pp	93,55,pp	93,11,pp	93,56,pp	93,12,pp	93,57,pp	B7,08-0F,pp	B7,28-2F,pp
Deck B	94,10,pp	94,55,pp	94,11,pp	94,56,pp	94,12,pp	94,57,pp	B8,08-0F,pp	B8,28-2F,pp
Deck C	95,10,pp	95,55,pp	95,11,pp	95,56,pp	95,11,pp	95,57,pp	B9,08-0F,pp	B9,28-2F,pp
Deck D	96,10,pp	96,55,pp	96,11,pp	96,56,pp	96,11,pp	96,57,pp	BA,08-0F,pp	BA,28-2F,pp
Deck C+D								

	After Touch ON	After Touch ON (Shift)
Deck A	A7,08-0F,pp	A7,28-2F,pp
Deck B	A8,08-0F,pp	A8,28-2F,pp
Deck C	A9,08-0F,pp	A9,28-2F,pp
Deck D	AA,08-0F,pp	AA,28-2F,pp
Deck C+D		

	LED 1-5 PAD 1	LED 1-5 PAD 2	LED 1-5 PAD 3	LED 1-5 PAD 4	LED 1-5 PAD 5	LED 1-5 PAD 6	LED 1-5 PAD 7	LED 1-5 PAD 8
Bank A	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank B	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank C	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank D	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp

TRAX-encoder	CC	Note	CC (Shift)	Note (Shift)	Pad 1-8 + Trax (move)
Deck A	B6,00,pp	96,20,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck B	B6,00,pp	96,21,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck C	B6,00,pp	96,22,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck D	B6,00,pp	96,23,pp	B6,45,pp	96,5F,pp	B6,00,pp

LOOP-encoder	CC	Note	CC (Shift)	Note (Shift)
Deck A	B6,04,pp	96,24,pp	B6,49,pp	96,63,pp
Deck B	B6,05,pp	96,25,pp	B6,4A,pp	96,64,pp
Deck C	B6,06,pp	96,26,pp	B6,4B,pp	96,65,pp
Deck D	B6,07,pp	96,27,pp	B6,4C,pp	96,66,pp

SLICER MODE 2nd layer

	Pad 1-8	Pad 1-8 (Shift)	Pad 1-8 + Trax (move)	CENSOR + PAD 1-8	SLIP + PAD 1-8	DECK SYNC + PAD 1-8	DECK button	DECK button (Shift)
Deck A	97,68-6F,pp	97,48-4F,pp	B6,00,pp	97,68-6F,pp	97,68-6F,pp	97,68-6F,pp	93,01,pp	93,48,pp
Deck B	98,68-6F,pp	98,48-4F,pp	B6,00,pp	98,68-6F,pp	98,68-6F,pp	98,68-6F,pp	94,01,pp	94,48,pp
Deck C	99,68-6F,pp	99,48-4F,pp	B6,00,pp	99,68-6F,pp	99,68-6F,pp	99,68-6F,pp	95,01,pp	95,48,pp
Deck D	9A,68-6F,pp	9A,48-4F,pp	B6,00,pp	9A,68-6F,pp	9A,68-6F,pp	9A,68-6F,pp	96,01,pp	96,48,pp
Deck C+D								---*

	CENSOR	CENSOR (Shift)	SLIP	SLIP (Shift)	DECK SYNC	DECK SYNC (Shift)	Velocity ON	Velocity ON (Shift)
Deck A	93,10,pp	93,55,pp	93,11,pp	93,56,pp	93,12,pp	93,57,pp	B7,68-6F,pp	B7,48-4F,pp
Deck B	94,10,pp	94,55,pp	94,11,pp	94,56,pp	94,12,pp	94,57,pp	B8,68-6F,pp	B8,48-4F,pp
Deck C	95,10,pp	95,55,pp	95,11,pp	95,56,pp	95,11,pp	95,57,pp	B9,68-6F,pp	B9,48-4F,pp
Deck D	96,10,pp	96,55,pp	96,11,pp	96,56,pp	96,11,pp	96,57,pp	BA,68-6F,pp	BA,48-4F,pp
Deck C+D								

	After Touch ON	After Touch ON (Shift)
Deck A	A7,68-6F,pp	A7,48-4F,pp
Deck B	A8,68-6F,pp	A8,48-4F,pp
Deck C	A9,68-6F,pp	A9,48-4F,pp
Deck D	AA,68-6F,pp	AA,48-4F,pp
Deck C+D		

	LED 1-5 PAD 1	LED 1-5 PAD 2	LED 1-5 PAD 3	LED 1-5 PAD 4	LED 1-5 PAD 5	LED 1-5 PAD 6	LED 1-5 PAD 7	LED 1-5 PAD 8
Bank A	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank B	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank C	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank D	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp

TRAX-encoder	CC	Note	CC (Shift)	Note (Shift)	Pad 1-8 + Trax (move)
Deck A	B6,00,pp	96,20,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck B	B6,00,pp	96,21,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck C	B6,00,pp	96,22,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck D	B6,00,pp	96,23,pp	B6,45,pp	96,5F,pp	B6,00,pp

LOOP-encoder	CC	Note	CC (Shift)	Note (Shift)
Deck A	B6,04,pp	96,24,pp	B6,49,pp	96,63,pp
Deck B	B6,05,pp	96,25,pp	B6,4A,pp	96,64,pp
Deck C	B6,06,pp	96,26,pp	B6,4B,pp	96,65,pp
Deck D	B6,07,pp	96,27,pp	B6,4C,pp	96,66,pp

HOT CUE MODE 1st layer

	Pad 1-8	Pad 1-8 (Shift)	Pad 1-8 + Trax (move)	CENSOR + PAD 1-8	SLIP + PAD 1-8	DECK SYNC + PAD 1-8	DECK button	DECK button (Shift)
Deck A	97,10-17,pp	97,30-37,pp	B6,00,pp	97,10-17,pp	97,10-17,pp	97,10-17,pp	93,01,pp	93,46,pp
Deck B	98,10-17,pp	98,30-37,pp	B6,00,pp	98,10-17,pp	98,10-17,pp	98,10-17,pp	94,01,pp	94,46,pp
Deck C	99,10-17,pp	99,30,37,pp	B6,00,pp	99,10-17,pp	99,10-17,pp	99,10-17,pp	95,01,pp	95,46,pp
Deck D	9A,10-17,pp	9A,30-37,pp	B6,00,pp	9A,10-17,pp	9A,10-17,pp	9A,10-17,pp	96,01,pp	96,46,pp
Deck C+D								---*

	CENSOR	CENSOR (Shift)	SLIP	SLIP (Shift)	DECK SYNC	DECK SYNC (Shift)	Velocity ON	Velocity ON (Shift)
Deck A	93,10,pp	93,55,pp	93,11,pp	93,56,pp	93,12,pp	93,57,pp	B7,10-17,pp	B7,30-37,pp
Deck B	94,10,pp	94,55,pp	94,11,pp	94,56,pp	94,12,pp	94,57,pp	B8,10-17,pp	B8,30-37,pp
Deck C	95,10,pp	95,55,pp	95,11,pp	95,56,pp	95,11,pp	95,57,pp	B9,10-17,pp	B9,30,37,pp
Deck D	96,10,pp	96,55,pp	96,11,pp	96,56,pp	96,11,pp	96,57,pp	BA,10-17,pp	BA,30-37,pp
Deck C+D								

	After Touch ON	After Touch ON (Shift)
Deck A	A7,10-17,pp	A7,30-37,pp
Deck B	A8,10-17,pp	A8,30-37,pp
Deck C	A9,10-17,pp	A9,30,37,pp
Deck D	AA,10-17,pp	AA,30-37,pp
Deck C+D		

	LED 1-5 PAD 1	LED 1-5 PAD 2	LED 1-5 PAD 3	LED 1-5 PAD 4	LED 1-5 PAD 5	LED 1-5 PAD 6	LED 1-5 PAD 7	LED 1-5 PAD 8
Bank A	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank B	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank C	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank D	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp

TRAX-encoder	CC	Note	CC (Shift)	Note (Shift)	Pad 1-8 + Trax (move)
Deck A	B6,00,pp	96,20,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck B	B6,00,pp	96,21,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck C	B6,00,pp	96,22,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck D	B6,00,pp	96,23,pp	B6,45,pp	96,5F,pp	B6,00,pp

LOOP-encoder	CC	Note	CC (Shift)	Note (Shift)
Deck A	B6,04,pp	96,24,pp	B6,49,pp	96,63,pp
Deck B	B6,05,pp	96,25,pp	B6,4A,pp	96,64,pp
Deck C	B6,06,pp	96,26,pp	B6,4B,pp	96,65,pp
Deck D	B6,07,pp	96,27,pp	B6,4C,pp	96,66,pp

HOT CUE MODE 2nd layer

	Pad 1-8	Pad 1-8 (Shift)	Pad 1-8 + Trax (move)	CENSOR + PAD 1-8	SLIP + PAD 1-8	DECK SYNC + PAD 1-8	DECK button	DECK button (Shift)
Deck A	97,70-77,pp	97,50-57,pp	B6,00,pp	97,70-77,pp	97,70-77,pp	97,70-77,pp	93,01,pp	93,46,pp
Deck B	98,70-77,pp	98,50-57,pp	B6,00,pp	98,70-77,pp	98,70-77,pp	98,70-77,pp	94,01,pp	94,46,pp
Deck C	99,70-77,pp	99,50-57,pp	B6,00,pp	99,70-77,pp	99,70-77,pp	99,70-77,pp	95,01,pp	95,46,pp
Deck D	9A,70-77,pp	9A,50-57,pp	B6,00,pp	9A,70-77,pp	9A,70-77,pp	9A,70-77,pp	96,01,pp	96,46,pp
Deck C+D								---*

	CENSOR	CENSOR (Shift)	SLIP	SLIP (Shift)	DECK SYNC	DECK SYNC (Shift)	Velocity ON	Velocity ON (Shift)
Deck A	93,10,pp	93,55,pp	93,11,pp	93,56,pp	93,12,pp	93,57,pp	B7,70-77,pp	B7,50-57,pp
Deck B	94,10,pp	94,55,pp	94,11,pp	94,56,pp	94,12,pp	94,57,pp	B8,70-77,pp	B8,50-57,pp
Deck C	95,10,pp	95,55,pp	95,11,pp	95,56,pp	95,11,pp	95,57,pp	B9,70-77,pp	B9,50-57,pp
Deck D	96,10,pp	96,55,pp	96,11,pp	96,56,pp	96,11,pp	96,57,pp	BA,70-77,pp	BA,50-57,pp
Deck C+D								

	After Touch ON	After Touch ON (Shift)
Deck A	A7,70-77,pp	A7,50-57,pp
Deck B	A8,70-77,pp	A8,50-57,pp
Deck C	A9,70-77,pp	A9,50-57,pp
Deck D	AA,70-77,pp	AA,50-57,pp
Deck C+D		

	LED 1-5 PAD 1	LED 1-5 PAD 2	LED 1-5 PAD 3	LED 1-5 PAD 4	LED 1-5 PAD 5	LED 1-5 PAD 6	LED 1-5 PAD 7	LED 1-5 PAD 8
Bank A	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank B	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank C	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank D	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp

TRAX-encoder	CC	Note	CC (Shift)	Note (Shift)	Pad 1-8 + Trax (move)
Deck A	B6,00,pp	96,20,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck B	B6,00,pp	96,21,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck C	B6,00,pp	96,22,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck D	B6,00,pp	96,23,pp	B6,45,pp	96,5F,pp	B6,00,pp

LOOP-encoder	CC	Note	CC (Shift)	Note (Shift)
Deck A	B6,04,pp	96,24,pp	B6,49,pp	96,63,pp
Deck B	B6,05,pp	96,25,pp	B6,4A,pp	96,64,pp
Deck C	B6,06,pp	96,26,pp	B6,4B,pp	96,65,pp
Deck D	B6,07,pp	96,27,pp	B6,4C,pp	96,66,pp

HOT LOOP MODE 1st layer

	Pad 1-8	Pad 1-8 (Shift)	Pad 1-8 + Trax (move)	CENSOR + PAD 1-8	SLIP + PAD 1-8	DECK SYNC + PAD 1-8	DECK button	DECK button (Shift)
Deck A	97,18-1F,pp	97,38-3F,pp	B6,00,pp	97,18-1F,pp	97,18-1F,pp	97,18-1F,pp	93,01,pp	93,48,pp
Deck B	98,18-1F,pp	98,38-3F,pp	B6,00,pp	98,18-1F,pp	98,18-1F,pp	98,18-1F,pp	94,01,pp	94,48,pp
Deck C	99,18-1F,pp	99,38-3F,pp	B6,00,pp	99,18-1F,pp	99,18-1F,pp	99,18-1F,pp	95,01,pp	95,48,pp
Deck D	9A,18-1F,pp	9A,38-3F,pp	B6,00,pp	9A,18-1F,pp	9A,18-1F,pp	9A,18-1F,pp	96,01,pp	96,48,pp
Deck C+D								---*

	CENSOR	CENSOR (Shift)	SLIP	SLIP (Shift)	DECK SYNC	DECK SYNC (Shift)	Velocity ON	Velocity ON (Shift)
Deck A	93,10,pp	93,55,pp	93,11,pp	93,56,pp	93,12,pp	93,57,pp	B7,18-1F,pp	B7,38-3F,pp
Deck B	94,10,pp	94,55,pp	94,11,pp	94,56,pp	94,12,pp	94,57,pp	B9,18-1F,pp	B8,38-3F,pp
Deck C	95,10,pp	95,55,pp	95,11,pp	95,56,pp	95,11,pp	95,57,pp	B9,18-1F,pp	B9,38-3F,pp
Deck D	96,10,pp	96,55,pp	96,11,pp	96,56,pp	96,11,pp	96,57,pp	BA,18-1F,pp	BA,38-3F,pp
Deck C+D								

	After Touch ON	After Touch ON (Shift)
Deck A	A7,18-1F,pp	A7,38-3F,pp
Deck B	A8,18-1F,pp	A8,38-3F,pp
Deck C	A9,18-1F,pp	A9,38-3F,pp
Deck D	AA,18-1F,pp	AA,38-3F,pp
Deck C+D		

	LED 1-5 PAD 1	LED 1-5 PAD 2	LED 1-5 PAD 3	LED 1-5 PAD 4	LED 1-5 PAD 5	LED 1-5 PAD 6	LED 1-5 PAD 7	LED 1-5 PAD 8
Bank A	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank B	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank C	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank D	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp

TRAX-encoder	CC	Note	CC (Shift)	Note (Shift)	Pad 1-8 + Trax (move)
Deck A	B6,00,pp	96,20,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck B	B6,00,pp	96,21,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck C	B6,00,pp	96,22,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck D	B6,00,pp	96,23,pp	B6,45,pp	96,5F,pp	B6,00,pp

LOOP-encoder	CC	Note	CC (Shift)	Note (Shift)
Deck A	B6,04,pp	96,24,pp	B6,49,pp	96,63,pp
Deck B	B6,05,pp	96,25,pp	B6,4A,pp	96,64,pp
Deck C	B6,06,pp	96,26,pp	B6,4B,pp	96,65,pp
Deck D	B6,07,pp	96,27,pp	B6,4C,pp	96,66,pp

HOT LOOP MODE 2nd layer

	Pad 1-8	Pad 1-8 (Shift)	Pad 1-8 + Trax (move)	CENSOR + PAD 1-8	SLIP + PAD 1-8	DECK SYNC + PAD 1-8	DECK button	DECK button (Shift)
Deck A	97,78-7F,pp	97,58-5F,pp	B6,00,pp	97,78-7F,pp	97,78-7F,pp	97,78-7F,pp	93,01,pp	93,48,pp
Deck B	98,78-7F,pp	98,58-5F,pp	B6,00,pp	98,78-7F,pp	98,78-7F,pp	98,78-7F,pp	94,01,pp	94,48,pp
Deck C	99,78-7F,pp	99,58-5F,pp	B6,00,pp	99,78-7F,pp	99,78-7F,pp	99,78-7F,pp	95,01,pp	95,48,pp
Deck D	9A,78-7F,pp	9A,58-5F,pp	B6,00,pp	9A,78-7F,pp	9A,78-7F,pp	9A,78-7F,pp	96,01,pp	96,48,pp
Deck C+D								---*

	CENSOR	CENSOR (Shift)	SLIP	SLIP (Shift)	DECK SYNC	DECK SYNC (Shift)	Velocity ON	Velocity ON (Shift)
Deck A	93,10,pp	93,55,pp	93,11,pp	93,56,pp	93,12,pp	93,57,pp	B7,78-7F,pp	B7,58-5F,pp
Deck B	94,10,pp	94,55,pp	94,11,pp	94,56,pp	94,12,pp	94,57,pp	B8,78-7F,pp	B8,58-5F,pp
Deck C	95,10,pp	95,55,pp	95,11,pp	95,56,pp	95,11,pp	95,57,pp	B9,78-7F,pp	B9,58-5F,pp
Deck D	96,10,pp	96,55,pp	96,11,pp	96,56,pp	96,11,pp	96,57,pp	BA,78-7F,pp	BA,58-5F,pp
Deck C+D								

	After Touch ON	After Touch ON (Shift)
Deck A	A7,78-7F,pp	A7,58-5F,pp
Deck B	A8,78-7F,pp	A8,58-5F,pp
Deck C	A9,78-7F,pp	A9,58-5F,pp
Deck D	AA,78-7F,pp	AA,58-5F,pp
Deck C+D		

	LED 1-5 PAD 1	LED 1-5 PAD 2	LED 1-5 PAD 3	LED 1-5 PAD 4	LED 1-5 PAD 5	LED 1-5 PAD 6	LED 1-5 PAD 7	LED 1-5 PAD 8
Bank A	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank B	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank C	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp
Bank D	9B,20-24,pp	9B,25-29,pp	9B,2A-2E,pp	9B,2F-33,pp	9B,34-38,pp	9B,39-3D,pp	9B,3E-42,pp	9B,43-47,pp

TRAX-encoder	CC	Note	CC (Shift)	Note (Shift)	Pad 1-8 + Trax (move)
Deck A	B6,00,pp	96,20,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck B	B6,00,pp	96,21,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck C	B6,00,pp	96,22,pp	B6,45,pp	96,5F,pp	B6,00,pp
Deck D	B6,00,pp	96,23,pp	B6,45,pp	96,5F,pp	B6,00,pp

LOOP-encoder	CC	Note	CC (Shift)	Note (Shift)
Deck A	B6,04,pp	96,24,pp	B6,49,pp	96,63,pp
Deck B	B6,05,pp	96,25,pp	B6,4A,pp	96,64,pp
Deck C	B6,06,pp	96,26,pp	B6,4B,pp	96,65,pp
Deck D	B6,07,pp	96,27,pp	B6,4C,pp	96,66,pp

SysEx messages

FO 0A 40 F7	Will be sent when slave TM1 is plugged in via link cable
FO 0A 00 F7	Enable Deck 3&4
FO 0A 01 F7	Disable Deck 4
FO 0A 02 F7	Disable Deck 3&4

PERFORMANCE MODE buttons

	Sampler 1 st layer	Sampler 2 nd	Slicer 1 st	Slicer 2 nd	Hot Cue 1 st	Hot 2 nd	Hot Loop 1 st	Hot Loop 2 nd
Deck A	93,05,pp	93,09,pp	93,06,pp	93,0A,pp	93,07,pp	93,0B,pp	93,08,pp	93,0C,pp
Deck B	94,05,pp	94,09,pp	94,06,pp	94,0A,pp	94,07,pp	94,0B,pp	94,08,pp	94,0C,pp
Deck C	95,05,pp	95,09,pp	95,06,pp	95,0A,pp	95,07,pp	95,0B,pp	95,08,pp	95,0C,pp
Deck D	96,05,pp	96,07,pp	96,06,pp	96,0A,pp	96,07,pp	96,0B,pp	96,09,pp	96,0C,pp

Long press HOT CUE Button

93,44,pp

Sampler Mode 1st layer TRIGGER

93,0D,pp
94,0D,pp
95,0D,pp
96,0D,pp

Notes

MIDI IN = MIDI OUT
Velocity and After Touch is always ON within Sampler Mode 2nd layer
Hardware-based = LED will change by hardware when switching between Deck buttons.
MIDI triggered = LED will light up by MIDI only. LED status will also be memorized in the background.
Hardware + MIDI = Specifically for Sampler mode 1st layer. Pressing buttons will change Bank A-D. Additionally when dedicated Bank button MIDI message is received, Bank will change too.
Default Start Up Mode = HOT CUE 1st layer
All Decks remember it's current/last used Performance Mode

Bank/Deck-buttons behaviour

NON-Shift-layer	Bank/Deck Buttons 1-4
Sample Mode 1st layer	Hardware-based + MIDI triggered (Switch Bank on incoming MIDI message)
NON-Sample Mode 1st layer	Hardware-based

SHIFT-layer	Bank/Deck Buttons 1-4
Sample Mode 1st layer	MIDI-triggered
NON-Sample Mode 1st layer	MIDI-triggered