

Functions:

- (1) Power on: When switched off, press and hold the multifunction button for seconds. A voice prompt "power on" will confirm the same. The red and blue LEDs will flash.
- (2) Power off: In any mode, press and hold the multifunction button for 5 seconds voice tone "power off" will confirm the same. The red and blue LED's will flash second before the device will turn off.
- (3) Play/Pause: Tap the multifunction button once to play/pause music.
- (4) Volume up: Tap the volume "+" buttons in steps to increase the volume. A beep will indicate maximum volume.
- (5) Volume down: Tap the volume "-" button in steps to decrease the volume. A will indicate minimum volume.
- (6) Answer/End call: Tap the multifunction button once when answering or ending a call to complete the action.
- (7) Reject call: Press and hold the multifunction button for 2 seconds when receiving a call to reject it. A beep will indicate this.
- (8) Previous Track: To go to the previous track, press and hold the "-" button for 2 seconds.
- (9) Next Track: To skip to the next track, press and hold the "+" button for 2 seconds.
- (10) Voice Assistant : Click the Multi-function Button for 3 times to activate Voice Assistant.

To Charge:

Use a micro USB charging cable to charge the earphone through either a laptop or an adaptor.

- (1) Low Battery: The remaining talk time is less than 10 minutes. There will be a 'tone' and a reminder every minute.
- (2) Charging: The red light is steady (please note that the earphone cannot be turn on when charging).
- (3) Fully charged: the blue light is steady.