NICE100+ Integrated Open-Loop Elevator Controller User Guide



Table of Contents

Preface	5
Introduction	7
Safety Instructions	11
Safety Disclaimer	12
Safety Levels and Definitions	12
Safety Instructions	12
Safety signs	14
1 Product Information	19
1.1 Model and Nameplate	20
1.2 Technical Data	20
1.3 Technical Specifications	21
1.4 Optional Parts	22
2 Installation and Wiring	23
2.1 Preparation	24
2.1.1 Environment Requirements	24
2.1.2 Space Requirements	24
2.2 Product Dimensions	24
2.3 Installation Instructions	25
2.4 Wiring of main control board (MCB) Terminals	26
2.5 Installation of Shaft Position Switches	29
2.5.1 Installation of Leveling Switches	29
2.5.2 Installation of Deceleration Switches	30
2.5.3 Installation of Slow-Down Switches	31
2.5.4 Installation of Limit Switches	32
2.5.5 Installation of Final Limit Switches	32
2.6 Wiring Diagram of the Integrated Control System	33
3 Use of the Operating Panel	34
3.1 LED Operating Panel	35
3.2 Operating Panel Elements	35
3.2.1 Function indicators	35
3.2.2 Keys	36
3.3 Parameter Menu Description	37

4 System Commissioning	39
4.1 Safety Checks Before Commissioning	40
4.2 Motor Commissioning	41
4.2.1 Asynchronous motor static auto-tuning mode 2	41
4.3 Shaft auto-tuning (only for motor wheel pulse type)	41
4.4 Riding Comfort Adjustment	42
4.4.1 Performance Adjustment of System Control	42
4.4.2 Mechanical Factors riding Comfort	43
4.5 Leveling Accuracy Adjustment	43
5 Parameter Description	45
5.1 Parameter Description	46
5.2 Parameter Groups	46
Group F0: Basic parameters	46
Group F1: Motor parameters	47
Group F2: Vector control parameters	47
Group F3: Running control parameters	49
Group F4: Floor parameters	50
Group F5: Terminal input parameters	52
Group F6: Elevator basic parameters	58
Group F7: Terminal output parameters	61
Group F8: Advanced function parameters	62
Group F9: Time parameters	63
Group FA: Keypad setting parameters	63
Group FB: Door parameters	71
Group FC: Protection function parameters	72
Group FD: Communication parameters	74
Group FE: Elevator function parameters	75
Group Fr: Leveling adjustment parameters	76
Group FP: User parameters	77
Group E0: The first set of detailed fault information	77
6 Troubleshooting	79
6.1 Description of Fault Levels	80
6.2 Fault Information and Troubleshooting	81

Appendix A Electromagnetic Compatibility	87
A1 Definition of Terms	88
A2 Introduction to EMC Standard	88
A2.1 EMC Requirements for Installation Environment	88
A22 Requirements on Satisfying the EMC Directive	88
A3 Selection of Peripheral EMC Devices	89
A.3.1 Installation of EMC Input Filter on Power Input Side	89
A32 Installation of AC Input Reactor on Power Input Side	89
A4 Shielded Cable	90
A4.1 Requirements for Shielded Cable	90
A42 Installation Requirements	91
A4.3 Cabling Requirements	91
A5 Solutions to EMC Interference	92
Revision History	93



Thank you for purchasing the NICE100+ integrated open-loop elevator controller.

NICE100+ is a new-generation integrated elevator controller independently developed and manufactured by Inovance, by optimizing the MD380L open loop elevator AC drive. NICE100+ has the following advantages: a) Using high-performance vector control technology, it supports both open loop vector control and V/F control; b) It drives an AC asynchronous motor without the need of an encoder. NICE100+ serves a maximum of 12 floors full collective with extension board and is widely used in low rise elevators.

This manual provides guidance on correct use of the NICE100+, including information on product features, safety precautions, construction and installation, operation, maintenance, and troubleshooting. Read and understand the manual before using the product, keep it carefully for future operation and maintenance.

The personnel who involve in system installation, commissioning, and maintenance must receive necessary trainings on safety and use of the product, understand this manual thoroughly, and have related experience before performing commissioning and maintenance tasks.

NOTE

- For illustration purpose, the drawings in the manual are sometimes shown without covers or protective guards. Remember to install the covers or protective guards as specified before using the product and operate in accordance with the instructions.
- The drawings in the manual are for illustration only. Actual products may vary.
- The instructions are subject to change, without notice, due to product upgrade, specification modification as well as efforts to increase the accuracy and convenience of the manual.
- Contact our agents or customer service center if you need a new user manual or have problems during the use.

Check the delivered product:

Upon unpacking, check:

- ♦ Whether the nameplate model and controller ratings are consistent with your order.
- ♦ Whether the controller is damaged during transportation. If you find any omission or damage, contact your supplier or Inovance immediately.

For first-time use:

For users who use this product for the first time, read this manual carefully. If you have any problem concerning the functions or performance, contact the technical support personnel of Inovance to ensure correct use.



1. Connection to peripheral devices




Figure 1. Connection diagram between NICE100+ and peripheral devices



◆ The preceding figure is a schematic diagram showing the interconnection between the controller and its peripheral devices.

Ground

- Some of the peripheral devices are obtainable through Inova. Contact our commercial staff if you need.
- ♦ The controller must be installed inside a power distribution box. Grounding is required for the power distribution box.

2. NICE100+ Basic Configuration

NICE100+ Basic Configuration Standard 6-Floors Full Collective, Expansion 12-Floors Full Collective



-9--9-



Safety Disclaimer	14
Safety Levels and Definitions	14
Safety Instructions	14
Safety signs	16

-11-

Safety Instructions Safety Disclaimer

Safety Disclaimer

 Read and comply with the safety instructions before you are performing any installation, operation, and maintenance on the equipment.

- To ensure the safety of humans and the device, follow the marks on the device and all the safety instructions in this
 document
- ◆ The "CAUTION", "WARNING", and "DANGER" are only supplements to the safety instructions.
- Use this equipment based on the designated environment requirements. Damages caused by improper usage are not covered by warranty.
- ◆ The company shall take no responsibility of any personal injuries or property damages caused by improper usage.

Safety Levels and Definitions

- 1. The Danger Danger sign indicates that failure to comply with the notice will result in server personal injuries or even death.
- 2. The Warning "Warning" sign indicates that failure to comply with the notice may result in server personal injuries or even death.
- 3. The Caution "Caution" sign indicates that failure to comply with the notice may result in minor or moderate personal injuries or damage to the equipment.

Safety Instructions

Unpacking



- ♦ Check whether the packing is intact and whether there is damage, water seepage, damp, and deformation.
- ♦ Unpack the package following the package sequence. Do not hit the package with force.
- ♦ Check whether there are damages, rust, or injuries on the surface of the product or product accessories.
- $\ \, \ \, \ \, \ \, \ \, \ \,$ Check whether the number of packing materials is consistent with the packing list.



- ♦ Do not install the equipment if you find damages, corrosions, or indications of use on the product or accessories.
- ♦ Do not install the equipment if you find water seepage, component missing or damage upon unpacking.
- ◆ Do not install the equipment if you find the packing list does not conform to the equipment you received.

Storage and Transportation



- Store this equipment based on the storage and transportation requirements on humidity and temperature.
- Avoid transporting the equipment in environment such as water splashing, rain, direct sunlight, high voltage, strong magnetic field, and strong vibration.
- Avoid storing the product for more than 3 months, long-term storage shall require stricter protection and necessary inspections.
- ♦ Pack the product strictly before you transport. Use a sealed box for long-distance transportation.
- Never transport this product with products or materials that harm or have negative impacts on this product.

Safety Instructions Safety Instructions



- Use professional loading and unloading equipment to carry large-scale or heavy products.
- ◆ When carry this equipment with bear hand, hold the product casing firmly with care preventing from parts falling, otherwise, it may result in personal jury or equipment damages.
- Handle the products with care, mind your steps, otherwise, it may result in personal juries or equipment damages.
- Never stand or stay below the equipment when the equipment is lifted by hoisting equipment.

Installation



- Read and comply with the safety instructions before performing installation.
- Do not modify this product.
- Do not rotate the product components or the fixed bolts and red marked bolts on product components.
- Do not install this product in places where there is strong electric field or strong magnetic field.
- When this product is installed in a cabinet or terminal device, the cabinet or terminal device must be equipped with protective shell. The proof class must comply with relevant IEC standards and local regulations.



- Do not allow non-professionals to perform product installation, wiring, maintenance, inspection or parts replacement.
- The installation, wiring, maintenance, inspection and parts replacement are intended to be performed by professional personnel only.
- ◆ Installation personnel must be familiar with product installation requirements and relevant technical materials.
- ◆ If you need to install transformer or other strong electromagnetic interference equipment, install shielding device at the same time to avoid product malfunction.

Wiring



Danger

- Do not allow non-professionals to perform product installation, wiring, maintenance, inspection or parts replacement.
- Never perform wiring at power-on. Failure to comply may result in electric shock.
- ◆ Cut off all power supplies before wiring. Wait at least 10 minutes after power-off so that residual voltage can discharge safely. Wait at least 10 minutes after power-off so that residual voltage can discharge safely.
- ◆ Make sure that the equipment is reliably grounded. Failure to comply may result in electric shock.
- Following the proper electrostatic discharge (ESD) procedures, and wear an anti-static wrist strap to perform wiring. Failure to comply may result in damage to the equipment or the internal circuit the product.

Warning

- Never connect the power cable with the product output terminals (U, V, W.). Failure to comply may result in equipment damage or
- When connecting driving equipment with the motor, make sure the phase sequence of the drive and motor are consistent to prevent motor reverse rotation.
- The cable used in wiring must conform to the wire diameter and shielding requirements, the shielding layer of the shielded cable must be reliably grounded at one end.
- After wiring, make sure there are no fallen screws or exposed wire inside the cabinet or product.

Power-on



Danger

- Before power-on, make sure that the equipment or products are intact, all wiring are safely connected, and the motor device allows a
- Before power-on, check if the power supply meets the equipment requirements, avoid equipment damage or fire.
- At power-on, equipment or product may start running abruptly, keep away from mechanical device.
- After power-on, never open the cabinet door or the protective shell to avoid electric shock.
- Never touch any terminals at power-on to avoid electric shock.
- Never dismantle the equipment or remove any parts from the equipment at power-on to avoid electric shock.

Operation

Safety signs Safety Instructions



Danger

- Never touch any terminals during operation. Failure to comply may result in electric shock.
- Never dismantle the equipment or remove any parts from the equipment during operation. Failure to comply may result in electric shock.
- Never touch the equipment shell, fan or resistor for temperature detection. Failure to comply may result in burn!
- Do not allow non-professional technicians to detect signals during operation. Failure to comply may result in equipment damage even
 personal injuries.



- Prevent metal or other objects from falling into the device during operation, failure to comply may result in equipment damage.
- ◆ Never use contactors to start or stop the equipment. Failure to comply may result in damage to the equipment!

Maintenance



Danger

- Do not allow non-professionals to perform product installation, wiring, maintenance, inspection or parts replacement.
- ♦ Never perform maintenance at power-on. Failure to comply may result in electric shock.
- ♦ Before maintenance, wait at least 10 minutes after power-off so that residual voltage can discharge safely.



 Following the equipment repair and maintenance requirements to perform routine and periodical inspection and maintenance, and keep a maintenance record.

Repair



Danger

- Do not allow non-professionals to perform product installation, wiring, maintenance, inspection or parts replacement.
- Never perform any inspection or maintenance operations at power-on. Failure to comply may result in electric shock.
- ♦ Before inspection or maintenance, wait at least 10 minutes so that residual voltage can discharge safely.



- Following the terms defined in the warranty agreement to repair the product.
- When the equipment has a fault or is damaged, follow the instructions of the professionals to perform troubleshooting or maintenance, and keep a maintenance record.
- Following the instructions of the quick-wear parts instructions to replace the damaged parts.
- Do not continue to use the damaged equipment. Failure to comply may result in worse damages.
- ♦ After replacement, perform a re-check of the wiring and specifications.

Disposal




- Following the local regulations or standards to dispose the retired equipment or products. Failure to comply may result in property damage or even death.
- Following the industry waste disposal standards to recycle the scrapped equipment to avoid environmental pollution.

Safety signs

To guarantee safety operations and maintenance of the equipment, follow the safety stickers on the equipment and products. Do not stain or remove the safety signs. Instructions of safety signs are as follows:

Safety Instructions Safety signs



1 General Precautions

Requirements on residual current device (RCD)


The controller generates high leakage current during running, which flows through the protective earthing conductor. Install a type-B RCD at primary side of the power supply. When selecting the RCD, you should consider the transient and steady-state leakage current to ground that may be generated at startup and during running of the controller. You can select a specialized RCD with the function of suppressing high harmonics or a general-purpose RCD with relatively large residual current.

High leakage current warning

The controller generates high leakage current during running, which flows through the protective earthing conductor. Earth connection must be done before connection of power supply. Earthing shall comply with local regulations and related IEC standards.

Motor insulation test

Perform the insulation test when the motor is used for the first time, or when it is re-used after being stored for a long time, or in a regular check-up, to prevent the poor insulation of motor windings from damaging the controller. The motor must be disconnected from the controller during the insulation test. A 500-V Mega-Ohm meter is recommended for the test. Ensure that the insulation resistance is not less than 5 M Ω .



Thermal protection of motor


If the rated capacity of the motor selected does not match that of the controller, especially when the rated power of the controller is greater than that of the motor, adjust the motor protection parameters on the operating panel of the controller or install a thermal relay for the motor circuit for protection.

Motor heat and noise

The output of the controller is pulse width modulation (PWM) wave with certain harmonic wave, and therefore, the motor temperature rise, noise, and vibration are slightly greater than those at running with the mains frequency.


♦ Voltage-sensitive device or capacitor on the output side of the controller

The controller outputs PWM waves. Do not install the capacitor for improving power factor or lightning protection voltagesensitive resistor on the output side of the controller. These may cause transient overcurrent or even damage to the controller. Safety signs Safety Instructions



Contactor on the input and output sides of the controller

When a contactor is installed between the input side of the controller and the power supply, the controller must not be started or stopped by turning on or off the contactor. When a contactor is installed between the output side of the controller and the motor, do not turn off the contactor when the controller is active. Otherwise, modules inside the controller may be damaged.



Use outside the rated voltage

The controller must not be used outside the allowable voltage range specified in this manual. Otherwise, components inside the controller may be damaged. If required, use a corresponding voltage step-up or step-down device.


♦ Surge suppressor

The controller has a built-in voltage dependent resistor (VDR) for suppressing the surge voltage generated when the inductive loads around the controller are switched on or off. If the inductive loads generate very high surge voltage, use a surge suppressor for the inductive load or use a surge suppressor together with a diode.

Do not connect the surge suppressor on the output side of the controller.

Altitude and de-rating

In places where the altitude is above 1000 m and the cooling effect reduces due to thin air, it is necessary to de-rate the controller. Contact Inovance for technical support.



Ambient temperature and de-rating

The controller is designed to operate under an ambient temperature between -10°C and +50°C. When the ambient temperature is above 40°C, the controller must be de-rated 1.5% every 1°C. The maximum working temperature is 50°C.

Safety Instructions Safety signs

Disposal

The electrolytic capacitors on the main circuits and PCB may explode when they are burnt. Poisonous gas is generated when the plastic parts are burnt. Treat them as ordinary industrial waste.

Adaptable motor

The controller is adaptable to squirrel-cage asynchronous motor. Select a proper controller according to motor nameplate.

The default parameters configured inside the controller are squirrel-cage asynchronous motor parameters. It is still necessary to perform motor auto-tuning or modify the default values based on actual conditions. Otherwise, the running effect and protection performance will be affected.

Precautions on selecting residual-current circuit breaker (RCCB)

Tripping may be caused if an improper RCCB is selected when the controller drives the motor. This is because the output wave of the controller has high harmonics and the motor cable and the cable connecting the controller and the motor produce leakage current, which is much larger than the current when the motor runs at the mains frequency. Thus, it is necessary to determine the proper RCCB sensitivity based on the general leakage current of the cables and the motor. The leakage current is dependent on the motor capacity, cable length, insulation class and wiring method. Generally, the leakage current on the output side of the controller is three times of the current when the motor runs at the mains frequency.

Protective Features

Adopting different protective features for various levels of faults, NICE380 provides the elevator running system with full abnormality protection.

The controller provides protective features against the following abnormalities:

Drive control abnormal

The related faults include drive overcurrent, over voltage/under voltage, power input/output phase loss, overload, and storage abnormality. If such a fault occurs, the controller performs protection immediately, stops output, applies the brake and prohibits running.

Leveling sensor abnormal

The related faults include sensor failure or sensor stuck. The controller judges whether a fault occurs based on the leveling signal change. If the leveling signal does not change within the set time, the system reports an alarm.

◆ Floor data abnormal

The system stores the floor information through the setup drive (for shaft type 1 only) or directly sets the floor pulse information (for shaft types 0, 2, and 3). If the floor data is abnormal, the system prompts the fault information at the first-time running. During actual running, the controller continuously compares position information input by DIs with the stored floor data. If the deviation is large, the system reports an alarm.

Safety signs Safety Instructions



1.1 Model and Nameplate	20
1.2 Technical Data	20
1.3 Technical Specifications	21
1.4 Optional Parts	22

1.1 Model and Nameplate




Figure 1-1 Product type designation




Figure 1-2 Nameplate

1.2 Technical Data

Table 1-1 Technical data

	Controller Model	Power Capacity (kVA)	Input Current (A) Output Current (A)		Adaptable Motor Power (kW)
Three-phase 380 V, range: -15% to 20%					
	NICE-L-I-4003 5.9 10.5 9.0 3				
	NICE-L-I-4005	8.9	14.8	13.0	5.5

1.3 Technical Specifications

Table 1-2 Technical specifications

	Item	Specification			
	Maximum frequency	99 Hz			
	Carrier frequency	2–12 kHz, adjusted automatically based on the load features			
	Motor control mode	Sensor-less vector control (SVC)/Voltage/Frequency (V/F) control			
	Startup torque	0.5 Hz: 180% (SVC)			
	Speed adjustment range	1:100 (SVC) 1:50 (V/F control)			
	Speed stability accuracy	±0.5% (SVC)			
	Overload	60s for 60%-150% of the rated curre	ent		
S	Motor auto-tuning	Static auto-tuning for asynchronous	motor		
ation	Distance control	Direct travel ride mode in which the	leveling position can be adjusted flexibly		
Basic specifications	Acceleration/Decelera tion curve	Automatic generation of multiple cur	ves		
asic	Slow-down	New reliable slow-down feature, auto	omatically identifying the position of the slow-down bracket		
ä	Setup drive	32-bit data, accurately recording the	positions in the shaft		
	Leveling adjustment	Flexible and easy leveling adjustmen	nt feature		
	Test function	Easy to implement multiple elevators	s commissioning functions		
	Fault protection	Solutions to different levels of elevat	or faults		
	Intelligent management	Remote monitoring, user management			
	Security check of peripheral devices after power-on	Security check of peripheral devices, such as grounding and short circuit, after power-on			
	Status monitor	Monitoring the state of feedback sign	nals to ensure that the elevator works properly		
	Disital issue (DI)	24 x DI Input: 24 V, 5 mA			
တ္	Digital input (DI)	3 higher-voltage detection input terminals of safety circuit and door lock circuit Input: 95–125 V			
ature	Communication port	1 Modbus communication port			
I/O features		25 relay outputs			
<u>×</u>	Output terminal block	The terminals can be allocated with	different functions.		
and display	Operating panel	5-digit LED display, querying/modifying most parameters and monitoring the system state			
Operation an	NEMS software	Connecting the control system and the host computer, convenient for querying/motoring the system state			
	Altitude	Below 1000 m (de-rated 1% for each 100 m higher)			
	Ambient temperature	-10°C to 50°C (de-rated if the ambie	ent temperature is above 40°C)		
	Humidity Maximum relative humidity 95%, non-condensing				
Vibration Maximum vibration: 5.9 m/s² (0.6 g)					
ronn	Storage temperature	ature -20°C to 60°C			
Vibration Maximum vibration: 5.9 m/s² (0.6 g) Storage temperature -20°C to 60°C Pollution degree PD2					
	IP level	IP20			
Earthing arrangements TN/TT					

1 Product Information 1.4 Optional Parts

1.4 Optional Parts

If any optional part in the following table is required, specify it in your order.

Table 1-3 Optional parts

Description	Model	Function	Remarks
External LED operating panel	MDKE	External LED display and operating panel	RJ45 interface
External LED operating panel	MDKE6	External LED display and operating panel	It can be used for copying parameters.
Extension cable	MDCAB	It is a standard 8-core network cable and can be connected to MDKE.	The cable length is 3 m in the standard configuration.



2.1 Prepara	ation	24
2.1.1 Env	vironment Requirements	24
2.1.2 Spa	ace Requirements	24
2.2 Product	t Dimensions	24
2.3 Installat	tion Instructions	25
2.4 Wiring o	of main control board (MCB) Terminals	26
2.5 Installat	tion of Shaft Position Switches	29
2.5.1 Inst	stallation of Leveling Switches	29
2.5.2 Inst	stallation of Deceleration Switches	30
2.5.3 Inst	stallation of Slow-Down Switches	31
2.5.4 Inst	stallation of Limit Switches	32
2.5.5 Inst	stallation of Final Limit Switches	32
2.6 Wiring [Diagram of the Integrated Control System	32

2 Installation and Wiring 2.1 Preparation

2.1 Preparation

2.1.1 Environment Requirements

- ♦ Ambient temperature: The ambient temperature substantially impacts the service life of the controller. Do not operate the controller outside the allowable ambient temperature (-10°C to 50°C);
- Install the controller on the surface of an incombustible object, and ensure that there is sufficient space around for heat dissipation;
- ◆ Install the controller at a place away from vibration. The vibration shall not exceed 0.6g;
- Install the controller at a place free from direct sunlight, high humidity and condensation;
- Install the controller at a place free from corrosive, explosive and combustible gas;
- Install the controller at a place free from oil dirt, dust and metal powder.

2.1.2 Space Requirements

The clearance to be reserved for installing the controller is as follows.





Figure 2-1 Installation clearances

2.2 Product Dimensions

The dimensions of the controller are as follows.



2.2 Product Dimensions 2 Installation and Wiring




Figure 2-2 Product dimensions

Table 2-1 Product dimensions

Integrated Controller	Α	В	Н	W	D	Bore Diameter
Models	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)
Three-phase 380 V, range: -15% to 20%						
NICE-L-I-4003			0.40	4=0		
NICE-L-I-4005	148	235	248	170	145	5.5

2.3 Installation Instructions

The NICE100+ is installed vertically upward on the support with screws fixed into the four mounting holes See the illustration below.




Figure 2-3 Tightening torques for bolts

The controller is generally installed in the control cabinet of the elevator equipment room. Pay attention to the following points when designing the control cabinet:

- ◆ The temperature inside the cabinet must not rise to 10°C higher than the temperature outside the cabinet.
- ♦ A closed control cabinet must be configured with a fan (or other air cooling device such as air conditioner) to ensure air circulation.
- ◆ The air from the fan must not blow directly to the drive unit because this easily causes dust adhesion and further a fault on the drive unit.
- ♦ A vent must be available at bottom of the control cabinet to form bottom-up air flow, which prevents heat island effect on the surface of components or partial thermal conductivity effect.
- If the fan does not meet the cooling requirements, install an air conditioner in the cabinet or in the equipment room. Note that the temperature inside the cabinet must not be too low; otherwise, condensation may occur, causing short-circuit of components.
- For special environment where the temperature is high but cannot be reduced effectively, de-rate the controller during use.

2.4 Wiring of main control board (MCB) Terminals

Terminal arrangement

The following figure shows terminal arrangement of the controller.




Figure 2-4 Terminal arrangement of NICE100+ controller

Description of Main Circuit Terminals

The following figure shows main circuit terminal arrangement.




Figure 2-5 Terminal arrangement of main circuit




Figure 2-6 Wiring of the main circuit

Table 2-2 Description of Main Circuit Terminals

Mark	Name	Description		
R, S, T	Three-phase power supply input terminals	Provide three-phase power supply.		
+, -	Positive and negative terminals of DC bus	Connect the external braking unit and energy feedback unit.		
РВ	Terminals for connecting braking resistor	(+), PB: Connect the braking resistor		
U, V, W	Controller output terminals	Connects three-phase motor		
(Grounding terminal	Grounding terminal		

◆ Description of Control Circuit Terminals

Table 2-3 Description of Control Circuit Terminals

	Mark	Terminal Name	Function Description	Terminal Arrangement		
	M24/ MCOM	External 24 VDC power supply	24 VDC power supply for the entire board			
CN6/ CN8	X1 to X8	DI	Input voltage range: 10–30 VDC Input impedance: $4.7~k\Omega$ optocoupler isolation Input current limit: $5~mA$ DI terminal functions are set in F5-01 to F5-24.	Ø M24 Ø MCOM Ø L1 Ø MCOM Ø L1 Ø L2 Ø 13 Ø 14 Ø 15 Ø 15 Ø 16		
	L1 to L6	Button function	Button input and button indicator output, 24 V power	② X7 ② X8		
		selection	for button illumination			
CN9	X9 to X20	DI	Input voltage range: $1030~\text{VDC}$ Input impedance: $4.7~\text{k}\Omega$ optocoupler isolation Input current limit: $5~\text{mA}$ DI terminal functions are set in F5-01 to F5-24.	①		
CN14	X25 to X27/ XCM	Higher-voltage detection terminal	Input voltage range: 110 VAC±15% 110 VDC±20% for safety circuit and door lock circuit, function set in F5-25 to F5-27	Ø XCM Ø X27 Ø X26 Ø X25 Ø XCM		
CN13	X21 to X24	DI	Input voltage range: 1030 VDC Input impedance: $4.7 \text{ k}\Omega$ optocoupler isolation Input current limit: 5 mA DI terminal functions are set in F5-01 to F5-24.			
	M24/ MCOM	External 24 VDC power supply	24 VDC power supply for the entire board			
CN5	Interface for	extension board MCTC-KZ-	-D	M0000000000000000000000000000000000000		
CN10	USB interface	Communication port	Used to connect the external WIFI module for commissioning via smart phones Used to burn the MCB program Used for residential monitoring	D CN10		
CN15	RJ45 interface	Interface for operating panel	Used to connect the operating panel			
CN7	L7-L18	Button function selection	Button input and button indicator output, 24 V power for button illumination	© X7 © X8 © X9 © X9 © X10 © X11 © X12 CN7 © X14 © X15 © X16 © X17 © X18		

Mark		Terminal Name	Function Description	Terminal Arrangement	
CN3	Y11-Y24	DO	Normally-open (NO), maximum current and voltage rating: 5 A, 250 VAC Function set in F7-00 to F7-03	Ø M8 Ø Y24 Ø Y23 Ø Y22 Ø Y22 Ø Y22 Ø Y22 Ø Y39 Ø Y48 Ø M7. Ø M7. Ø M7. Ø M7. Ø M7. Ø Y44 Ø Y44 Ø Y44 Ø Y44 Ø Y44	
CN2	Y5-Y10	DO	Normally-open (NO), maximum current and voltage rating: 5 A, 250 VAC Function set in F7-00 to F7-03	Y10 Y8 M6 Y8 CN2 M5 Y6 Y5	
CN1	Y0-Y4	DO	Normally-open (NO), maximum current and voltage rating: 5 A, 250 VAC Function set in F7-00 to F7-03	7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	
CN4	485+/-	485 interface	485 Communication	Ø GND Ø MOD+ Ø MOD-	
J9/J10	Factory reserved. Do not short them randomly. Otherwise, the controller may not work properly.				

Table 2-4 Description of indicators

Mark	Terminal Name	Function Description		
ER	Fault indicator	When a fault occurs on the controller, this indicator is ON (red).		
ОК	Normal running indicator	When the controller is in normal running state, this indicator is ON (green).		
CAN	Parallel control communication	This indicator is steady ON (green) when communication for parallel control is en-		
	indicator	abled, and blinks when the running in parallel mode is normal.		
L1 to L18	Button input indicator	This indicator is ON (green) when the button input is active.		
X1 to X24	DI signal indicator	This indicator is ON (green) when the external input is active.		
Y0 to Y24	DO signal indicator	This indicator is ON (green) when the system output is active.		

2.5 Installation of Shaft Position Switches

In elevator control, to implement landing accurately and running safely, the car position needs to be identified based on shaft position switch signals. These shaft position switch signals include the leveling switch signals, up/down slow-down switch signals, up/down limit switch signals, and up/down final limit switch signals. These shaft position signals are directly transmitted by the shaft cables to the MCB of the controller. For the wiring method, see the illustration below.

The following figure shows the arrangement of shaft position switches in the shaft.




Figure 2-7 Arrangement of shaft position switches in shaft

2.5.1 Installation of Leveling Switches

Leveling signals comprise the leveling switch and leveling plate and are directly connected to the input terminal of the controller. It is used to enable the car to land at each floor accurately.

The leveling switches are generally installed on the top of the car. By default, one leveling switch is used. The leveling plate is installed on the guide rail in the shaft. A leveling plate needs to be installed at each floor. Ensure that leveling plates at all floors are mounted with the same depth and verticality.




Figure 2-8 Installation position of leveling switches

Number of Leveling Switches	Installation Method	Connecting to Input Terminals of Controller	Parameter Setting
1	Door zone signal detection	O +24 VDC Door zone signal	F5-01 = 03 (normally open, NO)
		°+24 VDC Door zone signal X1	F5-01 = 103 (normally closed, NC)

2.5.2 Installation of Floor Deceleration Switches

Floor Deceleration switches comprise the deceleration sensor and deceleration plate and are directly connected to the input terminal of the controller. It is used to enable the car to land at each floor efficiently and accurately.

The deceleration sensors are generally installed on the top of the car. By default, one deceleration sensor is used, which can be either a mono-stable or a bi-stable switch. Two deceleration sensors are also supported (different sensors for up and down deceleration); The deceleration plate is installed on the guide rail in the shaft. Two deceleration plates (or magnets) need to be installed at each floor. Ensure that deceleration plates at all floors are mounted with the same depth and verticality.

For the open-loop controller (without encoders), deceleration switch signals play an important role in enabling the car to land at each floor efficiently and accurately. Installing deceleration switches at correct places improves the running efficiency of the elevator and prevents it from mistakenly passing the floor without stop. There are two deceleration switches at each floor: the up-deceleration switch and the down deceleration switch. The deceleration distance L1 indicates the distance from the deceleration switch to the deceleration plate at the current floor. The calculating formula is as follows:

$$L_1 > \frac{V_1^2 - V_2^2}{2 \times F_3 - 05}$$

In the formula, "L1" indicates the deceleration distance, "V1" indicates the F0-04 (Rated elevator speed), "V2" indicates the re-leveling speed, and "F3-05" indicates the deceleration rate.

The default value of F3-05 (Deceleration rate) is 0.5 m/s². The default value of F3-10 (Re-leveling speed) is 0.050 m/s². The deceleration distances calculated based on different rated elevator speeds are listed in the following table.

Table 2-5 Deceleration distance

Rated Elevator Speed (m/s)	0.25	0.4	0.5	0.63	0.75	1.0
Deceleration Distance (m)	0.3-0.4	0.5-0.6	0.6-0.8	0.8-1.0	1.0-1.2	1.3-1.5

Note the following:

- 1. If the leveling switch at the door zone and the deceleration switch are not at the same level, consider the relative distance between the leveling switch and the deceleration switch when arranging up and down deceleration plates. See the illustration below taking shaft type 0 as an example.
- 2. When installing deceleration plates at the top floor and the bottom floor, install the deceleration plates before the terminal slow-down switches where possible so that deceleration switches can act before terminal slow-down switches.




Figure 2-9 Installation position of deceleration switches

2.5.3 Installation of Slow-Down Switches

The slow-down switch is one of the key protective components protecting the elevator from over travel top terminal or over travel bottom terminal at maximum speed when the elevator position becomes abnormal. The controller supports one pair of slow-down switches. The slow-down distance L indicates the distance from the slow-down switch to the leveling plate at the terminal floor. The calculating formula is as follows:

In the formula, "L" indicates the slow-down distance, "V" indicates the F0-04 (Rated elevator speed), and "F3-08" indicates the special deceleration rate.

The default value of F3-08 (Special deceleration rate) is 0.5 m/s2. The slow-down distances calculated based on different rated elevator speeds are listed in the following table.

Table 2-6 Terminal slow-down distances

Rated Elevator Speed (m/s)	0.25	0.4	0.5	0.63	0.75	1.0
Terminal Slow-down Distance (m)	0.3-0.4	0.5-0.6	0.6-0.8	0.8-1.0	1.0-1.2	1.3-1.5

Note the following:

The slow-down switch supports the terminal floor reset function. It must be installed between the leveling plates of the terminal floor and the secondary terminal floor.

2.5.4 Installation of Limit Switches

The up limit switch and down limit switch protect the elevator from over travel top/bottom terminal when the elevator does not stop at the leveling position of the terminal floor.

- ♦ The up limit switch needs to be installed 30–50 mm away from the top leveling position. The limit switch acts when the car continues to run upward 30–50 mm from the top leveling position.
- ♦ The down limit switch needs to be installed 30–50 mm away from the bottom leveling position. The limit switch acts when the car continues to run downward 30–50 mm from the bottom leveling position.


2.5.5 Installation of Final Limit Switches

The final limit switch is to protect the elevator from over travel top/bottom terminal when the elevator does not stop completely upon passing the up/down limit switch.

- ♦ The up final limit switch is mounted above the up-limit switch. It is usually 150 mm away from the top leveling position.
- ◆ The down final limit switch is mounted below the down limit switch. It is usually 150 mm away from the bottom leveling position.

2.6 Wiring Diagram of the Integrated Control System

See the following figure for the details.





3.1 LED Operating Panel	.35
3.2 Operating Panel Elements	.35
3.2.1 Function indicators	. 35
3.2.2 Keys	
3.3 Parameter Menu Description	

The controller supports three commissioning tools: the operation control and information display panel (the "operating panel"), the host computer monitoring software, and the commissioning app for smart phones.

Tool	Function Description	Remarks
LED Operating Panel	It is used to view and modify parameters related to	Optional
LLD Operating Failer	elevator drive and control.	Ориона
Host computer monitoring	It is used to monitor the current elevator state,	Contact the council of the contact
software	view and modify all parameters, and upload and	Contact the supplier for software
(NEMS) download parameters on the PC.		

3.1 LED Operating Panel

The LED operation panel is connected to the RJ45 interface of the controller by using an 8-core flat cable. You can modify the parameters, monitor the working status and start or stop the controller by operating the operation panel. See the illustration below.




Figure 3-1 Diagram of operation panel

3.2 Operating Panel Elements

3.2.1 Function indicators



Table 3-1 Description of indicators

Indica	ator State	Indication	
RUN	RUN	OFF indicates the stoppage state.	
Running indicator	RUN	ON indicates the running state.	
LOCAL/REMOT Reserved		Reserved	
FWD/REV	FWD/REV	OFF: Elevator running up	
Elevator running direction indicator	FWD/REV	ON: Elevator running down	

Indica	ator State	Indication	
TUNE/TC	TUNE/TC	OFF: not applicable	
Auto-tuning indicator	TUNE/TC	ON: Auto-tuning state	
Hz A V		Frequency unit: Hz	
Hz — RPM — ; A		Current unit: A	
Hz A V		Voltage unit: V	
Hz RPM — A €% — V		Rotation speed unit: RPM	
Hz RPM — Å ₹% — ↓ ↓ ₹		Percentage: %	

3.2.2 Keys

Table 3-2 Description of keys

Key	Name	Function	
PRG	Programming	Enter or exit Level-I menu.	
ENTER	Enter	It is used to access a menu item and confirm parameter settings.	
	Up	Increase data or parameter number.	
\bigcirc	Down	Decrease data or parameter number.	
	Shift	Select the displayed parameters in turn in the stoppage or running state, and select the digit to be modified when modifying parameters.	
RUN	Run	Start the AC drive in the operating panel control mode.	
STOP	Stop/Reset	Stop the AC drive when it is in the running state and perform the reset operation when it is in the fault state.	
QUICK	Quick Menu	Enter or exit Level-I quick menu.	
MF.K	Fault Hide fault	Display or hide the fault information in the fault state, which facilitates parameter viewing.	

3.3 Parameter Menu Description

The operating panel has three levels of menu for parameter setting.

- Level I: parameter group
- ◆ Level II: parameter
- ◆ Level III: parameter value




Figure 3-2 Structure of the three-level menu

Note:

You can return to Level II menu from Level III menu by pressing as follows:

- ♦ After you press , the system saves the parameter setting first, and then goes back to Level II menu and shifts to the next parameter number.
- ♦ After you press , the system does not save the parameter setting, but directly returns to Level II menu and remains at the current parameter number.

In Level III menu, if the parameter has no blinking digit, it means that the parameter cannot be modified.

This may be because:

- Such a parameter is only readable. Such as actually detected parameters and running record parameters.
- Such a parameter cannot be modified in the running state and can only be changed at stoppage state



4.1 Safety Checks Before Commissioning	. 40
4.2 Motor Commissioning	.41
4.2.1 Asynchronous motor static auto-tuning mode 1	.41
4.2.2 Asynchronous motor static auto-tuning mode 2	.41
4.3 Shaft auto-tuning (only for motor wheel pulse type)	. 42
4.4 Riding Comfort Adjustment	.42
4.4.1 Performance Adjustment of System Control	.42
4.4.2 Mechanical Factors riding Comfort	.43
4.5 Leveling Accuracy Adjustment	. 43

4.1 Safety Checks Before Commissioning

The elevator needs to be commissioned after being installed; the correct commissioning guarantees safe and normal running of the elevator. Before performing electrical commissioning, check whether the electrical part and mechanical part are ready for commissioning to ensure safety. At least two persons need to be onsite during commissioning so that the power supply can be cut off immediately when an abnormality occurs.

1. Check mechanical safety.

Check that the shaft is unobstructed, there is no person in the shaft, inside or on top of the car, and the conditions for elevator safe running are met.

2. Check electrical wiring.

No.	Item		
1	The power supply R, S, T cables are wired correctly and securely.		
2	he UVW cables between the controller and the motor are wired correctly and securely.		
3	The controller (cabinet) and motor are grounded correctly.		
4	The safety circuit is conducted, and the emergency stop buttons and switches in the cabinet and in the equipment room can be enabled.		
5	The door lock circuit is conducted. The door lock circuit is disconnected when the car door or any hall door opens.		

3. Check electrical safety.

	No.	Item	
	1	The line voltage of the user power supply is within 380 to 440 VAC, and the phase unbalance degree does not exceed 3%.	
	2	The total lead-in wire gauge and total switch capacity meet the requirements.	
	3	There is no inter-phase or to-ground short circuit in the R, S, T power supply.	
There is no inter-phase or to-ground short circuit in the U, V, W phases of the controller. There is no integround short circuit in the U, V, W phases of the motor.		There is no inter-phase or to-ground short circuit in the U, V, W phases of the controller. There is no inter-phase or to-	
		ground short circuit in the U, V, W phases of the motor.	
	5	here is no short circuit to ground on the output side of the transformer.	
	6	There is no inter-phase or to-ground short circuit in the 220 V power supply.	
	7	The 24 V power supply has no short circuit between positive and negative or to-ground short circuit.	
	8	The CANbus/Modbus communication cable has no short circuit with the 24 V power supply or short circuit to ground.	

4.2 Motor Commissioning

The controller supports both V/F and SVC control. In SVC control, auto-tuning is required before startup of the motor in order that more precise control parameters can be obtained for the motor.

Table 4-1 Parameters Related to Motor Auto-tuning

Parameter No.	Parameter Name	Description	
F1-01 to F1-05	Motor rated power/voltage/current/frequency/speed	Model dependent, to be manually input	
F0.04		0: Operating panel control	
F0-01	Command source selection	1: Distance control	
		0: Disabled	
F1-11	Motor auto-tuning mode	2: Asynchronous motor static auto-tuning mode 2	

4.2.1 Asynchronous motor static auto-tuning mode 2




Figure 4-2 Asynchronous motor static auto-tuning mode 2

4.3 Shaft auto-tuning (only for motor wheel pulse type)

- 1) Make preparations for shaft auto-tuning.
- ♦ Check that the shaft switches are installed correctly. The signals are valid and reliable.
- Check the pulse signals are stable, the X input electrical level lasts for more than 20 ms (maximum resolution = 50 Hz).
- Check that the number of floors is set correctly.
- 2) Parameter No.

Parameter No.	Parameter Name	Description	Default Value	Remarks
F0-04	Rated elevator speed	0.250 to 1.000 m/s	0.5 m/s	-
F6-00	Top serving floor of the elevator	F6-01 to 12	6	Actual number of floors+1 minus bottom serving floor
F6-01	Bottom serving floor of the elevator	1 to F6-00	1	-



- If the parameter F0-04 is modified, the elevator must perform another shaft auto-tuning. Otherwise abnormal conditions may occur to the elevator during running.
- ◆ After F4-00 Shaft type is modified, the elevator controller must be re-powered on. If F4-00=1, shaft auto-tuning must be performed, otherwise the elevator cannot run normally.
- 3) Check that the conditions for shaft auto-tuning have been met.
- ◆ The elevator is in the inspection state.
- ◆ The elevator is at the leveling position of the bottom floor.
- ♦ The down slow-down switch 1 signal input to the MCB is active.
- The NICE100+ is not in the fault state. If there is a fault, press STOP/RES to reset the fault.



When there are only two floors, the elevator needs to run to bel ow the bottom leveling position, that is, at least one leveling sensor is below the leveling plate. This is the prerequisite for successful shaft auto-tuning.

4) Perform shaft auto-tuning.

When the preceding conditions are met, start shaft auto-tuning by using any of the following methods:

◆ Set F1-11 to 3 on the operating panel.

After shaft auto-tuning starts, the elevator runs at the inspection speed set in F3-11 and stops after reaching the leveling plate of the top floor. Then, the keypad on the MCB displays the present floor number (top floor), indicating that shaft auto-tuning is successful.

If fault E35 is reported during the process, it indicates that shaft auto-tuning fails. You need to rectify the fault according to the solution described in Troubleshooting and perform shaft auto-tuning again.

4.4 Riding Comfort Adjustment

The riding comfort is an important factor of the elevator's overall performance. Improper installation of mechanical parts and improper parameter settings will cause discomfort. Enhancing the riding comfort mainly involves adjustment of system control and the elevator's mechanical construction.

4.4.1 Performance Adjustment of System Control




Figure 4-3 Timing diagram of controller operation

Riding comfort adjustment at elevator startup and stop

Parameter	Name	Setting Range	Default
F2-00	Speed loop proportional gain 1	0 to 100	10
F2-01	Speed loop integral time 1	0.01 to 10.00s	1.00s
F2-03	Speed loop proportional gain 2	0 to 100	30
F2-04	Speed loop integral time 2	0.01 to 10.00s	1.00s

a) Adjustment to abnormal motor startup

F2-00, F2-01, F2-03 and F2-04 are used to adjust the speed dynamic response characteristics of the motor.

- ◆ To achieve a faster system response, increase the proportional gain or reduce the integral time. Be aware that either a too big gain or a too short time may lead to system oscillation.
- Decreasing the proportional gain or increasing the integral time will slow the dynamic response of the motor. However, too small proportional gain or too large integral time may cause motor speed tracking abnormality, resulting in fault E33 or instable leveling at stop.

The default setting is proper for most large-power motors, and you need not modify these parameters. These parameters need to be adjusted only for small-power motors ($P \le 5.5 \text{ kW}$) because they may have oscillation. To adjust, perform the following.

- Decrease the proportional gain first (between 10 and 40) to ensure that the system does not oscillate.
- ◆ Reduce the integral time (between 0.1 and 0.8) to ensure that the system has quick response but small overshoot.

b) Adjustment to elevator startup Related parameters:

Parameter	Name	Setting Range	
F8-15	DC injection braking current at startup	0 to 150	50%
F3-14	DC injection braking time at startup	0.000 to 1.000	0.300
F3-15	Brake release delay	0.000 to 1.000	0.050

4.4.2 Mechanical Factors riding Comfort

The mechanical construction affecting the riding comfort involves installation of the guide rail, guide shoe, steel suspension rope, brake, balance of the car and resonance caused by the car, guild rail and motor. For asynchronous motor, abrasion or improper installation of the gearbox may arouse poor riding comfort.

No.	Mechanical Factor	Description
1	Guide rail	Installation of the guide rail mainly involves: Verticality and surface flatness of the guide rail Smoothness of the guide rail connection
		Parallelism between two guide rails (including guide rails on the counterweight side)
2	Guide shoe	Tightness of the guide shoes (including the one on the counterweight side) also influences the riding
_	Guido orioo	comfort. The guide shoes must not be too loose or tight.
3	Steel suspension rope	The drive from the motor to the car totally depends on the steel rope. Large flexibility of the steel rope with irregular resistance during the car running may cause curly oscillation of the car. In addition, unbalanced stress of multiple steel ropes may cause the car to jitter during running.
4	Brake	The riding comfort during running may be influenced if the brake arm is installed too tightly or released incompletely.
5	Balance of the car	If the car weight is unbalanced, it will cause uneven stress of the guide shoes that connect the car and the guide rail. As a result, the guide shoes will rub with the guide rail during running, affecting the riding comfort.
6	Gearbox	For asynchronous motor, abrasion or improper installation of the gearbox may also affect the riding
О	Geardox	comfort.
		Resonance is an inherent character of a physical system, related to the material and quality of system components.
7	Resonance	If you are sure that the oscillation is caused by resonance, reduce the resonance by increasing or decreasing the car weight or counterweight and adding resonance absorbers at connections of the components (for example, place rubber blanket under the machine bed).

4.5 Leveling Accuracy Adjustment

Leveling adjustment parameters

Parameter	Name	Setting Range	Default	Unit
Fr-00	Leveling adjustment mode	0 to 1	0	-
Fr-01	Leveling adjustment record 1	0 to 15015	0	s
Fr-02	Leveling adjustment record 2		0	mm
Fr-28	Leveling adjustment record 28		0	mm



◆ The parameter value has five digits, the two high bytes of each value are used for leveling delay adjustment for up running, and the two low bytes are used for leveling delay adjustment for down running. Each parameter is used for the adjustment of a single floor. For example, Fr-02 is used for adjusting the leveling of floor 2. The adjustment of this parameter does not affect the leveling results of other floors.


Perform the leveling adjustment as follows:

Leveling adjustment in the equipment room

Parameters Fr-01 to Fr-12: Fr-01 is for the bottom floor, Fr-02 is for the physical floor 2, and so on. Inside each parameter, Bit1 and Bit2 are for the leveling stop delay during down running, Bit4 and Bit5 are for the leveling stop delay during up running. Bit4 and Bit5 are invalid for Fr-01, and Bit1 and Bit2 are invalid for Fr-12.



- The leveling stop delay is calculated starting from the time when the elevator receives the leveling signal. When two leveling signals are used, the calculation starts from the time when both leveling signals are received.
- ▶ The leveling adjustment must be performed after the riding comfort adjustment is completed.



Leveling adjustment inside the car





Figure 4-4 Flow diagram of leveling adjustment inside car





- ◆ After you set Fr-00 to 1, the elevator shields hall calls, automatically runs to the top floor, and keeps the door open after arrival.
- During adjustment, the car display board displays "00" or the value after adjustment. Positive value: up arrow + value, negative value: down arrow + value, adjustment range: 0 to 1.5s.
- ◆ After you save the adjustment result, the car display board displays the present floor.
 - Note that if a certain floor need not adjustment, you also need to save the data once. Otherwise, you cannot register
 the car call.

NOTE



5.1 Parameter Description	46
5.2 Parameter Groups	46
Group F0: Basic parameters	46
Group F1: Motor parameters	47
Group F2: Vector control parameters	47
Group F3: Running control parameters	49
Group F4: Floor parameters	50
Group F5: Terminal input parameters	52
Group F6: Elevator basic parameters	58
Group F7: Terminal output parameters	61
Group F8: Advanced function parameters	62
Group F9: Time parameters	63
Group FA: Keypad setting parameters	71
Group FB: Door parameters	72
Group FC: Protection function parameters	74
Group FD: Communication parameters	75
Group FE: Elevator function parameters	75
Group Fr: Leveling adjustment parameters	76
Group FP: User parameters	77
Group E0: The first set of detailed fault information	77

5.1 Parameter Description

The parameters adopt the three-level menu.

Level I: parameter group

◆ Level II: parameter

◆ Level III parameter value

The definitions of each column in the parameter table are as follows.

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation
The number of the parameter	The full name of the parameter	The valid setting range of the parameter	The original factory setting of the parameter	The minimum measurement unit of the parameter	Whether the parameter can be modified (including the modification conditions)

[&]quot;☆": The parameter value can be changed when the system is stopped or operational.

The system automatically restricts the properties of all parameters to prevent mal-function.

5.2 Parameter Groups

On the operation panel, press and then , and you can view the parameter groups. The parameter groups are classified as follows:

F0	Basic parameters	F9	Time parameters
F1	F1 Motor parameters		Keypad setting parameters
F2	Vector control parameters	Fb	Door parameters
F3	Running control parameters	FC	Protection parameters
F4	Floor parameters	Fd	Communication parameters
F5	Terminal input parameters	FE	Elevator function parameters
F6	Basic elevator parameters	FF	Factory parameters (reserved)
F7	Terminal output parameters	FP	User parameters
F8	Advanced function parameters	Fr	Leveling adjustment parameters

Group F0: Basic parameters

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation			
	F0: Basic parameters							
	Control mode	0: Sensorless vector control (SVC)						
F0-00	Control mode	2: V/F control	0	-	*			
	Command source	0: Operating panel control						
F0-01	selection	1: Distance control	1	-	*			
	Running speed under	0.050 / 50.04						
F0-02	operating panel control 0.050 to F0-04	0.050	m/s	☆				
	Maximum running	0.000 / 50.04						
F0-03	speed	0.200 to F0-04	0.480	m/s	*			
F0-04	Rated elevator speed	0.200 to 1.000	0.500	m/s	*			
F0-05	Maximum frequency	F1-04 to 99.00	50.00	Hz	*			
F0-06	Carrier frequency	0.5 to 12.0	10.0	kHz	*			

[&]quot;★": The parameter cannot be modified when the AC drive is in the running state;

[&]quot;•": The parameter is the actually measured value and cannot be modified.

Group F1: Motor parameters

Parameter	Parameter Name		Setting Range	Default	Unit	Operation
No.						
	Rated power	07.	F1: Motor parameters			T .
F1-01	Rated voltage	0.7 to 7		Model dependent	kW	*
F1-02	Rated current	0 to 55		Model dependent	V	*
F1-03			655.00	Model dependent	Α	*
F1-04	Rated frequency Rated rotation speed		99.00	Model dependent	Hz	*
F1-05	Current detection	0 to 30	100	Model dependent	RPM	*
F1-09	compensation	0 to 10	0	5	-	*
F1-10	DSP fault block	0 to 65	535	0	-	*
		0: Disa	bled			
		2: Asyr	nchronous motor static auto-			
	Auto tuning made	tuning	2			
F1-11	Auto-tuning mode	3: Sha	ft auto-tuning 1			
		4: Sha	ft auto-tuning (clear leveling	0		*
			ment data)		-	^
Parameter	Motor outo, tuning	mada	Function			
/alue	Motor auto- tuning	noue	Tunction			
0	Disabled		None			
	Asynchronous motor	static	Applicable for scenarios who	ere the load cannot be remov	ed, and a com	plete auto-
2	auto-		tuning is impossible. Stator	resistance, rotor resistance, I	eakage induct	ance, mutua
	tuning 2		inductance and no-load curr	rent will be auto-tuned		
3	Shaft auto-tuning 1		Leveling adjustment records in group Fr are preserved			
4	Shaft auto-tuning 2		Leveling adjustment records	in group Fr are cleared		
-1-12	Pulses per revolution of	0 to 10	000	10	PPR	*
	motor			-		1
ne valid sigi	nal pulses on the flywheel x10	per each	revolution of the motor (only	valid for motor flywneel signa	al used as sna	rt signai)
Asynchronous motor stator resistance		0.000 t	0 30.000	Model dependent	Ω	*
	Asynchronous motor rotor					
- 1-15	resistance		0 30.000	Model dependent	Ω	*
- 1-16	Asynchronous motor leakage		300.00	Model dependent	mH	*
	inductance Asynchronous motor mutual					
- 1-17	inductance	0.1 to 3000.0		Model dependent	mH	*
F1-18	Asynchronous motor	0.01 to 300.00		Model dependent	A	*
	Magnetizing current			-		
F1-25	Motor type	0: Asyr	nchronous motor	0	-	•
=2: Vector of	control parameters					T
F2-00	Speed loop proportional gain	0 to 10	0	10	-	*
F2-01	Speed loop integral time 1	0.01 to	10.00	1.00	s	*
F2-02	Switchover frequency 1	0.00 to	F2-05	3.00	Hz	*
F2-03	Speed loop prop.l gain 2	0 to 10	0	30	-	*
F2-04	Speed loop integral time 2	0.01 to	10.00	1.00	s	*
F2-05	Switchover frequency 2	F2-02	to F0-05	7.00	Hz	*
F2-06	Vector control slip gain	50 to 2	00	100	%	*
F2-08	Torque upper limit	0.0 to 2	200.0	150.0	%	*
F2-09	Over-excitation gain	0 to 20	0	64	-	*
	Running direction	0: Dire	ction unchanged			
F2-10	Training uncollon	1: Dire	ction reversed	0	-	*
F2-11	Retard Co-efficient	0~100		0	_	*
F2 12	0 – Disa		able	0	-	
1 4-14	2-12 Retard Co-efficient 1		able	U	-	*
F2-13	Excitation regulation proportional gain	0 to 60	000	2000	-	*
F2-14	Excitation regulation integral	0 to 60	000	1300	_	*
	gain Torque regulation proportion	al 0 to 60	000			
	1. Sigus regulation proportion	~· ∪ ເປ bU	UUU	2000	_	★
F2-15	gain gain					
F2-15 F2-16		0 to 60	000	1300	-	*

Parameter	Parameter Name	Setting Range	Default	Unit	Operation
No.		Octaing Range	Deladit	Offic	Operation
	F2: Vector co	ontrol parameters			
F2-18	Startup acceleration time	0.000 to 1.500	0.000	s	*
F2-19	Asynchronous motor SCV2, M-axis current loop proportional coefficient	5 to 300	20	_	☆
12 10	Asynchronous motor SCV2, M-axis current loop		20		
F2-20	integral coefficient	0 to 65535	0	-	☆
F0.01	Asynchronous motor SCV flux observation	0 to 200			٨
F2-21	compensation coefficient Asynchronous motor SCV flux observation low-pass	0.10.200	100	%	☆
F2-22	filter cutoff frequency	100 to 2000	500	-	☆
	Asynchronous motor SCV added M-axis current	0.4- 500			
F2-23	loop proportional closed-loop gain	0 to 500	200	-	☆
F2-24	Asynchronous motor SCV added T-axis current loop	0 to 500	0	_	☆
	proportional closed-loop gain SVC excitation current boost	0.0 to 50.0		-	
F2-25	SVC excitation current boost cutoff frequency	0 to F1-04	10.0	%	☆
F2-26	SVC speed loop filter	0.000 to 0.100	20.00	Hz	
F2-27	SVC torque limit mode selection	0 to 1000	0.000	-	☆
F2-28	SVC2 speed filter coefficient	0.000 to 1.000	0	-	☆
F2-29	Exciting current coefficient	1 to 1000	0.050	-	☆
F2-30	Torque limit filter coefficient	0 to 63	100	-	☆
F2-31		0 to 65535	63	-	×
	Turn off pulse-by-pulse current limit interruption	0: Turn on			
F2-32			0	-	☆
		1: Turn off 0 to 65535			
	Special treatment of synchronous frequency at SVC	0: Turn on			
F2-33	output phase loss detection	1: Turn off	0	-	☆
		0 to 65535			
		1: Input phase loss detection			
F2-34	Input phase loss detection time	time=2s	0		
		0: Input phase loss detection	0	-	☆
		time=1s			
F2-43	VF Torque boost gain	0.0 to 30.0	0.0	%	☆
F2-44	VF torque boost cutoff frequency	0.00 to F0-05	4.00	Hz	*
F2-45	VF slip compensation gain	0.0 to 200.0	100.0	%	☆
F2-46	VF over-excitation gain	0 to 200	0	-	☆
F2-47	VF oscillation suppression gain	0 to 100	30	-	☆
F2-48	VF oscillation suppression mode	0 to 4	3	-	☆
F2-49	VF overcurrent stall gain	50 to 200	170	-	☆
F2-50	VF overcurrent stall gain enabling bit	0 to 1	1	-	☆
F2-51	VF overcurrent stall frequency modulation Kp	0 to 100	20	-	☆
F2-52	VF multiplying speed overcurrent stall action current	50 to 200	50	_	☆
F2-53	compensation coefficient VF overvoltage stall gain	650.0 to 800.0	770.0	V	☆
F2-54	VF overvoltage stall gain enabling bit	0 to 1	0	-	☆
F2-55	VF overvoltage stall gain frequency modulation Kp	0 to 100	30	_	☆
F2-56	VF overvoltage stall gain voltage regulation Kp	0 to 100	30	-	☆
	Maximum frequency of VF overvoltage stall gain				
F2-57	increase	0 to 50	5	-	☆
F2-58	VF under voltage stall enabling bit	0 to 2	0	-	☆
F2-59	VF under voltage stall frequency modulation Kp	0 to 100	40	-	☆ .
F2-60	VF under voltage stall frequency modulation Ki	0 to 100	30	-	☆ .
F2-61	VF under voltage stall recovery judgment voltage VF under voltage stall recovery judgment voltage	85 to 120	85	-	☆
F2-62	time	0.1 to 10.0	0.5	-	☆
F2-63	VF under voltage stall gain	60 to 85	80	-	☆
F2-65	VF slip compensation response time	0.1 to 10.0	0.5	s	☆
F2-66	V/F slip compensation suspension	0 to 1	0	-	☆
	·	t .			

Group F3: Running control parameters

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation
F3: Running control parameters					
F3-00	Startup speed	0.000 to 0.030	0.008	m/s	*
F3-01	Startup holding time	0.000 to 0.500	0.300	s	*

These two parameters are used to set the startup speed and startup speed holding time. For details, see the S-curve.

The parameters may reduce the terrace feeling at startup due to static friction between the guide rail and the guide shoes.


F3-02	Acceleration rate	0.200 to 0.800	0.300	m/s2	*
F3-03	Acceleration jerk time 1	0.300 to 4.000	1.500	s	*
F3-04	Acceleration jerk time 2	0.300 to 4.000	1.500	s	*
F3-05	Deceleration rate	0.200 to 0.800	0.500	m/s2	*
F3-06	Deceleration jerk time 1	0.300 to 4.000	1.500	s	*
F3-07	Deceleration jerk time 2	0.300 to 4.000	1.500	s	*

These parameters are used to set the running curve during deceleration of the elevator.

F3-02 (F3-05) is the acceleration rate (deceleration rate) in the straight-line acceleration process (deceleration process) of the S curve. F3-03 (F3-07) is the time for the rate to increase from 0 to the value set in F3-02 (F3-05) in the end jerk segment of the S curve. The larger the value is, the smoother the jerk is.

F3-04 (F3-06) is the time for the rate to decrease from the value set in F3-02 (F3-05) to 0 in the start jerk segment of the S curve. The larger the value is, the smoother the jerk is.

Setting the running curve:



Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation
F3: Running control parameters					


These parameters are used to set the time related to the zero-speed holding current output and braking action delay.

F3-14 (DC injection braking time at startup) specifies the valid time for outputting DC injection braking at startup, during which the controller performs excitation on the motor and outputs zero-speed current with large startup torque.

F3-15 (Brake release delay) specifies the time from the moment when the system sends the brake release command to the moment when the brake is completely released, during which the system retains the zero-speed torque current output.

F8-11 (Stop torque output delay) specifies the time from the moment when the system brake is completely applied to the moment when the stop DC injection braking is canceled, during which the system retains the zero-speed torque current output.

F3-16 (Running end delay time) specifies the time during which the system keeps output when the running curve ends (output frequency less than 0.5 Hz or the speed is lower than the value set in F3-25).




Group F4: Floor parameters

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation	
	F4: Floor parameters					
		0 to 3				
		0: One deceleration signal, mono-stable				
F4-00	Shaft signal type	1: Motor flywheel signal				
		2: One deceleration signal, bi-stable	0	-	*	
		3: Two deceleration signals, mono-stable				

Parameter No.	Parameter Name	eter Name Setting Range		Unit	Operation
F4-01	Current floor	F6-01 to F6-00	1	-	*
F4-02	High byte of current floor position	0 to 65535	1	Pulses	•
F4-03	Low byte of current floor position	0 to 65535	10000	Pulses	•
F4-04	Length 1 of leveling plate	0 to 65535	0	Pulses	*
F4-05	Length 2 of leveling plate	0 to 65535	0	Pulses	*
F4-06	High byte of floor height 1	0 to 65535		Pulses	*
F4-07	Low byte of floor height 1	0 to 65535	20	Pulses	*
F4-08	High byte of floor height 2	0 to 65535	0	Pulses	*
F4-09	Low byte of floor height 2	0 to 65535	20	Pulses	*
F4-26	High byte of floor height 11	0 to 65535	0	Pulses	*
F4-27	Low byte of floor height 11	0 to 65535	20	Pulses	*
F4-35	Current position area	0 to 65535 0: At leveling position 1: Over the current floor 2: Under the current floor	0	-	•

This parameter is used to display the position within the current floor where the elevator car is located. If the current position pulses are the same as the pulses calculated for the current floor, the direction for re-levelling can be determined. If the elevator is running up and is under the current floor, the system determines that the elevator gets closer to the levelling if it runs up. When the elevator is running down and is over the current floor, the system determines that the elevator gets closer to the levelling if it runs down. See the illustration below.



Re-leveling in non-door zone: if the car is within the deceleration signal area, it will run up to re-leveling. Whichever is closer: the car re-levels to the closest floor based on the pulses of the current door zone.


Group F5: Terminal input parameters

	reminai input parame	iters			
Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation
IVO.		Group F5: Terminal input parameters			
F5-00	Attendant/Automatic switchover time	3 to 200	3	_	*
	call at current floor in attendant state, th	e system automatically switches over to the automatic (r	normal) state after	the time	set in this
parameter. After	this running is completed, the system a	automatically restores to the attendant state (Bit2 of F6-6	7 must be set to 1	I). When	the value of
this parameter is	smaller than 5, this function is disabled	d, and the system is in the normal attendant state.			
FF 04	X1 function selection	1 to 99 (normally open), 101 to 199 (normally closed)	00		_
F5-01		00: Unused 01: Reserved	03	-	*
F5-02	X2 function selection	02: Reserved	55	-	*
F- 00	X3 function selection	03: Door zone signal			
F5-03		04: Running output feedback signal	0	-	*
F5-04	X4 function selection	05: Brake output feedback signal 06: Brake travel switch feedback signal 1	109	-	*
_	X5 function selection	07: Reserved			
F5-05		08: Reserved	10	-	*
F5-06	X6 function selection	09: Inspection signal 10: Inspection up signal	11	-	*
	X7 function selection	10: Inspection down signal			
F5-07	A Turioueri edicoueri	12: First fire emergency signal	12	-	*
F5-08	X8 function selection	13: Reserved 14: Elevator lock signal	20	-	*
	X9 function selection	15: Up limit signal			
F5-09	As full clion selection	16: Down limit signal	115	-	*
F5-10	X10 function selection	17: Up slow-down signal 18: Down slow-down signal	116	-	*
	X11 function selection ▼	19: Overload signal			
F5-11	X11 Idilction Selection	20: Full-load signal	117	-	*
F5-12	X12 function selection	21: Emergency stop (safety feedback) signal	118	_	*
	X13 function selection	22: Door 1 open limit signal 23: Reserved			
F5-13	X13 Idilction Selection	24: Door 1 close limit signal	119	-	*
F5-14	X14 function selection	25: Reserved 26: Door 1 light curtain signal	22	_	*
	X15 function selection	27: Reserved			
F5-15	X13 full culoff selection	28: Attendant signal	126	-	*
F5-16	X16 function selection	29: Direct travel ride signal 30: Direction change signal	28	_	*
	X17 function selection	31: Reserved			
F5-17	ATT TUTICUOTI Selection	32: Reserved	30	-	*
F5-18	X18 function selection	33: UPS valid signal	124	-	*
	X19 function selection	34: Door open button 35: Door close button			
F5-19	X19 full culoff Selection	36: Safety circuit	00	-	*
F5-20	X20 function selection	37: Door lock circuit 1 38: Door lock circuit 2	00	-	*
	X21 function selection	39: Half-load signal			
F5-21	AZ Franction Selection	40: Motor overheat signal	00	-	*
F5-22	X22 function selection	41: Door machine 1 safety edge signal 42: Door machine 2 safety edge signal	00	-	*
	X23 function selection	43: Earthquake signal			
F5-23	A23 full culoff Selection	44: Reserved	00	-	*
		45: Light-load signal 46: Reserved			
		47: Fire emergency floor switchover signal			
		48: Reserved			
		49: Firefighter input			
		50: Brake travel feedback 2 51: Car lighting switch input			
F5-24 X24	X24 function selection	52: Car fan switch input	00	-	*
		53: Up deceleration signal input			
		54: Down deceleration signal input 55: Single deceleration signal input or motor flywheel			
		signal			
		56 to 79: Reserved			
		80: RCR feedback input 81: Inside-car STOP signal input			
		OTO: Signal input			

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation			
	Group F5: Terminal input parameters							
F5-25	X25 higher-voltage input function selection	1 to 16 00: Unused	01	-	*			
F5-26	X26 higher-voltage input function selection	01: Safety circuit signal	02	-	*			
F5-27	X27 higher-voltage input function selection	02: Door lock circuit 1 signal 03: Door lock circuit 2 signal 04 to 16: Reserved	03	-	*			
F5-28	I/O terminals state display 1	-	-	-	•			
F5-29	I/O terminals state display 2	-	-	-	•			

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation	
Group F5: Terminal input parameters						

After you enter the F5-28 menu, the operation panel displays the state of all I/O terminals of the system. The LEDs are numbered 1 to 5 from right to left. The segments are defined as follows: 5 4 3 2 1



Digit Sequence	Segment	Function		
	Α	Reserved	-	•
	В	Up Levelling signal active	-	•
	С	Down Leveling signal active	-	•
	D	Door zone signal active	-	•
1	Е	RUN contactor output feedback	-	•
	F	Brake output feedback 1 signal actve	-	•
	G	Brake output feedback 2 signal active	-	•
	DP	U.V.W shorting (FX) contactor feedback signal active	-	•
	А	Door lock jump out contactor feedback signal active	-	•
	В	Inspection signal active	-	•
	С	Inspection up signal active	-	•
2	D	Inspection down signal active	-	•
_	Е	Fire emergency Landing signal active	-	•
	F	Reserved	-	•
	G	Lift lock signal active	-	•
	DP	Up limit signal active	-	•
	Α	Down limit signal active	-	•
	В	Up terminal slowdown signal active	-	•
2	С	Down terminal slowdown signal active	-	•
3	D	Over load signal active	-	•
	Е	Full load signal active	-	•
	F	Emergency stop (safety feedback) signal active	-	•
	G	Door 1 open limit signal active	-	•
	DP	Door 2 open limit signal active	-	•

LED No.	Segment	Meaning of Segment	Meaning of Segment ON
	Α	Door 1 close limit signal	Door 1 close limit signal active
	В	Reserved	Reserved
	С	Door machine 1 light curtain signal	Door machine 1 light curtain signal active
4	D	Reserved	Reserved
4	E	Attendant signal	Attendant signal active
	F	Direct travel ride signal	Direct travel ride signal active
	G	Direction change signal	Direction change signal active
	DP	Independent running signal	Independent running signal active
	Α	Reserved	Reserved
	В	UPS input signal active	UPS input signal active
	С	Door open button	Door open button active
	D	Door close button	Door close button active
5	E	Door lock circuit 1 (low-voltage input)	Door lock circuit 1 signal active
	F	Door lock circuit 2 (low-voltage input)	Door lock circuit 2 signal active
	G	Half-load signal	Half-load signal active
	DP	Unused	Not applicable

Parameter No. Parameter Name Setting Range Default Unit Operation Group F5: Terminal input parameters


The following table describes the meaning of the LED segments indicating the I/O terminal state in F5-29.

LED No.	Segment	Meaning of Segment	Meaning of Segment ON
	Α	Unused	Not applicable
	В	Safety circuit signal	Safety circuit signal active
	С	Door lock circuit 1 signal (high-voltage input)	Door lock circuit 1 signal active
1	D	Door lock circuit 2 signal (high-voltage input)	Door lock circuit 2 signal active
	E	Unused	Not applicable
	F	Unused	Not applicable
	G	Unused	Not applicable
	DP	Unused	Not applicable
	А	Y0 output	Y0 output active
	В	Running contactor output	Running contactor output active
	С	Brake contactor output	Brake contactor output active
2	D	Higher-voltage startup of brake	Higher-voltage startup of brake active
	Е	Fan/light output	Fan/light output active
	F	Reserved	Reserved
	G	Door 1 open output	Door 1 open output active
	DP	Door 1 close output	Door 1 close output active
LED No.	Segment	Meaning of Segment	Meaning of Segment ON
А	Α	Reserved	Reserved
	В	Reserved	Reserved
	С	Low 7-segment a display output	Low 7-segment a display output active
	D	Low 7-segment b display output	Low 7-segment b display output active
3	E	Low 7-segment c display output	Low 7-segment c display output active
	F	Low 7-segment d display output	Low 7-segment d display output active
	G	Low 7-segment e display output	Low 7-segment e display output active
	DP	Low 7-segment f display output	Low 7-segment f display output active
	А	Low 7-segment g display output	Low 7-segment g display output active
	В	Up arrow display output	Up arrow display output active
	С	Down arrow output	Down arrow output active
	D	Minus sign display output	Minus sign display output active
4	Е	Returning to base floor at fire emergency output	Returning to base floor at fire emergency output active
	F	Buzzer output	Buzzer output active
	G	Overload output	Overload output active
	DP	Arrival gong output	Arrival gong output active

Parameter No.	Parai	Parameter Name		Setting Range	Default	Unit	Operation	
		(Group F	5: Terminal input parameters				
	A Full-load output		Full-load output active					
	В	Inspection output		Inspection output active				
	С	Fan/light output 2		Fan/light output 2 active				
	D	Door lock circuit shorting contactor output		Door lock circuit shorting contactor output active				
5	Е	BCD/Gray code/7-segment high-bit output		BCD/Gray code/7-segment high-bit output active				
	F	Controller normal running output		Controller normal running output active				
	G Unused DP Unused		Not applicable					
			Not applicable					
F5-30	Floor I/O terminal state display 1 -			-	-	•		

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation	
Group F5: Terminal input parameters						

After you enter the F5-30 menu, the operation panel displays the state of all floor I/O terminals of the system. The LEDs are numbered 1 to 5 from right to left. The segments are defined as follows:



The following table describes the meaning of the LED segments indicating the floor I/O terminal state in F5-30.

	А	Door 1 open button I/O	Door 1 open button I/O active
	В	Door 1 close button I/O	Door 1 close button I/O active
	С	Door 1 open delay button I/O	Door 1 open delay button I/O active
1	D	Floor 1 door 1 car call I/O	Floor 1 door 1 car call I/O active
'	E	Floor 2 door 1 car call I/O	Floor 2 door 1 car call I/O active
	F	Floor 3 door 1 car call I/O	Floor 3 door 1 car call I/O active
	G	Floor 4 door 1 car call I/O	Floor 4 door 1 car call I/O active
	DP	Floor 5 door 1 car call I/O	Floor 5 door 1 car call I/O active
	А	Floor 6 door 1 car call I/O	Floor 6 door 1 car call I/O active
	В	Floor 7 door 1 car call I/O	Floor 7 door 1 car call I/O active
	С	Floor 8 door 1 car call I/O	Floor 8 door 1 car call I/O active
2	D	Floor 9 door 1 car call I/O	Floor 9 door 1 car call I/O active
_	E	Floor 10 door 1 car call I/O	Floor 10 door 1 car call I/O active
	F	Reserved	Reserved
	G	Unused	Not applicable
	DP	Unused	Not applicable
	A	Floor 1 door 1 up call I/O	Floor 1 door 1 up call I/O active
	В	Reserved	Reserved
	С	Floor 2 door 1 up call I/O	Floor 2 door 1 up call I/O active
3	D	Floor 2 door 1 down call I/O	Floor 2 door 1 down call I/O active
-	E	Floor 3 door 1 up call I/O	Floor 3 door 1 up call I/O active
	F	Floor 3 door 1 down call I/O	Floor 3 door 1 down call I/O active
	G	Floor 4 door 1 up call I/O	Floor 4 door 1 up call I/O active
	DP	Floor 4 door 1 down call I/O	Floor 4 door 1 down call I/O active

LED No.	Segment	Meaning of Segment	Meaning of Segment ON
	Α	Floor 5 door 1 up call I/O	Floor 5 door 1 up call I/O active
	В	Floor 5 door 1 down call I/O	Floor 5 door 1 down call I/O active
	С	Floor 6 door 1 up call I/O	Floor 6 door 1 up call I/O active
4	D	Floor 6 door 1 down call I/O	Floor 6 door 1 down call I/O active
4	E	Floor 7 door 1 up call I/O	Floor 7 door 1 up call I/O active
	F	Floor 7 door 1 down call I/O	Floor 7 door 1 down call I/O active
	G	Floor 8 door 1 up call I/O	Floor 8 door 1 up call I/O active
	DP	Floor 8 door 1 down call I/O	Floor 8 door 1 down call I/O active
	Α	Floor 9 door 1 up call I/O	Floor 9 door 1 up call I/O active
	В	Floor 9 door 1 down call I/O	Floor 9 door 1 down call I/O active
	С	Reserved	Reserved
_	D	Floor 10 door 1 down call I/O	Floor 10 door 1 down call I/O active
5	ш	Reserved	Reserved
	F	Reserved	Reserved
	G	Unused	Not applicable
	DP	Unused	Not applicable

Group F6: Elevator basic parameters

Paramet	ter		Parameter Nam	e		Setting	Range		Default	Unit	Operation
				F	6: Eleva	tor basic parameters					
F6-00		Top serving floor	r of the elevator			F6-01 to 12			6	-	*
F6-01		Bottom serving f	loor of the elevator			1 to F6-00			1	-	*
F6-02		Parking floor				F6-01 to F6-00			1	-	*
F6-03		Fire emergency floor 1 F6-01 to F6-00				1	1	*			
F6-04		Elevator lock floo	or			F6-01 to F6-00			1	-	*
F6-05		Service floors				1: Respond to calls			65535		
1000		Gervice moors	T	1		2: Not respond to calls	I		00000	-	*
Bit	it Corresponding floor Service or not Setting Bit		Corresponding floor	Service or not		Bin	ary setti	ng			
Bit0	Flo	or 1	In service	1	Bit8	Floor 9	Not in service	0			
Bit1	Flo	or 2	Not in service	0	Bit9	Floor 10	In service	1			
Bit2	Flo	or 3	In service	1	Bit10	Floor 11	In service	1			
Bit3	Flo	or 4	In service	1	Bit11	Floor 12	Not in service	0			
Bit4	Flo	or 5	In service	1	Bit12	Reserved	None				
Bit5	Flo	or 6	In service	1	Bit13	Reserved	None				
Bit6	Flo	or 7	In service	1	Bit14	Reserved	None				
Bit7	Flo	or 8	Not in service	0	Bit15	Reserved	None				
			mal: 1111 0110 01 ² n the operation pan			Bit1: Returning to base deviation too large	floor if position				
F6-06		Elevator function	n control 1			Bit3: Buzzer not tweet upon re-leveling Bit5: Cancelling auto reset of door lock fault Bit6: Clear floor number and display direction in advance Bit8: Hall call not directional Bit10: Door lock disconnected once when inspection turned to normal			0	-	*
F6-07 Elevator function control 2		Bit2: Arrow blinking during running Bit3: Elevator lock in the attendant state Bit6: Fault code not displayed on keypad Bit9: Stop holding at brake feedback abnormal Bit10: Cancelling Err30 detection at re- leveling Bit12: Fault auto reset			0	-	*				
F6-08 Arrow blinking interval		0 to 5.0			1.0	-	*				
F6-09		Random test tim	ies			0 to 60000			0	-	*
						Bit0: Hall call Disable					
F6-10		Test function sel	lection			Bit1: Door open Disable)		0	-	*
						Bit2: Overload allowed					
						Bit3: Terminal Limit cancel					

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation
	F6: E	levator basic parameters			
F6-11	L1 function selection	00: Unused	231	-	*
F6-12	L2 function selection	201 to 203 (Door 1 open/close),	252	_	*
F6-13	L3 function selection	205 to 209 (Reserved), 210 to 229 (Door 1 car call),	232	-	*
F6-14	L4 function selection	230 to 249 (Door 1 up hall call),	253	-	*
F6-15	L5 function selection	250 to 269 (Door 1 down hall call),	233		*
	L6 function selection	270 to 399 (Reserved) 201: Door 1 open button			*
F6-16	L7 function selection	202: Door 1 close button	254	-	
F6-17		203: Door 1 open delay button	234	-	*
F6-18	L8 function selection	204: Reserved 205 to 210: (Reserved)	255	-	*
F6-19	L9 function selection	211: Floor 1 door 1 car call	235	-	*
F6-20	L10 function selection	212: Floor 2 door 1 car call	256	-	*
F6-21	L11 function selection	213: Floor 3 door 1 car call 214: Floor 4 door 1 car call	00	-	*
F6-22	L12 function selection	215: Floor 5 door 1 car call	00	-	*
F6-23	L13 function selection	216: Floor 6 door 1 car call	211	-	*
F6-24	L14 function selection	217: Floor 7 door 1 car call 218: Floor 8 door 1 car call	212	-	*
F6-25	L15 function selection	219: Floor 9 door 1 car call	213	-	*
F6-26	L16 function selection	220: Floor 10 door 1 car call	214	-	*
F6-27	L17 function selection	221: Floor 11 door 1 car call 222: Floor 12 door 1 car call	215	-	*
F6-28	L18 function selection	223: Reserved	216	-	*
F6-29	L19 function selection	224: Reserved	236		*
F6-30	L20 function selection	225: Reserved 226: Reserved	257	-	*
F6-31	L21 function selection	227 to 230: Reserved	237	-	*
F6-32	L22 function selection	231: Floor 1 door 1 up call	258	-	*
F6-33	L23 function selection	232: Floor 2 door 1 up call 233: Floor 3 door 1 up call	238	-	*
F6-34	L24 function selection	234: Floor 4 door 1 up call	259	-	*
F6-35	L25 function selection	235: Floor 5 door 1 up call	239		*
F6-36	L26 function selection	236: Floor 6 door 1 up call 237: Floor 7 door 1 up call	260	-	*
	L27 function selection	238: Floor 8 door 1 up call			
F6-37		239: Floor 9 door 1 up call	240	-	*
F6-38	L28 function selection	240: Floor 10 door 1 up call 241: Floor 11 door 1 up call	261	-	*
F6-39	L29 function selection	242: Reserved	241	-	*
F6-40	L30 function selection	243: Reserved	262	-	*
F6-41	L31 function selection	244: Reserved 245: Reserved	217	-	*
F6-42	L32 function selection	245. Reserved 246 to 251: Reserved	218	-	*
F6-43	L34 function selection	252: Floor 2 door 1 down call	219	-	*
F6-44	L34 function selection	253: Floor 3 door 1 down call 254: Floor 4 door 1 down call	220	-	*
F6-45	L35 function selection	255: Floor 5 door 1 down call 256: Floor 6 door 1 down call 257: Floor 7 door 1 down call 258: Floor 8 door 1 down call 259: Floor 9 door 1 down call 260: Floor 10 door 1 down call	221	-	*
F6-46	L36 function selection	261: Floor 11 door 1 down call	222	-	*
F6-47	L37 function selection	262: Floor 12 door 1 down call	00	-	*
F6-48	L38 function selection	263: Reserved	00	i	*
F6-49	L39 function selection	264: Reserved	00	-	*
F6-50	L40 function selection		00	-	*
F6-51	L41 function selection	265: Reserved	00	1	*
F0 F0	L42 function selection	266: Reserved 267 to 299: Reserved	00		
F6-52			00	-	*

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation
	F6: Eleva	ator basic parameters			
F6-62	Time interval of random running	0 to 1000 Bit1: Reserved	3	-	☆
		Bit4: Reserved			
F6-64	Program control selection 1	Bit5: Clearing calls immediately at elevator lock	0	-	*
		Bit9: Disabling reverse floor number clear			
		Bit11: Responding to car calls first Bit2: Inspection to stop due to slow-down			
		Bit4: Buzzer tweet during door open delay			
F6-65	Program control selection 2	Bit8: Door open at elevator lock	0	-	*
		Bit9: Display available at elevator lock			
		Bit11: Blinking at arrival			
		Bit1: Cancelling door open/close command at			
		delay after door open/close limit			
		Bit2: Not judging door lock state at door close output			
F6-66	Program control selection 3	Bit3: Door close command output during	0	-	*
		running			
		Bit4: Returning to base floor for verification at			
		first-time power-on			
		Bit0: Calls cancelled after entering attendant			
		state			
		Bit1: Not responding to hall calls			
		Bit2: Attendant/Automatic state switchover			
		Bit3: Door close at jogging			
F6-67	Attendant function selection	Bit4: Automatic door close	128	-	*
		Bit5: Buzzer tweeting at intervals in attendant			
		state			
		Bit6: Continuous buzzer tweeting in attendant			
		state			
		Bit7: Car call button blinking to prompt Bit0: Automatic entering of fire emergency			
		state once fire emergency switch is active			
		Bit3: Arrival gong output in inspection or fire emergency state			
		Bit4: Multiple car calls registered in fire			
		emergency state			
		·			
		Bit6: Closing door by holding down the door			
F6-68	Fire emergency function selection	close button Bit9: Displaying hall calls in fire emergency	40:	_	*
	- G,	state	16457		
		Bit11: Exiting fire emergency state for firefighter			
		Bit12: Not clearing car calls at reverse door			
		open in firefighter running state			
		door open button			
		Bit15: Automatic door open in fire emergency floor			
F6-68	Fire emergency function selection	Bit5: Retentive at power failure in fire emergency state Bit6: Closing door by holding down the door close button Bit9: Displaying hall calls in fire emergency state Bit11: Exiting fire emergency state for firefighter Bit12: Not clearing car calls at reverse door open in firefighter running state Bit14: Opening door by holding down the door open button	16457	-	

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation
F6-69	Emergency evacuation function selection	Bit0\Bit1: Direction determine mode Bit2: Stopping at evacuation parking floor Bit4: Reserved Bit8: Emergency running time protection Bit10: Emergency buzzer output Bit12: Reserved Bit13: Reserved Bit14: Emergency evacuation exit mode Bit15: India ARD evacuation mode	0	-	*
F6-73	Evacuation parking floor	0 to F6-00	0	-	*
F6-74	Blinking advance time	0.0 to 15.0	1	S	*

Group F7: Terminal output parameters

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation
F7-00	Y0 function selection	(Y0 is the special output used for emergency drive at power	32	-	*
F7-01	Y1 function selection	failure)	01	-	*
F7-02	Y2 function selection	Setting range: (00 to 05) or 32	02	ı	*
		00: Unused			
		01: Running contactor output			
F7-03	Y3 function selection	02: Brake contactor output	04 -	-	
17 00	TO Idilotto Toolootto	03: Reserved			*
		04: Lighting, fan output			
		05: Reserved			

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation
		F7: Terminal output parameters			
F7-04	Y4 function selection	Setting range: 06 to 99	26	-	*
F7-05	Y5 function selection	00: Unused 06: Door 1 open output	06	-	*
F7-06	Y6 function selection	07: Door 1 close output	07	_	*
		08: Reserved 09: Reserved			
F7-07	Y7 function selection	10: Low 7-segment a display output	48	-	*
F7-08	Y8 function selection	11: Low 7-segment b display output	49	-	*
F7-09	Y9 function selection	12: Low 7-segment c display output 13: Low 7-segment d display output	25	-	*
F7-10	Y10 function selection	14: Low 7-segment e display output	10	-	*
F7-11	Y11 function selection	15: Low 7-segment f display output	11	-	*
F7-12	Y12 function selection	16: Low 7-segment g display output 17: Up arrow display output	12	-	*
		18: Down arrow display output			
F7-13	Y13 function selection	19: Minus sign display output	13	-	*
F7-14	Y14 function selection	20: Returning to base floor at fire emergency 21: Buzzer output	14	-	*
F7-15	Y15 function selection	22: Overload output	15	-	*
F7-16	Y16 function selection	23: Arrival gong output 24: Full-load output	16	-	*
F7-17	Y17 function selection	25: Inspection output	17	-	*
F7-18	Y18 function selection	26: Fan output	18	_	*
_		27: Door lock circuit shorting contactor output 28: BCD/Gray code/7-segment high-bit output			*
F7-19	Y19 function selection	29: Controller normal running output	19	-	
F7-20	Y20 function selection	30: Electric lock output	20	-	*
F7-21	Y21 function selection	31: Reserved 32: Emergency evacuation at power failure	21	-	*
F7-22	Y22 function selection	33: Forced door close 1	22	-	*
F7-23	Y23 function selection	34: Forced door close 2 35: Faulty state	23	1	*
		36: Up signal 37: Medical sterilization output 38: Non-door zone stop output 39: Non-service state output 40: Reserved 41: High 7-segment a display output 42: High 7-segment b display output			
F7-24	Y24 function selection	43: High 7-segment c display output 44: High 7-segment d display output 45: High 7-segment e display output 46: High 7-segment f display output 47: High 7-segment g display output 48: UPS/ARD up running output 49: UPS/ARD down running output 50: Up running hall indicator output 51: Down running hall indicator output 52: Up/down running hall indicator output 53: Fire emergency state prompt output 54: Elevator normal mode output 55: Manual door lock cutoff prompt 56: Attendant state prompt output 57 to 99: Reserved	24	-	*

Group F8: Advanced function parameters

Parameter No.	Parameter Name	Setting Range	Default	Unit	Operation		
	F8: Advanced function parameters						
F8-05	Current car load	0 to 255	0	%	•		
F8-06	Mechanical friction torque	0.0 to 100.0	10	%	*		

F8-09	Emergency evacuation operation speed at power failure	0.000 to F3-11	0.05	m/s	*
F8-10	Emergency evacuation operation mode at power failure	0: Motor not running 1: UPS running 2: 48 V battery power supply	0	-	*
F8-11	Stop torque output delay	0.200 to 1.500	0.300	s	*
F8-12	Fire emergency floor 2	0 to F6-00	0	-	*
F8-13	Anti-nuisance function	Bit0: Reserved Bit1: Judged by light curtain Bit 2: Judged by light-load signal	0	-	*
F8-14	Startup mode	DC injection braking startup Pre-excitation startup (AC asynchronous motor)	0	-	*
F8-15	DC injection braking current at startup	0 to 150	50	%	*
F8-16	DC injection braking current at stop	0 to 150	30	%	*
F8-20	Delay of arrival at door zone in emergency evacuation	0.000 to 2.000	0	s	*
F8-21	Manual Door Open Buzzer Delay	0.000 to 2.000	0	s	*
F8-22	Auto Call Cancellation delay upon door safety disconnection on normal running	0 ~ 120s	120	S	*

Group F9: Time parameters

Parameter	Name	Setting Range	Default	Unit	Operation			
	F9: Time parameters							
F9-00	Idle time before returning to base floor	1 to 240 0: Disabled	10	min	☆			
F9-01	Fan/light turnoff time	0 to 6000 0: Disabled. The fan will always run.	60	s	☆			
F9-02	Motor running time limit	0 to 45 Invalid for the time less than 3s.	45	s	*			
F9-03	Accumulative running hours	0 to 65535 hours	0	h	•			
F9-05	High byte for number of running cycles	0 to 9999 Note: 1 indicates an actual number of 10,000 running cycles	0	-	•			
F9-06	Low byte for number of running cycles	0 to 9999	0	-	•			
F9-08	Set running time	0 to 9999	0	h	•			

Group FA: Keypad setting parameters

Parameter	Name	Setting Range	Default	Unit	Operation
	FA: Keypad setting parameters				
FA 00	Baud rate	0:9600			
FA-00		1:38400	1	-	-
FA-01	Display in running state	1 to 65535	65535	-	☆
FA-02	Display in stop state	1 to 65535	65535	-	☆

Parameter	Name	Setting Range	Default	Unit	Operation
	FA: K	eypad setting parameters			

It is used to set the parameters displayed on the keypad when the elevator is in the stop state. A total of 16 parameters can be displayed at stop. The use is the same as that of FA-01.

The 16 binary bits correspond to the stop state parameters listed in the following table.

Bit	Parameter Name	Default	Bit	Parameter Name	Default
Bit0	Rated elevator speed	1	Bit8	Input terminal 2 state	1
Bit1	Bus voltage	1	Bit9	Input terminal 3 state	1
Bit2	Current floor	1	Bit10	Output terminal 1 state	1
Bit3	Current position	1	Bit11	Output terminal 2 state	1
Bit4	Car load	1	Bit12	Reserved	0
	Slow-down distance at				
Bit5	rated speed	11	Bit13	Reserved	0
Bit6	System state	1	Bit14	Reserved	0
Bit7	Input terminal 1 state	1	Bit15	Reserved	0

The running and stop parameters of the controller are the important references for engineers to perform commissioning on site. The parameters are described as follows:

Running speed: indicates the actual running speed of the elevator. Its maximum value is F0-03 (Maximum running speed), in unit of m/s.

Set speed: indicates the set speed of the controller during elevator running. It is the running speed calculated by the system theoretically at which the elevator should run, in unit of m/s.

Bus voltage: indicates the DC bus voltage of the controller, in unit of $\mbox{m/s}.$

Current floor: indicates the information of the physical floor where the elevator is located. It is the same as the value of F4-01.

Current position: indicates the absolute distance from the current elevator car to the leveling plate of the first floor, in unit of m.

Car load: indicates the percentage of the car load to the rated load judged by the controller based on data from the sensor, in unit of %.

 $Output\ voltage: indicates\ the\ effective\ value\ of\ the\ equivalent\ voltage\ of\ the\ PWM\ wave\ output\ by\ the\ controller,\ in\ unit\ of\ V.$

Output current: indicates the effective value of the actual current when the controller drives the motor to turn, in unit of A.

Output frequency: indicates the actual frequency of the motor during running. It has a fixed corresponding relationship with the running speed. The unit is Hz.

Pre-torque current: indicates the percentage of the pre-torque current compensated during startup to the rated current, in unit of %.

The following describes the details for I/O terminal state display.

Input terminal 1 state: indicate the meaning of input terminals by bit. "1" indicates that the signal is active. A total of 16 bits are defined as below:

Bit	Description	Bit	Description
Bit0	Reserved	Bit8	Door lock circuit shorting feedback
Bit1	Up leveling signal	Bit9	Inspection signal
Bit2	Down leveling signal	Bit10	Inspection up signal
Bit3	Door zone signal	Bit11	Inspection down signal
Bit4	Running contactor feedback	Bit12	Fire emergency signal
Bit5	Brake contactor feedback	Bit13	Reserved
Bit6	Brake travel switch feedback	Bit14	Elevator lock signal
Bit7	Self-lock feedback	Bit15	Up limit signal

Parameter Name		Setting Range Default Unit Oper						
	FA: K	eypad settin	g parameters					
Input terminal 2	2 state: indicate the meaning of input terminals by b	oit. "1" indicate	s that the signal is active. A total o	of 16 bits are d	efined as b	elow:		
Bit	Description	Bit	Description					
Bit0	Down limit signal	Bit8	Door 1 close limit					
Bit1	Up slow-down signal	Bit9	Reserved					
Bit2	Down slow-down signal	Bit10	Door machine 1 light curtain					
Bit3	Overload signal	Bit11	Reserved					
Bit4	Full-load signal	Bit12	Attendant signal					
Bit5	Emergency stop (safety feedback) signal	Bit13	Direct travel ride signal					
Bit6	Door 1 open limit	Bit14	Direction change signal					
Bit7	Reserved	Bit15	Independent running					
Input terminal 3	3 state: indicate the meaning of input terminals by b	oit. "1" indicate	s that the signal is active. A total c	of 16 bits are d	efined as b	elow:		
Bit	Description	Bit	Description					
Bit0	Reserved	Bit8	The motor is overheated.					
Bit1	UPS input	Bit9	Door 1 safety edge					
Bit2	Door open button	Bit10	Reserved					
Bit3	Door close button	Bit11	Earthquake signal					
Bit4	Safety circuit	Bit12	Reserved					
Bit5	Door lock circuit 1	Bit13	Light-load					
Bit6	Door lock circuit 2	Bit14	Reserved					
Bit7	Half-load signal	Bit15	Fire emergency floor switchove	er				
Output termina	I 1 state: indicates the meaning of output terminals	by bit. "1" indi	cates that the signal is active. A to	otal of 16 bits a	are defined	as below:		
Bit	Description	Bit	Description					
Bit0	Reserved	Bit8	Reserved					
Bit1	Running contactor	Bit9	Reserved					
Bit2	Brake contactor	Bit10	Low 7-segment a display output	ut				
Bit3	Higher-voltage startup of brake	Bit11	Low 7-segment b display output					
Bit4	Fan/light output	Bit12	Low 7-segment c display output	ıt				
Bit5	Reserved	Bit13	Low 7-segment d display output	ıt				
Bit6	Door 1 open	Bit14	Low 7-segment e display output	ıt				
Bit7	Door 1 close	Bit15	Low 7-segment f display output	t				

Parameter Name			Setting Range	Default	Unit	Operation		
	FA: Ke	eypad setti	ing parameters					
Output termina	al 2 state: indicates the meaning of CTB outputs by b	oit. "1" indica	ates that the signal is active. A total	of 16 bits are	defined as l	pelow:		
Bit	Description	Bit	Description					
Bit0	Low 7-segment g display output	Bit8	Full-load output					
Bit1	Up arrow display output	Bit9	Inspection output					
Bit2	Down arrow display output	Bit10	Fan/light output 2					
Bit3	Minus sign display output	Bit11	Door lock circuit shorting contactor output					
Bit4	Returning to base floor at fire emergency output	Bit12	BCD/Gray code/7-segment cod	de high-byte o	utput			
Bit5	Buzzer output	Bit13	Controller normal running outpo	ut				
Bit6	Overload output	Bit14	Electric lock output					
Bit7	Arrival gong output	Bit15	Reserved					
	·							

System state: indicates the system state by bit. "1" indicates that the signal is active. A total of 16 bits are defined as below:

Bit	Description	Bit	Des	Description					
Bit0	Light curtain state 1	Bit8	Car state:						
Bit1	Light curtain state 2		1: Door open						
Bit2	Elevator lock signal	Bit10							
Bit3	Bit3 Fire emergency		2: Door open holding 3: Door close 4: Door close limit 5: Running						
Bit4	Elevator state:	Bit12	Full-load						
Bit5			Overload						
Bit6	Shaft auto-tuning Return to base floor at fire emergency	Bit14	Reserved						
Bit7	4: Firefighter operation 6: Attendant operation 7: Automatic (normal)		Reserved						
FA-03	Current encoder angle	0.0 to 360.0		0.0	degree	•			
FA-05	Software version (ZK)	0 to 65535		0	-	•			
FA-06	Software version (DSP)	0 to 65535		0	-	•			
FA-07	Heatsink temperature	0 to 100�		0	°C	•			
FA-08	Controller model	0 to 65535	0 to 65535 380 -			-			
FA-12	Logic information	0 to 65535		0	-	-			

It displays the elevator status parameters.

The LEDs are arranged as 5, 4, 3, 2, 1 from left to right. LED 1 shows the state of door 1. LEDs 2 and 3 have no display. LEDs 4 and 5 together show the elevator state. The following figure shows the elevator in inspection and door close state.




Figure 2-5 Elevator state display

Par	ame	ter	Name					Setting Range Default Unit Operation									
						FA: K	Сеура	nd setting									
The LE	Ds ar	e defined i	n the fol	lowing	table.				-								
	;	5			4	3		2		1							
		Flex	ator St	ato		No data		No data		Dog	or 1 State						
00						displayed	d d	displayed	0	Door 1 State							
00	Inspe	ection state	state 8 Elevator lock Idle elevator						0	Waiting state							
01	Shaf	t auto-tunir	ng 09	parki	ing				1	Door open state							
02)2 Micro-leveling 10		eveling at low				2	2 Door open limit									
		rning to	speed														
03		floor at fire	e 11		uation				3	Door close state							
		rgency		opera		-	-										
04		ighter	12	Moto	or auto-tuning				4	Door close limit							
05	runni	ing state	13		ad control				_	T DOOI GIOSE IIITIIL							
					efloor												
06		ndant	14	verifi	cation				-	-							
07	Auto	matic	-	-					-	-	T	T					
FA-13			rve infor					65535			0	-	-				
-		e system r ation. See	_			milar to the dis	splay o	of FA-12, L	EDs 5	4 and 3 have no display	, while LEDs 2	2 and 1 show	v the running				
					v.												
5 No d		4 No data		3 data		2	1										
displa		displaye		uata layed					Cur	ve information							
	,		-		00 Standby state		09 Deceleration start segment										
					Zer 01	o-speed start		10 Linear deceleration segment									
					seg	ment		10	Deceleration end segment								
					02	o-speed holdin ment	g	11									
						Reserved		12	Zero speed at stop								
					04 Sta	tup speed stag	ge	13	Current stop phase								
-		-			05 Acc	eleration start		14	Resei	Reserved							
					seg	egment			Reserved								
					06	ear acceleration ment	П	15	Stop data processing								
										eleration end		16 to 20	Auto	uning stage			
					seg	ment		10 10 20	Auto-	uning stage							
					08	ole-speed runn ment	iing	21	Emer	gency running							
		0~	eed refe	ranco	369		0.004	0 to 4.000				,					
	FA-14										0	m/s	•				
	FA-15	_	edback s	-				0 to 4.000			0	m/s	•				
FA-16 FA-17			Bus voltage Current position					999.9			0	V	•				
		_						0 300.0			0	m .	•				
	FA-18	,	Output current					0 999.9			0	Α	•				
	FA-19		tput freq					to 99.99			0	Hz	•				
	FA-20		rque cur					o 999.9			0	Α	•				
	FA-21	_	tput volt					999.9			0	V	•				
	FA-22	_	tput torq				0 to 200.0			0	%	•					
l	FA-23	3 Ou	Output power			0.00	0.00 to 99.99			0	kW	•					

0 to 65535

0

Communication interference


FA-24

Pa	rameter		Name	Name			Setting R	ange	Default	Unit	Operation
					FA: K	eypad se	etting paramete	rs			
It displ	ays the currer	nt comn	nunication quality of	of the sy	stem, as de	scribed in	the following table	e.			
	5		4		3		2		1		
SPI Communication No data CAN Communic			nication	No data		No data diaplayed					
	Quality		displayed	Quality		displayed	ľ	No data displayed			
0	High			0	High						
<u>↓</u> ↑			-	-							
9 Interrupted 9 Interrupted											
0_9 in/	dicates the co	mmunio	cation quality. The	areater	the number	is the lar	ner interference t	ne communication s	uffers and the	norer the c	communication

0–9 indicates the communication quality. The greater the number is, the larger interference the communication suffers and the poorer the communication quality is.

FA-26	Input state 1	0 to 65535	0	-	•
FA-27	Input state 2	0 to 65535	0	-	•
FA-28	Input state 3	0 to 65535	0	-	•
FA-29	Input state 4	0 to 65535	0	-	•
FA-30	Input state 5	0 to 65535	0	-	•
FA-31	Output state 1	0 to 65535	0	-	•
FA-32	Output state 2	0 to 65535	0	-	•
FA-33	Output state 3	0 to 65535	0	-	•
FA-34	Floor I/O state 1	0 to 65535	0	-	•
FA-35	Floor I/O state 2	0 to 65535	0	-	•
FA-36	Floor I/O state 3	0 to 65535	0	-	•
FA-37	Floor I/O state 4	0 to 65535	0	-	•

They show the system input and output status. For details, see the figure below.



Example of input state display

As shown in the preceding figure, the LEDs from right to left are numbered 1, 2, 3, 4, and 5. For FA-26 to FA-37, LEDs 5 and 4 show the function No.; LED 3 shows whether the function is valid (1) or invalid (0); the 16 segments of LEDs 1 and 2 show the states of the 16 functions in this parameter.

The preceding figure shows display of FA-16: LEDs 5, 4, and 3 show that function 10 (Inspection down) is 1 (Valid); LEDs 1 and 2 show that besides function 10, functions 4 (Running contactor feedback), 5 (Brake contactor feedback), 6 (Brake travel switch feedback) are valid.

Par	ameter		Name			Settir	ng Range	Default	Unit	Operation
				FA: Keypad setting parameters						
	FA-26 Inp	ut sta	te 1				FA-27 Input state 2			
No.	Function	No.	Function	No.	Function	No.	F	unction		
0	Reserved	8	Door lock circuit shorting feedback	0	Down limit signal	8	Door 1 close limit			
1	Up leveling signal	9	Inspection signal	1	Up emergency terminal slow- down signal	9	Reserved			
2	Down leveling signal	10	Inspection up	2	Down emergency terminal slow- down signal	10	Door machine 1 light curtain	1		
3	Door zone signal	11	Inspection down	3	Overload signal	11	Reserved			
4	Running contactor feedback	12	Fire emergency	4	Full-load signal	12	Attendant signal			
5	Brake contactor feedback	13	Reserved	5	Emergency stop	13	Direct travel ride signal			
6	Brake travel switch feedback	14	Elevator lock	6	Door 1 open limit	14	Direction change signal			
7	Reserved	15	Up limit signal	7	Reserved	15	Independent running			
	FA-28 Input state 3						FA-29 Input state 4			
No.	Function	No.	Function	No.	Function	No.	F	unction		
0	Reserved	8	The motor is overheated.	0	Virtual floor	8	Reserved			
1	UPS input	9	Door 1 safety edge	1	Firefighter switch	9	Reserved			
2	Door open button	10	Reserved	2	Brake travel switch feedback 2	10	Reserved			
3	Door close button	11	Earthquake signal	3	Reserved	11	Reserved			
4	Safety circuit	12	Back door forbidden	4	Reserved	12	Reserved			
5	Door lock circuit	13	Light-load	5	Reserved	13	Reserved			
6	Door lock circuit 2	14	Single/Double door selection	6	Reserved	14	Reserved			
7	Half-load signal	15	Fire emergency floor switchover	7	Reserved	15	Reserved			
	FA-30 Inp		ı				FA-31 Output state 1			
No.	Function	No.	Function	No.	Function	No.		unction		
0	Reserved	8	Reserved	0	Reserved	8	Reserved			
1	Higher-voltage safety circuit	9	Reserved	1	Running contactor output	9	Reserved			
2	Higher-voltage door lock circuit	10	Reserved	2	Brake contactor output	10	Low 7-segment a display ou	utput		
3	Higher-voltage door lock circuit 2	11	Reserved	3	Higher-voltage startup of brake	11	Low 7-segment b display ou	utput		
4	Reserved	12	Reserved	4	Fan/light output	12	Low 7-segment c display ou	ıtput		
5	Reserved	13	Reserved	5	Reserved	13	Low 7-segment d display ou	•		
6	Reserved	14	Reserved	6	Door 1 open	14	Low 7-segment e display ou	•		
7	Reserved	15	Reserved	7	Door 1 close	15	Low 7-segment f display out	tput		

Pai	rameter		Name			Settii	ng Range	Default	Unit	Operation		
				F	A: Keypad settin	g para	meters					
	FA-32 Ou	tput sta	ate 2			FA-33 Output state 3						
No.	Function	No.	Function	No.	Function	No.		Function				
0	Low 7-segment g display output	8	Full-load output	0	Emergency evacuation at power failure (valid).	8	Reserved					
1	Up arrow display output	9	Inspection output	1	Forced door close 1	9	High 7-segment a display output					
2	Down arrow display output	10	Fan/light output 2	2	Reserved	10	High 7-segment b display output					
3	Minus sign display output	11	Door lock circuit shorting contactor output	3	Fault state	11	High 7-segment c display output					
4	Returning to base floor at fire emergency output	12	BCD/Gray code/7-segment code high-byte output	4	Up signal	12	High 7-segment d display	output				
5	Buzzer output	13	Controller normal running output	5	Medical sterilization output	13	High 7-segment e display	output				
6	Overload output	14	Electric lock output	6	Non-door zone stop output	14	High 7-segment f display	output				
7	Arrival gong output	15	Reserved	7	Non-service state output	15	High 7-segment g display	output				

The input/output signals of all floors are viewed in FA-34 to FA-40, as described in the following table.

	FA-34 Floor	r I/O s	tate 1			FA-35	Floor I/O state 2 (door 1 car call)		
No.	Function	No.	Function	No.	Function	No.	Function		
0	Door 1 open	8	Reserved	0	Floor 1 car call	8	Floor 9 car call		
1	Door 1 close	9	Reserved	1	Floor 2 car call	9	Floor 10 car call		
2	Door 1 open delay	10	Door 2 open delay	2	Floor 3 car call	10	Floor 11 car call		
3	Reserved	11	Reserved	3	Floor 4 car call	11	Floor 12 car call		
4	Reserved	12	Reserved	4	Floor 5 car call	12	Floor 13 car call		
5	Reserved	13	Reserved	5	Floor 6 car call	13	Floor 14 car call		
6	Reserved	14	Reserved	6	Floor 7 car call	14	Floor 15 car call		
7	Reserved	15	Reserved	7	Floor 8 car call	15	Floor 16 car call		
FA-36	Floor I/O state 3 (d	door 1	up call)	FA-37	FA-37 Floor I/O state 4 (door 1 down call)				
No.	Function	No.	Function	No.	Function	No.	Function		
0	Floor 1 up call	8	Floor 9 up call	0	Reserved	8	Floor 9 down call		
1	Floor 2 up call	9	Floor 10 up call	1	Floor 2 down call	9	Floor 10 down call		
2	Floor 3 up call	10	Floor 11 up call	2	Floor 3 down call	10	Floor 11 down call		
3	Floor 4 up call	11	Floor 12 up call	3	Floor 4 down call	11	Floor 12 down call		
4	Floor 5 up call	12	Floor 13 up call	4	Floor 5 down call	12	Floor 13 down call		
5	Floor 6 up call	13	Floor 14 up call	5	Floor 6 down call	13	Floor 14 down call		
6	Floor 7 up call	14	Floor 15 up call	6	Floor 7 down call	14	Floor 15 down call		
7	Floor 8 up call	15	Reserved	7	Floor 8 down call	15	Floor 16 down call		

Parameter	Name	Setting Range	Default	Unit	Operation
	FA: k	Keypad setting parameters			
		0 to 65535			
		0: Display up direction#			
		1: Display down direction#			
		2: 1=Running; 0=Stop#			
	System state	3: 1=System full-load#			
FA-41		4: 1=System overload#	0		
1 A-41		5: 1=System half-load#	U	-	•
		6: 1=System light-load#			
FA-42	Input state 6	0 to 65535	0	-	•
FA-43	Input state 7	0 to 65535	0	-	•
FA-44	Non-standard version number	0 to 65535	0	-	•
FA-45	Manufacturer version number	0 to 65535	0	-	•
FA-46	Output state 4	0 to 65535	0	-	•
FA-47	Output state 5	0 to 65535	0	-	•

Group FB: Door parameters

Parameter	Name	Setting Range	Default	Unit	Operation
		FB: Door parameters			
FB-00	Number of door machine(s)	1 to 2	1	-	*
		0 to 65535			
	Service floors of door machine 1	1: Normal opening;			
FB-02		0: Opening forbidden	65535	-	☆
FB-03	Holding time of manual door open	1 to 60	5s	s	*
FB-05	Stop delay for returning to leveling floor	0.00 to 2.00	0	s	*
FB-06	Door open protection time	5 to 99	10	s	☆
		0 to 65535			
	Program control selection	Bit0 to Bit4: (Reserved)			
		Bit5: Synchronous motor current detection			
		Bit 6 to bit 12: Reserved			
FB-07		Bit13: Higher voltage/Lower voltage 1.5s	0	-	☆
		detection		- S S	
FB-08	Door close protection time	5 to 99	15	s	☆
FB-09	Door open/close protection times	0 to 20; 0: Disabled	0	-	☆
		0: Closing the door as normal at base floor		- S S S S S S S S S S S S S S S S S S S	
	Door state of standby elevator	1: Waiting with door open at base floor			
FB-10		2: Waiting with door open at each floor	0	-	☆
FB-11	Door open holding time for hall call	1 to 1000	5	s	☆
FB-12	Door open holding time for car call	1 to 1000	3	s	☆
FB-13	Door open holding time upon open delay valid	10 to 1000	30	s	☆

Parameter	Name	Setting Range	Default	Unit	Operation
		FB: Door parameters			
FB-14	Door open holding time at base floor	1 to 1000	10	s	☆
FB-15	Arrival gong output delay	0 to 1000	0	ms	☆
FB-16	Door lock waiting time at manual door	0 to 50	5s	s	☆
FB-17	Holding time for forced door close	5 to 180	120	s	☆
FB-18	Door function selection	Bit0: India manual door Bit1: India semi-automatic door mode 1 Bit2: India semi-automatic door mode 2 Bit3: No open/close limit for doors Bit5: Arrival gong hall call prompt Bit6: 1: Intermittent output of door lock verification prompts; O: Continuous output of door lock verification prompts Bit7: 1: Output continued if door lock is still inactive after three times of verifications; O: Disabled	0	s	☆
FB-19	Holding time for electromagnetic lock close	1 to 60	3	s	☆
FB-20	Holding time for electromagnetic lock release	1 to 60	3	s	☆
FB-21	Holding time for electromagnetic lock feedback	0 to 65535	500	ms	*
FB-22	Time limit for returning to leveling floor in emergency evacuation	0 to 60000	180	s	☆
FB-23	Holding time for door open after emergency evacuation complete	0 to 1000	5	s	☆

Group FC: Protection function parameters

Parameter	Name	Setting Range	Default	Unit	Operation
		FC: Protection function parameters			
		0 to 65535			
		Bit0: Short-circuit to ground detection at power-on enabled			
		Bit1: Canceling current detection at inspection startup			
	Short circuit to ground detection	Bit2: Decelerating to stop at valid light curtain			
	at power-on	Bit3: Password ineffective if no operation within 30 minutes			
		Bit4: Floor number not cleared if door lock is open during			
FC-00		running, elevator continues to run after door lock is closed .	18	-	*
		again			
		Bit 4 to bit 9: Reserved 0 to 65535			
		Bit0: Enable overload protection			
		0: Disabled; 1: Enabled			
		Bit1: Disable output phase loss protection			
		Bit2: Output phase loss protection mode			
		0: Only detection during running			
		1: Detection before and during running			
		Bit3: Reserved			
	Overload protection selection	Bit4: Light curtain judgment at door close limit			
		0: No re-open			
		1: Re-open			
		Bit5: Disable SPI communication judgment			
FC-01		Bit7: Reserved	69	-	*
		Bit8: Reserved			
		Bit9: Canceling Err55 alarm, stop at another floor			
		Bit 10 to bit 13: Reserved			
		Bit14: Canceling protection at input phase loss			

Parameter	Name	Setting Range	Default	Unit	Operation				
FC: Protection function parameters									
FC-02	Overload protection coefficient	0.20 to 10.00	1.00	-	*				
FC-03	Overload pre-warning coefficient	50 to 100%	80%	%	*				
FC-04	Underload detection level	0.0 to 100.0	10.0	%	•				
FC-05	Underload detection time	0.0 to 60.0	1.0	-	•				

If underload protection function is effective, when the output current of the AC drive is less than the value set in FC-04 (Underload detection level), and the underload lasts for longer than the time set in

FC-05 (Underload detection time), the output frequency of the AC drive will decrease to 7% of the rated frequency automatically. During underload protection period, if the load

is recovered, the AC drive will recover to its rated frequency automatically.

Parameters FC-17 to FC-46 record the latest 10 to 20 faults of the elevator. If the 10 detailed fault records are full, the earliest detailed fault record will be moved to the latest brief fault record. For example, if a new fault occurs, the fault code, subcode and time information of the fault recorded in group E9 (fault information) will be moved to FC-17 to FC-19. The brief fault record is a 4-digit number. The two high digits indicate the floor where the car is located when the fault occurs, and the two low digits indicate the fault code. For example, the 1st fault record is 0835, indicating that when the latest brief fault record (fault Err35) occurs, the car is near floor 8. The fault subcode is used to locate the causes of the fault.

Parameter	Name	Setting Range	Default	Unit	Operation
		FC: Protection function parameters			
FC-17	11th fault record	0 to 9999	0	_	•
FC-18	11th fault subcode	The two high digits indicate the floor number, and the two low	0	-	•
	11th fault time	digits indicate the fault code. For example, if Err30 (Elevator	0		
FC-19	12th fault record	position abnormal) occurs at floor 1, the fault record will be		-	•
FC-20		1030. 0: No fault	0	-	•
FC-21	12th fault subcode	1: Reserved	0	-	•
FC-22	12th fault time	2: Overcurrent during acceleration	0	-	•
FC-23	13th fault record	3: Overcurrent during deceleration	0	-	•
FC-24	13th fault subcode	4: Overcurrent during constant speed	0	-	•
FC-25	13th fault time	5: Overvoltage during acceleration	0	-	•
FC-26	14th fault record	6: Overvoltage during deceleration 7: Overvoltage during constant speed	0	-	•
	14th fault subcode	8: Reserved			
FC-27		9: Undervoltage	0	-	•
FC-28	14th fault time	10: AC drive overload	0	-	•
FC-29	15th fault record	11: Motor overload	0	-	•
FC-30	15th fault subcode	12: Power supply phase loss	0	-	•
FC-31	15th fault time	13: Power output phase loss	0	-	•
FC-32	16th fault record	14: Heatsink overheat 15: Power output abnormal	0		•
FC-33	16th fault subcode	16: Encoder fault	0	-	•
	16th fault time	17: Base signal fault			
FC-34		18: Current detection fault	0	-	•
FC-35	17th fault record	19: Motor auto-tuning fault	0	-	•
FC-36	17th fault subcode	20: Rotary encoder fault	0	-	•
FC-37	17th fault time	21: Reserved	0	-	•
FC-38	18th fault record	22: Leveling signal abnormal	0	-	•
FC-39	18th fault subcode	23: Reserved 24: Reserved	0		•
FC-40	18th fault time	25: Data storage abnormal	0	-	•
	19th fault record	26: Earthquake signal			
FC-41		27 to 28 Reserved	0	-	•
FC-42	19th fault subcode	29: PMSM stator shorting contactor feedback abnormal	0	-	•
FC-43	19th fault time	30: Elevator position abnormal	0	-	•
FC-44	20th fault record	33: Elevator speed abnormal	0	-	•
FC-45	20th fault subcode	34: Logic abnormal	0		•
		35: Shaft auto-tuning data abnormal 36: Running contactor feedback abnormal			
		37: Brake contactor feedback abnormal			
		38: Control rotary encoder signal abnormal			
		40: Elevator running time-out			
		41: Safety circuit interrupted			
		42: Door lock open during running			
		43: Up limit signal inactive during running			
		44: Down limit signal inactive during running 45: Up/Down slow-down switch inactive			
		46: Re-leveling abnormal			
FC-46	20th fault time	47: Door lock circuit shorting contactor stuck			
		48: Door open fault			
		49: Door close fault			
		50: Leveling signal continuously missing			
		53: Door lock short-circuit fault	0	-	•
		54: Overcurrent at inspection startup			
		55: Stop at another floor 57: SPI communication fault			
		58: Shaft position switch abnormal			

Group FD: Communication parameters

Parameter	Name	Setting Range	Default	Unit	Operation				
	FD: Communication parameters								
FD-00	Local machine address	0 to 127	1	-	*				
FD-01	Response delay	0 to 20	10	ms	*				
FD-02	Communication time-out	0 to 60.0	0	s	*				

These RS232 serial port communication parameters are used for communication with the monitor software in the host computer. FD-00 specifies the current address of the controller. The setting of these two parameters must be consistent with the setting of the serial port parameters on the host computer. FD-01 specifies the delay for the controller to send data by means of the serial port. Fd-02 specifies the communication timeout time of the serial port. Transmission of each frame must be completed within the time set in this parameter; otherwise, a communication fault occurs.

Group FE: Elevator function parameters

Parameter	Name	Setting Range	Default	Unit	Operation
		FE: Elevator function parameters		,	
		0: Full collective selective			
FE-00	Collective selective mode	1: Down collective selective	0	-	*
		2: Up collective selective 0000 to 1999			
FE-01	Floor 1 display	The two high digits indicate the display code of the ten's digit,	1901	-	☆
FF 02	Floor 2 display	and the two low digits indicate the display code of the terrs digit,	1000		
FE-02		digit Redundant info -	1902	-	☆
FE-03	Floor 3 display	00: Display "0"	1903	-	☆
		01: Display "1"			
FE-04	Floor 4 display	02: Display "2"	1904	-	$\stackrel{\sim}{\sim}$
	Floor 5 display	03: Display "3"			
FE-05	1 loor o dioplay	04: Display "4"	1905	-	☆
FE-06	Floor 6 display	05: Display "5"	1906	_	☆
12 00		06: Display "6"	1000		/ `
FE-07	Floor 7 display	07: Display "7"	1907	-	☆
	Floor O display				
FE-08	Floor 8 display	09: Display "9"	1908	-	☆
FE-09	Floor 9 display	10: Display "A"	1909	_	☆
1 2 03		11: Display "B"	1303		~
FE-10	Floor 10 display	12: Display "G"	0100	-	☆
		13: Display "H"			
		14: Display "L"			
		15: Reserved			
		16: Display "P"			
		17: Reserved			
		18: Display "-"			
		19: No display			
	Floor 11 display	23: Display "C"			
		24: Display "d"			
		25: Display "E"			
		26: Display "F"			
FE-11		28: Display "J"	0101	-	☆
		31: Display "o"			
		35: Display "U"			
		Greater than 35: No display			
		0: 7-segment code			
		1: BCD code			
FE-12	Hall call output selection	2: Gray code			
		3: Binary code	1	-	☆
		4: One-to-one output			

Parameter	Name	Setting Range	Default	Unit	Operation
		FE: Elevator function parameters			
FE-13	Elevator factory function setting selection	0 to 65535 If a bit is set to 1, the function indicated by this bit is enabled: Bit0: Reserved; Bit1: Reserved Bit2: Reserved Bit3: Reserved Bit4: Reserved Bit5: Forced door close Bit6: Door open valid at non-door zone in the inspection state Bit7: Door open and close once after inspection turned to normal Bit8: Reserved Bit9: Independent running Bit10: Reserved	0	-	Å
FE-14	Elevator factory function setting selection	Bit11: Door re-open after car call of the present floor Bit 12 to bit 15: Reserved 0 to 65535 If a bit is set to 1, the function indicated by this bit is enabled: Bit0: Reserved Bit1: Door open holding at open limit Bit2: Door close command not output upon door close limit Bit3: Manual door function selection Bit4: Auto reset for running and brake contactor stuck Bit5: Slow-down switch stuck detection Bit 6 to bit 9: Reserved Bit10: Reserved Bit11: Reserved Bit12: NC output selection of light/fan Bit 13 to bit 15: Reserved	0	-	☆
FE-15	Floor 12 display	Floor display settings are the same as parameters FE-01 to FE-11	0102	-	☆

Group Fr: Leveling adjustment parameters

Parameter	Name	Setting Range	Default	Unit	Operation
	Fr: Leveling adjustment parameters				
Fr -00	Leveling adjustment mode	0 to 1	0	-	*
Fr -01	Leveling adjustment record 1	0 to 15015	0	-	*
Fr -02	Leveling adjustment record 2	0 to 15015	0	-	*
Fr -03	Leveling adjustment record 3	0 to 15015	0	-	*
Fr -04	Leveling adjustment record 4	0 to 15015	0	-	*
Fr -05	Leveling adjustment record 5	0 to 15015	0	-	*
Fr -06	Leveling adjustment record 6	0 to 15015	0	-	*
Fr -07	Leveling adjustment record 7	0 to 15015	0	-	*
Fr -08	Leveling adjustment record 8	0 to 15015	0	-	*
Fr -09	Leveling adjustment record 9	0 to 15015	0	-	*
Fr -10	Leveling adjustment record 10	0 to 15015	0	-	*
Fr -11	Leveling adjustment record 11	0 to 15015	0	-	*
Fr -12	Leveling adjustment record 12	0 to 15015	0	-	*

Group FP: User parameters

Parameter	Name	Setting Range	Default	Unit	Operation
	FP: User parameters				
	Llaar nasaward	0 to 65535			
FP-00	User password	0: No password	0	-	\Rightarrow
		0: No update			
	Updating parameters	1: Restore factory setting			
FP-01		2: Clear recorded information	0 -		*
		0: Disabled			
FP-02	User-defined parameter display	1: Enabled	0	-	*

Group E0: The first set of detailed fault information

Parameter	Name	Setting Range	Default	Unit	Operation
	Group E0: The first set of detailed fault information				
E0-00	1st fault record Latest fault	0 to 9999	0	ı	•
E0-01	1st fault sub-code	0 to 65535	0	-	•
E0-02	1st fault time	0 to 65535	0		•
E0-03	Logic information of 1st fault record	0 to 65535	0		•
E0-04	Curve information of 1st fault record	0 to 65535	0		•
E0-05	Speed reference of 1st fault record	0.000 to 65.535	0	m/s	•
E0-06	Feedback speed of 1st fault record	0.000 to 65.535	0	m/s	•
E0-07	Bus voltage of 1st fault record	0 to 999.9	0	V	•

Parameter	Name	Setting Range	Default	Unit	Operation
E0-08	Present position of 1st fault record	0.0 to 300.0	0	m	•
E0-09	Output current of 1st fault record	0.0 to 999.9	0	Α	•
E0-10	Output frequency of 1st fault record	0.00 to 99.99	0	Hz	•
E0-11	Torque current of 1st fault record	0.0 to 999.9	0	А	•
E0-12	Input state 1 of 1st fault record	0 to 65535	0	-	•
E0-13	Input state 2 of 1st fault record	0 to 65535	0	-	•
E0-14	Input state 3 of 1st fault record	0 to 65535	0	-	•
E0-15	Input state 4 of 1st fault record	0 to 65535	0	-	•
E0-16	Input state 5 of 1st fault record	0 to 65535	0	-	•
E0-17	Input state 6 of 1st fault record	0 to 65535	0	-	•
E0-18	Input state 7 of 1st fault record	0 to 65535	0	-	•
E0-19	Output state 1 of 1st fault record	0 to 65535	0	-	•
E0-20	Output state 2 of 1st fault record	0 to 65535	0	-	•
E0-21	Output state 3 of 1st fault record	0 to 65535	0	-	•
E0-22	Output state 4 of 1st fault record	0 to 65535	0	-	•
E0-23	Output state 5 of 1st fault record	0 to 65535	0	-	•
E9-00	10th fault record	0 to 9999	0	-	•
E9-01	10th fault subcode	0 to 65535	0	-	•
E9-02	10th fault time	0 to 65535	0	-	•
	Logic information of 10th fault	0 to 65535			
E9-03	record	0 10 00000	0	-	•
	Curve information of 10th fault	0 to 65535			
E9-04	record	0.10 00000	0	-	•
F0.05	Speed reference of 10th fault	0.000 to 65.535		,	
E9-05	record		0	m/s	•
E9-06	Feedback speed of 10th fault	0.000 to 65.535	0	m/s	
	record				•
E9-07	Bus voltage of 10th fault record	0 to 999.9	0	V	•
E9-08	Present position of 10th fault record	0.0 to 300.0	0	m	
	Output current of 10th fault record	0.0 to 999.9			
E9-09	Output frequency of 10th fault	0.0 to 999.9	0	A	•
E9-10	record	0.00 to 99.99	0	Hz	•
E9-11	Torque current of 10th fault record	0.0 to 999.9	0	A	•
E9-11	Input state 1 of 10th fault record	0 to 65535	0	-	•
E9-13	Input state 2 of 10th fault record	0 to 65535	0	-	•
E9-14	Input state 3 of 10th fault record	0 to 65535	0	-	•
E9-15	Input state 4 of 10th fault record	0 to 65535	0	-	•
E9-16	Input state 5 of 10th fault record	0 to 65535	0	-	•
E9-17	Input state 6 of 10th fault record	0 to 65535	0	-	•
E9-18	Input state 7 of 10th fault record	0 to 65535	0	-	•
E9-19	Output state 1 of 10th fault record	0 to 65535	0	-	•
E9-20	Output state 2 of 10th fault record	0 to 65535	0	-	•
E9-21	Output state 3 of 10th fault record	0 to 65535	0	-	•
E9-22	Output state 4 of 10th fault record	0 to 65535	0	-	•
E9-23	Output state 5 of 10th fault record	0 to 65535	0	-	•
LJ-23			U		•



6.1 Description of Fault Levels	80
6.2 Fault Information and Troubleshooting	81

6.1 Description of Fault Levels

The controller has almost 70 pieces of alarm information and protective functions. It monitors various input signals, running conditions and feedback signals. If a fault occurs, the system implements the relevant protective function and displays the fault code.

The controller is a complicated electronic control system and the displayed fault information is graded into five levels according to the severity. The faults of different levels are handled according to the following table.

Fault Level	Action	Remarks
Level 1	Display the fault code.Output the fault relay action command.	1A. The elevator running is not affected on any condition.
Level 2	Display the fault code.Output the fault relay action command.	2A. The parallel/group control I function is disabled.
Level 2	■ Continue normal running of the elevator.	2B. The door pre-open/re-leveling function is disabled.
	■ Display the fault code. ■ Output the fault relay action command.	3A. In low-speed running, the elevator stops at special deceleration rate, and cannot restart.
Level 3	Stop output and apply the brake immediately after stop.	3B. In low-speed running, the elevator does not stop. In normal-speed running, the elevator stops, and then can start running at low speed after a delay of 3s.
Level 4	 Display the fault code. Output the fault relay action command. In distance control, the elevator decelerates to stop and cannot run again. 	4A. In low-speed running, the elevator stops at special deceleration rate, and cannot restart. 4B. In low-speed running, the elevator does not stop. In normal-speed running, the elevator stops, and then can start running at low speed after a delay of 3s.
		4C. In low-speed running, the elevator does not stop. In normal-speed running, the elevator stops, and then can start running at low speed after a delay of 3s.
Level 5	■ Display the fault code.■ Output the fault relay action command.■ The elevator stops immediately.	5A. In low-speed running, the elevator stops immediately and cannot restart. 5B. In low-speed running, the elevator does not stop. In normal-speed running, the elevator stops, and then can start running at low speed after a delay of 3s.

6.2 Fault Information and Troubleshooting

If an alarm is reported, the system performs corresponding processing based on the fault level. You can handle the fault according to the possible causes described in the following table.

Fault Code	Fault Description	Probable Causes	Solution	Level
Err02	Overcurrent during acceleration	 The main circuit output is grounded or short circuited. Motor auto-tuning is performed improperly. The load is too heavy. The encoder signal is incorrect. The UPS feedback signal is abnormal. 	 Check whether the running contactor at the controller output side is normal. Check whether the power cable jacket is damaged or possibly short circuited to ground. Check whether the power cable is connected reliably. Check the insulation of motor power terminals, and check whether the motor winding is short-circuited or grounded. Check whether PMSM stator shorting contactor causes controller output short circuit. 	5A
Err03	Overcurrent during deceleration	 The main circuit output is grounded or short circuited. Motor auto-tuning is performed improperly. The load is too heavy. The deceleration rate is too short. The encoder signal is incorrect. 	 Check whether motor parameters comply with the nameplate. Perform motor auto-tuning again. Check whether the brake keeps released before the fault occurs and whether the brake is stuck mechanically. Check whether the balance coefficient is correct. Check whether the encoder wirings are correct. For asynchronous motor, perform SVC and compare the current 	5A
Err04	Overcurrent during constant speed	 The main circuit output is grounded or short circuited. Motor auto-tuning is performed improperly. The load is too heavy. The encoder is seriously interfered. 	 to judge whether the encoder works properly. Check whether encoder pulses per revolution (PPR) is set correctly, encoder signal is interfered, the encoder cable runs through the duct independently, the cable is too long, or the shield is grounded at one end. Check whether the encoder is installed reliably, the rotating shaft is connected to the motor shaft reliably, or the encoder is stable during normal-speed running. Check whether UPS feedback is valid in the non-UPS running state (Err02). Check whether the acceleration/deceleration rate is too high. (Err02, Err03) 	5A
Err05	Overvoltage during acceleration	 The input voltage is too high. The regeneration power of the motor is too high. The braking resistance is too large, or the braking unit fails. The acceleration rate is too short. 	 Adjust the input voltage. Observe whether the bus voltage is normal and whether it rises too quickly during running. Check whether the balance coefficient is correct. 	5A
Err06	Overvoltage during deceleration	 The input voltage is too high. The braking resistance is too large, or the braking unit fails. The deceleration rate is too short. 	 Select a proper braking resistor and check whether the resistance is too large based on the recommended braking resistance table. Check whether the cable connecting the braking resistor is damaged, the cooper wire touches the ground, or the connection is reliable. 	5A
Err07	Overvoltage during constant speed	 The input voltage is too high. The braking resistance is too large, or the braking unit fails. 		5A
Err09	Under voltage	 Instantaneous power failure occurs on the input power supply. The input voltage is too low. The drive control board fails. 	Eliminate external power supply faults and check whether the power fails during running. Check whether the wiring of all power input cables is secure. Contact the agent or Inovance.	5A

Fault Code	Fault Description	Probable Causes	Solution	Level
Err10	Drive overload	 The brake circuit is abnormal. The load is too heavy. The encoder feedback signal is abnormal. The motor parameters are incorrect. Check the motor power cable. 	Check the brake circuit and power input. Reduce the load. Check whether the encoder feedback signal and setting are correct, and whether the initial angle of the encoder for the PMSM is correct. Check the motor parameter setting and perform motor auto-tuning. Check the motor power cable. (See the solution of Err02)	4A
Err11	Motor overload	■ FC-02 is set improperly.■ The brake circuit is abnormal.■ The load is too heavy.	Adjust the parameter (FC-02 can be set to the default value).See the solution of Err10.	ЗА
Err12	Power supply phase loss	The power input phases are not symmetric.The drive control board fails.	 Check whether the three phases of power supply are balanced and whether the power voltage is normal. If not, adjust the power input. Contact the agent or Inovance. 	4A
Err13	Power output phase loss	The output wiring of the main circuit is loose.The motor is damaged.	 Check the wiring. Check whether the contactor on the output side is normal. Eliminate the motor fault. 	4A
Err14	Module overheat	 The ambient temperature is too high. The fan is damaged. The air filter is blocked. 	 Lower the ambient temperature. Clear the air filter. Replace the damaged fan. Check whether the installation clearance of the controller satisfies the requirement. 	5A
Err15	Power output abnormal	Braking short-circuit occurs on the output side.The U, V, W output is abnormal.	 Check wiring of the braking resistor and braking unit is correct, without short-circuit. Check whether the main contactor works properly. Contact the agent or Inovance. 	5A
Err16	Current control fault	 The excitation current deviation is too large. The torque current deviation is too large. The time of exceeding torque upper limit is too long. 	 Check the circuit of the encoder. The output MCCB becomes OFF. The values of the current loop parameters are too small. Perform motor auto-tuning again if the zero-point position is incorrect. Reduce the load if it too heavy. 	5A
Err18	Current detection fault	■ The drive control board fails.	■ Contact the agent or Inovance.	5A
Err19	Motor auto-tuning fault	 The motor cannot rotate properly. The motor auto-tuning times out. The encoder of the PMSM is abnormal. 	 Enter the motor parameters correctly. Check the motor wiring and whether phase loss occurs on the contactor at the output side. Check the encoder wiring and ensure that the encoder PPR is set properly. Check whether the brake keeps released during no-load auto-tuning. Check whether the inspection button is released before the PMSM with-load auto-tuning is finished. 	5A
Err22	Leveling signal abnormal	 101: The leveling signal is active during floor switchover. 102: The falling edge of the leveling signal is not detected during elevator startup and floor switchover. 103: The leveling position deviation is too large in elevator autoruning state. 	 101, 102: Check whether the leveling and door zone sensors work properly. Check the installation verticality and depth of the leveling plates. Check the leveling signal input points of the MCB. 103: Check whether the steel rope slips. 	1A
Err25	Data storage abnormal	■ 101, 102: The storage data of the MCB is abnormal.	■ 101, 102: Contact the agent or Inovance.	4A


Fault Code	Fault Description	Probable Causes	Solution	Level
Err26	Earthquake signal	■ 101: The earthquake signal is active and the duration exceeds 2s.	■ 101: Check that the earthquake signal is consistent with the parameter setting (NC, NO) of the MCB.	3B
Err30	Elevator position abnormal	■ 101, 102: In the normal-speed running or re-leveling running mode, the running time is larger than the value of F9-02, but the leveling signal has no change.	■ 101, 102: Check whether the leveling signal cables are connected reliably and whether the signal copper wires may touch the ground or be short circuited with other signal cables. Check whether the distance between two floors is too large, causing too long re-leveling running time. Check whether signal loss exists in the encoder circuits.	4A
Err34	Logic fault	■ Logic of the MCB is abnormal.	■ Contact the agent or Inovance.	5A
Err35	Shaft auto- tuning data abnormal	 101: When shaft auto-tuning is started, the elevator is not at the bottom floor or the down slow-down is invalid. 102: The system is not in the inspection state when shaft auto-tuning is performed. 103: It is judged upon power-on that shaft auto-tuning is not performed. 104: In distance control mode, it is judged at running startup that shaft auto-tuning is not performed. 106, 107, 109, 114: The plate pulse length sensed at up/down leveling is abnormal. 108, 110: No leveling signal is received within 45s continuous running. 111, 115: The stored floor height is smaller than 50 cm. 112: The floor when auto-tuning is completed is not the top floor. 113: The pulse check is abnormal. 	 101: Check that the down slowdown switch is valid, and that F4-01 (Current floor) is set to 1. 102: Check that the inspection switch is in inspection state. 103, 104: Perform shaft auto-tuning. 106, 107, 109, 114: Check that NO/NC setting of the leveling sensor is set correctly. Check whether the leveling plates are inserted properly and whether there is strong power interference if the leveling sensor signal blinks. Check whether the leveling plate is too long for the asynchronous motor. 108, 110: Check whether the running times out: No leveling signal is received when the running time exceeds F9-02. 111, 115: Enable the super short floor function if the floor distance is less than 50 cm. If the floor distance is normal, check installation of the leveling plate for this floor and check the sensor. 112: Check whether the setting of F6-00 (Top floor of the elevator) is smaller than the actual condition. 113: Check whether the signal of the leveling sensor is normal. Perform shaft auto-tuning again. 	4C
Err36	Running contactor feedback abnormal	 101: The feedback of the running contactor is active, but the contactor has no output. 102: The controller outputs the running signal but receives no running feedback. 103: The startup current of the asynchronous motor is too small. 104: When both feedback signals of the running contactor are enabled, their states are inconsistent. 	 101, 102, 104: Check whether the feedback contact of the contactor acts properly. Check the signal feature (NO, NC) of the feedback contact. 103: Check whether the output cables UVW of the controller are connected properly. Check whether the control circuit of the running contactor coil is normal. 	5A
Err37	Brake contactor feedback abnormal	 101: The output of the brake contactor is inconsistent with the feedback. 102: When both feedback signals of the brake contactor are enabled, their states are inconsistent. 103: The output of the brake contactor is inconsistent with the feedback 2. 104: When both feedback 2 signals of the brake contactor are enabled, their states are inconsistent. 	 101 to 104: Check whether the brake coil and feedback contact are correct. Check the signal feature (NO, NC) of the feedback contact. Check whether the control circuit of the brake contactor coil is normal. 	5A
Err39	Motor overheat	■ 101: The motor overheat relay input remains valid for a certain time.	■ 101: Check whether the thermal protection relay is normal. Check whether the motor is used properly and whether it is damaged. Improve cooling conditions of the motor.	ЗА

Fault Code	Fault Description	Probable Causes	Solution	Level
Err40	Elevator running time-	■ Elevator running time-out	■ Check the related parameter, or contact the agent or Inovance.	4B
Err41	Safety circuit interrupted	■ 101: The safety circuit signal becomes OFF.	 101: Check the safety circuit switches and their states. Check whether the external power supply is normal. Check whether the safety circuit contactor acts properly. Confirm the signal feature (NO, NC) of the feedback contact of the safety circuit contactor. 	5A
Err42	Door lock open during running	■ 101: The door lock circuit feedback is invalid during the elevator running.	■ 101: Check whether the hall door lock and the car door lock are in good contact. Check whether the door lock contactor acts properly. Check the signal feature (NO, NC) of the feedback contact on the door lock contactor. Check whether the external power supply is normal.	5A
Err43	Up limit signal abnormal	■ 101: The up limit switch acts when the elevator is running in the up direction.	■ 101: Check the signal feature (NO, NC) of the up limit switch. Check whether the up limit switch is in good contact. Check whether the limit switch is installed at a relatively low position and acts even when the elevator arrives at the terminal floor normally.	4C
Err44	Down limit signal abnormal	■ 101: The down limit switch acts when the elevator is running in the down direction.	 101: Check the signal feature (NO, NC) of the down limit switch. Check whether the down limit switch is in good contact. Check whether the limit switch is installed at a relatively high position and thus acts even when the elevator arrives at the terminal floor normally. 	4C
Err45	Slow-down switch abnormal	 101: The down slow-down distance is insufficient during shaft autotuning. 102: The up slow-down distance is insufficient during shaft autotuning. 103: The slow-down position is abnormal during normal running. 104, 105: The elevator speed exceeds the maximum speed when slow-down is enabled. 	 101 to 103: Check whether the up slowdown and the down slow-down are in good contact. Check the signal feature (NO, NC) of the up slow-down and the down slow-down. 104, 105: Ensure that the obtained slowdown distance satisfies the slowdown requirement at the elevator speed. 	4B
Err48	Door open fault	■ 101: The consecutive times that the door does not open to the limit reaches the setting in Fb-13.	■ 101: Check whether the door machine system works properly. Check whether the CTB is normal. Check whether the door open limit signal is normal.	5A
Err49	Door close fault	■ 101: The consecutive times that the door does not close to the limit reaches the setting in Fb-13.	■ 101: Check whether the door machine system works properly. Check whether the CTB is normal. Check whether the door lock acts properly.	5A
Err50	Leveling signal continuously missing	 Leveling signal stuck or loss occurs for three consecutive times (Err22 is reported for three consecutive times) 	 Check whether the leveling and door zone sensors work properly. Check the installation verticality and depth of the leveling plates. Check the leveling signal input points of the MCB. Check whether the steel rope slips. 	5A
Err53	Door lock fault	 101: The door lock feedback signal remains active for more than 3s during door open. 102: The multiple door lock feedback signal states are inconsistent for more than 2s. 	■ 101: Check whether the door lock circuit is normal. Check whether the feedback contact of the door lock contactor acts properly. Check whether the system receives the door open limit signal when the door lock signal is valid. 102: Check whether when the hall door lock signal and the car door lock signal are detected separately, the detected states of the hall door locks and car door lock are inconsistent.	5A
Err54	Overcurrent at inspection startup Current	■ The current at startup for inspection exceeds 110% of the rated current.	■ Reduce the load. ■ Change Bit1 of FC-00 to 1 to cancel the startup current detection function.	5A
Err55	Stop at another floor	■ 101: During automatic running of the elevator, the door open limit is not achieved at the present floor.	■ 101: Check the door open limit signal at the present floor.	1A

Fault Code	Fault Description	Probable Causes	Solution	Level
Err57	SPI communication fault	communication.	 101, 102: Check the wiring between the control board and the drive board. 103: Contact the agent or Inovance. 	5A
Err58	Shaft position switch abnormal	 101: The up slowdown and down slowdown are disconnected simultaneously. 102: The up limit feedback and down limit feedback are disconnected simultaneously. 	■ 101, 102: Check whether the states (NO, NC) of the slow-down switches and limit switches are consistent with the parameter setting of the MCB. Check whether malfunction of the slow-down switches and limit switches occurs.	4B
Err62	Analog input cable broken	■ The analog input cable of the CTB or the MCB is broken.	 Check whether F8-08 is set correctly. Check whether the analog input cable of the CTB or MCB is connected incorrectly or broken. 	1A
Err63	Shaft type signal input abnormal	■ The selection of the shaft type is inconsistent with the deceleration signal input.	■ Check the parameter setting of the deceleration signal input.	4A



- ♦ The number (such as 1, 3...101, 102, 103...) in the table indicates the fault subcode.
- ◆ Fault Err41 is not recorded in the elevator stop state.
- ♦ Fault Err42 is reset automatically when the door lock circuit is shorted or 1s after the fault occurs in the door zone.
- ♦ If faults Err51 and Err52 persist, they are recorded once every one hour.



A.1	Definition of Terms	.88
A2	Introduction to EMC Standard	. 88
	A2.1 EMC Requirements for Installation Environment	. 88
	A22 Requirements on Satisfying the EMC Directive	. 88
A3	Selection of Peripheral EMC Devices	. 89
	A3.1 Installation of EMC Input Filter on Power Input Side	. 89
	A32 Installation of AC Input Reactor on Power Input Side	. 89
A.4	Shielded Cable	. 90
	A4.1 Requirements for Shielded Cable	. 90
	A42 Installation Requirements	. 91
	A43 Cabling Requirements	. 91
A.5	Solutions to EMC Interference	. 92

A1 Definition of Terms

- ◆ Electromagnetic compatibility (EMC) describes the ability of electronic and electrical devices or systems to work properly in the electromagnetic environment and not to generate electromagnetic interference that influences other local devices or systems. In other words, EMC includes two aspects: The electromagnetic interference generated by a device or system must be restricted within a certain limit; the device or system must have sufficient immunity to the electromagnetic interference in the environment.
- First environment: Environment that includes domestic premises. It also includes establishments directly connected without intermediate transformers to a low-voltage power supply network which supplies buildings used for domestic purposes.
- ♦ Second environment: Environment that includes all establishments other than those directly connected to a low-voltage power supply network which supplies buildings used for domestic purposes.
- Category C1 controller: Power Drive System (PDS) of rated voltage less than 1,000 V, intended for use in the first environment.
- Category C2 controller: PDS of rated voltage less than 1 000 V, which is neither a plug in device nor a movable device and, when used in the first environment, is intended to be installed and commissioned only by a professional person.
- ♦ Category C3 controller: PDS of rated voltage less than 1 000 V, intended for use in the second environment and not intended for use in the first environment.
- Category C4 controller: PDS of rated voltage equal to or above 1 000 V, or rated current equal to or above 400 A, or intended for use in complex systems in the second environment.

A2 Introduction to EMC Standard

A.2.1 EMC Requirements for Installation Environment

The integrator of the system installed with the controller is responsible for compliance of the system with the European EMC directive and standard EN 61800-3: 2004 +A1: 2012 Category C2, C3 or C4 according to the system application environment.

Machines and devices used in combination with the controller must also be CE certified and marked. The integrator who integrates the drive with the CE mark in into other devices has the responsibility of ensuring compliance with European directives and verifying that conditions meet requirements of EN 61800-3: 2004 Category C2.



NOTE

When applied in the first environment, the controller may generate radio interference. Besides the CE compliance described in this chapter, take measures to avoid the radio interference if required.

A.2.2 Requirements on Satisfying the EMC Directive

- The model selection table lists the recommended manufacturers and models of EMC filters which is required for the controller to fulfill EMC requirements. Keep the length of the connection cable between the controller and filter as short as possible. Recommended length is less than 30 cm. Install the filter and the controller on the same sheet metal. The PE terminals of the controller and the grounding point of the filter must be well connected with the sheet metal.
- Select the motor and control cable types according to the description in Shielded Cable.
- ◆ Perform the wiring of the controller according to instructions in Installation and Wiring.
- ♦ An AC input reactor is installed to eliminate the harmonics of the input current.

A.3 Selection of Peripheral EMC Devices

A.3.1 Installation of EMC Input Filter on Power Input Side

An EMC filter installed between the controller and the power supply can not only restrict the interference of electromagnetic noise in the surrounding environment on the controller, but also prevents the interference from the controller on the surrounding equipment. The controller satisfies the requirements of category C2 only with an EMC filter installed on the power input side. The installation precautions are as follows:

- Strictly comply with the ratings when using the EMC filter. The EMC filter is category I electric apparatus, and therefore, the metal housing ground of the filter should be in good contact with the metal ground of the installation cabinet on a large area, and requires good conductive continuity. Otherwise, it will result in electric shock or poor EMC effect.
- ◆ The grounds of the EMC filter and the PE conductor of the controller must be tied to the same common ground.

 Otherwise, the EMC effect will be affected seriously.
- The EMC filter should be installed as closely as possible to the power input side of the controller.

The following table lists the recommended manufacturers and models of EMC filters for the controller. Select a proper one based on actual requirements.

Power Rated AC Input Filter Model AC Input Filter Model Capacity Controller Model Input Changzhou Jianli (Schaffner) (kVA) Current (A) Three-phase 380 V, range: -15% to 15% NICE-L-I-4003 8.9 14.8 DL-16EBK5 FN 3258-16-33

Table A-1 Recommended manufacturers and models of EMC filter

A.3.2 Installation of AC Input Reactor on Power Input Side

NICE-L-I-4005

An AC input reactor is installed to eliminate the harmonics of the input current. As an optional device, the reactor can be installed externally to meet strict requirements of an application environment for harmonics. The following table lists the recommended manufacturers and models of input reactors.

Table A-2 Recommended manufacturers and models of AC input reactors

Controller Model	Power Capacity (kVA)	Rated Input Current (A)	AC Input Reactor Model (Inovance)		
Three-phase 380 V, range: -15% to 15%					
NICE-L-I-4005	8.9	14.8	MD-ACL-15-0.93-4T-2%		

A.4 Shielded Cable

A.4.1 Requirements for Shielded Cable

The shielded cable must be used to satisfy the EMC requirements of CE marking. Shielded cables are classified into three-conductor cable and four-conductor cable. If conductivity of the cable shield is not sufficient, add an independent PE cable, or use a four-conductor cable, of which one phase conductor is PE cable. See the illustration below.




Figure A-1 Cross-secion of shielded cable

The motor cable and PE shielded conducting wire (twisted shielded) should be as short as possible to reduce electromagnetic radiation and external stray current and capacitive current of the cable.

To suppress emission and conduction of the radio frequency interference effectively, the shield of the shielded cable is cooper braid. The braided density of the cooper braid should be greater than 90% to enhance the shielding efficiency and conductivity. See the illustration below.




Figure A-2 Braided density of cooper braid

It is recommended that all control cables be shielded. The grounding area of the shielded cable should be as large as possible. A suggested method is to fix the shield on the sheet metal using the metal cable clamp so as to achieve good contact.




Figure A-3 Metal cable clamp fixing the shield

The following figure shows the grounding method of the shielded cable.




Figure A-4 Grounding of shieled cable

A.4.2 Installation Requirements

- All the shielded cables should use shielded pair cables. Four-conductor cables may also be used for input cables.
- ◆ The motor cable and PE shielded conducting wire (twisted shielded) should be as short as possible to reduce electromagnetic radiation and external stray current and capacitive current of the cable. If the motor cable is over 100 meters long, an output filter or reactor is required.
- It is recommended that all control cables be shielded.
- The output power cable of the AC drive should use shielded cable, and the shield must be reliably grounded. For lead cables in exposure to interference, twisted pair shielded control cable should be used and the shield must be reliably grounded.

A.4.3 Cabling Requirements

- ♦ The motor cables must be far away from other cables. Recommended distance is bigger than 0.5 m. The several controllers can be laid in parallel.
- ◆ To avoid electromagnetic interference caused by rapid change of the output voltage of the controller, the motor cables and other cables must not be laid side by side for a long distance. It is recommended that the motor cables, power input cables and control cables be laid in different trunking. The cable trunking must be in good connection and well grounded.
- If the control cable must run across the power cable, make sure they are arranged at an angle of close to 90°. Other cables must not run across the drive.
- ◆ The power input and output cables of the controllers and weak-current signal cables (such as control cable) should be laid vertically (if possible) rather than in parallel.
- ◆ The cable trunking must be in good connection and well grounded. Aluminum trunking can be used to improve electric potential.
- ♦ The filter, controllers and motor should be connected to the system (machinery or appliance) properly, with spraying protection at the installation part and conductive metal in full contact.
- ◆ The motor should be connected to the system (machinery or appliance) properly, with spraying protection at the

installation part and conductive metal in full contact.




Figure A-5 Cabling requirements

A.5 Solutions to EMC Interference

The controller generates very strong interference. Although EMC measures are taken, the interference may still exist due to improper cabling or grounding during use. When the controller interferes with other devices, adopt the following solutions.

Interference Type	Solution		
ELCB tripping	■ Connect the motor housing to the PE of the controller .		
	■ Connect the PE of the controller to the PE of the mains power supply.		
	■ Add a safety capacitor to the power input cable.		
	Add magnetic rings to the input drive cable.		
Controller interference during running	■ Connect the motor housing to the PE of the controller.		
	■ Connect the PE of the controller to the PE of the mains power supply.		
	■ Add a safety capacitor to the power input cable and wind the cable with magnetic rings.		
	■ Add a safety capacitor to the interfered signal port or wind the signal cable with magnetic rings.		
	Connect the equipment to the common ground.		
	■ Connect the motor housing to the PE of the controller.		
	■ Connect the PE of the controller to the PE of the mains power supply.		
	■ Add a safety capacitor to the power input cable and wind the cable with magnetic rings.		
Communication	■ Add a matching resistor between the communication cable source and the load side.		
interference	■ Add a common grounding cable besides the communication cable.		
	■ Use a shielded cable as the communication cable and connect the cable shield to the common grounding point.		
I/O interference	■ Enlarge the capacitance at the low-speed DI. A maximum of 0.1 uF capacitance is suggested.		
	■ Enlarge the capacitance at the Al. A maximum of 0.22 uF is suggested.		

Revision History

Date	Revision	Change description
April 2018	A00	First issue.



by INOVANCE technology

Forward, Always Progressing! Inova Automation Pvt., Limited Chennai Head Office, Tamil Nadu

Add: III Floor, "NIBHI CORPORATE CENTRE", No.7, CBI Colony, 1st Main Link Road,

Perungudi, Chennai – 600 096.

www.inova-automation.com

www.inovance.cn (Industrial Automation)

www.szmctc (Monarch Elevator&Escalator Solutions)