

Preonic — DoorOfLife v2

Drop + OLKB Preonic rev3 · `preonic/rev3_drop` · layout `LAYOUT_preonic_1x2uC`

What you actually type on

Colemak at rest, with the always-on Function layer already applied. **This is the board in front of you when nothing is held.**

Esc	1	2	3	4	5	6	7	8	9	0	=
F7	Q	W	F	P	G	J	L	U	Y	–	R-ALT Menu
Tab	A	R	S	T	D	H	N	E	I	O	Bksp
Shift	Z	X	C	V	B	K	M	;	\	/	SHIFT Enter
Ctrl	Super	L-ALT Del	MEDIA `	F-KEYS Home	Space		MOUSE End	NAV ,	.	,	SETTINGS R-Ctrl

- Comes from the **letter layer**. These are the only keys that move when you swap Colemak ↔ QWERTY.
- Comes from the **Function layer**. Identical in both layouts.
- Layer key** — the black bar names the layer you reach by holding it.
- Dual-role** — taps as the big label, acts as the small one when held.

Reaching the other layers

Five keys along the bottom edge and right side. Each still types its own legend when tapped; hold it past **180 ms** and it switches layer instead.

HOLD THIS	TO REACH
<code>`</code> (backtick)	Media
Home	F-keys
End	Mouse
<code>,</code> (comma)	Navigation
R-Ctrl	Settings

Swapping Colemak and QWERTY

Hold **right Ctrl**, then press the key marked **COLEMAK**, **SWAP** or **QWERTY** on the Settings layer. Those are the same three physical keys whichever layout you are in, but they carry different letters — **A / R / S** in Colemak, **A / S / D** in QWERTY. The board plays that layout's own tune so you know it took, and remembers the choice across unplugging.

Function layer — always on

Always on. Every modifier, number, symbol and layer key lives here. Dotted cells are where the letter layer shows through.

Esc	1	2	3	4	5	6	7	8	9	0	=
F7	.	.	.	.	.	.	.	.	.	—	R-ALT Menu
Tab	.	.	.	.	.	.	.	.	.	.	Bksp
Shift	.	.	.	.	.	.	.	;	\	/	SHIFT Enter
Ctrl	Super	L-ALT Del	MEDIA ,	F-KEYS Home	Space		MOUSE End	NAV ,	.	.	SETTINGS R-Ctrl

The two letter layers

Only letters live here. Everything else is dotted, because the Function layer above supplies it — which is why swapping layouts cannot disturb your modifiers, numbers or layer keys.

COLEMAK

Your normal typing layout. Letters only — everything else comes from Function.

.	.	.	.	.	.	.	.	.	.	.	.
.	Q	W	F	P	G	J	L	U	Y	.	.
.	A	R	S	T	D	H	N	E	I	O	.
.	Z	X	C	V	B	K	M	.	.	.	.
.	.	.	.	.	.		.	.	.	.	.

QWERTY

Same board, QWERTY letters, for games that read key positions as QWERTY.

.	.	.	.	.	.	.	.	.	.	.	.
.	Q	W	E	R	T	Y	U	I	O	.	.
.	A	S	D	F	G	H	J	K	L	P	.
.	Z	X	C	V	B	N	M	.	.	.	.
.	.	.	.	.	.		.	.	.	.	.

QWERTY puts P on the home row, not the top row — the top-row spot it would want is — on the Function layer. WASD, the number row and the modifiers are all where a game expects them, which is the point.

F-keys layer

Hold Home.

F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12
*	PgDn	*	PgUp	Home	*	*	*	*	*	*	*
Ins	*	*	*	End	*	*	*	*	*	*	*
*	*	*	*	*	*	*	*	*	*	*	*
*	*	*	*	*	*		*	*	*	*	*

Navigation layer

Hold comma. Arrows and brackets left, numeric keypad right.

Bksp	[	Enter	]	Ins	*	*	*	NumLk	/	*	—
Del	Home	↑	End	(	PgUp	*	*	7	8	9	+
*	←	↓	→	)	PgDn	*	*	4	5	6	,
*	PrtSc	NumLk	Caps	*	*	*	*	1	2	3	=
*	*	*	*	*	*		*	0	0	.	Enter

The right-hand block is the **numeric keypad**, not the number row — it sends keypad codes, so it works with Num Lock as you'd expect.

Mouse layer

Hold End. Move the pointer without leaving the keyboard.

*	Slow	Medium	Fast	*	*	*	*	*	*	*	*
*	L-click	↑	R-click	Wheel ↑	*	*	*	*	*	*	*
*	←	↓	→	Wheel ↓	*	*	*	*	*	*	*
*	*	*	*	*	*	*	*	*	*	*	*
*	*	*	*	*	*		*	*	*	*	*

Media layer

Hold backtick.

*	*	*	*	*	*	*	*	*	*	*	*
*	Vol –	Play	Vol +	*	*	*	*	*	*	*	*
*	Rew	Stop	Fwd	*	*	*	*	*	*	*	*
*	Prev	Mute	Next	*	*	*	*	*	*	*	*
*	*	*	*	*	*		*	*	*	*	*

Settings layer

Hold right Ctrl. Layout switching, lighting, sound, and the bootloader.

NKRO on	*	*	*	*	*	*	*	*	*	*	BOOTLOADER
Light on/off	*	Colour +	*	Bright +	Speed +	*	*	*	*	*	*
*	COLEMAK	SWAP	QWERTY	*	*	*	*	*	*	*	*
*	Mode –	Colour –	Mode +	Bright –	Speed –	*	*	*	*	*	*
Wipe settings	*	*	*	*	Sound on/off		*	*	*	*	*

Every dual-role key

Tap is under **180 ms**. For the layer and Alt keys, pressing another key while holding commits to the hold immediately, so fast typing does not produce stray letters.

TAP FOR	HOLD FOR
Menu	R-Alt
Enter	Shift
Del	L-Alt
` (backtick)	MEDIA

TAP FOR	HOLD FOR
Home	F-KEYS
End	MOUSE
, (comma)	NAV
R-Ctrl	SETTINGS

Enter/Shift is the exception. It is a Space Cadet key, not a mod-tap, so it ignores that rule: it sends Enter on release whenever it was held for less than 180 ms, even if you pressed something else in between. Typing a fast capital with the right pinky can therefore produce a stray Enter. This matches the 2021 board, which used the same key — it is inherited behaviour, not new.

Knowing which mode you are in

Two signals, answering two different questions.

The underglow says where you are. At rest it shows the letter layout; while a layer key is held it shows that layer.

UNDERGLOW	MEANS
Teal	Colemak — at rest
Amber	QWERTY — at rest
Magenta	F-keys — while held
Violet	Navigation — while held
Green	Mouse — while held
Red	Media — while held
Blue	Settings — while held

A sound says something changed. Swapping letter layout plays that layout's own short tune, so you know it took effect without looking.

Layer colouring stands aside if you turn the light off or pick an animation, and it keeps whatever brightness you set. It is an indicator, not a hijack.

If something goes wrong

Three ways into the bootloader, most convenient first. The last one works even if the firmware is completely broken.

1. **Hold right Ctrl, then the top-right key** — that is `BOOTLOADER` on the Settings layer.
2. **Hold the top-left key while plugging in.** Built into the keyboard, so it works whatever keymap is loaded.
3. **The `reset` pinhole** on the back plate, top right. A paperclip reaches it with the case assembled; it depends on no firmware at all.

```
make preonic/rev3_drop:dooroflife_v2:flash    # this layout
make preonic/rev3_drop:dooroflife:flash        # the 2021 layout, unchanged
```

Generated from `keyboards/preonic/keymaps/dooroflife_v2/keymap.c`. Re-run `preonic-cheatsheet/make_cheatsheet.py` after changing the keymap.