AX-40 EQUIPMENT MAINTENANCE MANUAL

Fictional training document

1. Overview

The AX-40 is a fictional air circulation unit. Isolate the power supply before maintenance and allow moving parts to stop.

Inspect the intake grille weekly and clean it when dust is visible.

2. Technical specifications

Specification	Value
Model	AX-40
Rated voltage	24 V DC
Rated current	2.5 A
Airflow	180 m³/h
Operating temperature	5 °C to 40 °C
Filter inspection interval	30 days

AX-40 EQUIPMENT MAINTENANCE MANUAL

Fictional training document

3. Maintenance procedure

1. Switch off and isolate the power supply.
2. Remove the intake cover and inspect the filter.
3. Clean or replace the filter, then reinstall the cover.
4. Restore power and check for unusual noise.

4. Airflow diagram

Figure 1. Air moves from the intake through the filter to the fan.