Timbres in the Music Library

Bass timbres in BAS-DATA

	BANI	K 1	BANK 2		BANK 3		BANK 4	1
1 2 3 4 5 6 7 8			ABS40/41 Piz ABS40/41 Piz ABS40 Piz FF ABS41 Piz MP ABS42 Bowed ABS42 Bowed	2.5 5.6	EBS10 EBS11 EBS12 EBS13 Muted EBS13 Gliss EBS13 Ticks EBS12/13	0.8 1.0 0.8 0.1 0.4 0.1 0.9	EBS40/41 EBS40/41 EBS41/42 EBS40 ————————————————————————————————————	1.1 1.1 0.7 0.4 0.4 0.4 0.8
	BANI	K 5	BANK 6		BANK 7		BANK 8	3
1	EBS46	10.2		_				
2	EBS47	8.7						
3	EBS48	8.4			-			
4					-			
5								
6								
8								

ABS	Acoustic bass	FF	fortissimo
EBS	Electric bass	Gliss	glissando
		MP	mezzo piano
		Piz	pizzicato

Brass timbres in BRS-DATA

FHN French horn

FLG Fluegelhorn

TBN Trombone TPT Trumpet

	BANK 1	BANK 2		BANK 3		BANK 4	
1 -		1111440/47 24	7.4	TBN43	4.7	TPT46/41 2V	5.3
2 -		111140	6.4	TBN44	0.4	TPT47	1.8
3 -		FHN41	1.1	TBN44	0.4	TPT49	3.7
4 -		FHN42	3.4	TPT40/41 2V	9.6		_
5 -		FLG40	1.2	TPT42	5.1		
6 -		FLG40 LP	1.2	TPT42	3.4		
7 -		TBN40/41 2V	8.3	TPT44	4.5		
8 -		TBN42	7.1	TPT44	2.9		
1 - 2 - 3 - 4 - 5 - 6 -	BANK 5			BANK 7		BANK 8	
7 -							
8 -							

LP

2V

looped

two voices

Drum and cymbal timbres in DRM-DATA

	BANK 1	BANK 2		BANK 3	BANK 4		
1		BDR40/41 #1	0.6	BDR70 3V HM	1.1	SNR40/41 #1	0.4
2		BDR40/41 #2	0.4	BDR71 3V SM	1.2	SNR40/41 #2	0.5
3		BDR42	0.1	BDR70 HM	1.1	SNR40/41 #3	0.2
4		BDR43	0.1	BDR71 SM	1.2	SNR40/41 #4	0.2
5		BDR44	0.1		_	SNR40/41 #5	0.1
6		BDR45	0.1				Y-
7		BDR46	0.2			SNR50	6.8
8		BDR50	4.7		_		

	BANK 5		BANK 6		BANK 7	BANK 8	
1	TOM40/41	2.4	DRM KIT #1	2.4		CRA40/41	1.9
2	TOM42	1.1	DRM KIT #2	2.6		CRA42	2.2
3	TOM43	0.2	DRM KIT #3	2.9		-	
4	TOM50	6.5	DRM KIT #4	1.8		HIH40/41	5.1
5			DRM KIT #5	2.1		HIH40/41	2.5
6			DRM KIT #6	3.5		HIH40/41	1.6
7	XTK40/41	0.3				RID40/41	6.2
8	XTK40/41	0.2				SPL40/41	1.0

BDR	Bass drum	SNR	Snare drum	HM	hard mallet
CRA	Crash cymbal	SPL	Splash cymbal	SM	soft mallet
HIH	Hi-hat cymbal	TOM	Tom-tom	3V	three voices
RID	Ride cymbal	XTK	Drums played with cros	s-stick	

4.4 Music Library

Keyboard timbres in KBD-DATA

	BANK 1		BANK 2		BANK 3		BANK 4	
1 2 3					HPC10 HPC11 HPC15	6.6 10.3 12.0	EPN01-03 EPN01-03 Trm	5.9 5.9
4 5 6 7 8			PNO40 PNO41 PNO42/43 PNO44 PNO71-74	5.7 3.7 Low 2.9 3.8 16.0	HPC16 HPC40/41/42 HPC40/41 HPC41/42	9.4 2.9 1.7 1.7	ORG12/13 2V ORG12 ORG13 CST10	6.4 3.3 3.1 3.4
	BANK	5	BANK	6	BANK 7		BANK 8	
1	SYN40	1.2	SYN48	1.4	SYN52	1.5	SYN60	1.2
2	SYN41	0.8	SYN49	1.9	SYN53	0.5	SYN61	2.8
3	SYN42	0.7	SYN50	0.7	SYN54	1.0	SYN62	0.9
4	SYN43	1.1	SYN50	0.7	SYN55	0.5	SYN63	0.4
5	SYN44	1.9	SYN50	0.7	SYN56	0.7		
6	SYN45	1.4	SYN51	1.9	SYN57	0.5		
7	SYN46	0.4	SYN51	1.9	SYN58	0.6		
8	SYN47	0.4	SYN52	1.5	SYN59	0.4		
	CST EPN HPC	Celesta Electric Harpsict		PNO A	rgan coustic piano ynthesizer	Trr 2V		

Percussion timbres in PRC1DATA

	BANK 1	BANK 2	BANK	BANK 3		1
1			- CBL01	0.2	CBL05	0.1
2	-		CBL01 3V	0.2	CBL06	0.1
3			CBL02	0.2	CLV01/02	0.1
4			CBL02 3V	0.2	CBA01	0.1
5			- CBL03	0.8	CBA02	0.1
6			- CBL03	0.4	GUI01	1.1
7			- CBL03	0.3	GUI01 3V	1.1
8			- CBL04	0.4	GUI02	0.4

	BANK 5		BANK 6		BANK 7		BANK 8	
1	GUI02	0.4	MPC04	0.4	TBL01	0.7		
2	RAT01	0.5	MPC11/12	0.5	TMB01	0.4		
3	MPC01	0.7	MPC13	0.1	TAM01	0.5		
4	MPC16	0.5	MPC16	0.5	TRI01	0.4		
5	MPC02	0.8	CGA01 Tumba	0.2	WBK01	0.1		
6	MPC02	0.8	CGA01 Conga	0.4	WBK01	0.1		
7	MPC03	0.2	CGA01 Quinto	0.4	WBK02	0.1		
8	MPC04	0.4	CGA02	0.1				

CBA	Cabassa	RAT	Ratchet	TRI	Triangle
CBL	Cowbell	TAM	Tambourine	WBK	Wood block
CGA	Conga drum	TBL	Tabla	3v	three voices
CLV	Clave	TMB	Timbale		
GUI	Guiro				
MPC	Miscellaneous perc	ussion			

4.6 Music Library

Percussion timbres in PRC2DATA

	BANK 1		BANK 2		BANK 3	BANK 3		BANK 4	
1 2 3					GNG40 3V GNG40 Whip	2.2 0.7	TMP40 TMP55/56/57 TMP65/66/67	1.6 6.4 6.3	
5 6 7 8			CHI01-03 CHI40	16.6 3.6		3.2 1.2 0.9 0.2 0.3	TMP76/77 TMP86/87 ————————————————————————————————————	4.9 2.9 4.9 2.1	
	BANK 5		BANK	6	BANK 7		BANK 8		
1 2 3 4	MBA10/11 2V MBA12/13 2V MBA40/41 MBA40	3.8 8.7 1.5 0.9	SHK01 SHK01 2V SHK02 SHK03	0.1 0.1 0.1 0.1	SHK06 2V SHK07	0.1 0.1 0.1 0.1	SHK10	0.1	
5 6 7 8	MBA41 VIB10/11 XYL10/11 2V OBL40	0.7 5.6 2.0 2.0	SHK04 SHK04 2V SHK05 SHK05 2V	0.1 0.1 0.1 0.1	SHK08 2V SHK09	0.1 0.1 0.2 0.2	STD10 STD11 STD40 2V STD40	1.9 2.9 0.7 0.7	
	GNG G KBA K MBA M MBL M	hime ong alimba arimba iscellar rchestra	neous bells al bells	SHK STD TMP VIB WPH XYL	Shaker Steel drum Tympani Vibraphone Waterphone Xylophone	2V 3V			

String timbres in STG-DATA

	BANK 1	BANK	BANK 2		BANK 3		BANK 4	
1		BJO40	2.3	HRP40	2.7	HRP42	0.6	
2		SYN55	0.5	HRP41	10.0	HRP42	0.6	
3		GTR41	5.0	HRP41	5.2	HRP42	0.7	
4		GTR42	1.3	HRP42 Arpeg	5.3	HRP42	0.5	
5		GTR43	2.5	HRP42	0.7	HRP42	0.4	
6		GTR44	4.2	HRP42	0.6	HRP42	0.8	
7	X	GTR48	0.1	HRP42	0.5	HRP42	0.5	
8		HRP40	4.4	HRP42	0.6	HRP43	0.6	

	BANK 5		BANK 6		BANK 7	BANK 8	
1	STG40	2.1	VLN40	2.0			
2	CLO40/42	5.0	VLN41 VLN42	5.0 5.4			
4	CLO41/42	3.9	VLN43-45	4.9			
5	CLO42/43	8.0					
6 7 8	VLA40/42	5.7					

BJO	Banjo	STG	Strings	Arpeg	arpeggiated
CLO	Cello	VLA	Viola		
GTR	Guitar	VLN	Violin		
HRP	Harp				

Woodwind timbres in WND-DATA

	BANK 1	BANK 2	BANK 3		BANK 4	
1			BSN40	10.1	FLT40/41	4.8
2			BSN40	5.6	FLT40	7.5
3			B\$N41	1.9	FLT41	0.2
4			CLT40	5.9	FLT42	0.2
5			CLT41	1.0	FLT43	1.2
6			EHN40	6.3	FLT44	5.9
7			EHN41	1.7	FLT45	3.5
8			FLT40/41	7.7	FLT46	5.3

	BANK 5		BANK 6		BANK 7		BANK 8	
1	FLT44/46	11.2	MWW40 3V	0.7	VOX40	3.1		1.2
2	FLT45/46	8.8	MWW41 2V	1.4	VOX41	5.8		
3	OBQ10/11	5.2	MWW41	0.7	VOX42	2.3		
4	OBO11	4.7	MWW41	0.7				
5	OBO10	0.4	MWW42	0.2		- 4		
6	•		MWW42 LP	0.2			-	
7	SSX40/41 2V	3.1	MWW43	0.4				
8	TSX40	1.1	MWW43	0.4		_		

BSN	Bassoon	SSX	Soprano saxophone	LP	looped
CLT	Clarinet	TSX	Tenor saxophone	2V	two voices
EHN	English hom	VOX	Voice	3V	three voices
FLT	Flute				
MWW	Miscellaneous woody	vinds			
OBO	Ohne				