
Cummins Parts N-855-F, NT-855-F1, F2 Industrial Fire Pump Engines Catalog

Bulletin: 3379508



Parts Ordering for: N855F, NT855F1, F2 FirePumpEngines

Genuine Cummins Parts and service facilities are worldwide. There are more than 2400 Cummins Sales and Service locations in the principal cities of the United States and Canada, and more than 500 Sales and Service locations situated elsewhere throughout the free world. Each distribution outlet is thoroughly equipped with technical data, factory-trained mechanics, modern equipment and a full, adequate stock of Genuine Cummins Parts.

For quicker and better service, your parts requirements should be ordered from your nearest Cummins Distributor or Dealer. At any of the locations prompt, intelligent, courteous service is a basic trademark. Each is ready and eager to help in every possible way through personal contact or through the mail — at your convenience.

The satisfactory ordering and receiving of parts by the purchaser is greatly dependent upon the proper use of available information. In order that all avoidable errors may be eliminated, the following instructions are offered as the purchaser's guide:

1. Write your order clearly, using a typewriter if possible.

- Be sure to list the correct part number. If in doubt as to the correct part number, state the model and serial number of the engine on which the part is to be used. Part numbers are usually located in various places on the part itself.
- 3. When possible, arrange your purchase order in part number numerical sequence.
- Always specify shipping instructions "Best Way" is satisfactory if you have no preference
- 5. State your company name and shipping address clearly.


Genuine Cummins Parts mean QUALITY! They're designed and engineered to fit best in your Cummins Diesel. Each part is made of the highest quality material — on the most accurate of machines — by the top craftsmen of the trade.

You can be sure a Genuine Cummins Part will fit better — do the job better — lessen the chances of costly breakdown. When you buy replacement parts, buy quality. Buy Genuine Cummins Parts!


YOU OWN THE BEST . . . REPAIR WITH THE BEST


Table of Contents

Page	Page
Accessory Drive Pulley	Gear Cover
Alternator	Glow Plug
Air Cleaner	Heat Exchanger
Air Intake Manifold	Injector
Cam Follower And Housing	Instrument Panel
Camshaft	Lubricating Oil Cooler
Camshaft Bushings	Lubricating Oil Filter
Connecting Rods	Lubricating, Oil By Pass Filter
Corrosion Resistor	Lubricating Oil Pan
Crankcase Breather	Lubricating Oil Pump
Crankshaft	Main Bearings
Cylinder Block	Miscellaneous
Cylinder Head	Overspeed Stop
Cylinder Liners	Piston And Piston Rings 4
Dipstick And Tube	Piston Cooling Nozzle
Electrical Equipment	Push Rods
Exhaust Manifold	Rear Cover
Flange And Stub Shaft	Relay Contactor
Flywheel Housing	Rocker Levers, Cover And Housing 10,11
Flywheel And Ring Gear	Shutdown Valve
Flywheel Support	Starting Motor
Front Engine Support	Thermostat, Fire Pump
Fuel Filter	T-50 Turbocharger
Fuel Pump And Damper	Vibration Damper
Fuel Pump Drive	Water Manifold
Fuel Tubing	Water Pump
Gasket Sets 35	




ENGINE APPLICATION	CATION AUTOMOTIVE B.			AY	C- CONSTRUCTION	ON & INDUSTRIAL	P-I	NDUSTRIA	L POWE	R
PART NUMBER	PART NAME		NO. REQ'D	REF. NO.	PART NUMBER	PAR	TNAME		NO. REQ'D	REF. NO.
N-85 AR-09883 Bloc BM-27253 Bush 100670 Bush 157870 Bush 177734 Caps	k, cylinder (216810) ing assembly, camshai ing ing crew, cylinder head		1 1 1 6 36	1 2 3 4	S-129 S-190-C 199067 202903 132648 67963 S-604	MOUNTING PA Capscrew (3/8"- Capscrew (3/8"- Plug, pipe Pin, thrust ring Flange, oil pan s Gasket, suction Lockwasher (3/8	24 x 1'') 24 x 5/8'' uction flange	')	2 1 1 2 1 1 1	36 37 38 39 40 41
105953 Caps 69305-A Cove 68585 Dow to bl 67211 Dow 68445 Dow 9226 Dow 60408 Dow 70653 Dow 70089-1 Gask 9427 Lock 5-600 Lock 199067 Plug S-908 Plug S-911-B Plug S-911-B Plug S-966-E Plug S-901 Plug S-901 Plug S-910-B Plug S-910-B Plug S-915-A Plug S-716 Plug S-716 Plug S-716 Plug S-719 Plug	eel, main bearing cap to tel, head to block el, flywheel housing el, gear cover el, gear cover (Diamor et, water header cover ciplate (Washer, water header pipe pipe (3/8") pipe (3/4") pipe (1/8") pipe (1/4") pipe (1/4") pipe (1/4") pipe (1/4") pipe (1/4") pipe (1/2") hex socket expansion ner, Cylinder head	p ing o block and)	12 14 2 6 2 6 2 1 1 1 2 1 6 1 1 1 1 2 6 2 4 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	5 6 7 8 9 10 11 12 13 14 15 16 17 45 18 19 35 20 21 22 23 24 25	213740 202736 203245 214606 194115 183049 183056 S-2286 S-679 143938 143939 .143946 143947 143948 143947	Liner, cylinder Nameplate NT-2 Nameplate (B, C Retainer Ring, packing Seal, crevice Screw, nameplat Washer (25/64") Shim, liner (.003 Shim, liner (.003 Shim, liner (.023 Shim, liner (.033 Shim, liner (.035 Cap, main bearin Cap, main bearin	e (7'') 3'') 3'') 2'') 12'') ng No. 1,	3, 5	6 1 1 3 6 6 6 6 4 1 A/R A/R A/R A/R A/R A/R A/R A/R A/R A/R	34 34 34 34







ENGINE APPLI	CATION	AUTOMOTIVE		B · OFF-	HIGHW	AY	C - CONSTRUCTION	P - INDUSTRIA	AL POWE	R	
PART NUMBER		PART NAME	,		NO. REQ'D.	REF. NO.	PART NUMBER	PART I	NAME	NO. REQ'D.	REF. NO.
AR-08567 208470 142804 9300-1 S-911-B AR-07110 44387 44388 44385 44386 44383 44384 157280 60575 202903	Cranks Cranks Gear, c Key, g Plug, p Set, m Shell, Shell, upper) Shell, lower) Shell, upper) Shell,	crankshaft ear sipe (1/8") ain bearing main bearing (No. 7 main bearing (No. 2 main bearing (No. 2 main bearing (No. 1 main bearing (No. 1 thrust , ring , rust ring bearings may be pur .020", .030" and .	7 uppq 7 lowe 2, 4 ar 2, 4 ar 1, 3 ar	er) nd 6 nd 6 nd 5 nd 5	1 1 1 6 1 1 3 3 3 4 7 2	1 2 3 4 5 6 7 8 9 10 11 12 13	ADD: AR-08637 208460 140410 140411 145789 204836 S-163-B S-608 OMIT: 145789 ADD: 210758	Crankshaft, assem Crankshaft Capscrew, selflock Retainer VIBRATION DAM NT-855-F2 Damper, vibration Flange, crankshaft Capscrew (1/2"-2(Lockwasher (1/2") NT-855-F1 Same as above exceed Damper, vibration Damper, Vibration N-855-F Same as above exceed same same same same same same same same	MPER (1) × 1-1/8") (2) × 1-1/8")	1 1 1 1 6 6	14 15 16 18
196653 196654	Retain N-855		'4'')		1	17 19	USE: BM-71196 S-112-A	Damper, vibration Capscrew (1/2''-20		1 6	
OMIT: AR-08567 208470 196653 196654	1	shaft, assembly shaft rew			1 1 1				·		




LITORIE ALLE	SATISTI ASSESSMENT						
PART NUMBER	PART NAME	NO. REQ'D.	REF. NO.	PART NUMBER	PART NAME	NO. REQ'D.	REF. NO.
	CONNECTING ROD				RINGS		
	All Models				NT-855-F1, F2		
BM-52474 9195-3 187420 200861 69936 203660	Connecting rod assembly (121579) Bolt, connecting rod Bushing, piston pin Washer Nut * Shell, connecting rod bearing	6 12 6 12 12 12	1 2 3 4 5 6	AR-06390 147670 132880 168680 194610	Ring set, piston (standard Ring, compression Ring, compression Ring, compression Ring, oil	6 6 12 6 6	10 11 12 13
	PISTON	ĺ			N-855-F		
	NT-855-F1, F2			AR-06680 147670 132880	Ring set, piston Ring, compression Ring, compression	6 6 12	10 11
AR-06690 191970 200390 61908	Piston assembly Pin, piston Piston Ring, snap	6 6 6 12	7 8 9	194610	Ring, oil	6	13
1	N-855-F						
AR-7270 191970 195850 61908	Piston assembly Pin, piston Piston Ring, snap	6 6 6 12	7 8 9				
	* Connecting rod bearing shells may be purchased in .010", .020", .030" and .040" undersize.						




ENGINE APPLIC	ATION	AUTOMOTIVE	В-	OFF-HIGHW	AY	C - CONSTRUCTI	ON & INDUSTRIAL	P - INDUSTRIAI	POWE	R
PART NUMBER		PART NAME		NO. REQ'D.	REF. NO.	PART NUMBER	PART	AME	NO. REQ'D.	REF. NO.
209919 S-165 40662-A	All Mo Cover, Capscr		2′′)	1 8 A/R	1 3 5	143450 156226 69550	CAMSHAFT NT-855-F1, F2 Camshaft Gear, camshaft Key, gear		1 1 1	8 9 10
S-604 212832		asher (3/8'')		8 1	6 7	68193 9235-1	Plug, pipe (1/8'') Washer, thrust N-855-F Same as above exce	ept:	1	11 12
						OMIT: 143450	Camshaft		1	
						ADD: 129860	Camshaft		7	



ENGINE APPL	PART PART NAME		B - OFF-HIGHW	AY	C - CONSTRUCT	ION & INDUSTRIAL	L P · INDUSTRIAL PO		OWER	
		PART NAME	NO. REQ'D	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D	REF , NO.	
BM-70398 132770 68226-1	Cover,	cover dels gear (137164) g, accessory drive g, trunnion		1 2 3	S-112 S-127-A S-196 ₇ A 100915 60408 70653 214634 S-604 S-610 67270 138988 S-911-B 211225 208069 BM-56657 68192-A 68192-B 68192-C 185574 S-602 S-622	Capscrew (3/8"-16 Capscrew (7/16"-2 Capscrew (3/8") Capscrew (3/	6 x 1") 20 x 3") 20 x 2 3/4") 20 x 2")) "") thrust plate rust il mshaft thrust	2 1 15 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 2 17 1 1 1 1	44 55 67 78 9 10 111 122 133 144 155 166 177 18 19 19 19 19 20 21	




PART NUMBER
NT-855-F1, F2



ENGINE APPLI	CATION	AUTOMOTIVE	B - OFF	HIGHW	AY	C - CONSTRUCTION	ON & INDUSTRIAL	P - INDUSTRIA	L POWE	R
PART NUMBER		PART NAME		NO. REQ'D.	REF. NO.	PART NUMBER	PART N	AME	NO. REQ'D	REF. NO.
BM-67009 138808 175831 69736 42443 BM-37621 118377 107738 68512 118939 7348-2 BM-37634 118378 107738 68513 118939 9260-1	Housin Housin Plug, e Screw, Shaft, Cam fo Bushin Insert, Pin, ro Roller Cam fo exhaus Bushin Insert, Pin, ro Roller N-855 Same a Housin	cam follower bllower, injector (10 g cam follower iller ill bllower lever, intake st (120543) ig cam follower iller	8169) and	33666666666666631212121212312	1 2 3 4 6 7 8 9 10 12 7 13 9 14	S-129 68585 120819 9266 9266-A S-604 BM-47778 BM-47779	MOUNTING PART All Models Capscrew (3/8"-24 Dowel, housing to to Gasket (.026") Gasket (.015") Gasket (.007") Lockwasher (3/8") PUSH RODS All Models Push rod, intake an Push rod, injector	x 1'') block	18 6 A/R A/R A/R 18	17


NOTES

100000	
· · · · · · · · · · · · · · · · · · ·	
· · · · · · · · · · · · · · · · · · ·	
•	




ROCKER LEVER HOUSING, COVER, AND CRANKCASE BREATHER


ENGINE APPLIC	CATION AUTOMOTIVE B-O	FF-HIGHW	AY	C - CONSTRUCTI	ON & INDUSTRIAL	P - INDUSTRI	AL POWE	R
PART NUMBER	PART NAME	NO. REQ'D.	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF. NO.
AR-03312 BM-78589 194525 175830 62229 168319 BM-68740 161825 BM-95148 BM-95143 140330 S-212 168306 BM-95149 BM-95149 BM-95142 140330 S-212 168306 BM-95159	ROCKER LEVER HOUSING All Models Housing, rocker lever Housing, rocker lever Housing Plug, expansion Plug, ventilator Screw, rocker lever (140297) Plug, shaft Lever, exhaust valve Lever and bushing (168804) Bushing, lever Nut, adjusting screw Screw, adjusting Lever, exhaust valve Lever exhaust valve Lever and bushing (168802) Bushing, lever Nut, adjusting screw Screw, adjusting screw Screw, adjusting screw Screw, adjusting screw Screw, adjusting Lever, intake valve	3336333663333633333333333333333	1 2 3 4 5 6 7 8 9 10 12 8 9 10 13	S-176 S-118-A 149651 187589 193213 S-600 S-604 S-608 151127 158208 S-602 170226 S-176 150858 S-137 S-112	Capscrew (1/2"-12 Capscrew, heat shi (1/4"-20 x 5/8") Gasket, cover Gasket, housing to Gasket Lockwasher, heat Lockwasher (3/8" Lockwasher (1/2" Shield, heat Washer, housing to Washer, plain (13/ MOUNTING PAR N-855-F Bracket, lifting Capscrew, lifting to Capscrew, cover Capscrew, cover	shead shield (1/4"))) o head (32") TS pracket g to head	2 4 3 3 1 4 15 8 1 18 15	26 27 28 30 31 31 22 23 24
BM-95158 140330 S-212 168306 BM-95160 BM-95157 140330 S-212 168306 AR-02308 AR-02307 169353 194037 S-212 213109	Lever and bushing (168805) Bushing, lever Nut, adjusting screw Screw, adjusting Lever, intake valve Lever and bushing (168803) Bushing, lever Nut, adjusting screw Screw, adjusting Lever, injector rocker Lever and bushing (196564) Bushing, lever Socket Nut, adjusting screw Screw, adjusting screw Screw, adjusting screw	333333333366666666	13 8 9 10 11 8 9 10 14 15 16 9	149651 187589 S-604 S-608 S-602 257225 122133 S-167-A 122136 122135 S-600	Gasket, cover to h Gasket, rocker hor Lockwasher (3/8" Lockwasher, brack Washer, plain (13/ BREATHER NT-855-F1, F2 Breather, crankcas Body Capscrew, cover to Cover Gasket Lockwasher	using ') ket (1/2') 32'') se assembly	3 3 15 4 15 1 1 1 3 1 1 3	26 27 28 31 51 29 52 53 32
149768 150327 149628	ROCKER HOUSING COVER NT-855-F1, F2 Cover, rocker housing Cover, rocker housing Cover, rocker housing N-855-F Same as above except:	1 1 1	19 18 19	S-631 S-115 69793 69911-A 68562 S-604 S-605 S-205 S-3101 111670 121001	Washer, plain (9/3) Capscrew (5/16"-' Capscrew (3/8"-24 Clamp Flange Lockwasher (3/8" Lockwasher (5/16) Nut "O" ring vent tube Support, oil gauge Tube, breather	18 x 7/8'') 4 x 3/4'')) ''')	3 2 1 1 1 2 1 1 1	34
149768 150327 ADD: 149628	Cover, rocker housing Cover, rocker housing Cover, rocker housing	3	19					i
210051 176914 176926 101322 107981 150858 S-137 S-112	MOUNTING PARTS NT-855-F1, F2 Baffle Bracket, lifting Cap, oil filler (less chain) Caps, oil filler (with chain) Capscrew, housing Capscrew, cover (3/8"-16 x 2") Capscrew, cover (3/8"-16 x 1")	1 1 1 1 18 9 6	25 22 23 24					




ENGINE APPLIC	ATION	AUTOMOTIVE	B - OF	F-HIGHW	AY	C - CONSTRUCTIO	ON & INDUSTRIAL	P - INDUSTRIAI	NDUSTRIAL POWER	
PART NUMBER		PART NAME		NO. REQ'D.	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF. NO.
203562 S-120 70349 185804 105574 S-125 179688 157551 178788 67946 AS1602306MS S-604 S-610 S-605 S-962 110907 S-915-A S-908 20622 S-1354 S-602 S-602 S-622 S-622 S-626	Capscrew pan to blo Capscrew Capscrew pan to rea Capscrew Flange, oi Gasket, ol Gasket, de Hose, lub Lockwash Lockwash Lockwash Lockwash Plug, pipe Plug, pipe Plug, pipe Plug, pipe Screen, stage Washer, p Washer, p	(7/16"-14 x 1-3/ (5/16"-24 x.2-1/ar cover ill suction uction flange ill pan rain plug ricating oil her (3/8") her (5/16") the (1/2") the (1/2") the (3/8") uction plate tolain (13/32") tolain (11/32")	8") 8")	1 2 28 4 4 4 4 1 1 1 1 2 34 1 2 1 4 1 1 1 1 2 1 4 4 2 1 4 1 4 1 4	1 2 3 5 6 7 8 10 9 11 13 12 14 15 16 17 18 19 20 21	OMIT: 203562 AS1602306MS ADD: 203561 AS1602506MS AS1603306MS S-987 109753 114421 131998 101368 S-112 65274 S-604 S-915-A 101814 115590 101264	Pan, oil Hose, lubricating of Pan, oil Hose Hose Elbow, pipe Nipple, pipe Clamp, hose DIPSTICK BRAC All Models Bracket, dipstick Capscrew (3/8"-16 Gasket Lockwasher (3/8" Plug, pipe (1/2") Tube, dipstick Bracket, filler Tube, oil filler	S × 1")	1 1 1 1 1 1 4 1 4 A/R 1 1	24 25 26 27 11 28 29 30
203561	Same as a Pan, oil NT-855-F	bove except:		1	1					




ENGINE APPLIC	CATION	TION AUTOMOTIVE B-OFF-		-HIGHW	AY	C - CONSTRUCTION	ON & INDUSTRIAL	P - INDUSTRIA	L POWER	3
PART NUMBER	PART NAME			NO. REQ'D.	REF. NO.	PART NUMBER	PART	NAME	NO. REQ′D.	REF. NO.
AR-01058 153514 173368 179599 184265 8265 69901 S-16245 153518 184386 173176 183342 153520	Filter, Cartric Seal, c Seal, sl Shell a Bolt Gasket Plug, c Ring, s Seal, bl Shell Spring	olt , cartridge rt, cartridge		1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 12 2 3 4 5 6 7 8 3 9 10 11	BM-94090 153514 153528 165286 153517 8265 69901 250843 153518 153519 153521 153520	Filter, lubricating of Cartridge (paper) Seal, cartridge Seal, shell to filter Shell and bolt Bolt Gasket, copper Plug, pipe (1/8") Ring, snap Seal, bolt Spring, cartridge Support, cartridge Washer, bolt	oil, assembly head	1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 12 2 3 4 5 6 7 8 9 10 11




ENGINE APPLI	CATION	AUTOMOTIVE	B - OFF-H	IIGHW	AY	C - CONSTRUCTION	ON & INDUSTRIAL	P - INDUSTRIA	L POWE	₹
PART NUMBER		PART NAME	R	NO. EQ'D.	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF. NO.
	Filter, Bracke Capscri Capscri Coupli Coupli Cover Lockw Nut, br "O" rir Plug, co	SS FILTER 5-F1, F2 lubricating oil t, mounting ew, bracket ew, coupling half dge ng half with nuts ng half, cover rasher, bracket rasher, coupling half racket ng cover over mounting filter	R	NO. IEO'D. 1 2 8 2 1 1 1 1 8 2 8 1 1 1 2 1 1 1 1 1			PART	NAME		
25-906 252138 116029 131911 150037 252055	Suppor "O" rir Orifice Spring,	rt, upper ng, support		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	16 17 18 19					




NUMBER	PART NAME	REQ'D.		NUMBER	PART NAME	REQ'D.	
	LUBRICATING OIL COOLER NT-855-F2 Cooler, lubricating oil Capscrew (3/8"-16 x 2 1/4") Capscrew (3/8"-16 x 1 1/4") Capscrew (3/8"-16 x 2") Cock, drain Cover, cooler Element, cooler Gasket, cover to housing	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 2 3 4 5	S-103-D S-112 S-115 S-145 S-163 43828-B 43828-D 137114 68645 9221	PART NAME MOUNTING PARTS Capscrew (3/8"-16 x 1 1/4") Capscrew (5/16"-18 x 7/8") Capscrew (1/2"-13 x 1 1/4") Capscrew (3/8"-16 x 3 1/4") Clamp, hose Clamp, hose Connection, water Elbow Gasket, water connection	3 2 2 2 2 2 4 1	14 15 16 17 18 19
203922 146306 148295 S-604 S-910-B S-915-A S-995 142616 63322 180565	Gasket, cover to nousing Gasket, support to housing Housing, cooler "O" ring, element Lockwasher (3/8") Plug, pipe (1/4") Plug, pipe (1/2") Plug, pipe (3/4") Retainer, element Spacer Support, cooler	1 1 2 12 2 1 2 2 1 1 1	6 7 8 9 10 11 12	9221 121779 63495 110980 S-604 S-605 S-608 43463-A 142631 193370 193371	Gasket, water connection Gasket, support to block Hose, water by-pass Hose Lockwasher (3/8") Lockwasher (5/16") Lockwasher (1/2") "O" ring, water by-pass tube Support, oil cooler Tube, water inlet Tube, water by-pass	1 1 2 7 2 2 2 1 1 1 1 1 1 1	21 20 22 23 25 26 27 28 29




ENGINE APPLIC	ATION	AUTOMOTIVE	В-	OFF-HIGHW	AY	C - CONSTRUCT	ON & INDUSTRIAL	P - INDUSTRIA	L POWE	3
PART NUMBER		PART NAME		NO. REQ'D.	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF. NO.
BM-71721 S-103-D S-126 137064 125659 133190 133102 S-604 148294 S-910-B S-995 125658	NT-85 Coole Capsc Capsc Cover Eleme Gaske Housi Lockv "O" r Plug, I	r, lubricating oil rew (3/8"-16 x 1 1/ rew (3/8"-16 x 2 1/ , cooler ent, cooler t, cover to housing ng, cooler vasher (3/8")	(4'') (2'')	13611162211	1 2 3 4 5 6 7 8 9 10 11	S-103-D 70213 S-126 43828-B 121779 133179 63495 S-604 70206 133225 134288	Capscrew (3/8"-16 Capscrew (3/8"-16 Clamp, hose Gasket Gasket Hose Lockwasher (3/8") Lockwasher Support, cooler Pipe, by-pass	× 1 1/4′′)	5 2 4 1 1 2 7 2 1 1	12 13 14 15 16 17 18 19 21 22




ENGINE APPLIC	CATION	AUTOMOTIVE	B-OFF	-HIGHW	AY	C - CONSTRUCTION	ON & INDUSTRIAL	P - INDUSTRIA	L POWE	₹
PART NUMBER		PART NAME		NO. REQ′D.	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF. NO.
BM-70593 S-126 139329 BM-57837 110848 127863 148293 S-910-B 110827 68210 S-604 S-995	N-855- Cooler Capscri Cover, Housin Elemer Housin "O" rir Plug, p Retainin Gasket Lockw	, lubricating oil ew (3/8"-16 x 2 1/2 cooler g and element nt, cooler g, cooler		1 4 1 1 1 2 2 2 1 4 2	12 34567890	S-103-D 43828-B 121779 63495 S-604	MOUNTING PAR Capscrew (3/8"-16 Clamp, hose Gasket Hose Lockwasher (3/8")	x 1 1/4")	54125	11 12 13 14 15




ENGINE APPL	ICATION	AUTOMOTIVE	B - OFF-HIGHV	VAY	C - CONSTRUCT	ION & INDUSTRIAL	P - INDUSTR	IAL POWE	R
PART NUMBER		PART NAME	NO. REQ'D	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF. NO.
	N-855- Pump, Body a Bushing Capsore Gear, ic Bushing Dowel Gasket Gear, n Head, f Bushing Lockpi Lockwi Plate Plug, p Plunge, g Shaft, ic Spring, Yoke	CATING OIL PUMP F and NT-855-F1 Iubricating oil and bushing (173160) gew ew (3/8"-16 x 7/8") dier (68589) g Brive main drive filter (173162) gey-pass by-pass ate asher (3/8") ipe (3/8") ipe (1/2") r drive				MOUNTING PAR Capscrew (7/16"- Capscrew (7/16"- Gasket, pump to Lockwasher (7/16	20 × 1") 20 × 3") 20 × 2-1/2") block		




NUMBER	ENGINE APPLICATION	ON AUTOMOTIVE	B - OFF-HIGHW	AY	C - CONSTRUCT	ION & INDUSTRIAL	P · INDUSTRI	AL POWE	R
NT-855-F2		PART NAME				PART	NAME		REF. NO.
S-610	NUMBER LU NT BM-94088 Pur 151917 Bor 68586 Bus S-109 Car S-130-A Car S-169-A Car S-199-A Car S-196-A Car 101662 Car 69519 Dor 151911 Gas BM-20443 Ger 68586 Bus 68586 Bus 68586 Bus 68588 Ger 133855 Ger 133855 Ger BM-94081 Her 200819 Dis 153526 Sea 251152 Spr BM-94080 Ger 68586 Bus S-604 Lor S-605 Lor S-610 Lor 109319 Lor	BRICATING OIL PUMP -855-F2 mp, lubricating oil dy, inner dy and bushing (164163) shing oscrew (3/8"-16 × 7/8") oscrew (3/8"-16 × 5-1/4") oscrew (3/8"-16 × 4-1/2") oscrew (3/8"-16 × 4-1/2") oscrew (7/16"-20 × 2-3/4") oscrew (5/16"-18 × 4-1/2") oscrew (5/16") oscr	1 1 1 2 1 3 2 1 1 2 2 2 1 1 1 1 1 1 1 1	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23	S-995 S-908 133848 164164 68274 185696 126304 S-101-A 69960 169657 S-103-D 134284 134285 121907 S-604	Plug, pipe (3/4") Plug, pipe (3/8") Shaft, idler Shaft, drive Spring, by-pass valv Tube, piston-coolir Yoke, retaining MOUNTING PART Capscrew (7/16"-2 Capscrew, hex head Capscrew (3/8"-16 Flange, scavenger p Gasket, flange to b Gasket, pump to bl Lockwasher (3/8")	/e ng oil (**s** (**)	2 1 1 1 1 1 1 1 2 1 1 2 1 1 1 2	26 27 28 29 30 31 32 33 34 35 36 37 38 39 40




ENGINE APPL	ICATION	AUTOMOTIVE	B - OFF-HIG	HWA	AY	C - CONSTRUCTI	ON & INDUSTRIAL	P - INDUSTRIA	L POWER	3
PART NUMBER		PART NAME	NC REC		REF. NO.	PART NUMBER	PART !	NAME	NO. REQ'D.	REF. NO.
AR-04284 154966 AR-04283 115519 196845 S-2268 191175 AR-06589 200509 112302 S-16255 170895 199410 196844 200328 178570	Pump, Pulley, Pump, Bearing Body, Fitting Fitting Impelli Seal, st Ring, r Ring, s Seal, st Seal, st Spacer	water (with pulley) water pump water (less pulley) g, water pump water pump I, grease I, relief eer, water pump (20176)		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 2 3 4 5 6 8 9 10 11 12 13	106549 105831 S-165 130240 130226 130227 S-604 AR-5068 190397 191517 194380	All Models Capscrew Capscrew (3/8"-24 Capscrew (3/8"-24 Gasket, pump Gasket, support Support, water put Lockwasher (3/8" ACCESSORY DRI All Models Pulley, drive (1904 Sleeve, pulley Nut, pulley Washer, plain	x 2'') x 1 1/2'') mp) VE PULLEY	1 6 2 1 1 1 8 8	14 15 16 17 18 19 20 21 22 23




PART NUMBER	PART NAME	NO REQ		REF. NO.	PART NUMBER	PART NAME	NO. REQ'D.	REF. NO.
137069 204733 203945 S-929-B 162654 S-102-D S-103-D S-165-B 108707 69317 S-112 103023 S-145 43828-E S-962-E 44426 137062 137061 137059 137057 194728 137155 135585 137067 1370767 1370767 137076 137077 137076 137071 70186 64030 137052 S-604 S-610 S-607 S-608 S-2902	HEAT EXCHANGER (All Models) Brace, heat exchanger Brace, heat exchanger Bracket, housing Bushing, pipe Cap, filler Capscrew (3/8"-16 x 3") Capscrew (1/2"-13 x 7 1/2") Capscrew (1/2"-13 x 7 1/2") Capscrew (3/8"-16 x 1 1/4") Capscrew (3/8"-16 x 1") Capscrew (3/8"-16 x 1") Capscrew (1/2"-13 x 1 1/4") Capscrew (1/2"-13 x 1 1/4") Clamp, hose Cock, drain Connection, inlet Connection, inlet Connection, outlet Cover, heat exchanger Cover Element Gasket, element to housing Gasket, relief valve Gasket, cover to element Gasket, outlet connection Gasket, inlet connection Hose Housing Lockwasher (3/8") Lockwasher (3/16") Lockwasher (1/2") Neck, filler	1	111111302121122111111111111111111111111	1 2 3 3 4 4 5 6 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 5 29 30 31 32 23 33 34	137074 137075 68241 131449 140939 AR-07196 S-622 S-602 132756 S-1000-A 204723 S-1099 S-1098	"O" ring "O" ring Plug, zinc electrode Screw Support Valve Washer, plain (15/32") Washer, plain VENT TUBE Elbow, flexible fitting Tube, vent, heat exchanger to exhaust manifold outlet connection Nut Sleeve, flexible fitting	1 1 3 4 1 1 1 2 2 2 2 2	35 36 37 38 39 40 41 42 43 45




ENGINE APPLI	CATION	AUTOMOTIVE	B-OFF	HIGHW	AY	C - CONSTRUCTION	ON & INDUSTRIAL	P - INDUSTRIA	L POWE	R
PART NUMBER		PART NAME		NO. REQ'D.	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF. NO.
	-	R MANIFOLD								:
133144 133819 133077 S-103-D 43828-C 130394 63241-F 70624 148203 S-604 S-910-B S-915-A	Manifo Manifo Capscri Clamp Coupli Hose "O" rii	old, water (front) old, water (center) old, water (rear) ew (3/8"-16 x 1-1/4" ng ng ng asher (3/8")		1 1 12 2 2 1 4 6 12 1	1 2 3 4 5 6 7 8 9 10					




CORROSION RESISTOR	ENGINE APPLI	CATION	AUTOMOTIVE		B - OFF-	HIGHW	AY	C - CONSTRUCT	ON & INDUST	RIAL	P - INDUST	RIALP	OWER	١
All Models Resistor, corrosion 258264 299083 Element pre-charged (WF-2013) Head 299080 Element, service (WF-2010) Resistor, corrosion 1 S-172-B Capscrew Capscrew (1/4"-20 x 1-1/2") 3 Capscrew (1/4"-20 x 1-1/2") 3 Clamp, hose 4 Clamp, hose 4 Clamp, hose 5 Spacer 70470 Elbow 2 Tr9941 Hose 1 S-604 Lockwasher (3/8) 6 1	PART NUMBER		PART NAME							PART	NAME	N R	IO. EQ'D.	REF. NO.
	258264 299083 204163	All Mo Resisto Elemei Head	dels or, corrosion nt pre-charged (WF-	-2013		1 1 1	1	187317 212128 S-172-B S-156-B 179904 65297 70470 179941 S-604	Adapter Bracket, of Capscrew Capscrew Clamp, ho Spacer Elbow Hose Lockwash	corrosion (1/4''-20 ose	resistor		1 1 4 3 4 3 2 1 6	3 4 5 6 7 8 9 10 11




	ATION AUTOMOTIVE	B - OFF-HIGH	IWAY	C - CONSTRUCT	ION & INDUSTRIAL	P · INDUSTRIA	L POWE	R
PART NUMBER	PART NAME	NO. REQ	REF. D. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF.
	AIR INTAKE MANIFOLD AII Models Manifold, air intake MOUNTING PARTS Capscrew (3/8"-16 × 1") Capscrew (3/8"-16 × 1-1/2 Gasket, manifold Gasket, plate Lockwasher (3/8") Plate, manifold cover Plug, pipe (1/4") Plug, pipe (1/4") Plug, pipe (1/2") Plug, pipe (1") Washer, plain (13/32") Washer, plain (13/32") Plug Gasket Plug, glow plug opening Gasket, glow plug	//) 12	D. NO. 1 2 3 4 5 6 7 8 9 1 1 1 1 1 2 2 2 2 3		AIR INTAKE COINT-855-F1, F2 Connection, air information MOUNTING PAR Capscrew (3/8"-16 Clamp, hose Gasket, connection Lockwasher (3/8" Plug, pipe Washer, plain (13/N-855-F Connection, intaken MOUNTING PAR Capscrew (3/8"-16 Gasket Lockwasher (3/8" Washer, plain (13/Plug, pipe	take TS 6 × 1-1/2") In to manifold to turbocharger 32") TS 6 × 1-1/4")	1 4 2 1 1 4 4 1 1 1 4 4 1 1	13 14 15 16 17 18 19 20




ENGINE APPLICAT	ION AUTOMOTIVE	B - OFF-HIGHW	/AY	C - CONSTRUCTI	ON & INDUSTRIAL	P · INDUSTRIA	POWER	3
PART NUMBER	PART NAME	NO. REQ'D	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF. NO.
	IR CLEANER T-855-F1, F2							
201043 B- 193815 G 111585 Pr 201046 R 111580 N 111576 R 201044 C 201045 C 111603 D 111604 D	leaner, air (16" diameter) ody asket refilter od and band assembly ut, wing od up assembly up isc ecal pring	1 1 1 1 1 2 2 1 1 1 1	1 2 3 4 5 6 7 8 9					
148324 B S-111 C S-112 C S-120-A C 125741 C 195873 H 103808 H S-604 L S-605 L S-205 N S-221 N 197221 Si	racket, air cleaner apscrew (5/16"-18 x 1-1/apscrew (3/8"-16 x 1") apscrew (3/8"-24 x 7/8") apscrew (3/8"-24 x 7/8") lamp, "T" bolt ood, air cleaner ose ockwasher (3/8") ockwasher (5/16") ut (3/8") ut (5/16") trap, air cleaner ube, air cleaner	1	26 12 27 28 15 16 17 19 20 29 21 23 30					




ENGINE APPLI	CATION	AUTOMOTIVE	B-OFF	HIGHW	AY	C - CONSTRUCTIO	ON & INDUSTRIAL	P INDUSTRIAL	POWER	₹
PART NUMBER		PART NAME		NO. REQ'D.	REF. NO.	PART NUMBER	PART	IAME	NO. REQ'D.	REF. NO.
	AIR CI N-855-	LEANER								
106833 107135 AF-253 107136 107137 107134 122121	Cover, Elemer Gasket Gasket Shell, a Spring	nt s, element s, flange air cleaner , clip		1 1 1 1 1 3	1 2 3 4 5 6					
106126 157670 125741 105313 103808 105916 S-115 S-111 S-117 S-186-A S-221 S-605 S-626 180112 S-658	Adapte Bracke Clamp Elbow Hose, Strap Capscr Capscr Capscr Capscr Capscr Capscr Vut (5 Locky Washe Tube,	et , hose flexible rew (5/16"-18 × 7/8 rew (5/16"-18 × 1-1, rew (3/8"-16 × 3/4" rew (5/8"-18 × 1-1/4	/2'') /2''))	1 1 1 2 2 6 2 2 4 1 2 8 6 1 1	7 8 9 10 11 12 13 14 15					







ENGINE APPLICA	ATION AUTOMOTIVE	B - OFF-HIGHW	AY	C - CONSTRUCTI	ON & INDUSTRIAL	P - INDUSTRIAL		3
PART NUMBER	PART NAME	NO. REQ'D	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF. NO.
	EXHAUST MANIFOLD				CONNECTIONS			
157515 S-145-B 200908 200919 105199 67971 139266 132977 114638 S-608	Manifold, exhaust Capscrew (1/2"-13 x 1 1/4" Capscrew (7/16"-14 x 4") Clamp, manifold Dowel, manifold to block Flange, blind Gasket, flange Gasket, manifold Lockplate Lockwasher (1/2") N-855-F Same as above except:	1 4 12 6 2 1 1 6 12 4	1 2 3 4 5 6 7 8 9 10	S-105 S-109 S-923-E 133147 43828-C 65399 130740 BM-93806 186780 63495-B S-604 146076 S-915-A S-679	Capscrew (3/8"-16 Capscrew (3/8"-16 Cock, drain Connection, water Clamp, hose Gasket, water inlet Gasket, thermostat Housing, thermostat Seal Hose, water connec Lockwasher (3/8") Thermostat Plug, pipe (1/2") Washer, plain (5/8"	x 7/8") inlet connection housing it (146097)	4 4 1 1 2 1 2 1 1 4 1 1 4	11 12 13 14 15 16 17 18 19 20 21 22
OMIT: 157515	Manifold, exhaust	1	1					
ADD: 145065	Manifold, exhaust	1	1					
N.								



ENGINE APPLI	CATION	AUTOMOTIVE	B - OFF-H	IIGHW.	AY	C - CONSTRUCTION & INDUSTRIAL		P - INDUSTRIAL POWER		3
PART NUMBER		PART NAME	 F	NO. REQ'D.	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF. NO.
AR-08536 129510 158826 142689 AR-08782 116391 S-911-B S-915-A 69550 S-316 170658 116388 116389 116390 170664	Drive, Capscr Coupli Gear, (Housin Bushin Plug, p Key, s Key, s Shaft, Washe Washe	fuel pump ew (3/8"-16 x 1") ng drive housing ng (208671) g, housing pipe (1/8") pipe (1/2") haft haft drive r, thrust r, clamping		1 1 1 1 1 2 1 1 1 1 1	1 2 3 4 5 6 7 8 9 0 1 1 1 2 3 1 3	215581 200809 S-610 181236	MOUNTING PAR Capscrew (7/16"-2 Gasket Lockwasher (7/16 Seal, keyway	20 × 1 1/8′′}	5 1 5 1	14 15 16 17




ENGINE APPLIC	ATION	AUTOMOTIVE	B OF	F-HIGHW	AY	C - CONSTRUCTION	ON & INDUSTRIAL	P - INDUSTRIA	L POWE	R
PART NUMBER		PART NAME		NO. REQ'D.	REF.	PART NUMBER	PART	NAME	NO. REQ'D	REF. NO.
best perform Cummins Dis for complete	I mins PT ance and stributor rebuild	Fuel Pump is calib d fuel economy for or Dealer has the s and calibration.	your engin pecial tools	e. Your s require	ed	BM-91830 211284	N-855-F Pump, gear Gasket FUEL FILTER		1 1	12 11
throttle screv result. Only PT F pump calibra will record th	w setting fuel Syst ation are the specif in front o	disturb the fuel press as serious damage em Parts which can listed here. Your C ic part number of y if this catalog.	to your en be replace ummins Di	gine ma d withou stributo	y ut	156171 FF-105-D 251406 66292 142784 69901	All Models Fuel filter Cartridge Gasket, cover Gasket, drain plug Head, filter Plug, drain		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	13 14 15 16 17
BM-76340 153336 S-105-C 202897 S-600 139988 100099 153338 151900 70704 160514	Dampe Body, Capscri Diaphr Lockw "O" rir "O" rir Plate, c Seal, di Washer	er, fuel damper ew (1/4"-20 x 1-1/4 agm asher (1/4") ng ng Jamper amper to gear pump		1 1 2 1 2 1 1 1 1 1 2 1	1 2 3 4 5 6 7 8 9 10	145663 S-112 S-151-C 129859 S-1092 190706 135332 S-604 S-609 210010	MOUNTING PAR Bracket, fuel filter Capscrew (3/8"-16 Capscrew (9/16"-1 Connection, elboy Connector Decal Elbow Lockwasher (3/8" Lockwasher (9/16) Tube	5 × 1") 18 × 1") v (90 deg.)	1 4 2 1 1 4 2 1 1	22 19 23 20 21 21 24
BM-90270 210647	NT-85 ! Pump,	SUPPLY GEAR PU 5-F1, F2 gear (R.H. 3/4'') , pump	MP	1 1	12 11					



ENGINE APPL	ICATION	AUTOMOTIVE	B - OFF-HIGHW	B - OFF-HIGHWAY		ON & INDUSTRIAL	P - INDUSTRIAL POWER		R
PART NUMBER		PART NAME	NO. REQ'D.	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF.
	SHUTDO	WN VALVE				INJECTOR			
216930 196066 S-1215 196056 196057 S-607 129888 129839 129768 196055	Coil Capscrew Disc, orif Disc, pilo Lockwasl "O" ring Shield Spring Spacer	ice pting ner (3/16")	1 4 1 1 1 1 1 1 1	10 1 2 3 4 5 6 7 8	AR-40039 191916 AR-40051 185139 AR-40061 167157 196943 174299 173086 101754 193736 203426 185138	Injector Link, injector Injector (less link) Adapter Barrel and plunger Ball, check Cup Clip Gasket "O" ring Pin, spiral Retainer, cup		66666666612166	11 12 13 14 15 16 17 18 19 20 21
146054 S-105-C S-170-C 203619 181466 154087 70088 67684	Capscrew Capscrew Lockwas "O" ring	/ her ning valve	1 1 2 1 2 2 2 2 2		174298 166009 165006 191218	Screen Spring Capscrew Clamp, injector ho N-855-F Same as above exception		6 6 12 6	22 23 24 25
					AR-40126 208423 AR-40154	Injector Cup, injector Injector, less link		666	

PART		NO.	REF.	PART			NO.	REF
NUMBER	PART NAME	REQ'D.	NO.	NUMBER	PART N	AME	REQ'D	
	FUEL TUBING							
	NT-855-F1, F2	j		})	}
	İ							ĺ
76286 25837	Adapter Bushing	1 2		,				
37 7 96	Capscrew (3/8"-24 x 1/2")	2					1	
07460	Clamp, hose	2		ļ			1	
04263	Clamp, hose	1					1	
48376 81213	Connector Elbow	1 1	i				1	
80371	Clamp, tube	2						1
03071	Elbow	<u> </u>					1	
93762	Elbow, (90 deg.)	1					1	
-1005-A	Elbow Lockwasher (5/8")	1 1					ł	1
-603 -604	Lockwasher (3/8")	1 1					ļ.	l
-223	Nut (3/8")	{ i					1	ł
-911-B	Plug, pipe (1/8'')	[1						
10010	Plug, tube Tube, fuel suction	1 1					1	
17474	Tube, fuel supply	Į i l		1			ł	ł
08445	Tube, fuel return	1						
87186	Tube	1					i	1
08444 78079	Tube, injector drain Valve	1 1					ł	l
85505	Valve, check	1						
	FUEL TUBING							
	N-855-F			1				1
25 8 3 7	Bushing, reducing	2	İ	}				}
-223	Nut	1					<u> </u>	1
48376 07460	Connector, tube Clamp, hose	2	l				1	ļ
04263	Clamp, hose	ł i		[1	l
-1005-A	Elbow	1	l				1	
3765	Elbow, (90 deg.)	1	•]			1	1
93762 81213	Elbow, (90 deg.) Elbow	1 1	ł				1	l
61213	Lockwasher (5/8'')	Ιί	İ	1			1	
17471	Tube, fuel supply	1		ļ .			1	l
87186	Tube	1 1		1			ł	1
:08444 5-911-B	Tube, fuel drain Plug, pipe	1		ļ <u> </u>				
210010	Tube, fuel suction	li]				1	l
85505	Valve, check	1		1			1	
78079	Valve	1					ļ	l
	}			}				}
				1			1	
			İ	1				
							1	
								1
			ļ	1				1
				•				
	ļ	J	I	1				1



ENGINE APPLIC	ATION	AUTOMOTIVE	B-OF	F-HIGHW	AY	C - CONSTRUCTION	ON & INDUSTRIAL	P - INDUST	RIAL POWE	R
PART NUMBER		PART NAME		NO. REQ'D	REF. NO.	PART NUMBER	PART	NAME	NO. REQ'D.	REF. NO.
	INSTR All Mo	UMENT PANEL				S-647 S-607 102484	Washer Washer, vibration Washer, safety	isolator	2 3 3	19 20
199986 66741 156646 3000105 122395 102470 102471 108102 213755 S-114 S-113-A 105831 123847 S-709 S-1059 S-1047-A 68139 66733 41627-R ASO401660MS 102486 177728 177728 177729 S-259 S-224 139051 69017 64709 66573 69151 S-2286 103240 69504 S-604 S-609 S-603-A	Amme Hourn Adapte Box, ju Bracke Bracke Bracke Cable, Capscr Capscr Conne Plug (2 Coupli Elbow Gauge Hose Isolato Market Market Nut (1 Plate, Ring, 1 Spacer Strap Screw Screw Washe Washe	neter and tachometer, tachometer, tachometer driverunction set, mounting set, mounting set, circuit tachometer sew (1/4"·20 × 3/4" sew (9/16"-18 × 2") sew (3/8"-24 × 2") set, squeeze type 2-1/8") ng, tube to, tube to, tube to, water temperature set, vibration from (U.L.) from (F.M.) /4") terminal block tachometer adapter		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 2 3 4 5 6 7 8 9 10 11 12 13	218901 S-127-C 218902 170065 128028 S-673 S-603 187734 102480 S-188-C S-167-A S-190-C 180372 S-600 S-604 S-224 S-631 S-223 S-601 137795 213056	N-855-F (only) Block, terminal Capscrew (5/8"-1 Marker, terminal Plate, mounting Screw round head Washer Washer (5/8" loc THROTTLE COI Control, throttle Bracket, throttle Capscrew (1/4"-2 Capscrew (3/8"-2 Clip Lockwasher (3/8 Nut Washer, plain (9/ Nut Washer Capscrew Bracket, throttle	control 20 x 1/2") 20 x 7/8") 24 x 5/8") ") "32") cable	1 1 1 1 2 2 1 1 1 3 3 1 1 1 1 1	21

PART	PART NAME		EF. PART	PART NAME	NO.	REI
NUMBER	PART NAME	REO'D. N	NUMBER	TANT NAME	REQ'D.	NO
	ELECTRICAL EQUIPMENT			RELAY CONTACTOR		
Engine Com equipment r Delco-Remy Neville Com	1	rical rers, The e Leece- ir service	211088 S-105-C S-109 S-145 199573 S-224 S-600 S-604 S-608	Bracket, contactor Capscrew (1/4"-20 x 1-1/4") Capscrew (3/8"-16 x 7/8") Capscrew (1/2"-13 x 1-1/4") Contactor, D.C. Relay Nut Washer, 1/4 lock Washer, 3/8 lock Washer, 1/2 lock	1 4 1 2 2 4 4 1 2	
	ALTERNATOR			OVERSPEED STOP		
213807 178655 178599 201464 5-120 5-145 5-165 5-187 201465 203535 5-200 5-604 203310	Alternator Belt Belt (NT-855-F2) Bracket Capscrew (3/8"-16 x 1-3/4") Capscrew (1/2"-13 x 1-1/4") Capscrew (NT-855-F2) Capscrew (1/2"-13 x 6") Link, alternator adjusting Link (NT-855-F2) Nut Washer, 3/8 lock Washer, adjusting Pulley	1 1 1 3 1 1 1 1 1 1 3 3 1	210314 100014 128922 S-168-C 108707 S-600 S-224 216400 S-631 62962	Stop, overspeed Adapter Bracket Capscrew (1/4"-20 x Capscrew (3/8"-16 x 1-1/2") Lockwasher (1/4") Nut (1/2") Shaft Washer, plain (9/32") Washer, rubber	1 1 2 2 2 2 2 1 2 2	
	SWITCH, MAGNETIC		}	}		
111435 S-167-A S-600 S-224 118848	Bracket Capscrew (1/4"-20 x 7/8") Lockwasher (1/4") Nut (1/4") Switch, magnetic STARTING MOTOR	1 2 2 2 2				i
43604 5-103-A 5-603 9245	Motor, starting Capscrew (5/8"-11 x 2") Lockwasher (5/8") Spacer	1 3 3 1				
			.g ^r 4		1 1	

PART NUMBER	PART NAME	NO. REQ'D.	REF. NO.	PART NUMBER	PART NAME	NO. REQ'D.	REF NO.
	FLYWHEEL HOUSING				DAMPER SHIELD		
111293 S-106 188936	All Models Housing, flywheel Capscrew (1/2"-13 x 1-3/4") Capscrew (1/2"-13 x 1-3/4")	1 4 9		S-107 161184 S-605	Capscrew (5/16"-18 x 3/4") Shield, vibration damper Washer (5/16" lock) BELT SHIELD	4 1 4	
106289 9226 9246 199064 S-600 S-603 S-608 S-200 70214 S-601 S-658	Capscrew (1/2"-13 x 2-1/4") Dowel Cover, inspection hole Gasket Lockwasher (1/4") Lockwasher (5/8") Lockwasher (1/2") Nut (1/2") Screw Washer, plain Washer, plain (5/8")	3 2 1 1 2 9 7 3 2 7		S-107 S-119-C 108707 S-221 217059 161446 S-605 S-604 S-610 S-602	Capscrew (5/16"-18 x 3/4") Capscrew (7/16"-20 x 3-1/4") Capscrew (3/8"-16 x 1-1/2") Nut Shield, belt Support, belt shield Washer (5/16 lock) Washer (3/8 lock) Washer (7/16 lock) Washer	1 1 3 1 1 1 1 1 1 3	
	FLYWHEEL AND RING GEAR				GASKET SETS	ļ	
	NOTE: Flywheel not sold separately, sold as assembly only.				N-855-F		
BM-00933 (3453) 4851	Flywheel and ring gear Flywheel (3453)	1 1 1		AR-06757 BM-50745 BM-68356	Engine gasket set Cylinder head gasket set Fuel pump gasket set	1 1 1	
4851 204165 200861	Gear, ring Bolt, self-locking Washer	6			NT-855-F1		
200801	FRONT ENGINE AND FLYWHEEL HOUSING SUPPORT	0		AR-06763 BM-77916 BM-68356	Engine gasket set Cylinder head gasket set Fuel pump gasket set	1 1 1	
	All Model				NT-855-F2		
AR-11195 21082 S-125 108602 S-608 S-218 43586	Support, front engine Support, flywheel housing Capscrew (1/2"-13 x 2") Capscrew (1/2"-13 x 3-3/4") Lockwasher (1/2") Nut, tie-rod Rod, tie	1 1 4 2 6 8 2		AR-06764 BM-77916 BM-68356	Engine Gasket set Cylinder head gasket set Fuel pump gasket set	1 1 1	
	FLANGE AND STUD SHAFT						
BM-22416 40049-B 61239-Z 61238-K S-145 S-608	Flange and stub shaft Flange Key Shaft Capscrew (1/2"-13 x 1-1/4") Lockwasher (1/2")	1 1 1 1 8 8					
	MISCELLANEOUS						
190706 104597 S-901 218147 212461 218146 208359	Decal, fuel filter Plate, name fuel system Plug, pipe Wiring, diagram Wiring, diagram (N855-F, NT-855-F1) Wiring, diagram, installation (NT-855-F2) Wiring diagram, installation (NT-855-F1)	1 1 1 1 1 1 1					
185583 210372 168736 168737	Wiring diagram, installation (N-855-F) Tag Switch, lub. pressure Switch, water temperature	1 1 1 1					

Cummins Engine Company, Inc. Columbus, Indiana, U.S.A. 47201

Registered Office:

Cummins Engine Company, Ltd.
Coombe House St. George's Square
New Malden, England

Cable: INTCUMLON MALDEN Registration No. 573951 England

Overseas Factories:

Cummins Engine Company, Ltd. Shotts, Lanarkshire, Scotland Cable: CUMSCOT SHOTTS

Cummins Engine Company, Ltd.

Yarm Road, Darlington, County Durham, England

Cable: CUMDAR DARLINGTON

Cummins Diesel Australia

Ringwood, Victoria Cable: CUMAUS