Error Codes Reference

[??]

This section lists various error code constants defined in ESP-IDF.

For general information about error codes in ESP-IDF, see Error Handling.

`ESP_FAIL` (-1): Generic esp_err_t code indicating failure

`ESP_OK` (0): esp_err_t value indicating success (no error)

`ESP_ERR_NO_MEM` **(0x101)**: Out of memory

`ESP_ERR_INVALID_ARG` **(0x102)**: Invalid argument

`ESP_ERR_INVALID_STATE` **(0x103)**: Invalid state

`ESP_ERR_INVALID_SIZE` **(0x104)**: Invalid size

`ESP_ERR_NOT_FOUND` **(0x105)**: Requested resource not found

`ESP_ERR_NOT_SUPPORTED` **(0x106)**: Operation or feature not supported

`ESP_ERR_TIMEOUT` **(0x107)**: Operation timed out

`ESP_ERR_INVALID_RESPONSE` **(0x108)**: Received response was invalid

`ESP_ERR_INVALID_CRC` **(0x109)**: CRC or checksum was invalid

`ESP_ERR_INVALID_VERSION` **(0x10a)**: Version was invalid

`ESP_ERR_INVALID_MAC` **(0x10b)**: MAC address was invalid

`ESP_ERR_NOT_FINISHED` **(0x10c)**: Operation has not fully completed

`ESP_ERR_NOT_ALLOWED` **(0x10d)**: Operation is not allowed

`ESP_ERR_NVS_BASE` **(0x1100)**: Starting number of error codes

`ESP_ERR_NVS_NOT_INITIALIZED` **(0x1101)**: The storage driver is not initialized

`ESP_ERR_NVS_NOT_FOUND` **(0x1102)**: A requested entry couldn't be found or namespace doesn’t exist yet and mode is NVS_READONLY

`ESP_ERR_NVS_TYPE_MISMATCH` **(0x1103)**: The type of set or get operation doesn't match the type of value stored in NVS

`ESP_ERR_NVS_READ_ONLY` **(0x1104)**: Storage handle was opened as read only

`ESP_ERR_NVS_NOT_ENOUGH_SPACE` **(0x1105)**: There is not enough space in the underlying storage to save the value

`ESP_ERR_NVS_INVALID_NAME` **(0x1106)**: Namespace name doesn’t satisfy constraints

`ESP_ERR_NVS_INVALID_HANDLE` **(0x1107)**: Handle has been closed or is NULL

`ESP_ERR_NVS_REMOVE_FAILED` **(0x1108)**: The value wasn’t updated because flash write operation has failed. The value was written however, and update will be finished after re-initialization of nvs, provided that flash operation doesn’t fail again.

`ESP_ERR_NVS_KEY_TOO_LONG` **(0x1109)**: Key name is too long

`ESP_ERR_NVS_PAGE_FULL` **(0x110a)**: Internal error; never returned by nvs API functions

`ESP_ERR_NVS_INVALID_STATE` **(0x110b)**: NVS is in an inconsistent state due to a previous error. Call nvs_flash_init and nvs_open again, then retry.

`ESP_ERR_NVS_INVALID_LENGTH` **(0x110c)**: String or blob length is not sufficient to store data

`ESP_ERR_NVS_NO_FREE_PAGES` **(0x110d)**: NVS partition doesn't contain any empty pages. This may happen if NVS partition was truncated. Erase the whole partition and call nvs_flash_init again.

`ESP_ERR_NVS_VALUE_TOO_LONG` **(0x110e)**: Value doesn't fit into the entry or string or blob length is longer than supported by the implementation

`ESP_ERR_NVS_PART_NOT_FOUND` **(0x110f)**: Partition with specified name is not found in the partition table

`ESP_ERR_NVS_NEW_VERSION_FOUND` **(0x1110)**: NVS partition contains data in new format and cannot be recognized by this version of code

`ESP_ERR_NVS_XTS_ENCR_FAILED` **(0x1111)**: XTS encryption failed while writing NVS entry

`ESP_ERR_NVS_XTS_DECR_FAILED` **(0x1112)**: XTS decryption failed while reading NVS entry

`ESP_ERR_NVS_XTS_CFG_FAILED` **(0x1113)**: XTS configuration setting failed

`ESP_ERR_NVS_XTS_CFG_NOT_FOUND` **(0x1114)**: XTS configuration not found

`ESP_ERR_NVS_ENCR_NOT_SUPPORTED` **(0x1115)**: NVS encryption is not supported in this version

`ESP_ERR_NVS_KEYS_NOT_INITIALIZED` **(0x1116)**: NVS key partition is uninitialized

`ESP_ERR_NVS_CORRUPT_KEY_PART` **(0x1117)**: NVS key partition is corrupt

`ESP_ERR_NVS_CONTENT_DIFFERS` **(0x1118)**: Internal error; never returned by nvs API functions. NVS key is different in comparison

`ESP_ERR_NVS_WRONG_ENCRYPTION` **(0x1119)**: NVS partition is marked as encrypted with generic flash encryption. This is forbidden since the NVS encryption works differently.

`ESP_ERR_ULP_BASE` **(0x1200)**: Offset for ULP-related error codes

`ESP_ERR_ULP_SIZE_TOO_BIG` **(0x1201)**: Program doesn't fit into RTC memory reserved for the ULP

`ESP_ERR_ULP_INVALID_LOAD_ADDR` **(0x1202)**: Load address is outside of RTC memory reserved for the ULP

`ESP_ERR_ULP_DUPLICATE_LABEL` **(0x1203)**: More than one label with the same number was defined

`ESP_ERR_ULP_UNDEFINED_LABEL` **(0x1204)**: Branch instructions references an undefined label

`ESP_ERR_ULP_BRANCH_OUT_OF_RANGE` **(0x1205)**: Branch target is out of range of B instruction (try replacing with BX)

`ESP_ERR_OTA_BASE` **(0x1500)**: Base error code for ota_ops api

`ESP_ERR_OTA_PARTITION_CONFLICT` **(0x1501)**: Error if request was to write or erase the current running partition

`ESP_ERR_OTA_SELECT_INFO_INVALID` **(0x1502)**: Error if OTA data partition contains invalid content

`ESP_ERR_OTA_VALIDATE_FAILED` **(0x1503)**: Error if OTA app image is invalid

`ESP_ERR_OTA_SMALL_SEC_VER` **(0x1504)**: Error if the firmware has a secure version less than the running firmware.

`ESP_ERR_OTA_ROLLBACK_FAILED` **(0x1505)**: Error if flash does not have valid firmware in passive partition and hence rollback is not possible

`ESP_ERR_OTA_ROLLBACK_INVALID_STATE` **(0x1506)**: Error if current active firmware is still marked in pending validation state (ESP_OTA_IMG_PENDING_VERIFY), essentially first boot of firmware image post upgrade and hence firmware upgrade is not possible

`ESP_ERR_OTA_ALREADY_IN_PROGRESS` **(0x1507)**: Error if another OTA operation is already in progress on the same partition

`ESP_ERR_OTA_SPI_MODE_MISMATCH` **(0x1508)**: Error if the firmware's SPI flash mode doesn't match the running firmware

`ESP_ERR_EFUSE` **(0x1600)**: Base error code for efuse api.

`ESP_OK_EFUSE_CNT` **(0x1601)**: OK the required number of bits is set.

`ESP_ERR_EFUSE_CNT_IS_FULL` **(0x1602)**: Error field is full.

`ESP_ERR_EFUSE_REPEATED_PROG` **(0x1603)**: Error repeated programming of programmed bits is strictly forbidden.

`ESP_ERR_CODING` **(0x1604)**: Error while a encoding operation.

`ESP_ERR_NOT_ENOUGH_UNUSED_KEY_BLOCKS` **(0x1605)**: Error not enough unused key blocks available

`ESP_ERR_DAMAGED_READING` **(0x1606)**: Error. Burn or reset was done during a reading operation leads to damage read data. This error is internal to the efuse component and not returned by any public API.

`ESP_ERR_BURN_WR_DIS` **(0x1607)**: Error to burn WR_DIS field.

`ESP_ERR_IMAGE_BASE` **(0x2000)**

`ESP_ERR_IMAGE_FLASH_FAIL` **(0x2001)**

`ESP_ERR_IMAGE_INVALID` **(0x2002)**

`ESP_ERR_WIFI_BASE` **(0x3000)**: Starting number of WiFi error codes

`ESP_ERR_WIFI_NOT_INIT` **(0x3001)**: WiFi driver was not installed by esp_wifi_init

`ESP_ERR_WIFI_NOT_INIT` **(0x3001)**: WiFi driver was not installed by esp_wifi_init

`ESP_ERR_WIFI_NOT_STARTED` **(0x3002)**: WiFi driver was not started by esp_wifi_start

`ESP_ERR_WIFI_NOT_STARTED` **(0x3002)**: WiFi driver was not started by esp_wifi_start

`ESP_ERR_WIFI_NOT_STOPPED` **(0x3003)**: WiFi driver was not stopped by esp_wifi_stop

`ESP_ERR_WIFI_NOT_STOPPED` **(0x3003)**: WiFi driver was not stopped by esp_wifi_stop

`ESP_ERR_WIFI_IF` **(0x3004)**: WiFi interface error

`ESP_ERR_WIFI_IF` **(0x3004)**: WiFi interface error

`ESP_ERR_WIFI_MODE` **(0x3005)**: WiFi mode error

`ESP_ERR_WIFI_MODE` **(0x3005)**: WiFi mode error

`ESP_ERR_WIFI_STATE` **(0x3006)**: WiFi internal state error

`ESP_ERR_WIFI_STATE` **(0x3006)**: WiFi internal state error

`ESP_ERR_WIFI_CONN` **(0x3007)**: WiFi internal control block of station or soft-AP error

`ESP_ERR_WIFI_CONN` **(0x3007)**: WiFi internal control block of station or soft-AP error

`ESP_ERR_WIFI_NVS` **(0x3008)**: WiFi internal NVS module error

`ESP_ERR_WIFI_NVS` **(0x3008)**: WiFi internal NVS module error

`ESP_ERR_WIFI_MAC` **(0x3009)**: MAC address is invalid

`ESP_ERR_WIFI_MAC` **(0x3009)**: MAC address is invalid

`ESP_ERR_WIFI_SSID` **(0x300a)**: SSID is invalid

`ESP_ERR_WIFI_SSID` **(0x300a)**: SSID is invalid

`ESP_ERR_WIFI_PASSWORD` **(0x300b)**: Password is invalid

`ESP_ERR_WIFI_PASSWORD` **(0x300b)**: Password is invalid

`ESP_ERR_WIFI_TIMEOUT` **(0x300c)**: Timeout error

`ESP_ERR_WIFI_TIMEOUT` **(0x300c)**: Timeout error

`ESP_ERR_WIFI_WAKE_FAIL` **(0x300d)**: WiFi is in sleep state(RF closed) and wakeup fail

`ESP_ERR_WIFI_WAKE_FAIL` **(0x300d)**: WiFi is in sleep state(RF closed) and wakeup fail

`ESP_ERR_WIFI_WOULD_BLOCK` **(0x300e)**: The caller would block

`ESP_ERR_WIFI_WOULD_BLOCK` **(0x300e)**: The caller would block

`ESP_ERR_WIFI_NOT_CONNECT` **(0x300f)**: Station still in disconnect status

`ESP_ERR_WIFI_NOT_CONNECT` **(0x300f)**: Station still in disconnect status

`ESP_ERR_WIFI_POST` **(0x3012)**: Failed to post the event to WiFi task

`ESP_ERR_WIFI_POST` **(0x3012)**: Failed to post the event to WiFi task

`ESP_ERR_WIFI_INIT_STATE` **(0x3013)**: Invalid WiFi state when init/deinit is called

`ESP_ERR_WIFI_INIT_STATE` **(0x3013)**: Invalid WiFi state when init/deinit is called

`ESP_ERR_WIFI_STOP_STATE` **(0x3014)**: Returned when WiFi is stopping

`ESP_ERR_WIFI_STOP_STATE` **(0x3014)**: Returned when WiFi is stopping

`ESP_ERR_WIFI_NOT_ASSOC` **(0x3015)**: The WiFi connection is not associated

`ESP_ERR_WIFI_NOT_ASSOC` **(0x3015)**: The WiFi connection is not associated

`ESP_ERR_WIFI_TX_DISALLOW` **(0x3016)**: The WiFi TX is disallowed

`ESP_ERR_WIFI_TX_DISALLOW` **(0x3016)**: The WiFi TX is disallowed

`ESP_ERR_WIFI_TWT_FULL` **(0x3017)**: no available flow id

`ESP_ERR_WIFI_TWT_FULL` **(0x3017)**: no available flow id

`ESP_ERR_WIFI_TWT_SETUP_TIMEOUT` **(0x3018)**: Timeout of receiving twt setup response frame, timeout times can be set during twt setup

`ESP_ERR_WIFI_TWT_SETUP_TIMEOUT` **(0x3018)**: Timeout of receiving twt setup response frame, timeout times can be set during twt setup

`ESP_ERR_WIFI_TWT_SETUP_TXFAIL` **(0x3019)**: TWT setup frame tx failed

`ESP_ERR_WIFI_TWT_SETUP_TXFAIL` **(0x3019)**: TWT setup frame tx failed

`ESP_ERR_WIFI_TWT_SETUP_REJECT` **(0x301a)**: The twt setup request was rejected by the AP

`ESP_ERR_WIFI_TWT_SETUP_REJECT` **(0x301a)**: The twt setup request was rejected by the AP

`ESP_ERR_WIFI_DISCARD` **(0x301b)**: Discard frame

`ESP_ERR_WIFI_DISCARD` **(0x301b)**: Discard frame

`ESP_ERR_WIFI_ROC_IN_PROGRESS` **(0x301c)**: ROC op is in progress

`ESP_ERR_WIFI_ROC_IN_PROGRESS` **(0x301c)**: ROC op is in progress

`ESP_ERR_WIFI_REGISTRAR` **(0x3033)**: WPS registrar is not supported

`ESP_ERR_WIFI_WPS_TYPE` **(0x3034)**: WPS type error

`ESP_ERR_WIFI_WPS_SM` **(0x3035)**: WPS state machine is not initialized

`ESP_ERR_ESPNOW_BASE` **(0x3064)**: ESPNOW error number base.

`ESP_ERR_ESPNOW_BASE` **(0x3064)**: ESPNOW error number base.

`ESP_ERR_ESPNOW_NOT_INIT` **(0x3065)**: ESPNOW is not initialized.

`ESP_ERR_ESPNOW_NOT_INIT` **(0x3065)**: ESPNOW is not initialized.

`ESP_ERR_ESPNOW_ARG` **(0x3066)**: Invalid argument

`ESP_ERR_ESPNOW_ARG` **(0x3066)**: Invalid argument

`ESP_ERR_ESPNOW_NO_MEM` **(0x3067)**: Out of memory

`ESP_ERR_ESPNOW_NO_MEM` **(0x3067)**: Out of memory

`ESP_ERR_ESPNOW_FULL` **(0x3068)**: ESPNOW peer list is full

`ESP_ERR_ESPNOW_FULL` **(0x3068)**: ESPNOW peer list is full

`ESP_ERR_ESPNOW_NOT_FOUND` **(0x3069)**: ESPNOW peer is not found

`ESP_ERR_ESPNOW_NOT_FOUND` **(0x3069)**: ESPNOW peer is not found

`ESP_ERR_ESPNOW_INTERNAL` **(0x306a)**: Internal error

`ESP_ERR_ESPNOW_INTERNAL` **(0x306a)**: Internal error

`ESP_ERR_ESPNOW_EXIST` **(0x306b)**: ESPNOW peer has existed

`ESP_ERR_ESPNOW_EXIST` **(0x306b)**: ESPNOW peer has existed

`ESP_ERR_ESPNOW_IF` **(0x306c)**: Interface error

`ESP_ERR_ESPNOW_IF` **(0x306c)**: Interface error

`ESP_ERR_ESPNOW_CHAN` **(0x306d)**: Channel error

`ESP_ERR_ESPNOW_CHAN` **(0x306d)**: Channel error

`ESP_ERR_DPP_FAILURE` **(0x3097)**: Generic failure during DPP Operation

`ESP_ERR_DPP_TX_FAILURE` **(0x3098)**: DPP Frame Tx failed OR not Acked

`ESP_ERR_DPP_INVALID_ATTR` **(0x3099)**: Encountered invalid DPP Attribute

`ESP_ERR_DPP_AUTH_TIMEOUT` **(0x309a)**: DPP Auth response was not received in time

`ESP_ERR_DPP_INVALID_LIST` **(0x309b)**: Channel list given in esp_supp_dpp_bootstrap_gen() is not valid or too big

`ESP_ERR_DPP_CONF_TIMEOUT` **(0x309c)**: DPP Configuration was not received in time

`ESP_ERR_MESH_BASE` **(0x4000)**: Starting number of MESH error codes

`ESP_ERR_MESH_WIFI_NOT_START` **(0x4001)**: Wi-Fi isn't started

`ESP_ERR_MESH_WIFI_NOT_START` **(0x4001)**: Wi-Fi isn't started

`ESP_ERR_MESH_NOT_INIT` **(0x4002)**: mesh isn't initialized

`ESP_ERR_MESH_NOT_INIT` **(0x4002)**: mesh isn't initialized

`ESP_ERR_MESH_NOT_CONFIG` **(0x4003)**: mesh isn't configured

`ESP_ERR_MESH_NOT_CONFIG` **(0x4003)**: mesh isn't configured

`ESP_ERR_MESH_NOT_START` **(0x4004)**: mesh isn't started

`ESP_ERR_MESH_NOT_START` **(0x4004)**: mesh isn't started

`ESP_ERR_MESH_NOT_SUPPORT` **(0x4005)**: not supported yet

`ESP_ERR_MESH_NOT_SUPPORT` **(0x4005)**: not supported yet

`ESP_ERR_MESH_NOT_ALLOWED` **(0x4006)**: operation is not allowed

`ESP_ERR_MESH_NOT_ALLOWED` **(0x4006)**: operation is not allowed

`ESP_ERR_MESH_NO_MEMORY` **(0x4007)**: out of memory

`ESP_ERR_MESH_NO_MEMORY` **(0x4007)**: out of memory

`ESP_ERR_MESH_ARGUMENT` **(0x4008)**: illegal argument

`ESP_ERR_MESH_ARGUMENT` **(0x4008)**: illegal argument

`ESP_ERR_MESH_EXCEED_MTU` **(0x4009)**: packet size exceeds MTU

`ESP_ERR_MESH_EXCEED_MTU` **(0x4009)**: packet size exceeds MTU

`ESP_ERR_MESH_TIMEOUT` **(0x400a)**: timeout

`ESP_ERR_MESH_TIMEOUT` **(0x400a)**: timeout

`ESP_ERR_MESH_DISCONNECTED` **(0x400b)**: disconnected with parent on station interface

`ESP_ERR_MESH_DISCONNECTED` **(0x400b)**: disconnected with parent on station interface

`ESP_ERR_MESH_QUEUE_FAIL` **(0x400c)**: queue fail

`ESP_ERR_MESH_QUEUE_FAIL` **(0x400c)**: queue fail

`ESP_ERR_MESH_QUEUE_FULL` **(0x400d)**: queue full

`ESP_ERR_MESH_QUEUE_FULL` **(0x400d)**: queue full

`ESP_ERR_MESH_NO_PARENT_FOUND` **(0x400e)**: no parent found to join the mesh network

`ESP_ERR_MESH_NO_PARENT_FOUND` **(0x400e)**: no parent found to join the mesh network

`ESP_ERR_MESH_NO_ROUTE_FOUND` **(0x400f)**: no route found to forward the packet

`ESP_ERR_MESH_NO_ROUTE_FOUND` **(0x400f)**: no route found to forward the packet

`ESP_ERR_MESH_OPTION_NULL` **(0x4010)**: no option found

`ESP_ERR_MESH_OPTION_NULL` **(0x4010)**: no option found

`ESP_ERR_MESH_OPTION_UNKNOWN` **(0x4011)**: unknown option

`ESP_ERR_MESH_OPTION_UNKNOWN` **(0x4011)**: unknown option

`ESP_ERR_MESH_XON_NO_WINDOW` **(0x4012)**: no window for software flow control on upstream

`ESP_ERR_MESH_XON_NO_WINDOW` **(0x4012)**: no window for software flow control on upstream

`ESP_ERR_MESH_INTERFACE` **(0x4013)**: low-level Wi-Fi interface error

`ESP_ERR_MESH_INTERFACE` **(0x4013)**: low-level Wi-Fi interface error

`ESP_ERR_MESH_DISCARD_DUPLICATE` **(0x4014)**: discard the packet due to the duplicate sequence number

`ESP_ERR_MESH_DISCARD_DUPLICATE` **(0x4014)**: discard the packet due to the duplicate sequence number

`ESP_ERR_MESH_DISCARD` **(0x4015)**: discard the packet

`ESP_ERR_MESH_DISCARD` **(0x4015)**: discard the packet

`ESP_ERR_MESH_VOTING` **(0x4016)**: vote in progress

`ESP_ERR_MESH_VOTING` **(0x4016)**: vote in progress

`ESP_ERR_MESH_XMIT` **(0x4017)**: TX fail, the tx state is a value other than timeout and disconnect

`ESP_ERR_MESH_XMIT` **(0x4017)**: TX fail, the tx state is a value other than timeout and disconnect

`ESP_ERR_MESH_QUEUE_READ` **(0x4018)**: error in reading queue

`ESP_ERR_MESH_QUEUE_READ` **(0x4018)**: error in reading queue

`ESP_ERR_MESH_PS` **(0x4019)**: mesh PS is not specified as enable or disable

`ESP_ERR_MESH_PS` **(0x4019)**: mesh PS is not specified as enable or disable

`ESP_ERR_MESH_RECV_RELEASE` **(0x401a)**: release esp_mesh_recv_toDS

`ESP_ERR_MESH_RECV_RELEASE` **(0x401a)**: release esp_mesh_recv_toDS

`ESP_ERR_ESP_NETIF_BASE` **(0x5000)**

`ESP_ERR_ESP_NETIF_INVALID_PARAMS` **(0x5001)**

`ESP_ERR_ESP_NETIF_IF_NOT_READY` **(0x5002)**

`ESP_ERR_ESP_NETIF_DHCPC_START_FAILED` **(0x5003)**

`ESP_ERR_ESP_NETIF_DHCP_ALREADY_STARTED` **(0x5004)**

`ESP_ERR_ESP_NETIF_DHCP_ALREADY_STOPPED` **(0x5005)**

`ESP_ERR_ESP_NETIF_NO_MEM` **(0x5006)**

`ESP_ERR_ESP_NETIF_DHCP_NOT_STOPPED` **(0x5007)**

`ESP_ERR_ESP_NETIF_DRIVER_ATTACH_FAILED` **(0x5008)**

`ESP_ERR_ESP_NETIF_INIT_FAILED` **(0x5009)**

`ESP_ERR_ESP_NETIF_DNS_NOT_CONFIGURED` **(0x500a)**

`ESP_ERR_ESP_NETIF_MLD6_FAILED` **(0x500b)**

`ESP_ERR_ESP_NETIF_IP6_ADDR_FAILED` **(0x500c)**

`ESP_ERR_ESP_NETIF_DHCPS_START_FAILED` **(0x500d)**

`ESP_ERR_ESP_NETIF_TX_FAILED` **(0x500e)**

`ESP_ERR_FLASH_BASE` **(0x6000)**: Starting number of flash error codes

`ESP_ERR_FLASH_OP_FAIL` **(0x6001)**

`ESP_ERR_FLASH_OP_TIMEOUT` **(0x6002)**

`ESP_ERR_FLASH_NOT_INITIALISED` **(0x6003)**: esp_flash_chip_t structure not correctly initialised by esp_flash_init().

`ESP_ERR_FLASH_UNSUPPORTED_HOST` **(0x6004)**: Requested operation isn't supported via this host SPI bus (chip->spi field).

`ESP_ERR_FLASH_UNSUPPORTED_CHIP` **(0x6005)**: Requested operation isn't supported by this model of SPI flash chip.

`ESP_ERR_FLASH_PROTECTED` **(0x6006)**: Write operation failed due to chip's write protection being enabled.

`ESP_ERR_HTTP_BASE` **(0x7000)**: Starting number of HTTP error codes

`ESP_ERR_HTTP_MAX_REDIRECT` **(0x7001)**: The error exceeds the number of HTTP redirects

`ESP_ERR_HTTP_CONNECT` **(0x7002)**: Error open the HTTP connection

`ESP_ERR_HTTP_WRITE_DATA` **(0x7003)**: Error write HTTP data

`ESP_ERR_HTTP_FETCH_HEADER` **(0x7004)**: Error read HTTP header from server

`ESP_ERR_HTTP_INVALID_TRANSPORT` **(0x7005)**: There are no transport support for the input scheme

`ESP_ERR_HTTP_CONNECTING` **(0x7006)**: HTTP connection hasn't been established yet

`ESP_ERR_HTTP_EAGAIN` **(0x7007)**: Mapping of errno EAGAIN to esp_err_t

`ESP_ERR_HTTP_CONNECTION_CLOSED` **(0x7008)**: Read FIN from peer and the connection closed

`ESP_ERR_HTTP_NOT_MODIFIED` **(0x7009)**: HTTP 304 Not Modified, no update available

`ESP_ERR_HTTP_RANGE_NOT_SATISFIABLE` **(0x700a)**: HTTP 416 Range Not Satisfiable, requested range in header is incorrect

`ESP_ERR_HTTP_READ_TIMEOUT` **(0x700b)**: HTTP data read timeout

`ESP_ERR_HTTP_INCOMPLETE_DATA` **(0x700c)**: Incomplete data received, less than Content-Length or last chunk

`ESP_ERR_HTTP_REDIRECT_DOWNGRADE` **(0x700d)**: HTTPS origin redirected to a non-HTTPS scheme (downgrade blocked)

`ESP_ERR_ESP_TLS_BASE` **(0x8000)**: Starting number of ESP-TLS error codes

`ESP_ERR_ESP_TLS_CANNOT_RESOLVE_HOSTNAME` **(0x8001)**: Error if hostname couldn't be resolved upon tls connection

`ESP_ERR_ESP_TLS_CANNOT_CREATE_SOCKET` **(0x8002)**: Failed to create socket

`ESP_ERR_ESP_TLS_UNSUPPORTED_PROTOCOL_FAMILY` **(0x8003)**: Unsupported protocol family

`ESP_ERR_ESP_TLS_FAILED_CONNECT_TO_HOST` **(0x8004)**: Failed to connect to host

`ESP_ERR_ESP_TLS_SOCKET_SETOPT_FAILED` **(0x8005)**: failed to set/get socket option

`ESP_ERR_ESP_TLS_CONNECTION_TIMEOUT` **(0x8006)**: new connection in esp_tls_low_level_conn connection timeouted

`ESP_ERR_ESP_TLS_SE_FAILED` **(0x8007)**: esp-tls use Secure Element returned failed

`ESP_ERR_ESP_TLS_TCP_CLOSED_FIN` **(0x8008)**: esp-tls's TPC transport connection has benn closed (in a clean way)

`ESP_ERR_ESP_TLS_SERVER_HANDSHAKE_TIMEOUT` **(0x8009)**: TLS handshake timeout

`ESP_ERR_MBEDTLS_CERT_PARTLY_OK` **(0x8010)**: mbedtls parse certificates was partly successful

`ESP_ERR_MBEDTLS_CTR_DRBG_SEED_FAILED` **(0x8011)**: mbedtls api returned error

`ESP_ERR_MBEDTLS_SSL_SET_HOSTNAME_FAILED` **(0x8012)**: mbedtls api returned error

`ESP_ERR_MBEDTLS_SSL_CONFIG_DEFAULTS_FAILED` **(0x8013)**: mbedtls api returned error

`ESP_ERR_MBEDTLS_SSL_CONF_ALPN_PROTOCOLS_FAILED` **(0x8014)**: mbedtls api returned error

`ESP_ERR_MBEDTLS_X509_CRT_PARSE_FAILED` **(0x8015)**: mbedtls api returned error

`ESP_ERR_MBEDTLS_SSL_CONF_OWN_CERT_FAILED` **(0x8016)**: mbedtls api returned error

`ESP_ERR_MBEDTLS_SSL_SETUP_FAILED` **(0x8017)**: mbedtls api returned error

`ESP_ERR_MBEDTLS_SSL_WRITE_FAILED` **(0x8018)**: mbedtls api returned error

`ESP_ERR_MBEDTLS_PK_PARSE_KEY_FAILED` **(0x8019)**: mbedtls api returned failed

`ESP_ERR_MBEDTLS_SSL_HANDSHAKE_FAILED` **(0x801a)**: mbedtls api returned failed

`ESP_ERR_MBEDTLS_SSL_CONF_PSK_FAILED` **(0x801b)**: mbedtls api returned failed

`ESP_ERR_MBEDTLS_SSL_TICKET_SETUP_FAILED` **(0x801c)**: mbedtls api returned failed

`ESP_ERR_MBEDTLS_SSL_READ_FAILED` **(0x801d)**: mbedtls api returned failed

`ESP_ERR_HTTPS_OTA_BASE` **(0x9000)**

`ESP_ERR_HTTPS_OTA_IN_PROGRESS` **(0x9001)**: OTA operation in progress

`ESP_ERR_HTTPD_BASE` **(0xb000)**: Starting number of HTTPD error codes

`ESP_ERR_HTTPD_HANDLERS_FULL` **(0xb001)**: All slots for registering URI handlers have been consumed

`ESP_ERR_HTTPD_HANDLER_EXISTS` **(0xb002)**: URI handler with same method and target URI already registered

`ESP_ERR_HTTPD_INVALID_REQ` **(0xb003)**: Invalid request pointer

`ESP_ERR_HTTPD_RESULT_TRUNC` **(0xb004)**: Result string truncated

`ESP_ERR_HTTPD_RESP_HDR` **(0xb005)**: Response header field larger than supported

`ESP_ERR_HTTPD_RESP_SEND` **(0xb006)**: Error occurred while sending response packet

`ESP_ERR_HTTPD_ALLOC_MEM` **(0xb007)**: Failed to dynamically allocate memory for resource

`ESP_ERR_HTTPD_TASK` **(0xb008)**: Failed to launch server task/thread

`ESP_ERR_HW_CRYPTO_BASE` **(0xc000)**: Starting number of HW cryptography module error codes

`ESP_ERR_HW_CRYPTO_DS_HMAC_FAIL` **(0xc001)**: HMAC peripheral problem

`ESP_ERR_HW_CRYPTO_DS_INVALID_KEY` **(0xc002)**: given HMAC key isn't correct

`ESP_ERR_HW_CRYPTO_DS_INVALID_DIGEST` **(0xc004)**: message digest check failed

`ESP_ERR_HW_CRYPTO_DS_INVALID_PADDING` **(0xc005)**: padding check failed, but result

`ESP_ERR_MEMPROT_BASE` **(0xd000)**: Starting number of Memory Protection API error codes

`ESP_ERR_MEMPROT_MEMORY_TYPE_INVALID` **(0xd001)**: Memory type invalid in given context

`ESP_ERR_MEMPROT_SPLIT_ADDR_INVALID` **(0xd002)**: Splitting address invalid in given context

`ESP_ERR_MEMPROT_SPLIT_ADDR_OUT_OF_RANGE` **(0xd003)**: Splitting address out of range

`ESP_ERR_MEMPROT_SPLIT_ADDR_UNALIGNED` **(0xd004)**: Splitting address not aligned to required boundaries

`ESP_ERR_MEMPROT_UNIMGMT_BLOCK_INVALID` **(0xd005)**: Required unified-management block is not valid

`ESP_ERR_MEMPROT_WORLD_INVALID` **(0xd006)**: Required World identifier is not valid

`ESP_ERR_MEMPROT_AREA_INVALID` **(0xd007)**: Required Area identifier is not valid

`ESP_ERR_MEMPROT_CPUID_INVALID` **(0xd008)**: Required CPU/Core identifier is not valid

`ESP_ERR_TCP_TRANSPORT_BASE` **(0xe000)**: Starting number of TCP Transport error codes

`ESP_ERR_TCP_TRANSPORT_CONNECTION_TIMEOUT` **(0xe001)**: Connection has timed out

`ESP_ERR_TCP_TRANSPORT_CONNECTION_CLOSED_BY_FIN` **(0xe002)**: Read FIN from peer and the connection has closed (in a clean way)

`ESP_ERR_TCP_TRANSPORT_CONNECTION_FAILED` **(0xe003)**: Failed to connect to the peer

`ESP_ERR_TCP_TRANSPORT_NO_MEM` **(0xe004)**: Memory allocation failed

`ESP_ERR_NVS_SEC_BASE` **(0xf000)**: Starting number of error codes

`ESP_ERR_NVS_SEC_HMAC_KEY_NOT_FOUND` **(0xf001)**: HMAC Key required to generate the NVS encryption keys not found

`ESP_ERR_NVS_SEC_HMAC_KEY_BLK_ALREADY_USED` **(0xf002)**: Provided eFuse block for HMAC key generation is already in use

`ESP_ERR_NVS_SEC_HMAC_KEY_GENERATION_FAILED` **(0xf003)**: Failed to generate/write the HMAC key to eFuse

`ESP_ERR_NVS_SEC_HMAC_XTS_KEYS_DERIV_FAILED` **(0xf004)**: Failed to derive the NVS encryption keys based on the HMAC-based scheme

---

Was this page helpful?

