## INDEX

	Subject	Chapter	Section Page
P	Program Restart	6	- · 6.2.4 ····· 167 - · 4.1 ···· 114
R	Rapid Traverse Rate	6	• • 6.1.11 ···· 157 • • 2.9.13 ··· 33 • • 6.1.16 ··· 159
	Registration of User Macros	4	• • 4.5.4 ····· 137 • • 4.2.3 ···· 120
	ROUTINE INSPECTION SCHEDULE		•
S	S2-Digit Programming	2	2. 9. 24 60
	Setting and Parameter Tape Verifying	· · 4 · · ·	. 4.4.2 · · · · · · 133 · 4.4.4 · · · · · · 133 · 4.3.6 · · · · · · 127
	Setting of Baud Rate and Others of Serial Ingerface Simultaneously Controllable Axes of Four-axis Control† Simultaneously Controllable Axes of Three-axis Control SINGLE BLOCK Switch Skip Function (G31)†	2	· · 2.3.3 ······ 7 · · 2.3.2 ····· 7 · · 6.1.17 ···· 159 · · 2.9.17 ···· 36
	SPINDLE SPEED OVERRIDE Switch†	2	. 2,5
	STORED LEADSCREW ERROR COMPENSATION A STORED LEADSCREW ERROR COMPENSATION AND STORED STROKE LIMIT <sup>†</sup> , PREPARATION FOR Stored Stroke Limit (G22, G23) <sup>†</sup> Subroutine Program (M98, M99)	7	. 7.4
т	SWITCHING UNITS ON THE CONTROL STATION	2	· · 2.6.1 ····· 14 · · 2.6.2 ···· 14 · · 5.1.1 ···· 17
	TAPE CODE	4	. 4.4
	TAPE READER	5	5.2.2 14