Table 5-2 List of Alarm Codes (Cont'd)

Code	Causes	Code	Causes
374	FG ERROR (4)	394	TG ERROR (4)
	FG ERROR 4		TG LEAD DISCONNECTION
375	FG ERROR (5)	395	TG ERROR (5)
	FG ERROR 5		TG LEAD DISCONNECTION
381	RPG ERROR (X)	400	SEQ ERROR
	RPG ERROR X		SEQUENCE ERROR (2)
382	RPG ERROR (Y)	419	SEQ ERROR
	RPG ERROR Y		SEQUENCE ERROR (2)
383	RPG ERROR (Z)	300	SEQ ERROR
	RPG ERROR Z		SEQUENCE ERROR (3)
384	RPG ERROR (4)	519	SEQ ERROR
	RPG ERROR 4		SEQUENCE ERROR (3)
385	RPG ERROR 5	800	MEM ERROR
	PROGRAM ERROR 5		BUBBLE FAILURE INPUT/OUTPUT FAILURE
391	TG ERROR (X)	801	MEM ERROR
	TG LEAD DISCONNECTION		BUBBLE FAILURE INITIAL ERROR
392	TG ERROR (Y)	802	MEM ERROR
	TG LEAD DISCONNECTION		BUBBLE FAILURE UNDEFINED COMMAND
393	TG ERROR (Z)	803	MEM ERROR
	TG LEAD DISCONNECTION		BUBBLE FAILURE TRANSFER MISSING