

Character	Purpose
#	Send QSO Number. Can be followed by + or - and a single integer to modify the number sent
@	Send call in Call Window*
*	Same as “@” unless an ALT-D call (dupe check and Work call on inactive radio) is available, in which case the ALT-D call is sent(This is a quick way to allow you to program a CWmessage for the second radio when you are on the first radio
\$	Send salutation and name if known (e.g., GE TREE). Adds a space at the end of message.
%	Send name from name database (adds a space at end if name present)
:	Send characters from keyboard until <ENTER> or <ESC> is pressed
~	Send proper salutation without name (GM, GA or GE) based upon callsign
\	Send call as set by MY CALL command
	Send name that was copied into Exchange Window (RST QTH NAME Exchange)
[	Wait for a number to be typed to use as strength of an RST- and send it on CW
]	Repeat the last complete RST sent with the “[“ command
-	Space (use at the start or end of a message, where spaces in the Contest.CFG file are ignored)
^	Half-length space
}	Send prefix or suffix only of corrected call (only when callsignhas been changed since QSO began)
{	Send complete corrected call (only when callsign has been changed since QSO began)
)	Send callsign of last QSO in the editable log
(	Send name received in previous Sprint QSO (at the bottom of the editable log)
>	Clear RIT - requires interfaced radio; only works with Kenwood and Yaesu rigs
+	End of message (AR)
<	End of Work (SK)
=	Pause (BT)
!	QRL? (SN or VE)
&	QRX (AS)

Special CW Characters