

ROS PRINT/PATCH COMMANDS

NOTE

All input is in DECIMAL unless prefixed by 8R.

All output is in OCTAL.

All printing commands output to teletype on which command was typed, unless LPR typed at end of command, in which case Line Printer will be used if available.

PRBLK <Disc No.> <SCT Offset> <Start Offset> <End Offset> LPR
Print contents of block from specified disc.

PABLK <Disc No.> <SCT Offset> <Start Offset>
<New Value 1> <New Value 2> <New Value 3> etc.
Modify contents of block on specified disc

PRINTS <Store Address> <No. of words> LPR
Print contents of fast store

PATCH <Store Address> <New Value 1> <New Value 2> etc.
Modify contents of fast store

PRINTB <Block name> LPR
Print contents of selected fast store blocks known to the system by name.

PRDISC <Disc No.> <Start track> <Start sector> <Start word
in sector> <No. of words> LPR
Print contents of disc

PADISC <Disc No.> <Start track> <Start sector> <Start word in sector>
<New Value 1> <New Value 2> etc.
Modify contents of disc.

ROS MAINTENANCE COMMANDS

(Device Numbers all start from 1)

STATUS <Module Type>

<Module Type> may be CPUS, STORES, PARALLEL,
SERIAL, or may be omitted.

Prints status of devices and/or ports.

REMOVE <Device Type> <No.>

Removes the device from the online system.

RESTORE <Device Type> <No.>

or

RESTORE <Device Type><No.> PORT <A or B>

Tests and if OK returns device (or port) to the online system.

DIAGNOSE <Device Type><No.> <XT>

XT is the "Tag" to identify I/O to the test process.

T may be any letter from A-Z not already in use.

Runs Diagnostic tests for device.

TEST <Device Type> <No.> <XT>

Runs diagnostics for device in Test Mode

IN <XT> <Command>

Inputs commands or data to Test Mode process XT.

SUSPEND <XT>

Suspends test process XT at end of current DIAL instruction.

CANCEL <XT>

Stop and delete test process XT

WHATTESTS

Lists tests currently in progress, with tags.