DISC CONTROLLER REGISTER SET

REGISTER	OFFSET	
MAR	00	
IAR	01	
STATUS	02	
CURRENT ADDRESS	03	
COMMAND	05	
START ADDRESS	06	TRANSFER CAPABILITY REGISTER
TRANSFER SIZE	07	
DATA IN	10	
DATA OUT	11	

MAGNETIC TAPE CONTROLLER REGISTER SET

REGISTER	OFFSET
MAR	00
IAR	01
STATUS	02
COMMAND	03
BLOCK SIZE	04
DATA IN	05
DATA OUT	06
DEVICE	07
DIAGNOSTIC	10
APPLICATIONS	11
DRIVE	12

LINE PRINTER CONTROLLER REGISTER SET

REGISTER	OFFSET
MAR	00
IAR	01
STATUS	02
COMMAND	03
DATA OUT	04
DATA IN	05
DEVICE	06

PARALLEL TELETYPE CONTROLLER REGISTER SET

REGISTER	OFFSET
MAR	00
IAR	01
STATUS	02
COMMAND	03
DATA IN	04
DATA OUT	05

SERIAL- PARALLEL ADAPTOR REGISTER SET

REGISTER	OFFSET	
MAR	00	
IAR	01	
STATUS	02	
COMMAND	03	
INPUT ADDRESS	04	DATA IN REGISTERS
INPUT DATA	05	
INPUT TIMESTAMP	06	
SERIAL INPUT (ADDRESS)	07	
SERIAL INPUT (DATA)	10	
TIMESTAMP	11	
OUTPUT ADDRESS	12	DATA OUT REGISTERS
OUTPUT DATA	13	
SERIAL OUTPUT ADDRESS	14	
SERIAL OUTPUT DATA	15	
DIAGNOSTIC	16	

SERIAL TELETYPE CONTROLLER REGISTER SET

REGISTER	OFFSET
STATUS	01
COMMAND	02
DATA IN	03
DATA OUT	04

SERIAL PUNCH CONTROLLER REGISTER SET

REGISTER	OFFSET
STATUS	01
COMMAND	02
DATA OUT	03

SERIAL READER CONTROLLER REGISTER SET

REGISTER	OFFSET
STATUS	01
COMMAND	02
DATA IN	03

BACKING AND INITIALISING STORE CONTROL UNIT

ADDRESS STRUCTURE

ADDRESS OFFSET	READS	WRITES
0000	MODULE ADDRESS	-
0001	INVERSE ADDRESS	-
0002	STATUS	-
0003	ALL ONES	COMMAND
0004-0007	AS FOR 0000-0003	SECTORS PER TRACK & WORDS PER SECTOR
0010-0013	TRANSFER WIRED DISC IDENTITY TRACK & SECTOR (P?)	TRANSFER TRACK & SECTOR
0014-0017	ROUTINE WIRED DISC IDENTITY TRACK & SECTOR	-
0020	BUFFER TRANSFER POINTER VIA FORECAST	SECTOR COUNT
0021	FORECAST (P)	"
0022	FORECAST (P)	"
0023	FORECAST	"
0024	FORECAST (P)	TRANSFER WORD COUNT
0025	REFRESH VIA FORECAST (P?)	"
0026	BASE SECTOR VIA FORECAST	"
0027	FORECAST (P)	"
0030-0033	DATA IN (P?)	BUFFER TRANSFER POINTER
0034-0037	"	CHECKCODE VERIFIER
0040-0043	ALL ZEROES	INSPECTION
0044-0047	"	MASTER CLEAR
0050-0053	CURRENT PARALLEL & SERIAL (P!)	CURRENT PARALLEL & SERIAL
0054-0057	"	-
0060-0067	CONDITIONALS & SLOTS (P?)	-
0070-0077	BUFFER	BUFFER
0100-0177	SPARE BUFFER LOCATIONS	SPARE BUFFER LOCATIONS
0200-0577	WORK LIST	WORK LIST
0600-7777	DATA BUFFER	DATA BUFFER

NOTES

ALL ADDRESSES MARKED WITH A DASH CAUSE THE DATA SUPPLIED TO BE LOADED INTO THE DATA OUT REGISTER, BUT THAT DATA WILL NOT BE TRANSFERRED TO ANY OTHER REGISTER.

ALL ADDRESSES MARKED WITH (P) WILL ALWAYS GIVE A READ DATA PARITY FAULT; WITH (P?) WILL OCCASIONALLY GIVE A READ DATA PARITY FAULT; WITH (P!) WILL OCCASIONALLY GIVE A READ DATA PARITY FAULT AND A BUFFER PARITY FAULT. THESE ADDRESSES SHOULD ONLY BE READ WITH INTERFACE FAULTS INHIBITED SET.

CONSOLE CONTROL UNIT

ADDRESS STRUCTURE

ADDRESS OFFSET	READS	WRITES
0000	MODULE ADDRESS	-
0001	INVERSE ADDRESS	-
0002	STATUS	-
0003	ALL ONES	COMMAND
0004-0007	AS FOR 0000-0003	WORDS PER SECTOR
0010-0013	ALL ZEROES	TRACK & DEVICE SELECTION
0014-0017	"	-
0020	BUFFER TRANSFER POINTER VIA FORECAST	SECTOR COUNT
0021	FORECAST (P)	"
0022	FORECAST (P)	"
0023	FORECAST	"
0024	FORECAST (P)	TRANSFER WORD COUNT
0025	REFRESH VIA FORECAST (P?)	"
0026	BASE SECTOR VIA FORECAST	"
0027	FORECAST (P)	"
0030-0033	DATA IN (P?)	BUFFER TRANSFER POINTER
0034-0037	"	-
0040	-	VDU (DATA OUT)
0041	VDU (DATA IN)	-
0042 AFC	SECONDARY STATUS (P)	-
0043 REGISTERS	-	DIAGNOSTIC
0044	-	- } POWER CLEAR
0045	-	- } POWER CLEAR
0046	-	- } POWER CLEAR
0047	-	-
0050-0053	PARALLEL & SERIAL 1 (P!)	PARALLEL & SERIAL 1
0054-0057	" 2 (P!)	" 2
0060-0067	DIAGNOSTIC BITS	-
0070-0077	NOT USED	NOT USED
0100-7777	DATA BUFFER	DATA BUFFER

NOTE SEE NOTES ON PAGE 19.

EXCHANGEABLE DISC SYSTEM

ADDRESS STRUCTURE

ADDRESS OFFSET	READS	WRITES
0000	MODULE ADDRESS	-
0001	INVERSE ADDRESS	-
0002	STATUS	
0003	ALL ONES	COMMAND
0004-0007	AS FOR 0000-0003	SECTORS/TRACK & WORDS/SECTOR
0010-0013	TRACK & SECTOR (P?)	TRACK & SECTOR
0014-0017		-
0020	BUFFER TRANSFER POINTER VIA FORECAST	SECTOR COUNT
0021	FORECAST (P)	"
0022	FORECAST (P)	"
0023	FORECAST	"
0024	FORECAST (P)	TRANSFER WORD COUNT
0025	REFRESH VIA FORECAST (P?)	"
0026	ADDITIONAL FUNCTIONS ADDRESS VIA FORECAST	"
0027	FORECAST (P)	"
0030-0033	DATA IN (P?)	BUFFER TRANSFER POINTER
0034-0037	"	CHECKCODE VERIFIER
0040	WORK STATUS	WORK ITEM
0041	DIAGNOSTICS 1 (DRIVE HIGHWAY)	MICROPROGRAM CLOCK COUNTER
0042	ALL ZEROES	DIAGNOSTICS 3 (STAR SELECT)
0043	"	DIAGNOSTICS 5 (MICROPROGRAM FORCE)
0044-0047	MONITORING POINTS AFC	-
0050-0053	CURRENT PARALLEL & SERIAL WHEN SELECTED (P1)	CURRENT PARALLEL & SERIAL
0054-0057	"	-
0060-0067	BUFFER CONTROL MONITORING POINTS	-
0070	WORDS PER SECTOR	WORDS PER SECTOR
0071	WORDS PER ADDRESS	WORDS PER TRACK
0072	BITS DATA PREAMBLE	BITS DATA PREAMBLE
0073	BITS IN ADDRESS PREAMBLE	BITS IN ADDRESS PREAMBLE
0074-0077	DATA BUFFER	DATA BUFFER
0100-0137	WORK ITEM	WORK ITEM
0140-0177	WORK STATUS	WORK STATUS
0200-0237	LAST SECTOR ADDRESS	LAST SECTOR ADDRESS
0240-7777	DATA BUFFER	DATA BUFFER

NOTE SEE NOTES ON PAGE 19.