

Fault Indicators			Primary Indicators			Secondary Indicators		
MIF00	Bus Corrupt	1835	MIP00	=0	1856A	MIS00	Microprogram O/F	1835
01			01	<0	1856A	01		
02	Interrupt T/O	1835	02	Overflow	1856A	02	Inhibit Slot Decode	1835
03			03	Spare	1856A	03		
04	Spare	1856A	04	Second Group	1856A	04		
05	Slave T/O	1856A	05	Inh. Interface Flts.	1856A	05	Interval Timer Matured	1856A
06	Cap. Parity Fault	1847A	06	Odd Data Parity	1856A	06	Multiply	1847A
07	Sumcheck Fault	1840A	07	1st Attempt	1856A	07	Divide	1840A
08	Base/Limit Fault	1847A	08	Inhibit Interrupts	1856A	08	Set Read Capability	1847A
09	Interface T/O	1840A				09	IAR Decrement	1840A
10	Parity Comparison	1847A				10	Out = Limit	1847A
11	Read Data Parity	1847A				11	Trap	1847A
12	Invalid Operation	1847A				12	Time Up	1847A
13	Power Failure	1847A				13	Cycle Intercomplete	1847A
14	Invalid Control Code	1840A				14	Move	1840A
15	Trap with MIP08	1840A				15	Fault Toggle	1840A
16	Hardware Fault 1	1840A				16	Fault Link From B.P.W.	1840A
17	W.D.T. Expired	1840A				17	Dump Process Before Int	1840A
18	Access Violation	1840A				18	Internal Mode	1840A
19	Hardware Fault 2	1840A				19	Cap. Pointer in OPP	1840A
20	[LS Capability Register on which failure occurred. MS]	1840A				20	HAD Increment	1840A
21		1840A				21	Even Parity Internal	1840A
22		1840A				22	Busy	1840A
23		1840A				23	Status	1840A

