

MicroStation / OpenBuildings Shortcuts

ENTRY POINTS / POP-UPS	
POP-UPS / MENUS	
Space	Shortcut Pop-up
Q or [	Quick Tools Menu
RMB Hold	Context Menu
Shift + F10	Ribbon Group Menu
Shift + Alt + RMB	View Tools Pop-up
Ctrl + Shift + RMB	Navigation Menu
SHORTCUT MENU LETTERS	
G	G Shortcuts Menu
L	Lock Shortcuts Menu
P	Point Shortcuts Menu
R	Rotate Shortcuts Menu
W	W Shortcuts Menu
`	Bump Tool Settings
\	Workflow Menu

MAIN INTERFACE	
HELP / SEARCH / RIBBON	
F1	Help
F2	Ribbon Key Tips
F3	Tool Key Tips
F4	Search Ribbon
VIEW / DRAFTING AIDS	
F5	View Attributes
F6	Saved Views
F8	Grid On / Off
WINDOWS	
F7	Keyboard Shortcuts
F9	Key-in Window
F10	Tool Settings
F11	AccuDraw Window
F12	Focus Home
Alt + F8	Macros

PANELS / DIALOGS	
Ctrl + T	Toolboxes
Ctrl + I	Element Information
Ctrl + B	View Attributes
Ctrl + G	Group
Ctrl + U	Ungroup

FILE / EDIT / PRINT	
Ctrl + N	New File
Ctrl + O	Open File
Ctrl + S	Save File
Ctrl + F	Save Settings
Ctrl + P	Print
Ctrl + W	Close File
Ctrl + Z	Undo
Ctrl + R	Redo
Ctrl + C	Copy
Ctrl + X	Cut
Ctrl + V	Paste
Esc	Cancel / Exit Tool

QUICK TOOLS			
Tool	Q Menu	[Menu	
Attributes	Q, 1	[, 6	
Primary	Q, 2	[, 7	
Selection	Q, 3	[, 8	
Placement	Q, 4	[, 9	
Manipulate	Q, 5	[, 0	
Modify	Q, 6	[, -	
Groups	Q, 7	[, =	
Select	Q, Q	[, [	
Move	Q, W	[, P	
Copy	Q, E	[, O	
Rotate	Q, R	[, I	
Scale	Q, T	[, U	
Mirror	Q, Y	[, Y	
Delete	Q, U	[, T	
Measure	Q, A	[, D	
Text	Q, S	[, F	
Dimensioning	Q, D	[, G	
Detailing	Q, G	[, H	
Patterns	Q, F	[, J	
AccuDraw	Q, H	[, K	
Snaps Toolbox	Q, J	[, L	
Locks	Q, K	[, ;	
View Tools	Q, L	[, '	

PRIMARY TOOLS / ATTRIBUTES	
PRIMARY TOOL DIALOGS	
Ctrl + F1	Models
Ctrl + F2	References
Ctrl + F3	Raster Manager
Ctrl + F4	Point Clouds
Ctrl + F5	Saved Views
Ctrl + F6	Level Manager
Ctrl + F7	Level Display
Ctrl + F8	Cell Library
Ctrl + F9	Aux Coordinates
Ctrl + F10	Explorer
Ctrl + F11	Details
ACTIVE ATTRIBUTES	
Shift + F1	Element Template
Shift + F2	Active Level
Shift + F3	Active Color
Shift + F4	Active Line Style
Shift + F5	Active Line Weight
Shift + F6	Transparency
Shift + F7	Priority

MOUSE / VIEW	
MOUSE BUTTONS	
Left Click	Data Point / Accept
Right Click	Reset / Back Out
Middle Click	Tentative Snap
WHEEL NAVIGATION	
Wheel	Zoom In / Out
Shift + Wheel	Pan Left / Right
Ctrl + Wheel	Pan Up / Down
VIEW	
Fit View	View All Visible Geometry

SNAPS / ACCUSNAP	
OPEN SNAP TOOLS	
Q, J / [, L	Open Snaps Toolbox
DIRECT SNAP KEYS	
C	Center Snap
I	Intersect Snap
N	Nearest Snap
K	Snap Divisor
ACCUSNAP CONTROL	
H, S	AccuSnap On / Off
H, U	Hold AccuSnap

ACCUDRAW DIRECT KEYS	
SETUP / MODE	
Enter	Smart Lock Axis / Value
M	Rectangular / Polar
O	Set Origin
B	Base Rotation / ACS
LOCKS	
A	Lock Angle
D	Lock Distance
X	Lock X
Y	Lock Y
Z	Lock Z
ROTATION / VIEW	
V	Rotate To View
T	Rotate To Top
F	Rotate To Front
S	Rotate To Side
E	Cycle Rotation Plane
INPUT / UTILITY	
P	Point / Data Point Key-in
?	AccuDraw Help
Q	Deactivate AccuDraw
~	Cycle Tool Setting

ACCUDRAW LOCKS	
L, I	Lock Index
L, P	ACS Plane + Snap + Grid
L, A	ACS Plane Lock
L, S	ACS Plane Snap
L, Z	Sticky Z

ACCUDRAW ROTATION	
R, Q	Rotate Quick
R, A	Rotate ACS
R, C	Rotate To ACS
R, E	Rotate To Element
R, V	Rotate View To Plane
R, X	Rotate Plane 90 Deg X
R, Y	Rotate Plane 90 Deg Y
R, Z	Rotate Plane 90 Deg Z

ACCUDRAW WINDOWS / HOLDS	
G, T	Tool Settings
G, K	Key-in Window
G, S	AccuDraw Settings
G, A	Get ACS
W, A	Write ACS
H, A	Hold AccuDraw