
egoShield with 4 push-buttons and OLED display



The control in the library has the following functionality:

• *Idle state*

- o Press **FWD** or **REV** to manually move 10 deg in either direction
- o Press and hold FWD or REV to move continuous until releasing
- o Press and hold **RECORD** to enter recording state
- o Press **PLAY** to enter *Play state*, and play recorded sequence
- o Press and hold **STOP** to invert PID mode (either PID ON or PID OFF)

• Record state

- o Press **RECORD** to record position
- o Press and hold **STOP** to go into *Idle state* again
- o If PID ON:
 - Press FWD or REV to manually move 10 deg in either direction
 - Press and hold FWD or REV to move continuous until releasing
- o If PID OFF:
 - Also possible to move by hand

• Play state

- o Press **PAUSE** to enter *Pause state* at next position
- o Press and hold **STOP** to stop play and go into *Idle state*
- o Press and hold **FWD** to play sequence in loop
- o Press and hold **REV** to stop looping

• Pause state

- o Press **PLAY** to continue playing by entering *Play state*
- o Press and hold **STOP** to go into *Idle state*