Tempico Software

Release 1.3.0

Tausand Electronics

Dec 12, 2025

CONTENTS:

1 StartStopLogic module 3

2 LifeTimeLogic module 11

3 TimeStampLogic module 23

4 CountsEstimatedLogic module 37

5 main module 53

6 Indices and tables 59

Python Module Index 61

Index 63

Tempico Software is a program developed by Tausand Electronics, with Joan Amaya and David Guzman as the lead developers. It is implemented in Python, utilizing key libraries such as PyQt5 (integrated with PySide2) for the graphical user interface, HIDAPI for serial communication, and PyGraph for data visualization. The software facilitates the use of Tausand Tempico TP1004 devices, streamlining the creation of histograms and lifetime measurements. For more information, visit tausand.com.

CHAPTER

ONE

STARTSTOPLOGIC MODULE

class Logic.StartStopLogic.**StartStopLogic**(*parent*, *disconnect*, *device*, *check1*, *check2*, *check3*, *check4*, *startbutton*, *stopbutton*, *savebutton*, *save_graph_1*, *clear_channel_A*, *clear_channel_B*, *clear_channel_C*, *clear_channel_D*, *connect*, *mainWindow*, *statusValue*, *statusPoint*, *timerStatus*, **args*, ***kwargs*)

Bases: `object`

This class handles the functionality for managing buttons, checkboxes, and graphs for histograms related to the Start-Stop measurements. It controls which channels are active, manages the display of histograms, and records the data from the Tempico device based on the user's interactions. It also handles the zooming feature for creating bars according to the time range received from the device.

Parameters

- **parent** – The parent QWindow for the logic.
- **disconnect** – The QPushButton used to disconnect.
- **device** – The Tempico device class that handles the measurements.
- **check4** (*check1, check2, check3,*) – QCheckBoxes that control the visibility of each histogram.
- **stopbutton** (*startbutton,*) – QPushButtons to start and stop the measurement process.
- **save_graph_1** (*savebutton,*) – QPushButtons to save data and save the graph.
- **clear_channel_D** (*clear_channel_A, clear_channel_B, clear_channel_C,*) – QPushButtons to clear data for each respective channel.
- **connect** – QPushButton to connect to the Tempico device.
- **mainWindow** – The main window (QWindow) for the GUI.
- **statusPoint** (*statusValue,*) – QLabel widgets for displaying status information (e.g., values and points).

autoRangeA()

Automatically adjusts the zoom level of channel A to the maximum value in the data.

The function sets a sentinel for zoom changes, checks if there are any data points in channel A, and if so, finds the maximum value. It then calls the changeZoomMax function to adjust the zoom accordingly.

Returns None

autoRangeB()

Automatically adjusts the zoom level of channel B to the maximum value in the data.

The function sets a sentinel for zoom changes, checks if there are any data points in channel B, and if so, finds the maximum value. It then calls the changeZoomMax function to adjust the zoom accordingly.

Returns None

`autoRangeC()`

Automatically adjusts the zoom level of channel C to the maximum value in the data.

The function sets a sentinel for zoom changes, checks if there are any data points in channel C, and if so, finds the maximum value. It then calls the changeZoomMax function to adjust the zoom accordingly.

Returns None

`autoRangeD()`

Automatically adjusts the zoom level of channel D to the maximum value in the data.

The function sets a sentinel for zoom changes, checks if there are any data points in channel D, and if so, finds the maximum value. It then calls the changeZoomMax function to adjust the zoom accordingly.

Returns None

`changeColorThread(color)`

`changeStatusColor(color)`

Changes the color of the status point in the status bar based on the input value.

This method updates the status point's color by drawing a filled circle with the specified color. The mapping of numerical values to colors is as follows: - 0: Gray - 1: Green - 2: Yellow - 3: Orange

Parameters `color` – A numerical value representing the desired color (int). 0 for gray, 1 for green, 2 for yellow, 3 for orange.

Returns None

`changeStatusThread(newText)`

Updates the text displayed in the status bar.

This method sets the status value text to the specified new text, reflecting the current status or information relevant to the user.

Parameters `newText` – The text to display in the status bar (str).

Returns None

`changeZoomMax(newMaxValue, channel)`

Automatically adjusts the zoom level of the plot to the maximum value found.

The function sets the x-axis range of the specified channel's plot to [0, newMaxValue]. It considers whether measurements have been taken and limits the zoom change based on the sentinel zoom change counters.

Parameters

- `newMaxValue` – The new maximum value for the zoom range (float).
- `channel` – The channel to which the zoom change applies (str). Expected values are 'A', 'B', 'C', or 'D'.

Returns None

`clear_a()`

Clears the lists containing measured data for channel A by resetting them to empty lists.

Returns None

`clear_b()`

Clears the lists containing measured data for channel B by resetting them to empty lists.

Returns None

`clear_c()`

Clears the lists containing measured data for channel C by resetting them to empty lists.

Returns None

`clear_d()`

Clears the lists containing measured data for channel D by resetting them to empty lists.

Returns None

`createDialog()`

Creates a dialog box to notify the user when the connection with the device has been lost.

This method displays a critical error message box indicating that the connection with the device has been lost. It also stops any ongoing graphic updates, hides relevant graphics, and disables the disconnect button while enabling the connect button.

Returns None

`create_graphs()`

Creates histograms and plots for the selected channels (A, B, C, D) and arranges them on the GUI.

This function initializes the graphical components and assigns the appropriate properties to the plots based on the selected channels. It also manages the layout of the graphs, resizing them according to the number of selected channels (1, 2, 3, or 4). After setting up the graphical components, the function starts a worker thread that handles the measurement process in parallel with the GUI thread, ensuring the UI remains responsive.

Returns None

`dialogChangeMode(channel)`

Opens a dialog box to ask the user if they want to change the mode for the selected channel.

The dialog informs the user that the collected data for the specified channel falls mostly outside the reliable range of mode 1 and prompts them to switch to mode 2. If the user confirms, the function updates the mode and processes the data accordingly.

Parameters `channel` – The channel for which to change the mode (str). Expected values are 'channel A', 'channel B', 'channel C', or 'channel D'.

Returns None

`disconnectedDevice()`

Disables device interaction controls when the device is disconnected.

This function updates the GUI to reflect that the device is no longer connected by disabling the disconnect and start buttons and enabling the connect button.

Returns None

`hide_graphic2()`

Disables the start and stop buttons in the graphical interface.

This function is typically used to prevent user interaction during certain operations.

Returns None

`resetSaveSentinels()`

`save_graphic()`

Saves the current data according to the selected format specified in the dialog box.

The function starts by retrieving the default histogram name and the current date, which is formatted to create a unique filename. It then initializes lists to hold filenames, data, settings, and column names for the saved files.

A dialog box is displayed for the user to select the desired file format (txt, csv, or dat) for saving the data. Once the user accepts the selection, the function checks if the selected format has already been saved before.

If the selected format has not been saved, it collects data from the various channels (A, B, C, D) if their corresponding sentinel variables indicate they should be saved. It retrieves the average cycles, mode, number of stops, stop edge, and stop mask for each channel to include in the settings. The function then attempts to save the collected data in the specified format.

If the save operation is successful, a message box is displayed, confirming the successful save and showing the folder path and file names. If an error occurs during the save process, an error message box is shown.

If the selected format has already been saved, a message box is displayed with the previous save information.

Returns None

`save_plots()`

Saves the current plots in the selected image format.

This method opens a dialog for the user to select an image format (PNG, TIFF, or JPG) and saves the plots for channels A, B, C, and D if their respective flags are set to True. The plots are saved with a timestamp in the specified format in the default folder path.

Returns None

`show_graphic(`*device_new*`)`

Sets the device and its channels, enabling the start button for measurement.

Parameters `device_new` – The new device to be set (DeviceType).

Returns None

`startTimerConnection()`

Starts the timer that periodically checks the device connection.

The timer runs every 500 milliseconds to monitor connectivity. This is typically called after a measurement finishes or when the application is idle.

Returns None

`start_graphic()`

Starts the graphical representation of the measurement based on the selected channels.

If no channels are selected, it prompts the user to select at least one channel before proceeding. It also disables certain buttons to prevent interaction during the measurement process.

Returns None

`stopTimerConnection()`

Stops the timer responsible for checking the device connection.

This function is typically called when a measurement begins to avoid interference during the acquisition process.

Returns None

`stop_graphic()`

Enables the functions to initiate a new measurement while disabling the buttons to clear graphs. It also updates the status bar text and color.

Returns None

threadComplete()

Handles the completion of the measurement thread by enabling the ability to switch between windows. It also calls the stop_graphic() function to update the UI accordingly.

Returns None

threadRunning(*status*)

Updates the thread creation status.

This method sets the threadCreatedSentinel attribute to indicate whether a thread has been created based on the provided status value.

Parameters **status** – The status indicating whether a thread has been created (int). Use 0 to indicate that the thread has been created, and 1 to indicate that it has not.

Returns None

updateBashDataPure(*valuesPureA*, *valuesPureB*, *valuesPureC*, *valuesPureD*)

updateBashSignal(*valueListA*, *valueListB*, *valueListC*, *valueListD*)

updateDataPure(*value*, *channel*)

Updates the raw data values for the specified channel.

This method appends the new raw value (in picoseconds) to the list of data for the specified channel (A, B, C, or D).

Parameters

- **value** – The raw data value to append to the data list (float or int). This value is in picoseconds.
- **channel** – The channel identifier for which the value is to be updated (str). Accepted values are "A", "B", "C", and "D".

Returns None

updateSignal(*value*, *channel*)

Updates the normalized data values for the specified channel and refreshes the corresponding histogram.

This method appends the new value to the list of normalized data for the specified channel (A, B, C, or D) and calls the update_histogram method to refresh the histogram with the updated data.

Parameters

- **value** – The normalized value to append to the data list (float or int).
- **channel** – The channel identifier for which the value is to be updated (str). Accepted values are "A", "B", "C", and "D".

Returns None

update_histogram(*data*, *curve*, *indexChannel*)

Calculates and updates the histogram for the specified channel based on the measured data.

The function first checks the selected channel (A, B, C, or D) and retrieves the current view range from the corresponding view box. It then creates bins for the histogram based on this range, using a total of 61 bins.

Finally, it computes the histogram of the provided data and updates the specified curve in the plot with the histogram values.

Parameters

- **data** – The measured data used to calculate the histogram (list).

- **curve** – The curve item from the plot in PyQt5 with PyQtGraph that corresponds to the channel (PlotCurveItem).
- **indexChannel** – The identifier of the channel for the histogram, which can be "A", "B", "C", or "D" (str).

Returns None

`zoom_changedA()`

Automatically calculates and updates the histogram for channel A when the user zooms in on the corresponding graph.

The function checks if the zoom was triggered by code or user action. If it was triggered by the user, it increments the sentinel for zoom changes. It then retrieves the current x-range from the view box for channel A and computes the bin width for the histogram.

Next, it creates 61 bins based on the x-range and calculates the histogram using the measured data. The histogram data is then used to update the curve item for channel A in the plot.

Param None

Returns None

`zoom_changedB()`

Automatically calculates and updates the histogram for channel B when the user zooms in on the corresponding graph.

The function checks if the zoom was triggered by code or user action. If it was triggered by the user, it increments the sentinel for zoom changes. It then retrieves the current x-range from the view box for channel B and computes the bin width for the histogram.

Next, it creates 61 bins based on the x-range and calculates the histogram using the measured data. The histogram data is then used to update the curve item for channel B in the plot.

Param None

Returns None

`zoom_changedC()`

Automatically calculates and updates the histogram for channel C when the user zooms in on the corresponding graph.

The function checks if the zoom was triggered by code or user action. If it was triggered by the user, it increments the sentinel for zoom changes. It then retrieves the current x-range from the view box for channel C and computes the bin width for the histogram.

Next, it creates 61 bins based on the x-range and calculates the histogram using the measured data. The histogram data is then used to update the curve item for channel C in the plot.

Param None

Returns None

`zoom_changedD()`

Automatically calculates and updates the histogram for channel D when the user zooms in on the corresponding graph.

The function checks if the zoom was triggered by code or user action. If it was triggered by the user, it increments the sentinel for zoom changes. It then retrieves the current x-range from the view box for channel D and computes the bin width for the histogram.

Next, it creates 61 bins based on the x-range and calculates the histogram using the measured data. The histogram data is then used to update the curve item for channel D in the plot.

Param None

Returns None

CHAPTER

TWO

LIFETIMELOGIC MODULE

class Logic.LifeTimeLogic.**LifeTimeLogic**(*comboBoxStartChannel: PySide2.QtWidgets.QComboBox*, *comboBoxStopChannel: PySide2.QtWidgets.QComboBox*, *graphicFrame: PySide2.QtWidgets.QFrame*, *startButton: PySide2.QtWidgets.QPushButton*, *stopButton: PySide2.QtWidgets.QPushButton*, *initialParametersButton: PySide2.QtWidgets.QPushButton*, *clearButton: PySide2.QtWidgets.QPushButton*, *saveDataButton: PySide2.QtWidgets.QPushButton*, *savePlotButton: PySide2.QtWidgets.QPushButton*, *statusLabel: PySide2.QtWidgets.QLabel*, *pointLabel: PySide2.QtWidgets.QLabel*, *binWidthComboBox: PySide2.QtWidgets.QComboBox*, *numberBins: PySide2.QtWidgets.QComboBox*, *functionComboBox: PySide2.QtWidgets.QComboBox*, *numberMeasurementsSpinBox: PySide2.QtWidgets.QSpinBox*, *totalMeasurements: PySide2.QtWidgets.QLabel*, *totalStart: PySide2.QtWidgets.QLabel*, *totalTime: PySide2.QtWidgets.QLabel*, *timeRange: PySide2.QtWidgets.QLabel*, *device*, *applyButton: PySide2.QtWidgets.QPushButton*, *parameterTable: PySide2.QtWidgets.QTableWidget*, *MainWindow*, *timerConnection: PySide2.QtCore.QTimer*)

Bases: `object`

Class responsible for the logic and functionality of the LifeTime (Fluorescence Lifetime Measurement) window.

This class manages the creation and updating of graphical plots related to LifeTime, controls user interactions with various buttons, and ensures that measurements are taken from the specified channels. The class handles: - Initialization of the graphical interface elements. - Starting and stopping of measurements. - Saving of data and plots. - Displaying parameters of the measurements, such as the number of measurements taken, and the percentage of completion.

Parameters

- **comboBoxStartChannel** – The combo box for selecting the start channel (QComboBox).
- **comboBoxStopChannel** – The combo box for selecting the stop channel (QComboBox).
- **graphicFrame** – The frame that holds the graphical plot (QFrame).
- **startButton** – The button to start the measurements (QPushButton).
- **stopButton** – The button to stop the measurements (QPushButton).
- **initialParametersButton** – The button to configure initial parameters (QPushButton).

- **clearButton** – The button to clear the graphs and data (QPushButton).
- **saveDataButton** – The button to save the measurement data (QPushButton).
- **savePlotButton** – The button to save the graph plot (QPushButton).
- **statusLabel** – The label showing the current status (QLabel).
- **pointLabel** – The label displaying the current point in the measurement (QLabel).
- **binWidthComboBox** – The combo box for selecting the bin width (QComboBox).
- **numberBins** – The combo box for selecting the number of bins (QComboBox).
- **functionComboBox** – The combo box for selecting a function (QComboBox).
- **numberMeasurementsSpinBox** – The spin box for specifying the number of measurements (QSpinBox).
- **totalMeasurements** – The label showing the total number of measurements (QLabel).
- **totalStart** – The label showing the number of measurements taken from the start channel (QLabel).
- **totalTime** – The label showing the total time of measurements (QLabel).
- **timeRange** – The label showing the time range for the measurements (QLabel).
- **device** – The connected Tempico device used for measurements.
- **applyButton** – The button for applying selected parameters (QPushButton).
- **parameterTable** – The table displaying the parameters of the measurements (QTableWidget).
- **MainWindow** – The main window that holds the application UI elements.
- **timerStatus** – The timer used for periodic updates (QTimer).

Returns None

`applyAction()`

Captures the action of the 'apply' button, calculates the selected fit, and stores the resulting parameters.

This function determines which fitting function is selected from *functionComboBox* and attempts to calculate the fit using the measured time and data. If the parameters can be determined, they are stored in *FitParameters*. If not, a dialog informs the user that the parameters could not be determined.

Variables assignment: - The parameters *i0*, *tau0*, and other fit-specific variables are calculated using the corresponding fit function. - If the fit is successful, the rounded parameters are stored in *FitParameters*. - If the fit fails or returns "Undefined", a message box is shown to inform the user of the error.

Returns None

`applyInitialDialog()`

Updates the initial parameters based on user input from the parameter dialog.

This function is called when the user clicks the "Apply" button in the parameter dialog. It retrieves the values from the input fields corresponding to the selected fitting function and assigns them to the appropriate instance variables.

The following parameters are updated based on the selected fit type: - For Exponential fit: - I0 (initial value) - tau0 (decay constant) - For Kohlrausch fit: - I0 (initial value) - tau0 (decay constant) - beta (exponent) - For Shifted Exponential fit: - I0 (initial value) - tau0 (decay constant) - alpha (shift parameter) - b (baseline value) - For Double Exponential fit: - I0 (initial value) - tau0 (first decay constant) - tau1 (second decay constant) - alpha (mixing coefficient)

Variables assignment: - The updated values are assigned to their respective initial parameter variables. - A boolean flag indicating that initial parameters have changed is set to True for the relevant fit type.

Returns None

`calculateR2`(*data*, *fitData*)

Calculates the R^2 value based on the observed and fitted data.

Parameters

- `data` – The observed data points (array-like).
- `fitData` – The fitted data points (array-like).

Returns The R^2 value indicating the goodness of fit (float).

`changeCreatedStatus`()

Notifies that the measurement thread has been created.

This function sets the status of thread creation to True.

Returns None

`changeFunction`()

Updates the parameter values in the UI based on the selected function in the functionComboBox.

This function checks the current fitting function (e.g., "ExpDecay", "Kohlrausch", "ShiftedExponential", or "DoubleExponential") and updates the parameter labels accordingly. If the parameters have already been calculated, it will display the values along with their uncertainties and units. If the parameters are not available, it sets the values to "Undefined".

Variables assignment: - Parameters like "I0", "tau0", "Beta", "alpha", "b", "R^2", and their respective uncertainties are assigned using *insertParameters()* based on the fitting model. - Units are assigned through the *self.units* attribute for certain parameters (e.g., tau0).

Behavior by function: - ExpDecay: Updates *I0*, *tau0*, and *R^2*. - Kohlrausch: Updates *I0*, *tau0*, *Beta*, and *R^2*. - ShiftedExponential: Updates *I0*, *tau0*, *alpha*, *b*, and *R^2*. - DoubleExponential: Updates *I0*, *tau0*, *tau1*, *alpha*, and *R^2*.

Returns None

`changeStatusColor`(*color*)

Changes the color of the point in the status bar. Each color is assigned a specific numeric value.

Parameters `color` – The numeric value corresponding to the desired color (int). - 0: Gray - 1: Green - 2: Yellow - 3: Orange

Returns None

`changeStatusLabel`(*textValue*)

Changes the text of the status label.

Parameters `textValue` – The text to set for the status label (str).

Returns None

`checkDeviceStatus`()

Verifies the device's operational status by attempting to read its identification.

This function performs the following actions: - Attempts to read the identification from the device to ensure it is functioning correctly. - If the read operation fails, it stops any running worker thread and disconnects the device from the serial port. - Displays an error message indicating that the connection with the device has been lost.

Returns None

clearGraphic()

Clears the measured data and time lists when a measurement is in progress and also clears the graphic by executing the worker's clear function.

Returns None

connectedDevice(*device*)

Configures the UI options when the Tempico device is connected.

This function enables and disables the appropriate buttons and starts the timer to monitor the device status. - Enables the disconnect button and disables the connect button. - Starts a status timer with a 500 ms interval. - Assigns the connected device to the class attribute and enables the start button.

Parameters **device** – The connected Tempico device.

Returns None

disconnectedDevice()

Configures the UI options when the Tempico device is disconnected.

This function disables and enables the appropriate buttons and stops the timer that monitors the device status. - Disables the disconnect button and enables the connect button. - Stops the status timer. - Disables the start button.

Returns None

double_Exponential(*t*, *I0*, *tau0*, *tau1*, *alpha*)

Computes the value of a double exponential decay function.

This function calculates the value of a double exponential decay function using the given parameters: time *t*, initial value *I0*, decay constants *tau0* and *tau1*, and mixing parameter *alpha*.

Variables assignment: - The computed value is returned directly and not assigned to any variable within the function.

Parameters

- **t** – The time at which to evaluate the function (float).
- **I0** – The initial value of the exponential function (float).
- **tau0** – The first decay constant (float).
- **tau1** – The second decay constant (float).
- **alpha** – The mixing parameter that determines the contribution of the first decay (float).

Returns The value of the double exponential decay function at time *t*.

Return type float

enableAfterFinisihThread()

Executes when a measurement ends, either by pressing the stop button or when it has naturally finished. Re-enables the buttons, combo boxes, and fields necessary for a new measurement or for saving data. Resets the default parameters for the settings.

Returns None

exp_decay(*t*, *I0*, *tau0*)

Computes the value of an exponential decay function.

This function calculates the value of the exponential decay function using the given parameters for time *t*, initial value *I0*, and decay constant *tau0*.

Variables assignment: - The computed value is returned directly and not assigned to any variable within the function.

Parameters

- **t** – The time at which to evaluate the function (float).
- **I0** – The initial value of the exponential function (float).
- **tau0** – The decay constant (float).

Returns The value of the exponential decay function at time *t*.

Return type float

finishedThreadMeasurement()

Executes when the measurement thread finishes.

This function enables the UI components related to new measurements and resets the settings to default.

Returns None

fitDoubleExponential(*xData*, *yData*)

Fits a double exponential decay model to the provided data.

This function fits a double exponential decay model to the given *xData* and *yData* using the initial guesses for the parameters (I0, tau0, tau1, alpha). If the fit is successful, it updates the corresponding values for each parameter and plots the fitted curve. If the fit fails, a warning message is displayed to the user.

Variables assignment: - *self.FitCov*: Stores the covariance values for I0, tau0, tau1, and alpha, or "nan" if not calculable. - *self.xDataFitCopy*: Stores a copy of the *xData* for the fitted curve. - *self.yDataFitCopy*: Stores the computed y-values for the fitted curve. - *self.R2*: Stores the calculated R^2 value for the fit. - *self.curveFit*: Updates the plot with the fitted curve data.

Parameters

- **xData** – The x-axis data points (array-like).
- **yData** – The y-axis data points (array-like).

Returns Tuple (I0_opt, tau0_opt, tau1_opt, alpha_opt) containing the fitted values of I0, tau0, tau1, and alpha, or ("Undefined", "Undefined", "Undefined", "Undefined") if fitting fails.

Return type tuple(float, float, float, float) or tuple(str, str, str, str)

fitExpDecay(*xData*, *yData*)

Calculates the exponential decay fit for the given data.

This function attempts to fit an exponential decay model to the provided *xData* and *yData*. If successful, the optimal parameters (I0, tau0) are used to update the respective labels in the parameters table along with their uncertainties (covariance), and the fitted curve is plotted. If the fit cannot be performed, it alerts the user via a message box.

Variables assignment: - *self.FitCov*: Contains the covariance values for I0 and tau0, or "nan" if not calculable. - *self.xDataFitCopy*: Stores a copy of the *xData* for the fitted curve. - *self.yDataFitCopy*: Stores the computed y-values for the fitted curve. - *self.R2*: Stores the calculated R^2 value for the fit. - *self.curveFit*: Updates the plot with the fitted curve data.

Parameters

- **xData** – The x-axis data points (array-like).
- **yData** – The y-axis data points (array-like).

Returns Tuple (I0_opt, tau0_opt) containing the fitted values of I0 and tau0, or ("Undefined", "Undefined") if fitting fails.

Return type tuple(float, float) or tuple(str, str)

fitKohlrauschFit(*xData*, *yData*)

Calculates the Kohlrausch fit for the given data.

This function attempts to fit a Kohlrausch (stretched exponential) model to the provided *xData* and *yData*. If successful, the optimal parameters (I0, tau0, Beta) are used to update the respective labels in the parameters table along with their uncertainties (covariance), and the fitted curve is plotted. If the fit cannot be performed, it alerts the user via a message box.

Variables assignment: - *self.FitCov*: Contains the covariance values for I0, tau0, and Beta, or "nan" if not calculable. - *self.xDataFitCopy*: Stores a copy of the *xData* for the fitted curve. - *self.yDataFitCopy*: Stores the computed y-values for the fitted curve. - *self.R2*: Stores the calculated R^2 value for the fit. - *self.curveFit*: Updates the plot with the fitted curve data.

Parameters

- **xData** – The x-axis data points (array-like).
- **yData** – The y-axis data points (array-like).

Returns Tuple (I0_opt, tau0_opt, beta_opt) containing the fitted values of I0, tau0, and Beta, or ("Undefined", "Undefined", "Undefined") if fitting fails.

Return type tuple(float, float, float) or tuple(str, str, str)

fitShiiftedExponential(*xData*, *yData*)

Fits a shifted exponential decay model to the provided data.

This function fits a shifted exponential decay model to the given *xData* and *yData* using the initial guesses for the parameters (I0, tau0, alpha, b). If the fit is successful, it updates the corresponding values for each parameter and plots the fitted curve. If the fit fails, a warning message is displayed to the user.

Variables assignment: - *self.FitCov*: Stores the covariance values for I0, tau0, alpha, and b, or "nan" if not calculable. - *self.xDataFitCopy*: Stores a copy of the *xData* for the fitted curve. - *self.yDataFitCopy*: Stores the computed y-values for the fitted curve. - *self.R2*: Stores the calculated R^2 value for the fit. - *self.curveFit*: Updates the plot with the fitted curve data.

Parameters

- **xData** – The x-axis data points (array-like).
- **yData** – The y-axis data points (array-like).

Returns Tuple (I0_opt, tau0_opt, alpha_opt, b_opt) containing the fitted values of I0, tau0, alpha, and b, or ("Undefined", "Undefined", "Undefined", "Undefined") if fitting fails.

Return type tuple(float, float, float, float) or tuple(str, str, str, str)

getTempicoChannel()

Assigns the Tempico device channels based on the selected values from the combo boxes. The selected start and stop channels are assigned to the variables *currentStartChannel* and *currentStopChannel*, respectively. It also enables the corresponding channels.

Returns None

getUnits(*value*)

Receives a numerical value in picoseconds (ps) and returns a list with two values: the appropriate units for the value and a number indicating by how much to divide the value for conversion.

Parameters **value** – The numerical value in picoseconds to convert.

Returns A list containing the appropriate unit as a string and a number indicating the divisor for conversion.

`indexChangeStartChannel()`

Verifies that the options of the start and stop combo boxes are not the same when the start combo box is changed. If they are the same, it reverts to the previously selected option.

Returns None

`indexChangeStopChannel()`

Verifies that the options of the start and stop combo boxes are not the same when the stop combo box is changed. If they are the same, it reverts to the previously selected option.

Returns None

`initialParametersDialog()`

Displays a dialog for selecting initial parameters for fitting functions.

This dialog allows the user to select a type of fitting function and input the corresponding parameters. The parameters that can be set include: - I0 (initial value) - tau0 (decay constant) - beta (for Kohlrausch fit) - alpha (for Shifted Exponential fit) - b (for Shifted Exponential fit)

The dialog contains a ComboBox to select the function type, and the input fields dynamically update based on the selected function. It includes "Apply" and "Reset" buttons to apply changes or revert to default values.

Variables assignment: - The input values from the dialog are assigned to respective attributes, but are not directly returned.

Returns None

`insertParameters(`*index*, *Parameter*, *Value*, *Cov*, *Units*`)`

Inserts the parameter values into the fitting table at the specified row.

This function updates the table used for displaying the fitted parameters by inserting the parameter name, its value, the covariance (uncertainty), and the units in the specified row of the table.

Variables assignment: - The parameter name is assigned to the first column of the specified row (*index*). - The value of the parameter is assigned to the second column. - The covariance of the parameter is assigned to the third column. - The units of the parameter are assigned to the fourth column.

Parameters

- **`index`** – The row index where the values will be inserted (int).
- **`Parameter`** – The name of the parameter to be displayed (str).
- **`Value`** – The value of the parameter to be displayed (str).
- **`Cov`** – The covariance (uncertainty) of the parameter (str).
- **`Units`** – The units of the parameter (str).

Returns None

`kohl_decay(`*t*, *I0*, *tau0*, *beta*`)`

Computes the value of a Kohlrausch (stretched exponential) decay function.

This function calculates the value of the stretched exponential (Kohlrausch) decay function using the given parameters: time *t*, initial value *I0*, decay constant *tau0*, and stretching parameter *beta*.

Variables assignment: - The computed value is returned directly and not assigned to any variable within the function.

Parameters

- **`t`** – The time at which to evaluate the function (float).
- **`I0`** – The initial value of the exponential function (float).

- **tau0** – The decay constant (float).
- **beta** – The stretching exponent, controlling the deviation from a simple exponential decay (float).

Returns The value of the stretched exponential decay function at time *t*.

Return type float

`lostConnection()`

`maxRound(string)`

Determines the number of decimal places needed for at least three significant figures.

Parameters **string** – The number as a string (str).

Returns Number of decimal places (int).

`resetInitialDialog()`

Resets the initial parameters in the dialog based on the measured data.

This function is called when the user clicks the "Default Values" button in the parameter dialog. It resets the initial parameters to sensible defaults derived from the measured data. The following resets occur based on the selected fitting function:

- **For Exponential fit:**
  - I0 is set to the maximum value of measured data.
  - tau0 is set to the mean of measured time.
- **For Kohlrausch fit:**
  - I0 is set to the maximum value of measured data.
  - tau0 is set to the mean of measured time.
  - beta is set to 1.0 (default value).
- **For Shifted Exponential fit:**
  - I0 is set to the maximum value of measured data.
  - tau0 is set to the mean of measured time.
  - alpha is set to 0 (default value).
  - b is set to 0 (default value).
- **For Double Exponential fit:**
  - I0 is set to the maximum value of measured data.
  - tau0 is set to the mean of measured time.
  - alpha is set to 0 (default value).
  - tau1 is set to the mean of measured time.

The corresponding input fields in the dialog are updated with these new values. Flags indicating that the initial parameters have not changed are also reset to False for the relevant fit type.

Returns None

`resetParametersLabels()`

Resets all the fit parameters to 'Undefined' and clears the current fit type.

This function sets the list *FitParameters* to contain "Undefined" values for all parameters and clears *currentFit*. Additionally, it resets the *R2* value to "Undefined". Depending on the selected fit type in *functionComboBox*, the respective parameter labels in the table are updated to reflect "Undefined" values.

Variables assignment: - *FitParameters* is reset to a list of "Undefined". - *currentFit* is cleared to an empty string. - *R2* is reset to "Undefined". - The *insertParameters* method is used to update the table with "Undefined" values for each parameter based on the selected function in *functionComboBox*.

Returns None

`resetSaveSentinels()`

`roundStringPCov(number)`

Converts a number to a string representation in scientific notation with two decimal places.

Parameters `number` – The input number (float).

Returns String representation in scientific notation (str).

`saveLifeTimeData()`

Saves the data in the selected format (TXT, CSV, or DAT) based on the user's choice.

Returns None

`saveMode()`

Saves the current modes of the channels before starting a measurement. The modes are stored in the variables *oldChannelA*, *oldChannelB*, *oldChannelC*, and *oldChannelD*, allowing for restoration to the original settings after the measurement.

Returns None

`savePlotLifeTime()`

Saves the graph image in the specified format (PNG, TIFF, or JPG) based on the user's selection. :return: None

`setOldMode()`

Restores the modes of the channels after a measurement is completed. The channels are set to their previous modes stored in *oldChannelA*, *oldChannelB*, *oldChannelC*, and *oldChannelD*.

Returns None

`shifted_decay_function(t, I0, tau0, alpha, b)`

Computes the value of a shifted exponential decay function.

This function calculates the value of a shifted exponential decay function using the given parameters: time *t*, initial value *I0*, decay constant *tau0*, shift parameter *alpha*, and constant offset *b*.

Variables assignment: - The computed value is returned directly and not assigned to any variable within the function.

Parameters

- `t` – The time at which to evaluate the function (float).
- `I0` – The initial value of the exponential function (float).
- `tau0` – The decay constant (float).
- `alpha` – The shift parameter, determining the horizontal shift of the decay function (float).
- `b` – The constant offset added to the decay function (float).

Returns The value of the shifted exponential decay function at time *t*.

Return type float

`startMeasurement()`

Initiates the measurement process by clearing previous data, resetting the UI, and starting a new measurement thread.

This function performs several actions to prepare for and start a new measurement: - Stops the status timer and disables/enables relevant buttons. - Clears previous graph data and resets parameter labels. - Saves the current channel modes and resets save parameters. - Updates the status label and color to indicate a running measurement. - Clears previously measured data and time, resetting the plot. - Retrieves the selected channels and initializes a new measurement thread with the selected parameters. - Connects signals from the worker thread to corresponding slots in the main thread for UI updates.

Returns None

`startTimer()`

Starts the timer that triggers the update_timer function every second.

This function initiates the timer for the ongoing measurement, allowing the update_timer function to be executed at one-second intervals.

Returns None

`startTimerConnection()`

Starts the timer to check the device connection status every 500 milliseconds.

This method initiates periodic checks to monitor if the connected device remains active and responsive. The interval is set to 500 ms.

Returns None

`stopMeasurement()`

Stops the measurement thread if it is created and executes the function enableAfterFinishedThread() if the thread is not created.

Returns None

`stopTimer()`

Stops the timer that triggers the update_timer function.

This function halts the timer responsible for updating the measurement time and sets the totalTime label to indicate that no measurement is currently running.

Returns None

`stopTimerConnection()`

Stops the timer responsible for checking the device connection status.

This method halts the periodic checks performed by *timerConnection* to avoid unnecessary polling or to pause the connection validation during inactive states.

Returns None

`timeRangeValue()`

Converts the value from the timeRange label to picoseconds (ps).

Returns float The value converted to picoseconds.

`updateLabel(units)`

Updates the label of the x-axis in the graph with the correct units for the data.

This function takes the units as a string and updates the x-axis label accordingly.

Parameters `units` – The units to be displayed on the x-axis label (str).

Returns None

updateLabels(*totalMeasurements*, *totalStarts*)

Updates the labels for total measurements and total starts with the given values.

This function sets the text of the totalMeasurements and totalStart labels according to the parameters provided.

Parameters

- **totalMeasurements** – The text to set for the total measurements label (str).
- **totalStarts** – The text to set for the total starts label (str).

Returns None

updateMeasurement(*listOfNewValues*, *domainMeasurement*)

Updates the measured data and time with new values and refreshes the graph.

This function receives a new list of values representing counts and their corresponding update times, assigning them to the variables measuredData and measuredTime, and updates the graph accordingly.

Parameters

- **listOfNewValues** – The new list of measurement values (list).
- **domainMeasurement** – The list of times corresponding to the measurement values (list).

Returns None

update_timer()

Updates the timer for the ongoing measurement by adding one second.

This function increments the time variable by one second and updates the totalTime label to reflect the new time.

Returns None

CHAPTER

THREE

TIMESTAMPLOGIC MODULE

class Logic.TimeStampLogic.**TimeStampLogic**(*enableCheckBoxA: PySide2.QtWidgets.QCheckBox*, *enableCheckBoxB: PySide2.QtWidgets.QCheckBox*, *enableCheckBoxC: PySide2.QtWidgets.QCheckBox*, *enableCheckBoxD: PySide2.QtWidgets.QCheckBox*, *startNormalButton: PySide2.QtWidgets.QPushButton*, *pauseNormalButton: PySide2.QtWidgets.QPushButton*, *stopNormalButton: PySide2.QtWidgets.QPushButton*, *startScheduleButton: PySide2.QtWidgets.QPushButton*, *pauseScheduleButton: PySide2.QtWidgets.QPushButton*, *stopScheduleButton: PySide2.QtWidgets.QPushButton*, *startLimitedButton: PySide2.QtWidgets.QPushButton*, *pauseLimitedButton: PySide2.QtWidgets.QPushButton*, *stopLimitedButton: PySide2.QtWidgets.QPushButton*, *startDate: PySide2.QtWidgets.QDateEdit*, *startTime: PySide2.QtWidgets.QTimeEdit*, *finishDate: PySide2.QtWidgets.QDateEdit*, *finishTime: PySide2.QtWidgets.QTimeEdit*, *numberMeasurementsSpinBox: PySide2.QtWidgets.QSpinBox*, *showTableCheckBox: PySide2.QtWidgets.QCheckBox*, *measurementLabelA: PySide2.QtWidgets.QLabel*, *measurementLabelB: PySide2.QtWidgets.QLabel*, *measurementLabelC: PySide2.QtWidgets.QLabel*, *measurementLabelD: PySide2.QtWidgets.QLabel*, *valueMeasurementA: PySide2.QtWidgets.QLabel*, *valueMeasurementB: PySide2.QtWidgets.QLabel*, *valueMeasurementC: PySide2.QtWidgets.QLabel*, *valueMeasurementD: PySide2.QtWidgets.QLabel*, *valueTotalMeasurement: PySide2.QtWidgets.QLabel*, *tableTimeStamp: PySide2.QtWidgets.QTableWidget*, *statusLabel: PySide2.QtWidgets.QLabel*, *colorLabel: PySide2.QtWidgets.QLabel*, *saveDataComplete: PySide2.QtWidgets.QCheckBox*, *tabNormalMeasurement: PySide2.QtWidgets.QWidget*, *tabScheduleMeasurement: PySide2.QtWidgets.QWidget*, *tabLimitedMeasurement: PySide2.QtWidgets.QWidget*, *saveDataButton: PySide2.QtWidgets.QPushButton*, *tabs: PySide2.QtWidgets.QTabWidget*, *autoSaveComboBox: PySide2.QtWidgets.QComboBox*, *helpSaveButton: PySide2.QtWidgets.QPushButton*, *parent*, *device: pyTempico.core.TempicoDevice*, *timerConnection: PySide2.QtCore.QTimer*)

Bases: object

Class responsible for managing the logic and interface of the TimeStamp measurement tab.

This class handles long-duration timestamp measurements across different operational modes, including: - **Normal** mode: Starts and stops measurements manually. - **Scheduled** mode: Automatically starts/stops measurements based on configured start and end date-times. - **Limited** mode: Runs measurements until a predefined number of events is recorded.

It provides real-time updates of the measurement status, displays results in a table, and supports manual and automatic data saving in multiple formats. It also offers visual feedback, per-channel control, and user configuration for saving behaviors.

The main responsibilities include: - Managing three measurement modes: normal, scheduled, and limited. - Displaying measurement data in a table, including per-channel and total counts. - Handling delayed start and stop based on date and time settings. - Enabling saving of data manually or automatically in *.txt*, *.csv*, and *.dat* formats. - Tracking system and measurement status through visual and textual indicators. - Controlling visibility and behavior of measurement labels and checkboxes. - Providing help dialogs and UI feedback during configuration.

Parameters

- `enableCheckBoxA` – Checkbox to enable/disable channel A (QCheckBox).
- `enableCheckBoxB` – Checkbox to enable/disable channel B (QCheckBox).
- `enableCheckBoxC` – Checkbox to enable/disable channel C (QCheckBox).
- `enableCheckBoxD` – Checkbox to enable/disable channel D (QCheckBox).
- `startNormalButton` – Button to start normal measurement mode (QPushButton).
- `pauseNormalButton` – Button to pause normal measurement mode (QPushButton).
- `stopNormalButton` – Button to stop normal measurement mode (QPushButton).
- `startScheduleButton` – Button to start scheduled measurement mode (QPushButton).
- `pauseScheduleButton` – Button to pause scheduled measurement mode (QPushButton).
- `stopScheduleButton` – Button to stop scheduled measurement mode (QPushButton).
- `startLimitedButton` – Button to start limited measurement mode (QPushButton).
- `pauseLimitedButton` – Button to pause limited measurement mode (QPushButton).
- `stopLimitedButton` – Button to stop limited measurement mode (QPushButton).
- `startDate` – Date selector for scheduled start date (QDateEdit).
- `startTime` – Time selector for scheduled start time (QTimeEdit).
- `finishDate` – Date selector for scheduled end date (QDateEdit).
- `finishTime` – Time selector for scheduled end time (QTimeEdit).
- `numberMeasurementsSpinBox` – Spin box to configure number of measurements in limited mode (QSpinBox).
- `showTableCheckBox` – Checkbox to show/hide the measurement table (QCheckBox).
- `measurementLabelA` – Label title for channel A measurement (QLabel).
- `measurementLabelB` – Label title for channel B measurement (QLabel).
- `measurementLabelC` – Label title for channel C measurement (QLabel).
- `measurementLabelD` – Label title for channel D measurement (QLabel).
- `valueMeasurementA` – Label showing count value for channel A (QLabel).

- **valueMeasurementB** – Label showing count value for channel B (QLabel).
- **valueMeasurementC** – Label showing count value for channel C (QLabel).
- **valueMeasurementD** – Label showing count value for channel D (QLabel).
- **valueTotalMeasurement** – Label showing total count value (QLabel).
- **tableTimeStamp** – Table displaying recorded timestamp data (QTableWidget).
- **statusLabel** – Label showing current system status (QLabel).
- **colorLabel** – Color-coded label to indicate measurement state (QLabel).
- **saveDataComplete** – Checkbox to toggle full data saving after measurement (QCheckBox).
- **tabNormalMeasurement** – Tab widget for normal measurement UI (QWidget).
- **tabScheduleMeasurement** – Tab widget for scheduled measurement UI (QWidget).
- **tabLimitedMeasurement** – Tab widget for limited measurement UI (QWidget).
- **saveDataButton** – Button to manually save timestamp data (QPushButton).
- **tabs** – Main tab widget that hosts all measurement tabs (QTabWidget).
- **autoSaveComboBox** – Combo box to select preferred format for automatic saving (QComboBox).
- **helpSaveButton** – Button to show help dialog for save options (QPushButton).
- **parent** – The parent UI element containing this tab (usually QMainWindow).
- **device** – The connected TempicoDevice used for timestamp acquisition.
- **timerConnection** – Timer object for device connection polling (QTimer).

Returns None

`autoSaveAction()`

Performs periodic autosave during a measurement.

This function is triggered automatically at regular intervals while a measurement is running. It saves the current batch of measurement data to a file using the predefined autosave format, then clears the saved data from memory to free resources.

Returns None

`autoSaveActionRoute()`

Performs the final autosave when a measurement ends.

This function is executed as the last step of a measurement when either the user stops it manually or the scheduled time finishes. It saves all remaining measurement data to a file using the selected autosave format (*txt*, *csv*, or *dat*), clears the in-memory data lists, and updates the corresponding flags indicating that the data has been saved.

Returns None

`autoSaveSettings(currentTab)`

Configures and starts the autosave timer based on the user's interval selection.

If not in the "Scheduled" tab, prompts the user to select the save format.

`beginMeasurementTime()`

Starts the scheduled timestamp measurement when the countdown timer reaches zero.

This function is automatically called after the waiting period in a scheduled measurement. It performs the following actions: - Clears previous data and resets internal sentinels. - Sets up pre-measurement values

and stops the device connection timer. - Applies auto-save settings and generates the file name if needed. - Initializes the measurement worker thread in "scheduled" mode. - Starts a timer to monitor when the measurement should stop automatically. - Updates the UI to reflect that the measurement is now running.

Returns None

`captureMeasurement`(*valuesA*, *valuesB*, *valuesC*, *valuesD*, *valuesStart*, *totalMeasurementsChannelA*, *totalMeasurementsChannelB*, *totalMeasurementsChannelC*, *totalMeasurementsChannelD*, *totalMeasurements*)

Inserts new measurement data into the table, updates the internal data structures, and refreshes channel/total measurement labels.

Called when the worker thread emits new measurement values for each channel.

- Adds rows for each measurement (A, B, C, D, and Start events) at the top of the table.
- Stores timestamps, stop values, and channel IDs in internal lists.
- Limits table size to 50,000 rows.
- Updates labels showing total measurements per channel and overall.

`changeLabelToUpdate`(*textValue*)

Updates the status label or measurement status value depending on the reordering state.

If not currently reordering, updates *statusValueMeasurements*. If reordering, updates the *statusLabel* text directly.

Parameters **textValue** (*str*) – The text to display.

Returns None

`changeStatusColor`(*color*)

Changes the color of the point in the status bar. Each color is assigned a specific numeric value.

Parameters **color** – The numeric value corresponding to the desired color (int). - 0: Gray - 1: Green - 2: Yellow - 3: Orange

Returns None

`changeStatusLabel`(*textValue*)

Updates the status label text unless a save operation is in progress.

If a save is occurring, the label is set to "Saving Data" instead.

Parameters **textValue** (*str*) – The text to display if not currently saving.

Returns None

`checkBoxSaveData`()

Handles the behavior of the "Save Data" checkbox for enabling or disabling auto-save options. Includes a confirmation dialog when disabling auto-save.

`checkBoxSaveDataAfterMeasurement`()

Handles the behavior of the "Save Data" checkbox for enabling or disabling auto-save options. Includes a confirmation dialog when disabling auto-save.

`clearData`()

Clears all data and resets save-related sentinels from the previous measurement.

This includes: - Resetting autosave and manual save flags. - Clearing stored measurement data and timestamps. - Resetting the display table. - Clearing internal autosave buffer via *savefile*.

Returns None

`connectedDevice`(*device*)

Handles UI and internal state updates when the device is connected in the TimeStamp logic tab.

This function performs the following actions: - Enables the disconnect button and disables the connect button in the main window. - Updates the internal sentinel to indicate the device is now connected. - Stores the reference to the connected device instance. - Enables the start buttons for normal, scheduled, and limited measurement modes.

Parameters `device` – The connected device instance.

Returns None

`countToBegin`()

Updates the countdown status before the scheduled measurement begins.

This function is called periodically by a QTimer during the waiting period before a scheduled measurement starts. It performs the following actions: - Calculates the remaining time until the scheduled start. - If time is still remaining: - Updates the status label and color with a formatted countdown. - If the start time has been reached or passed: - Stops the timer. - Calls the function to begin the actual measurement (*beginMeasurementTime*).

Returns None

`countToStop`()

Updates the countdown status until the scheduled measurement ends.

This function is called periodically by a QTimer during an active scheduled measurement. It performs the following actions: - Calculates the remaining time until the configured end time. - If time is still remaining: - Updates the status label with the current measurement state and formatted time. - If the end time has been reached or passed: - Automatically stops the scheduled measurement by calling *stopScheduledMeasurement()*.

Returns None

`dialogFormatStart`(*currentTab*)

Displays a dialog for selecting the file format when autosave is enabled.

This function is called at the start of a measurement to let the user choose the file format (*txt*, *csv*, or *dat*) for automatic data saving. If the user accepts, the selection is stored and measurement continues. If the user cancels, the measurement is stopped according to the current tab (*Normal*, *Scheduled*, or *Limited*) and common post-measurement settings are restored.

Parameters `currentTab` (*str*) – The tab where the measurement was started ("Normal", "Scheduled", or "Limited").

`dialogHelpSaveButton`()

Opens a help dialog explaining how autosave works.

Returns None

`dialogToShowSave`()

Displays a confirmation dialog for a successful save operation.

This function shows an information dialog indicating that the files have been saved successfully. It includes the save folder path and the generated file name based on the measurement start date and selected format.

Returns None

`disconnectedDevice`()

Handles UI and internal state updates when the device is disconnected.

This function performs the following actions: - Resets the internal sentinel indicating whether data is currently being saved. - Updates the status label and color to reflect that no measurement is running. - Disables

the disconnect button and enables the connect button in the main window. - Disables the start buttons for normal, scheduled, and limited measurement modes.

Returns None

`fileNameAutoSave()`

Generates and stores the autosave file name.

This function builds the complete file path for the autosave operation based on the save folder, file prefix, measurement start date, and selected file format. The resulting path is stored in the *fileName* class attribute for later use.

Returns None

`finalMessageAfterSave()`

Displays a confirmation dialog indicating that the file was saved successfully.

This function shows an information message box with the final save message (*self.saveFinalText*), informing the user of the file's location and name.

Returns None

`finishedMeasurements()`

`finishedThread()`

Handles post-measurement actions after the normal measurement thread finishes.

If autosave is enabled, prompts the user to save. Then resets saving state and stops the normal measurement.

`finishedThreadLimited()`

`finishedThreadSchedule()`

`formatWaitingTime(secondsTotal)`

Formats a time duration (in seconds) into a human-readable string for countdown display.

This function is used to show the remaining time before a scheduled measurement starts or ends. The format adapts depending on the total duration: - If more than one day: *"Xd HH:MM:SS"* - If more than one hour: *"H:MM:SS"* - If less than one hour: *"M:SS"*

Parameters `secondsTotal` – Total time in seconds to format.

Returns A formatted string representing the remaining time.

Return type str

`getAproxTotalData(availableRamMb)`

`getAvailableRam()`

`notSelectedFormatLimitedStop()`

Cancels the limited measurement setup when no save format is selected while auto-save is enabled.

This function is triggered when the user initiates a limited measurement with auto-save enabled but closes the format selection dialog without choosing a file format.

It performs the following actions: - Aborts the measurement setup and resets saving state. - Updates the status label and color to indicate no measurement is running. - Re-enables the start button and disables pause/stop controls. - Re-enables the measurement count spinbox. - Restores tab access for the local interface and main window. - Resumes the device connection timer.

Returns None

`notSelectedFormatNormalStop()`

Cancels the normal measurement initialization when no save format is selected while auto-save is enabled.

This function is triggered when the user attempts to start a normal measurement with auto-save enabled but closes the format selection dialog without choosing any format (e.g., pressing the X).

It performs the following actions: - Stops any saving process and resets saving state. - Updates UI labels and colors to indicate no measurement is running. - Re-enables the start button and disables pause/stop buttons. - Re-enables all measurement tabs and resumes connection monitoring. - Restores main window tab interactivity.

Returns None

`notSelectedFormatScheduledStop()`

Cancels the scheduled measurement setup when no save format is selected while auto-save is enabled.

This function is triggered when the user attempts to start a scheduled measurement with auto-save enabled but closes the format selection dialog without choosing a format (e.g., presses the close [X] button).

It performs the following actions: - Stops any saving operation and resets saving state. - Updates UI status and color to indicate no measurement is running. - Re-enables the start button and disables pause/stop buttons. - Restores tab interactivity for other measurement modes and the main window. - Resumes the timer for monitoring device connection.

Returns None

`onAutoSaveIntervalChanged()`

Warns the user if they change the auto-save interval from index 0 to any other value.

`pauseLimitedMeasurement()`

Toggles the pause/resume state of a limited measurement based on number of events.

This function allows the user to temporarily pause or resume a limited measurement in progress. It communicates with the background worker thread to suspend or resume data acquisition accordingly.

The function performs the following actions: - If the current button text is “Pause”: - Sends a pause signal to the worker thread. - Updates the button text to “Continue”. - If the current button text is “Continue”: - Temporarily disables the button to avoid duplicate clicks. - Sends a resume signal to the worker thread. - Updates the button text back to “Pause” and re-enables it.

Returns None

`pauseNormalMeasurement()`

Toggles the pause/resume state of a normal measurement.

This function allows the user to pause and later resume an ongoing normal measurement. It interacts with the background worker thread to suspend or resume data acquisition accordingly.

The function performs the following actions: - If the current state is “Pause acquisition”: - Sends a signal to the worker thread to pause the measurement. - Updates the button text to “Continue acquisition”. - If the current state is “Continue acquisition”: - Temporarily disables the button to avoid duplicate clicks. - Sends a signal to the worker thread to resume the measurement. - Restores the button text to “Pause acquisition” and re-enables it.

Returns None

`pauseScheduledMeasurement()`

Toggles the pause/resume state of a scheduled measurement.

This function allows the user to pause or resume an ongoing scheduled measurement. It communicates with the background worker thread to suspend or resume the acquisition process.

The function performs the following actions: - If the current button text is “Pause”: - Sends a pause signal to the worker thread. - Updates the button text to “Continue”. - If the current button text is “Continue”: - Temporarily disables the button to prevent multiple clicks. - Sends a resume signal to the worker thread. - Updates the button text back to “Pause” and re-enables the button.

Returns None

`resetSaveSentinels()`

Resets all save-related sentinels when the save folder is changed.

This ensures that previously saved or autosaved data is marked as outdated, so it can be saved again in the new location if necessary.

Returns None

`resetValuesSentinels()`

Resets all channel sentinels to False.

Returns None

`saveDataAction(format, date)`

Handles the logic for saving measurement data, either from autosave or manual save.

This function determines if the data has already been saved in the requested format. If so, it notifies the user without duplicating the file. If the data was autosaved in a different format, it converts the temporary file to the selected format and saves it. If the data has not been saved yet, it creates a new file with the current measurement data.

Additionally, it displays informational dialogs to confirm the save or alert the user if the process fails.

Parameters

- **format** (*str*) – The desired file format to save (*"txt"*, *"csv"*, or *"dat"*).
- **date** (*datetime*) – The date and time used to generate the filename for saving.

`saveDataButtonAction()`

Opens a dialog for selecting the file format when saving data manually.

This function is triggered when the user clicks the manual "Save" button. It displays a dialog with available formats (*txt*, *csv*, *dat*) and, upon acceptance, calls *saveDataAction* with the selected format and the current date and time.

Returns None

`saveSettings()`

Builds and stores the header for the data file, including device and active channel settings.

The header contains: - Active channels in the measurement. - General device configurations. - Per-channel settings for each active channel.

`setErrorAutoSaving()`

`setValuesBeforeMeasurement()`

Activates channel sentinels based on the selected checkboxes.

Returns None

`settingsAfterMeasurement()`

Restores common UI controls after completing any measurement type.

Re-enables connection, save options, and channel selection checkboxes.

`settingsBeforeMeasurement()`

Applies common UI settings before starting any type of measurement.

Disables save options and channel checkboxes to prevent changes during acquisition.

Returns None

showDialogIncorrectDates()
Shows a warning dialog if the end date is earlier than the start date in a scheduled measurement.

showDialogIncorrectInitDate()
Shows a warning dialog if the start date is earlier than the current date and time.

showDialogNoChannels()
Shows a warning dialog if no channels are selected for measurement.

showProgressDialog(*filename*)
Displays a modal dialog showing the progress of the file saving process.

This function creates and shows a progress dialog with a label and a progress bar. It starts a background worker (*ProcessingDataSaved*) to process the file saving and updates the progress bar in real time via signals. When the process finishes, it triggers the final confirmation message.

Parameters **filename** (*str*) – The full path of the file being saved.

startLimitedMeasurement()
Starts a limited timestamp measurement based on a fixed number of measurement cycles.

This mode runs the acquisition process until the user-defined number of measurements is reached. The function performs the following actions: - Verifies that at least one channel (A, B, C, or D) is selected. - If none are selected, shows an alert and aborts the start. - If valid: - Disables other measurement tabs to prevent mode switching. - Disables the start button and enables pause/stop controls. - Prepares measurement parameters and auto-save options. - Generates the filename if auto-save is active. - Initializes the worker thread in "limited" mode, passing the number of desired measurements. - Connects thread signals to appropriate UI update handlers. - Starts the background thread and updates the UI to reflect the running state.

Returns None

startNormalMeasurement()
Starts a normal timestamp measurement.

Normal measurements begin immediately when the user presses "Start" and continue until manually stopped. This function performs the following actions: - Validates that at least one channel (A, B, C, or D) is selected. - If no channels are selected, an alert dialog is displayed and the measurement is not started. - If valid:

- Disables the start button and enables pause/stop controls.
- Disables other measurement tabs to prevent mode changes mid-measurement.
- Saves pre-measurement settings and prepares auto-save behavior if selected.
- Updates UI labels and status indicators to reflect active measurement.
- Creates and starts a background thread (*WorkerThreadTimeStamping*) to handle the measurement process.
- Connects worker signals to UI update slots.

Returns None

startScheduledMeasurement()
Initiates a scheduled timestamp measurement with start and end times defined by the user.

Scheduled measurements begin at a future time and automatically stop at the configured end time. This function performs the following actions: - Verifies that at least one channel is selected for measurement. - Disables tab navigation to prevent mode switching. - Retrieves and converts the start and end date-time values from the UI fields. - Validates:

- That the start time is not in the past.
- That the end time is after the start time.

- If validation fails, corresponding alert dialogs are shown.
- **If validation passes:**
  - Initializes auto-save format selection if enabled.
  - Configures a countdown timer (*timerBeginMeasurement*) to wait until the scheduled start time.
  - Updates the UI to reflect the waiting state with remaining time.
  - Begins measurement immediately if the scheduled start time is now or has passed.

Returns None

`startTimerConnection()`

Starts the connection monitoring timer to periodically check the device status.

This function activates the *timerConnection*, which verifies the connection with the Tempico device every 500 milliseconds. It is typically called after a measurement has ended or when the device is reconnected, ensuring continuous monitoring of the device's availability.

Returns None

`stopLimitedButtonAction()`

Stops an ongoing limited measurement.

This function disables the pause and stop buttons for the limited measurement mode and sends a stop signal to the worker thread.

Returns None

`stopLimitedMeasurement()`

Stops the limited measurement process, regardless of whether the target number of measurements has been reached.

This function can be used by the user to interrupt the measurement at any point. It performs the following actions: - Marks the measurement as completed (even if prematurely). - Stops the background worker thread. - Updates the UI status and color to reflect that no measurement is running. - Resets the pause button state (if previously in "Continue" mode). - Re-enables the start button and disables pause/stop buttons. - Re-enables the measurement count spinbox for further configuration. - Restores tab navigation for both the local interface and main window. - Signals the main window to re-enable settings and perform cleanup. - Restarts the timer that monitors device connection.

Returns None

`stopNormalButtonAction()`

Stops an ongoing normal measurement.

This function disables the pause and stop buttons for the normal measurement mode and sends a stop signal to the worker thread.

Returns None

`stopNormalMeasurement()`

Stops an ongoing normal measurement and resets the interface to its default state.

This function performs the following actions: - Marks the measurement as completed by setting the corresponding sentinel. - Sends a stop signal to the background worker thread. - Updates the UI to reflect that no measurement is running (label, color, buttons). - If the measurement was paused, resets the pause button

text to "Pause acquisition". - Re-enables tab switching and restores the initial measurement configuration. - Restarts the timer for checking device connection. - Notifies the main window to reflect the updated system state and re-enable settings.

Returns None

`stopScheduledMeasurement()`

Stops a scheduled measurement at any point — before it starts (waiting phase) or during execution.

This function handles both scenarios: - If the measurement hasn't started yet and is waiting for the scheduled start time:

- Cancels the countdown timer and resets all UI elements to their default state.
- **If the measurement is already running:**
  - Stops the data acquisition thread and the timer responsible for countdown to the end.
  - Updates the internal state and UI accordingly.

In both cases, the function: - Resets saving state and UI labels. - Restores tab and button availability. - Notifies the main window to re-enable configuration options. - Calls post-measurement cleanup logic.

Returns None

`stopScyheduledButtonAction()`

Stops an ongoing scheduled measurement.

If the measurement is still in the waiting state, it calls *stopScheduledMeasurement()* directly. Otherwise, it stops the scheduled timer, disables the pause and stop buttons, and sends a stop signal to the worker thread.

Returns None

`stopTimerConnection()`

Stops the connection monitoring timer during an active measurement.

This function is called when a measurement begins to prevent interference from the periodic connection checks. It halts the *timerConnection*, which normally runs in the background to monitor the status of the Tempico device.

Returns None

`updateCheckBoxLabels()`

Updates the visibility of measurement labels and values based on each channel's checkbox state.

This function performs the following actions: - For each channel (A, B, C, D), if its corresponding checkbox is checked: - The label and value indicator showing the number of measurements for that channel are made visible. - If unchecked, both elements are hidden.

This allows dynamic feedback on active channels during timestamp measurements.

Returns None

`updateProgressDialog(percent)`

Updates the progress dialog during the save process.

This function updates the progress bar and label to reflect the current progress percentage. If the progress reaches or exceeds 100%, the dialog is automatically closed.

Parameters `percent` (*int*) – The current progress percentage (0 to 100).

Returns None

updateShowTable()

Toggles the visibility of the timestamp data table based on the checkbox state.

This function performs the following actions: - If the "Show Table" checkbox is checked, the timestamp data table is displayed. - If the checkbox is unchecked, the table is hidden.

Returns None

updateValueTotalMeasurements(*text*)

Updates the label showing the total measurements.

updateValuesMeasurementA(*text*)

Updates the label showing the measurement value for channel A.

updateValuesMeasurementB(*text*)

Updates the label showing the measurement value for channel B.

updateValuesMeasurementC(*text*)

Updates the label showing the measurement value for channel C.

updateValuesMeasurementD(*text*)

Updates the label showing the measurement value for channel D.

CHAPTER

FOUR

COUNTSESTIMATEDLOGIC MODULE

class Logic.CountsEstimatedLogic.**CountEstimatedLogic**(*channelACheckBox: PySide2.QtWidgets.QCheckBox, channelBCheckBox: PySide2.QtWidgets.QCheckBox, channelCCheckBox: PySide2.QtWidgets.QCheckBox, channelDCheckBox: PySide2.QtWidgets.QCheckBox, startButton: PySide2.QtWidgets.QPushButton, stopButton: PySide2.QtWidgets.QPushButton, mergeRadio: PySide2.QtWidgets.QRadioButton, separateGraphics: PySide2.QtWidgets.QRadioButton, deatachedGraphics: PySide2.QtWidgets.QRadioButton, timeRangeComboBox: PySide2.QtWidgets.QComboBox, clearButtonChannelA: PySide2.QtWidgets.QPushButton, clearButtonChannelB: PySide2.QtWidgets.QPushButton, clearButtonChannelC: PySide2.QtWidgets.QPushButton, clearButtonChannelD: PySide2.QtWidgets.QPushButton, saveDataButton: PySide2.QtWidgets.QPushButton, savePlotButton: PySide2.QtWidgets.QPushButton, countChannelAValue: PySide2.QtWidgets.QLabel, countChannelBValue: PySide2.QtWidgets.QLabel, countChannelCValue: PySide2.QtWidgets.QLabel, countChannelDValue: PySide2.QtWidgets.QLabel, countChannelAUncertainty: PySide2.QtWidgets.QLabel, countChannelBUncertainty: PySide2.QtWidgets.QLabel, countChannelCUncertainty: PySide2.QtWidgets.QLabel, countChannelDUncertainty: PySide2.QtWidgets.QLabel, tableCounts: PySide2.QtWidgets.QTableWidget, graphicsFrame: PySide2.QtWidgets.QFrame,*

Class responsible for managing the logic and graphical representation of the Count Estimation window.

This class handles user interactions and graphical updates related to photon/event count estimations across multiple channels (A, B, C, D). It coordinates the initialization of graphical elements, manages real-time measurements, and provides options for data saving, graphical visualization modes, and uncertainty tracking per channel. The main responsibilities include: - Initializing and updating graphical frames for each measurement channel. - Starting and stopping the count measurements. - Handling user interactions with checkboxes, radio buttons, and combo boxes. - Displaying and updating count values and their uncertainties. - Managing separate, merged, or detached graphics. - Saving count data and graphical plots. - Monitoring the device connection and measurement state.

Parameters

- `channelACheckBox` – Checkbox for enabling/disabling measurements on channel A (QCheckBox).
- `channelBCheckBox` – Checkbox for enabling/disabling measurements on channel B (QCheckBox).
- `channelCCheckBox` – Checkbox for enabling/disabling measurements on channel C (QCheckBox).
- `channelDCheckBox` – Checkbox for enabling/disabling measurements on channel D (QCheckBox).
- `startButton` – Button to start the count measurement (QPushButton).
- `stopButton` – Button to stop the count measurement (QPushButton).
- `mergeRadio` – Radio button to merge all channel plots into one graph (QRadioButton).
- `separateGraphics` – Radio button to display plots separately per channel (QRadioButton).
- `deatachedGraphics` – Radio button to display detached external graphics (QRadioButton).
- `timeRangeComboBox` – Combo box for selecting the time range for plot visualization (QComboBox).
- `clearButtonChannelA` – Button to clear the graph and data of channel A (QPushButton).
- `clearButtonChannelB` – Button to clear the graph and data of channel B (QPushButton).
- `clearButtonChannelC` – Button to clear the graph and data of channel C (QPushButton).
- `clearButtonChannelD` – Button to clear the graph and data of channel D (QPushButton).
- `saveDataButton` – Button to save count data for all channels (QPushButton).
- `savePlotButton` – Button to save the plot images (QPushButton).
- `countChannelAValue` – Label displaying current count value on channel A (QLabel).
- `countChannelBValue` – Label displaying current count value on channel B (QLabel).
- `countChannelCValue` – Label displaying current count value on channel C (QLabel).
- `countChannelDValue` – Label displaying current count value on channel D (QLabel).
- `countChannelAUncertainty` – Label showing uncertainty of channel A (QLabel).
- `countChannelBUncertainty` – Label showing uncertainty of channel B (QLabel).
- `countChannelCUncertainty` – Label showing uncertainty of channel C (QLabel).
- `countChannelDUncertainty` – Label showing uncertainty of channel D (QLabel).

- **tableCounts** – Table displaying count and uncertainty data per measurement cycle (QTableWidget).
- **graphicsFrame** – Frame container for holding the graphical layouts (QFrame).
- **channelAFrameLabel** – Frame label associated with channel A graphics (QFrame).
- **channelBFrameLabel** – Frame label associated with channel B graphics (QFrame).
- **channelCFrameLabel** – Frame label associated with channel C graphics (QFrame).
- **channelDFrameLabel** – Frame label associated with channel D graphics (QFrame).
- **statusLabel** – Label showing the system status (QLabel).
- **pointStatusLabel** – Label showing the status of the current measurement point (QLabel).
- **deatachedCheckBox** – Checkbox to toggle between embedded and detached graphics layout (QCheckBox).
- **detachedLabelCheckBox** – Checkbox to toggle detached labels in the plot layout (QCheckBox).
- **helpButton** – Button that displays a help/information dialog (QPushButton).
- **device** – The connected measurement device.
- **parent** – The parent window containing the UI (usually a QMainWindow).
- **timerConnection** – Timer responsible for checking device connection status (QTimer).

Returns None

`captureFinalDate`(*date*)

Stores the final date received from a signal.

Parameters **date** – QDateTime - The end date of the measurement range.

Returns None

`captureInitalDate`(*date*)

Stores the initial date received from a signal.

Parameters **date** – QDateTime - The start date of the measurement range.

Returns None

`captureMeasurement`(*secondsTime*, *dateTime*, *channelAValue*, *channelAUncertainty*, *channelBValue*, *channelBUncertainty*, *channelCValue*, *channelCUncertainty*, *channelDValue*, *channelDUncertainty*)

Captures and processes a new set of measurement values emitted via signal, updating the UI and internal data structures.

This function is connected to a QSignal from the background worker thread and is responsible for handling a single measurement cycle. It validates the presence of data, provides real-time user feedback when no measurements are detected for specific channels, updates plots with valid values, populates the measurement table, and refreshes visual labels.

This function performs the following actions: - Checks for zero values in any channel and informs the user if one or more channels are not receiving valid measurements. - Updates the status bar and color indicator depending on whether all channels are acquiring data. - Appends valid count values and timestamps to the corresponding lists for each channel. - Updates the graphical curves for each channel if valid data is present. - Converts zero and -1 values into status messages like "Low Counts" or "Not Selected" for display purposes. - Adds the latest measurement row to both the main table (*tableCounts*) and its clone

(*cloneTable*). - Updates the live count and uncertainty labels for any actively selected channel. - Refreshes the visible X-axis range of the graphs using *updateGraphic()*.

Parameters

- **secondsTime** – Timestamp in seconds since measurement start (float).
- **dateTime** – Human-readable datetime string for the measurement (str).
- **channelAValue** – Count value for channel A (float or int).
- **channelAUncertainty** – Uncertainty value for channel A (float).
- **channelBValue** – Count value for channel B (float or int).
- **channelBUncertainty** – Uncertainty value for channel B (float).
- **channelCValue** – Count value for channel C (float or int).
- **channelCUncertainty** – Uncertainty value for channel C (float).
- **channelDValue** – Count value for channel D (float or int).
- **channelDUncertainty** – Uncertainty value for channel D (float).

Returns None

changeStatusColor(*color*)

Changes the color of the point in the status bar. Each color is assigned a specific numeric value.

Parameters **color** – The numeric value corresponding to the desired color (int). - 0: Gray - 1: Green - 2: Yellow - 3: Orange

Returns None

changeStatusLabel(*textValue*)

Updates the status label with a new message.

This function sets the text of the *statusLabel* widget to the given string. It is used throughout the application to inform the user of the current measurement status, errors, warnings, or progress.

Parameters **textValue** – str - The message to display in the status label.

Returns None

checkBoxListenerChannels()

Updates the visibility of graphical elements and table columns based on the state of the channel checkboxes.

This function performs the following actions: - Checks the state of each channel's checkbox (A, B, C, D). - Shows or hides the corresponding frame label for each channel depending on whether the checkbox is checked. - Calls *hideColumns()* to hide the table columns associated with unchecked channels. - Calls *updateGraphicsLayout()* to refresh the displayed plots based on the selected channels.

Returns None

clearChannelA()

Clears all stored measurement data for channel A and updates the corresponding plot.

This function is called when the user clicks the Clear button for channel A. It resets the timestamp lists and count values associated with channel A, and refreshes the plot to reflect the cleared state.

This function performs the following actions: - Empties the list of raw timestamps and formatted date timestamps for channel A. - Clears the list of count values associated with channel A. - Updates the channel A curve to remove all plotted data.

Returns None

`clearChannelB()`

Clears all stored measurement data for channel B and updates the corresponding plot.

This function is called when the user clicks the Clear button for channel B. It resets the timestamp lists and count values associated with channel B, and refreshes the plot to reflect the cleared state.

This function performs the following actions: - Empties the list of raw timestamps and formatted date timestamps for channel B. - Clears the list of count values associated with channel B. - Updates the channel B curve to remove all plotted data.

Returns None

`clearChannelC()`

Clears all stored measurement data for channel C and updates the corresponding plot.

This function is called when the user clicks the Clear button for channel C. It resets the timestamp lists and count values associated with channel C, and refreshes the plot to reflect the cleared state.

This function performs the following actions: - Empties the list of raw timestamps and formatted date timestamps for channel C. - Clears the list of count values associated with channel C. - Updates the channel C curve to remove all plotted data.

Returns None

`clearChannelD()`

Clears all stored measurement data for channel D and updates the corresponding plot.

This function is called when the user clicks the Clear button for channel D. It resets the timestamp lists and count values associated with channel D, and refreshes the plot to reflect the cleared state.

This function performs the following actions: - Empties the list of raw timestamps and formatted date timestamps for channel D. - Clears the list of count values associated with channel D. - Updates the channel D curve to remove all plotted data.

Returns None

`closeDialogChannels(`*channel*`)`

Handles cleanup and UI updates when a detached graphics dialog is closed.

This function is triggered when a user manually closes a detached dialog window corresponding to a specific channel. It clears the internal reference to the dialog and unchecks the associated channel checkbox to reflect that the channel is no longer active in the detached view.

This function performs the following actions: - Sets the corresponding *dialogXCreated* variable to *None*, where X is the channel (A–D). - Unchecks the checkbox for the specified channel to visually indicate it is no longer selected.

Parameters `channel` – The identifier of the channel whose dialog was closed ('A', 'B', 'C', or 'D').

Returns None

`closeLabelDialog()`

Resets the dialog state and unchecks the measurement label checkbox if the dialog was closed while still marked as active.

Returns None

`closeTableDialog()`

Handles cleanup when the detached table dialog is closed.

This function is triggered when the detached table dialog (*dialogTableOpen*) is closed by the user. It performs the following actions to maintain consistency in the UI state:

- Sets the internal dialog reference *dialogTableOpen* to *None*.
- Unchecks the *deatachedCheckBox* to reflect that the detached view is no longer active.

This ensures that the application's interface remains synchronized and avoids inconsistencies when reopening or reattaching the measurement table view.

Returns None

`connectedDevice`(*device*)

Handles the UI and internal state updates when the device is successfully connected.

This function performs the following actions: - Enables the disconnect button and disables the connect button in the main window. - Updates the internal sentinel to indicate that the device is connected and measurements are allowed. - Stores the reference to the connected device. - Enables the start button to allow measurements to begin. - (Optional) Starts a timer for updating measurement status (currently commented out).

Parameters `device` – The connected device instance.

Returns None

`constructAllGraphics`()

Constructs and initializes the unified graphical layout for all measurement channels.

This function calls *factoryGraphsAllChannels* to generate a single plot widget that contains curves for channels A, B, C, and D. Each curve is customized by color and visibility based on whether its corresponding checkbox is enabled. The resulting components are stored as instance variables for centralized access and updates.

This function performs the following actions: - Calls *factoryGraphsAllChannels* to create the shared plot and individual channel curves. - Stores the plot widget, plot item, and all channel-specific curves as instance variables.

Returns None

`constructGraphicA`()

Constructs and initializes the graphical components for channel A.

This function uses the *factoryGraphChannels* method to generate the graphical layout for channel A, including the main plot widget, the plot area, and the curve used to display count data. The resulting components are stored as instance variables for later access and updates during measurement.

This function performs the following actions: - Calls *factoryGraphChannels* with channel 'A' to generate the graph. - Stores the returned plot widget, plot item, and curve for channel A.

Returns None

`constructGraphicB`()

Constructs and initializes the graphical components for channel B.

This function uses the *factoryGraphChannels* method to generate the graphical layout for channel B, including the main plot widget, the plot area, and the curve used to display count data. The resulting components are stored as instance variables for later access and updates during measurement.

This function performs the following actions: - Calls *factoryGraphChannels* with channel 'B' to generate the graph. - Stores the returned plot widget, plot item, and curve for channel B.

Returns None

`constructGraphicC`()

Constructs and initializes the graphical components for channel C.

This function uses the *factoryGraphChannels* method to generate the graphical layout for channel C, including the main plot widget, the plot area, and the curve used to display count data. The resulting components are stored as instance variables for later access and updates during measurement.

This function performs the following actions: - Calls *factoryGraphChannels* with channel 'C' to generate the graph. - Stores the returned plot widget, plot item, and curve for channel C.

Returns None

`constructGraphicD()`

Constructs and initializes the graphical components for channel D.

This function uses the *factoryGraphChannels* method to generate the graphical layout for channel D, including the main plot widget, the plot area, and the curve used to display count data. The resulting components are stored as instance variables for later access and updates during measurement.

This function performs the following actions: - Calls *factoryGraphChannels* with channel 'D' to generate the graph. - Stores the returned plot widget, plot item, and curve for channel D.

Returns None

`createCloneTable()`

Creates and configures a cloned table instance for storing a copy of the measurement data.

This function initializes a separate *QTableWidget* that mirrors the structure of the main count table. It includes predefined column headers for the date and channels A, B, C, and D. The cloned table is set to stretch its columns to fit the available space and is made read-only to prevent user edits.

This function performs the following actions: - Creates a new *QTableWidget* instance with 5 columns. - Sets the horizontal headers to ['Date', 'A', 'B', 'C', 'D']. - Enables automatic stretching of column widths. - Disables editing to preserve the integrity of the data.

Returns None

`createDialogFactory(`*channel*`)`

Creates and returns a non-modal dialog window for displaying detached graphics for the specified channel.

This factory function is used when the user selects the "detached graphics" mode. It generates a dedicated *QDialog* for a given channel (A, B, C, or D), configures its appearance and behavior, and positions it to avoid overlap with other dialogs. The dialog is linked to a callback that ensures proper cleanup when it is closed.

This function performs the following actions: - Instantiates a *QDialog* as a child of the main window. - Sets the dialog title and default size. - Connects the *finished* signal to a cleanup method for the channel. - Assigns a fixed screen position for each channel to avoid visual overlap.

Parameters `channel` – A string indicating the target channel ('A', 'B', 'C', or 'D').

Returns A configured, ready-to-display *QDialog* for the given channel.

`createRow(`*leftLabel*, *rightLabel*`)`

Creates a horizontal row frame containing two labels.

This function constructs a *QFrame* that represents a single row in a dialog or panel. It arranges two given *QLabel* widgets — one aligned to the left and the other to the right — using a *QHBoxLayout*. The labels are styled with a consistent font size and the vertical margins are removed to minimize vertical spacing between rows.

This method is used to visually structure measurement data (such as estimated counts and uncertainties) in a clean, compact format.

Parameters

- `leftLabel` – QLabel - The label to place on the left side of the row.

- **rightLabel** – QLabel - The label to place on the right side of the row.

Returns QFrame - A frame containing the two labels arranged horizontally.

deatachedTable()

Manages the visibility of the estimated counts table in a detached dialog window.

This function is triggered when the *deatachedCheckBox* is toggled. If the checkbox is checked, it opens a new non-modal *QDialog* containing the cloned measurement table (*cloneTable*). If the checkbox is unchecked, it closes the dialog and resets the internal reference to *None*.

This function performs the following actions: - If the detached table mode is enabled:

- Creates and configures a new *QDialog* with the cloned table.
- Displays the dialog to the user.
- Connects the dialog's close event to a cleanup function.

- **If the detached table mode is disabled:**
  - Closes the existing dialog if it is open.
  - Clears the internal dialog reference.

Returns None

detachedLabels()

Displays or hides a dialog showing current measurement values for selected channels.

When the 'Detached current measurement' checkbox is checked, this function creates and displays a non-modal QDialog containing the current estimated count rates and their uncertainties for each selected channel (A–D). Each visible row in the dialog corresponds to a channel, displaying the estimated counts (in cps) and the associated uncertainty. If a channel is not selected, its row remains hidden.

The dialog layout is organized using a sunken panel-style QFrame with a vertical layout. A bold header row indicates the meaning of each column. This interface allows users to quickly inspect the most recent count values without modifying the ongoing measurement.

If the checkbox is unchecked, any open measurement dialog is closed automatically.

Returns None

disconnectedDevice()

Handles the UI and internal state updates when the device is disconnected.

This function performs the following actions: - Disables the disconnect button and enables the connect button in the main window. - Disables the start button to prevent new measurements from being initiated. - (Optional) May start a timer for monitoring status or reconnection attempts (currently commented out).

Returns None

eliminateCheckBoxChannels(*channelList*)

Handles the removal of channels with insufficient measurement signals and prompts the user to continue or stop.

This function is triggered when one or more selected channels fail to meet the minimum pulse requirements for reliable count estimation (e.g., fewer than 500 pulses per second). It presents a dialog informing the user about the affected channels and asks whether to continue the measurement with the remaining valid channels or to stop entirely.

This function performs the following actions: - Builds a human-readable list of the channels that failed to provide sufficient data. - Displays a warning dialog with the option to continue or cancel the measurement. - If the user chooses to continue:

- Disables the affected channels in the device.
- Unchecks and disables the associated checkboxes.
- Disables the "Clear" button for each affected channel.
- Marks the *measurementChannelX* sentinel as *False* for each affected channel.
- **If the user chooses not to continue:**
  - Stops the measurement thread.
- Signals the worker thread to proceed based on the user's decision via *continueEvent*.

Parameters `channelList` – A list of channel identifiers (e.g., ['A', 'C']) that failed to meet the minimum measurement conditions.

Returns None

`enableButtons()`

Enables or disables the clear buttons for each channel based on the current selection state.

This function checks which channels (A–D) have been marked as selected for measurement and enables their corresponding "Clear" buttons. If a channel is not selected, its clear button remains disabled. Additionally, it disables the disconnect button to prevent accidental disconnection during an active measurement setup.

This function performs the following actions: - Enables the "Clear" button for each selected channel. - Disables the "Clear" button for any unselected channel. - Disables the disconnect button in the main window.

Returns None

`factoryGraphChannels(channel)`

Creates and returns a configured plot widget for the specified measurement channel.

This factory function generates a graphical layout for visualizing count data from one of the four available channels (A, B, C, or D). The plot is customized with a unique color per channel, grid display, axis labeling, and a legend. It returns the PyQtGraph components necessary for real-time plotting.

This function performs the following actions: - Selects a predefined color for the specified channel. - Initializes a *GraphicsLayoutWidget* with a white background. - Adds a plot to the widget with grid lines, axis labels, and legend. - Creates a stylized curve object for plotting count data using markers and colored lines. - Returns the components needed to integrate the plot into the GUI and update it dynamically.

Parameters `channel` – A single-character string indicating the channel ('A', 'B', 'C', or 'D').

Returns A tuple containing: - *GraphicsLayoutWidget*: the plot container. - *PlotItem*: the configured plot. - *PlotDataItem*: the curve used for plotting the counts.

`factoryGraphsAllChannels()`

Creates and returns a single plot widget containing curves for all selected measurement channels.

This factory function generates a unified graphical layout that displays the estimated counts for channels A, B, C, and D in a single plot. Each channel is represented with a distinct color and labeled curve, depending on whether its checkbox is enabled. This approach consolidates the visualization into one graph rather than creating separate ones per channel.

This function performs the following actions: - Defines a unique color for each channel (A, B, C, D). - Initializes a *GraphicsLayoutWidget* with a white background and grid lines. - Configures a single plot with

appropriate axis labels and a legend. - Creates curve objects for each channel using stylized markers and pens. - Only assigns a name to a curve if its corresponding channel checkbox is checked. - Returns the complete widget and all channel curves for display and real-time updates.

Returns A tuple containing: - *GraphicsLayoutWidget*: the shared plot container for all channels. - *PlotItem*: the unified plot area. - *PlotDataItem*: curve for channel A. - *PlotDataItem*: curve for channel B. - *PlotDataItem*: curve for channel C. - *PlotDataItem*: curve for channel D.

`finishedThread()`

Handles the post-execution cleanup and UI updates when the measurement thread finishes.

This function is automatically triggered when the background measurement thread completes. It resets internal sentinels, updates the UI to reflect the end of the measurement, enables or disables appropriate buttons depending on whether data was captured, and invokes the standard stop measurement routine.

This function performs the following actions: - Resets all *selectChannelX* sentinels (A–D) to *False*. - Enables the Start button and disables the Stop button. - If any channel has collected data, enables the save buttons for data and plots. - Disables all "Clear" buttons for individual channels. - Updates the status label and color to indicate that no measurement is running. - Calls *stopMeasure()* to finalize the stop process and restore the interface to its initial state.

Returns None

`getChannelsMeasure()`

Determines which measurement channels are selected and updates internal sentinels accordingly.

This function evaluates the state of each channel's checkbox (A, B, C, D) to establish which channels will participate in the measurement. It sets the corresponding selection and measurement sentinels to *True* or *False* based on the checkboxes. Additionally, it disables the checkbox for any unselected channel to prevent user changes during the active measurement session.

This function performs the following actions: - Assumes all channels are selected by default. - Checks the state of each channel checkbox and updates:

- *selectChannelX*: sentinel to include channel X in the measurement loop.
- *measurementChannelX*: sentinel to track measurement activity per channel.
- Disables the checkbox for any channel that was not selected to lock in the configuration.

Returns None

`helpButtonDialog()`

Displays an informational dialog with instructions for using the Count Estimation window.

This function shows a modal QMessageBox with an information icon to guide the user on how to correctly connect the signal sources for pulse estimation. It clarifies that a periodic signal should be connected to the Start input, and the sources to be measured should be connected to the Stop channels.

Returns None

`hideColumns()`

Updates the visibility of the table columns based on the selected measurement channels.

This function ensures that only the columns corresponding to active channels (A–D) are visible in both the main and cloned data tables. It first shows all channel columns, then hides those whose associated checkboxes are unchecked.

This function performs the following actions: - Ensures all channel columns (1–4) are visible initially in both *tableCounts* and *cloneTable*. - Checks the state of each channel's checkbox. - Hides the column in both tables for any channel that is not currently selected.

Returns None

`lostConnection()`

Displays a critical error message indicating that the device connection has been lost.

This function sets the sentinel flag *disconnectedMeasurement* to True and shows a modal QMessageBox with a critical icon to inform the user that the connection to the device has been lost. The dialog must be acknowledged before continuing.

Returns None

`noChannelsSelected()`

Displays a warning dialog indicating that no channels have been selected for measurement.

This function is called when the user attempts to start a measurement without selecting any channels. It generates a modal warning dialog to inform the user that at least one channel must be selected to proceed.

This function performs the following actions: - Opens a *QMessageBox* warning with a title and informative message. - Prevents the measurement process from starting until the issue is resolved.

Returns None

`noMeasurementsFounded()`

Displays a warning dialog and disables channel interactions when no measurements are detected.

This function is triggered when the system fails to obtain valid measurements from any of the selected channels. It informs the user of the issue, disables the "Clear" buttons for all channels, and resets the internal sentinels that indicate active measurement states.

This function performs the following actions: - Shows a *QMessageBox* warning explaining that no measurements were found and outlines the minimum requirements for detection (e.g., 500 pulses per second). - Disables the "Clear" buttons for channels A–D to prevent further user interaction. - Resets *measurementChannelX* sentinels (A–D) to *False*, marking all channels as inactive.

Returns None

`resetSaveSentinels()`

`resetSentinels()`

Resets internal channel selection sentinels and re-enables all channel checkboxes.

This function is typically called after a measurement is stopped. It clears the selection flags (*selectChannelX*) for all channels (A–D) and re-enables their corresponding checkboxes in the UI, allowing the user to configure new measurement selections.

This function performs the following actions: - Sets all *selectChannelX* sentinels to *False*, indicating no active selections. - Enables the checkboxes for channels A, B, C, and D to restore full configuration flexibility.

Returns None

`resetValues()`

Resets all measurement-related data, graphics, tables, and save-state sentinels to their initial state.

This function is typically called before starting a new measurement session. It ensures that all previous data and UI elements are cleared to avoid inconsistencies or overlapping results. It resets internal storage lists, clears the curves on the plots, empties the result tables, and resets file save status indicators.

This function performs the following actions: - Clears all count values and timestamps for channels A–D. - Clears the corresponding date-formatted timestamp lists. - Resets the row count of the main and cloned data tables. - Clears all data from the plotted curves for each channel. - Resets internal sentinels that track whether the data has been saved in TXT, CSV, or DAT format.

Returns None

returnSettings()

Restores the previously saved configuration settings to the Tempico device.

This function is typically called after a measurement session ends. It applies the saved settings—previously captured via *saveSettings()*—back to the Tempico device for all channels (A–D). This includes restoring the number of runs, number of stops, mode, averaging cycles, and stop mask values. If any of the required variables were not initialized (e.g., due to a missing *saveSettings()* call), the function catches the *NameError* and prints the exception.

This function performs the following actions: - Restores the number of acquisition runs for the entire device. - Restores the number of averaging cycles for each channel. - Restores the number of stop events for each channel. - Restores the operation mode for each channel. - Restores the stop mask configuration for each channel. - Catches and prints *NameError* if any setting is undefined.

Returns None

rightAlignedItem(*value*)

Creates a QTableWidgetItem with right-aligned and vertically centered text.

This function takes a value, converts it to a string, wraps it in a QTableWidgetItem, and sets the text alignment to align the content to the right and center it vertically. It is used to ensure consistent formatting of numerical or textual data in table cells.

Parameters **value** (*Any*) – The value to be displayed in the table cell.

Returns A QTableWidgetItem with the specified alignment.

Return type QTableWidgetItem

saveData()

Saves the current data according to the selected format specified in the dialog box.

The function starts by retrieving the default histogram name and the current date, which is formatted to create a unique filename. It then initializes lists to hold filenames, data, settings, and column names for the saved files.

A dialog box is displayed for the user to select the desired file format (txt, csv, or dat) for saving the data. Once the user accepts the selection, the function checks if the selected format has already been saved before.

If the selected format has not been saved, it collects data from the various channels (A, B, C, D) if their corresponding sentinel variables indicate they should be saved. It retrieves the average cycles, mode, number of stops, stop edge, and stop mask for each channel to include in the settings. The function then attempts to save the collected data in the specified format.

If the save operation is successful, a message box is displayed, confirming the successful save and showing the folder path and file names. If an error occurs during the save process, an error message box is shown.

If the selected format has already been saved, a message box is displayed with the previous save information.

Returns None

savePlots()

Saves the current plots in the selected image format.

This method opens a dialog for the user to select an image format (PNG, TIFF, or JPG) and saves the plots for channels A, B, C, and D if their respective flags are set to True. The plots are saved with a timestamp in the specified format in the default folder path.

Returns None

saveSettings()

Saves the current configuration settings of the Tempico device for all channels.

This function queries the device and stores key configuration parameters for each channel (A–D), such as the number of stops, acquisition mode, averaging cycles, and stop mask. These values are cached in instance variables so they can be restored later (e.g., after a measurement session). If the device is unavailable or any read operation fails, the function safely ignores the error.

This function performs the following actions: - Retrieves and stores the global number of acquisition runs. - Retrieves and stores the number of stops per channel. - Retrieves and stores the operation mode per channel. - Retrieves and stores the number of averaging cycles per channel. - Retrieves and stores the stop mask per channel. - Ignores exceptions silently if the device is not ready.

Returns None

`startMeasure()`

Starts the count measurement process by configuring the UI, preparing internal states, and launching the background worker thread.

This function is triggered when the user clicks the Start button. It verifies that at least one measurement channel (A–D) is selected. If so, it proceeds to initialize the measurement by disabling conflicting buttons and tabs, saving current settings, resetting values, and setting up the worker thread responsible for data acquisition. If no channels are selected, it displays a dialog warning the user.

This function performs the following actions: - Verifies that at least one channel checkbox is active. - Disables the Start button and enables the Stop button. - Disables data saving buttons and tab navigation to prevent user interference. - Saves current settings and stops the connection monitoring timer. - Resets measurement values and identifies the selected channels. - Updates the UI status bar to indicate active measurement. - Creates and configures a *WorkerThreadCountsEstimated* thread to perform background data acquisition. - Connects various thread signals to corresponding update methods in the class. - Starts the measurement thread. - If no channels are selected, displays a warning dialog requiring the user to activate at least one channel.

Returns None

`startTimerConnection()`

Starts the connection monitoring timer to periodically check the device status.

This function activates the *timerConnection*, which verifies the connection with the Tempico device every 500 milliseconds. It is typically called after a measurement has ended or when the device is reconnected, ensuring continuous monitoring of the device's availability.

Returns None

`stopMeasure()`

Stops the ongoing measurement process and restores the UI and device to their initial configuration.

This function is triggered when the user clicks the Stop button. It halts the background measurement thread, resets relevant internal flags (sentinels), re-enables UI tabs and controls, and restores the initial settings of the Tempico device if the disconnection did not occur. If the device was disconnected during measurement, it triggers the disconnection handling routine.

This function performs the following actions: - Re-enables the disabled UI tabs to allow user interaction post-measurement. - Calls *resetSentinels()* to clear internal flags related to active measurement channels. - Disables the Stop button and signals the worker thread to stop. - If the device is still connected:

- Restarts the connection-monitoring timer.
- Re-enables the disconnect button.
- **If the device was disconnected during measurement:**
  - Triggers the disconnection handling logic in the main window.
- Updates the main window status to indicate that no measurement is currently running.

- Calls *returnSettings()* to restore device parameters to their original configuration.

  Returns None

`stopTimerConnection()`

Stops the connection monitoring timer during an active measurement.

This function is called when a measurement begins to prevent interference from the periodic connection checks. It halts the *timerConnection*, which normally runs in the background to monitor the status of the Tempico device.

Returns None

`updateGraphic()`

Updates the visible X-axis range of all channel plots based on the selected time window.

This function is triggered when the user changes the time range using the *timeRangeComboBox*. It determines the most recent timestamp in channel A and adjusts the X-axis range for all plots (A–D) accordingly, displaying only the data within the selected time interval.

This function performs the following actions: - Verifies that channel A has data; if not, it exits early. - Attempts to extract the number of seconds from the selected combo box option. - Calculates the minimum and maximum X-axis values based on the most recent timestamp. - Updates the X-axis range of all plots (A, B, C, and D) to reflect the selected time window.

Returns None

`updateGraphicsLayout()`

Updates the graphical layout based on the selected visualization mode and active channel checkboxes.

This function dynamically reconfigures how the channel plots are displayed, depending on the selected radio button mode: separate graphics, merged graph, or detached dialogs. It ensures that the interface reflects the current user selections by showing or hiding the corresponding curves, windows, or layouts.

This function performs the following actions: - If **separate graphics** mode is selected:

- Closes any open detached dialogs.
- Clears the current layout inside the *graphicsFrame*.
- Creates individual graphs for each selected channel (A–D).
- **Arranges them responsively:**
  - 1 channel → full frame.
  - 2 channels → one above the other.
  - 3 channels → two top, one bottom.
  - 4 channels → 2×2 grid layout.
- **If merge graphics mode is selected:**
  - Closes detached dialogs if any exist.
  - Clears the layout in *graphicsFrame*.
  - Creates a single graph containing all curves.
  - Displays or hides each curve depending on its checkbox status.
- **If detached graphics mode is selected:**
  - Clears the main *graphicsFrame* layout.

- For each selected channel (A–D), opens a dedicated dialog window.
- Loads previous data into the newly created plots.
- Closes dialog windows for unchecked channels.

Returns None

`updateLabels`(*channel*, *value*, *uncertainty*)

Updates the UI labels displaying the latest measurement value and its uncertainty for the specified channel.

This function formats and sets the value and uncertainty labels for a given channel (A–D). If the value is a string (e.g., "Low Counts" or "Not Selected"), it is displayed as-is. If it is a numeric value, the function rounds it for clearer presentation before updating the corresponding labels.

This function performs the following actions: - Determines if the value is a string or numeric. - Rounds numeric values (value to 2 decimals, uncertainty to 5 decimals). - Updates the *QLabel* elements associated with the selected channel to reflect the latest measurement results.

Parameters

- **`channel`** – The target channel identifier ('A', 'B', 'C', or 'D').
- **`value`** – The most recent measured value (float, int, or str).
- **`uncertainty`** – The associated uncertainty of the measurement (float or str).

Returns None

CHAPTER

FIVE

MAIN MODULE

class main.**MainWindow**(*parent=None*, **args*)

Bases: PySide2.QtWidgets.QMainWindow

Main application window class.

This class is responsible for creating the main window of the application, including its tabs and graphical user interface (GUI) components. It serves as a bridge between the UI classes that handle the design elements and the logic classes that manage the application's functionalities.

The main tasks of this class include: - Initializing the main window and its layout. - Creating and managing tabs for different sections of the application. - Integrating UI design elements with the logical operations for each functionality.

Parameters

- **parent** (*QWidget, optional*) – The parent widget (optional).
- **args** (*tuple*) – Additional arguments.

Helpg2Button()

about_settings()

Opens the About window displaying information about the company, version, and repository.

This function opens a window showing details about the company (Tausand), the software version, and the location of the repository. It does not perform any checks or validations and directly displays the About window.

It does not take any parameters and does not return a value. :returns: None

activeMeasurement()

Activates the sentinel indicating that a measurement is currently running.

This function sets the internal flag to True, which is used to track the active state of a measurement process.

Returns None

clicked_tabs()

Executes an action when a tab is clicked and creates the corresponding window.

This function checks which tab is currently active and constructs the associated window by invoking the appropriate function. If the tab corresponds to the Start/Stop Histogram, it stops the LifeTime timer and constructs the Start/Stop Histogram window. If the tab corresponds to the Lifetime Measurements, it constructs the Lifetime window and sets up the LifeTime logic if it has not been initialized yet.

It does not take any parameters and does not return a value. :returns: None

closeEvent(*event*)

Handles the close event of the main window and prompts the user for confirmation.

This function is triggered when the user attempts to close the main window. It displays a dialog asking if the user is sure about closing the application (Tempico software). If the user confirms by selecting "Yes", the event is accepted and the application closes. If the user selects "No", the close event is ignored, and the application remains open.

Parameters **event** (*QCloseEvent*) – The close event triggered when attempting to close the window.

Returns None

construct_counts_estimated(*parent*)

Constructs the Counts Estimated window.

This function takes a *QTabWidget* parent, and if the sentinel is not set, it creates an instance of the *Ui_CountsEstimated* class and sets up the UI using the given parent.

It ensures the UI is initialized only once by checking the *sentinel3* flag.

Parameters **parent** (*QWidget*) – The parent widget (typically a *QTabWidget*) for the counts estimated window.

Returns None

construct_g2(*parent*)

Constructs the g2 Measurements window.

This function takes a *QTabWidget* parent, and if the sentinel is not set, it creates an instance of the *Uig2* class and sets up the UI using the given parent.

It does not return a value.

Parameters **parent** (*QWidget*) – The parent widget (typically a *QTabWidget*) for the lifetime measurements window.

Returns None

construct_lifetime(*parent*)

Constructs the Lifetime Measurements window.

This function takes a *QTabWidget* parent, and if the sentinel is not set, it creates an instance of the *UiLifeTime* class and sets up the UI using the given parent.

It does not return a value.

Parameters **parent** (*QWidget*) – The parent widget (typically a *QTabWidget*) for the lifetime measurements window.

Returns None

construct_start_stop_histogram(*parent*)

Constructs the Start/Stop Histogram window.

This function takes a *QTabWidget* parent, and if the sentinel is not set, it creates an instance of the *Ui_HistogramaStartStop* class and sets up the UI using the given parent.

It does not return a value.

Parameters **parent** (*QWidget*) – The parent widget (typically a *QTabWidget*) for the histogram window.

Returns None

construct_time_stamping(*parent*)

Constructs the Counts Estimated window.

This function takes a *QTabWidget* parent, and if the sentinel is not set, it creates an instance of the *Ui_CountsEstimated* class and sets up the UI using the given parent.

It ensures the UI is initialized only once by checking the *sentinel3* flag.

Parameters **parent** (*QWidget*) – The parent widget (typically a *QTabWidget*) for the counts estimated window.

Returns None

disconnect_button_click()

Handles the disconnect button click event.

This function hides the graphical display, disables the disconnect button, and re-enables the connect button. It also closes the connected device and resets its reference to *None*. If additional graphics like *g2Graphic* or *LifeTimeGraphic* are active, it will disconnect them as well.

It does not take any parameters and does not return a value. :returns: None

disconnectedDevice()

Handles device disconnection without displaying any user interface dialogs.

This function is triggered when the connection with the device is lost. It notifies all relevant components to handle the disconnection and sets the connected device reference to None.

Returns None

enableSettings()

Re-enables the device and general settings dialogs if they are open.

If either the device configuration or general settings dialog is currently visible, this function refreshes and reactivates their interactive fields by calling the corresponding *get_settings()* and *enableSettings()* methods.

Returns None

folderPrefixClicked()

general_settings_clicked()

Opens the general settings window for device-wide configurations.

This function checks if a device is connected. If no measurement is currently running, it opens the general settings window where configurations that affect the entire device (regardless of the channel) can be adjusted. If a measurement is running, a message box is displayed to inform the user that changes cannot be made while the measurement is in progress. If no device is connected, a message box is shown indicating that no device was found.

It does not take any parameters and does not return a value. :returns: None

manageConection()

Manages the connection status with the measurement device.

This function checks if the device is still connected. If the connection is lost, it stops the timer responsible for monitoring the device, removes the device instance, disables measurement functionalities in all tabs, and displays an error dialog to inform the user.

Returns None

noMeasurement()

Deactivates the sentinel indicating that no measurement is currently running.

This function sets the internal flag to False, marking that there is no active measurement process at the moment.

Returns None

open_dialog()

Opens a dialog window to detect and connect a measurement device.

This function creates and displays a dialog window that lists available measurement devices and their corresponding ports. Users can select a device and either connect or cancel the operation.

If the 'Connect' button is clicked: - The selected device is connected, and all relevant software options are enabled. - The function tries to open the device and, upon success, interacts with graphical components (if any are present) to reflect the connected status.

If the 'Cancel' button is clicked: - No options are activated.

In case of a connection error, a message box is displayed informing the user of the failure.

Returns None

parameters_action()

resetSaveSentinelsAllWindows()

resizeEvent(*event*)

Handles the window resize event and adjusts the column widths of the parameters table.

This function is triggered when the user resizes the main window. It resizes the columns of the parameters table in the LifeTime tab based on the current window width. The column widths are scaled proportionally to ensure the table adapts to the new window size.

Parameters **event** (*QResizeEvent*) – The resize event triggered when the window is resized.

Returns None

saveSettings()

Retrieves and stores the current device configuration into internal variables.

This function queries the connected device for channel-specific settings such as averaging cycles, mode, number of stops, stop edge type, stop mask, threshold voltage, and number of runs. These values are saved into instance attributes for later use, such as restoring settings or displaying them in the UI.

Returns None

settings_clicked()

Opens the settings window when the settings option is clicked.

This function checks if a device is connected. If no measurement is currently running, it displays the settings window for channel configuration. If a measurement is running, a message box is shown informing the user that changes cannot be made while a measurement is in progress. If no device is connected, a message box alerts the user that no device was found.

It does not take any parameters and does not return a value. :returns: None

staticMetaObject = <PySide2.QtCore.QMetaObject object>

class main.**SplashScreen**

Bases: PySide2.QtWidgets.QMainWindow

Splash screen class for the application.

This class creates a splash screen that displays an image for a brief period before fading out and transitioning to the main application window.

The key responsibilities of this class include: - Displaying a splash screen with a specified image. - Timing the display duration and handling the transition to the main application window.

Parameters **parent** (*QWidget, optional*) – The parent widget (optional).

show_main_window()

Displays the main window of the application.

This function creates an instance of the main window (*MainWindow*) and displays it. After showing the main window, it closes the current window.

It does not take any parameters and does not return a value. :returns: None

staticMetaObject = <PySide2.QtCore.QMetaObject object>

main.**execProgram()**

CHAPTER

SIX

INDICES AND TABLES

- genindex
- modindex
- search

PYTHON MODULE INDEX

l

Logic.CountsEstimatedLogic, 38
Logic.LifeTimeLogic, 11
Logic.StartStopLogic, 3
Logic.TimeStampLogic, 24

m

main, 53

INDEX

A

about_settings() (*main.MainWindow method*), 53
activeMeasurement() (*main.MainWindow method*), 53
applyAction() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 12
applyInitialDialog() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 12
autoRangeA() (*Logic.StartStopLogic.StartStopLogic method*), 3
autoRangeB() (*Logic.StartStopLogic.StartStopLogic method*), 3
autoRangeC() (*Logic.StartStopLogic.StartStopLogic method*), 4
autoRangeD() (*Logic.StartStopLogic.StartStopLogic method*), 4
autoSaveAction() (*Logic.TimeStampLogic.TimeStampLogic method*), 26
autoSaveActionRoute() (*Logic.TimeStampLogic.TimeStampLogic method*), 26
autoSaveSettings() (*Logic.TimeStampLogic.TimeStampLogic method*), 26

B

beginMeasurementTime() (*Logic.TimeStampLogic.TimeStampLogic method*), 26

C

calculateR2() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 13
captureFinalDate() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 40
captureInitalDate() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 40
captureMeasurement() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 40
captureMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 27
changeColorThread() (*Logic.StartStopLogic.StartStopLogic method*), 4
changeCreatedStatus() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 13
changeFunction() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 13
changeLabelToUpdate() (*Logic.TimeStampLogic.TimeStampLogic method*), 27
changeStatusColor() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 41
changeStatusColor() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 13
changeStatusColor() (*Logic.StartStopLogic.StartStopLogic method*), 4
changeStatusColor() (*Logic.TimeStampLogic.TimeStampLogic method*), 27
changeStatusLabel() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 41
changeStatusLabel() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 13
changeStatusLabel() (*Logic.TimeStampLogic.TimeStampLogic method*), 27
changeStatusThread() (*Logic.StartStopLogic.StartStopLogic method*), 4
changeZoomMax() (*Logic.StartStopLogic.StartStopLogic method*), 4
checkBoxListenerChannels() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 41
checkBoxSaveData() (*Logic.TimeStampLogic.TimeStampLogic*

method), 27
checkBoxSaveDataAfterMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 27
checkDeviceStatus() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 13
clear_a() (*Logic.StartStopLogic.StartStopLogic method*), 4
clear_b() (*Logic.StartStopLogic.StartStopLogic method*), 4
clear_c() (*Logic.StartStopLogic.StartStopLogic method*), 5
clear_d() (*Logic.StartStopLogic.StartStopLogic method*), 5
clearChannelA() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 41
clearChannelB() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 41
clearChannelC() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 42
clearChannelD() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 42
clearData() (*Logic.TimeStampLogic.TimeStampLogic method*), 27
clearGraphic() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 13
clicked_tabs() (*main.MainWindow method*), 53
closeDialogChannels() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 42
closeEvent() (*main.MainWindow method*), 53
closeLabelDialog() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 42
closeTableDialog() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 42
connectedDevice() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 43
connectedDevice() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 14
connectedDevice() (*Logic.TimeStampLogic.TimeStampLogic method*), 27
construct_counts_estimated() (*main.MainWindow method*), 54
construct_g2() (*main.MainWindow method*), 54
construct_lifetime() (*main.MainWindow method*), 54
construct_start_stop_histogram() (*main.MainWindow method*), 54
construct_time_stamping() (*main.MainWindow method*), 54
constructAllGraphics() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 43
constructGraphicA() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 43
constructGraphicB() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 43
constructGraphicC() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 43
constructGraphicD() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 44
CountEstimatedLogic (*class in Logic.CountsEstimatedLogic*), 38
countToBegin() (*Logic.TimeStampLogic.TimeStampLogic method*), 28
countToStop() (*Logic.TimeStampLogic.TimeStampLogic method*), 28
create_graphs() (*Logic.StartStopLogic.StartStopLogic method*), 5
createCloneTable() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 44
createDialog() (*Logic.StartStopLogic.StartStopLogic method*), 5
createDialogFactory() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 44
createRow() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 44

D

deatachedTable() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 45
detachedLabels() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 45
dialogChangeMode() (*Logic.StartStopLogic.StartStopLogic method*), 5
dialogFormatStart() (*Logic.TimeStampLogic.TimeStampLogic method*), 28
dialogHelpSaveButton() (*Logic.TimeStampLogic.TimeStampLogic method*), 28
dialogToShowSave() (*Logic.TimeStampLogic.TimeStampLogic method*), 28
disconnect_button_click() (*main.MainWindow method*), 55
disconnectedDevice() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 45
disconnectedDevice() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 14
disconnectedDevice()

(*Logic.StartStopLogic.StartStopLogic method*), 5
disconnectedDevice() (*Logic.TimeStampLogic.TimeStampLogic method*), 28
disconnectedDevice() (*main.MainWindow method*), 55
double_Exponential() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 14

E

eliminateCheckBoxChannels() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 45
enableAfterFinisihThread() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 14
enableButtons() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 46
enableSettings() (*main.MainWindow method*), 55
execProgram() (*in module main*), 57
exp_decay() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 14

F

factoryGraphChannels() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 46
factoryGraphsAllChannels() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 46
fileNameAutoSave() (*Logic.TimeStampLogic.TimeStampLogic method*), 29
finalMessageAfterSave() (*Logic.TimeStampLogic.TimeStampLogic method*), 29
finishedMeasurements() (*Logic.TimeStampLogic.TimeStampLogic method*), 29
finishedThread() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 47
finishedThread() (*Logic.TimeStampLogic.TimeStampLogic method*), 29
finishedThreadLimited() (*Logic.TimeStampLogic.TimeStampLogic method*), 29
finishedThreadMeasurement() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 15
finishedThreadSchedule() (*Logic.TimeStampLogic.TimeStampLogic method*), 29
fitDoubleExponential() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 15
fitExpDecay() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 15
fitKohlrauschFit() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 15
fitShiiftedExponential() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 16
folderPrefixClicked() (*main.MainWindow method*), 55
formatWaitingTime() (*Logic.TimeStampLogic.TimeStampLogic method*), 29

G

general_settings_clicked() (*main.MainWindow method*), 55
getAproxTotalData() (*Logic.TimeStampLogic.TimeStampLogic method*), 29
getAvailableRam() (*Logic.TimeStampLogic.TimeStampLogic method*), 29
getChannelsMeasure() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 47
getTempicoChannel() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 16
getUnits() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 16

H

helpButtonDialog() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 47
Helpg2Button() (*main.MainWindow method*), 53
hide_graphic2() (*Logic.StartStopLogic.StartStopLogic method*), 5
hideColumns() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 47

I

indexChangeStartChannel() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 16
indexChangeStopChannel() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 17
initialParametersDialog() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 17
insertParameters() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 17

K

kohl_decay() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 17

L

LifeTimeLogic (*class in Logic.LifeTimeLogic*), 11
Logic.CountsEstimatedLogic
    module, 38
Logic.LifeTimeLogic
    module, 11
Logic.StartStopLogic
    module, 3
Logic.TimeStampLogic
    module, 24
lostConnection() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 48
lostConnection() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 18

M

main
    module, 53
MainWindow (*class in main*), 53
manageConection() (*main.MainWindow method*), 55
maxRound() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 18
module
    Logic.CountsEstimatedLogic, 38
    Logic.LifeTimeLogic, 11
    Logic.StartStopLogic, 3
    Logic.TimeStampLogic, 24
    main, 53

N

noChannelsSelected() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 48
noMeasurement() (*main.MainWindow method*), 55
noMeasurementsFounded() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 48
notSelectedFormatLimitedStop() (*Logic.TimeStampLogic.TimeStampLogic method*), 29
notSelectedFormatNormalStop() (*Logic.TimeStampLogic.TimeStampLogic method*), 29
notSelectedFormatScheduledStop() (*Logic.TimeStampLogic.TimeStampLogic method*), 30

O

onAutoSaveIntervalChanged() (*Logic.TimeStampLogic.TimeStampLogic method*), 30
open_dialog() (*main.MainWindow method*), 55

P

parameters_action() (*main.MainWindow method*), 56
pauseLimitedMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 30
pauseNormalMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 30
pauseScheduledMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 30

R

resetInitialDialog() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 18
resetParametersLabels() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 18
resetSaveSentinels() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 48
resetSaveSentinels() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 19
resetSaveSentinels() (*Logic.StartStopLogic.StartStopLogic method*), 5
resetSaveSentinels() (*Logic.TimeStampLogic.TimeStampLogic method*), 31
resetSaveSentinelsAllWindows() (*main.MainWindow method*), 56
resetSentinels() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 48
resetValues() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 48
resetValuesSentinels() (*Logic.TimeStampLogic.TimeStampLogic method*), 31
resizeEvent() (*main.MainWindow method*), 56
returnSettings() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 48
rightAlignedItem() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 49
roundStringPCov() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 19

S

save_graphic() (*Logic.StartStopLogic.StartStopLogic*

method), 5
save_plots() (*Logic.StartStopLogic.StartStopLogic method*), 6
saveData() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 49
saveDataAction() (*Logic.TimeStampLogic.TimeStampLogic method*), 31
saveDataButtonAction() (*Logic.TimeStampLogic.TimeStampLogic method*), 31
saveLifeTimeData() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 19
saveMode() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 19
savePlotLifeTime() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 19
savePlots() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 49
saveSettings() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 49
saveSettings() (*Logic.TimeStampLogic.TimeStampLogic method*), 31
saveSettings() (*main.MainWindow method*), 56
setErrorAutoSaving() (*Logic.TimeStampLogic.TimeStampLogic method*), 31
setOldMode() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 19
settings_clicked() (*main.MainWindow method*), 56
settingsAfterMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 31
settingsBeforeMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 31
setValuesBeforeMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 31
shifted_decay_function() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 19
show_graphic() (*Logic.StartStopLogic.StartStopLogic method*), 6
show_main_window() (*main.SplashScreen method*), 56
showDialogIncorrectDates() (*Logic.TimeStampLogic.TimeStampLogic method*), 31
showDialogIncorrectInitDate() (*Logic.TimeStampLogic.TimeStampLogic method*), 32
showDialogNoChannels() (*Logic.TimeStampLogic.TimeStampLogic method*), 32
showProgressDialog() (*Logic.TimeStampLogic.TimeStampLogic method*), 32
SplashScreen (*class in main*), 56
start_graphic() (*Logic.StartStopLogic.StartStopLogic method*), 6
startLimitedMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 32
startMeasure() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 50
startMeasurement() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 19
startNormalMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 32
startScheduledMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 32
StartStopLogic (*class in Logic.StartStopLogic*), 3
startTimer() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 20
startTimerConnection() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 50
startTimerConnection() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 20
startTimerConnection() (*Logic.StartStopLogic.StartStopLogic method*), 6
startTimerConnection() (*Logic.TimeStampLogic.TimeStampLogic method*), 33
staticMetaObject (*main.MainWindow attribute*), 56
staticMetaObject (*main.SplashScreen attribute*), 57
stop_graphic() (*Logic.StartStopLogic.StartStopLogic method*), 6
stopLimitedButtonAction() (*Logic.TimeStampLogic.TimeStampLogic method*), 33
stopLimitedMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 33
stopMeasure() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 50
stopMeasurement() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 20
stopNormalButtonAction() (*Logic.TimeStampLogic.TimeStampLogic method*), 33
stopNormalMeasurement() (*Logic.TimeStampLogic.TimeStampLogic method*), 33
stopScheduledMeasurement()

(*Logic.TimeStampLogic.TimeStampLogic method*), 34
stopScyheduledButtonAction() (*Logic.TimeStampLogic.TimeStampLogic method*), 34
stopTimer() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 20
stopTimerConnection() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 51
stopTimerConnection() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 20
stopTimerConnection() (*Logic.StartStopLogic.StartStopLogic method*), 6
stopTimerConnection() (*Logic.TimeStampLogic.TimeStampLogic method*), 34

T

threadComplete() (*Logic.StartStopLogic.StartStopLogic method*), 6
threadRunning() (*Logic.StartStopLogic.StartStopLogic method*), 7
timeRangeValue() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 20
TimeStampLogic (*class in Logic.TimeStampLogic*), 24

U

update_histogram() (*Logic.StartStopLogic.StartStopLogic method*), 7
update_timer() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 21
updateBashDataPure() (*Logic.StartStopLogic.StartStopLogic method*), 7
updateBashSignal() (*Logic.StartStopLogic.StartStopLogic method*), 7
updateCheckBoxLabels() (*Logic.TimeStampLogic.TimeStampLogic method*), 34
updateDataPure() (*Logic.StartStopLogic.StartStopLogic method*), 7
updateGraphic() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 51
updateGraphicsLayout() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 51
updateLabel() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 20
updateLabels() (*Logic.CountsEstimatedLogic.CountEstimatedLogic method*), 52
updateLabels() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 20
updateMeasurement() (*Logic.LifeTimeLogic.LifeTimeLogic method*), 21
updateProgressDialog() (*Logic.TimeStampLogic.TimeStampLogic method*), 34
updateShowTable() (*Logic.TimeStampLogic.TimeStampLogic method*), 34
updateSignal() (*Logic.StartStopLogic.StartStopLogic method*), 7
updateValuesMeasurementA() (*Logic.TimeStampLogic.TimeStampLogic method*), 35
updateValuesMeasurementB() (*Logic.TimeStampLogic.TimeStampLogic method*), 35
updateValuesMeasurementC() (*Logic.TimeStampLogic.TimeStampLogic method*), 35
updateValuesMeasurementD() (*Logic.TimeStampLogic.TimeStampLogic method*), 35
updateValueTotalMeasurements() (*Logic.TimeStampLogic.TimeStampLogic method*), 35

Z

zoom_changedA() (*Logic.StartStopLogic.StartStopLogic method*), 8
zoom_changedB() (*Logic.StartStopLogic.StartStopLogic method*), 8
zoom_changedC() (*Logic.StartStopLogic.StartStopLogic method*), 8
zoom_changedD() (*Logic.StartStopLogic.StartStopLogic method*), 8