

Team 5176 — Driver Controller Reference

Xbox controller wired on DriverStation port 0 | generated from RobotContainer.java / IO.java / RebuiltCommands.java

Sticks — always active

Control	Action
Left Stick	Translate the robot (field-relative)
Right Stick (X-axis)	Rotate the robot

Buttons & Triggers

Button	Action
A	Toggle shoot: starts shooter, waits 0.75s to spin up, then starts transport + spindexer — or stops all three if already shooting
X	Hold to reverse spindexer + transport (clears a jam). On release, resumes forward if the shoot toggle (A) is on, or stops if it isn't
Y	Drive-to-pose: CENTER field position, auto-picked for current alliance + bumps shooter target to 1800 RPM while held
B	Unused
LB (Left Bumper)	Deploy intake arm
RB (Right Bumper)	Retract intake arm
Back / View	Toggle reverse transport + spindexer, or stop if already spinning
Right Trigger (> 50%)	Toggle intake rollers on / off
Left Trigger (> 50%)	Toggle intake rollers in reverse / off
D-Pad Up	Tower climb → reset position
D-Pad Down	Tower climb → climb position

Notes

- Y is the only drive-to-pose button now — the old left/right variants (previously bound to X and B) were removed. The robot auto-detects alliance color, so the button feels the same on either alliance.
- X used to drive to a second pose; it's now the jam-clear button: hold to spin the spindexer + transport backward, release to resume whatever the shoot toggle (A) currently says. B is currently unbound.
- “Toggle” buttons (A, Back/View, both triggers) check the subsystem's current state each press, so one button starts and stops the action.
- Y only drives while held (whileTrue) — release it to return to manual stick control.
- Pressing A now has a built-in 0.75s spin-up delay before balls feed into the shooter, for more consistent shots.

Keep this sheet with the driver station. Update it any time button bindings change in IO.java or RobotContainer.java.