

Team 5176 — Driver Controller Reference

Xbox controller wired on DriverStation port 0 | generated from RobotContainer.java / IO.java / RebuiltCommands.java

Sticks — always active

Control	Action
Left Stick	Translate the robot (field-relative)
Right Stick (X-axis)	Rotate the robot

Buttons & Triggers

Button	Action
A	Toggle shoot: starts shooter + transport + spindexer, or stops all three if already shooting
X	Drive-to-pose: LEFT field position (same relative spot on either alliance) + bumps shooter target to 1800 RPM while held
Y	Drive-to-pose: CENTER field position + bumps shooter target to 1800 RPM while held
B	Drive-to-pose: RIGHT field position + bumps shooter target to 1800 RPM while held
LB (Left Bumper)	Deploy intake arm
RB (Right Bumper)	Retract intake arm
Back / View	Toggle reverse transport + spindexer, or stop if already spinning
Right Trigger (> 50%)	Toggle intake rollers on / off
Left Trigger (> 50%)	Toggle intake rollers in reverse / off
D-Pad Up	Tower climb → reset position (0)
D-Pad Down	Tower climb → climb position (30)

Notes

- X / Y / B drive to the same relative field role (left / center / right) on both alliances — the robot auto-detects alliance color and picks the matching pose constant, so the buttons feel the same regardless of which alliance you're on.
- "Toggle" buttons check the subsystem's current state each press, so the same button starts and stops the action — no separate start/stop buttons to remember.
- Drive-to-pose buttons (X/Y/B) only drive while held (whileTrue) — release the button to return to manual stick control.

Keep this sheet with the driver station. Update it any time button bindings change in IO.java or RobotContainer.java.