Set up your LayerHound

Watch every printer in your farm from one dashboard, on your own network. About 10 minutes, no programming needed.

You'll need: your LayerHound and its power supply, a phone or computer on your home network, and an Ethernet cable if you have one (Wi-Fi works too).

1 Connect it

With a cable: plug LayerHound into your router with an Ethernet cable, then plug in the power. Wait about 2 minutes.

No cable? Plug in the power and wait a minute or two. On your phone, join the Wi-Fi network **LayerHound-Setup**. A setup page opens: pick your home Wi-Fi and enter its password. Then reconnect your phone to your home Wi-Fi.

2 Open the dashboard

On a phone or computer on the same network, open:

`http://layerhound.local`

or scan the code.

If it doesn't open, see the tips below.

layerhound.local

3 Make it yours

- **Name your farm.** You can change it later.
- **Create your admin password.** There's no default password. Use at least 8 characters and keep it somewhere safe.
- **Choose whether to share anonymous usage stats.** Nothing is sent unless you say yes.
- **Save your recovery key.** It sets a new password if you ever forget yours. Write it here and keep this sheet somewhere safe:

RECOVERY KEY

_____ – _____ – _____ – _____

4 Add your printers

LayerHound looks for printers on your network by itself. They show up on the Dashboard as **printers found on your network**:

- **Klipper:** press **Add**.
- **Bambu Lab:** type the printer's access code, from its screen under network or WLAN settings.
- **OctoPrint:** press **Allow in OctoPrint**, then **Allow** in OctoPrint.

Not listed? Use **Print Farm → Add printer**.

Good to know

- **layerhound.local won't open?** Make sure you're on the same network as LayerHound. Some Android phones and Windows PCs can't open **.local** names: find "layerhound" in your router's device list and open **http://** followed by its IP address.
- **Before unplugging,** use **Settings → About & maintenance → Shut down board**, then wait until the activity light stops blinking.
- **Away from home:** use **Settings → Remote access**. Never open LayerHound to the internet with port forwarding.
- **Forgot your password?** On the sign-in screen, choose **Forgot your password?** and enter your recovery key.
- **Questions or ideas?** Use **Send feedback** in the dashboard menu. It goes straight to Team Tactical RC.

The full owner's guide covers accounts, backups, the setup hotspot, troubleshooting and more. Scan the code to open it.

LayerHound by Team Tactical RC. Free and open source.

Controlling printers (pause, cancel, start) is optional and off by default (Settings → Printer controls). Not affiliated with Bambu Lab, Klipper, OctoPrint, Radxa or the other makers named here. LayerHound and the hound logo are trademarks of Team Tactical RC.