Normal maintenance schedule (except Europe, but including Russia)

I : Inspect and if necessary, adjust, correct, clean or replace.

R : Replace or change.

MAINTENANCE INTERVALS		Number of months or driving distance, whichever comes first							
	Months	24	48	72	96	120	144	168	192
	Milesx1,000	20	40	60	80	100	120	140	160
	Kmx1,000	30	60	90	120	150	180	210	240
MAINTENANCE ITEM									
Cooling system		I	I	I	I	I	I	I	I
Coolant *1		At first, replace at 180,000 km (120,000 miles) or 10 years: after that, replace every 30,000 km (25,000 miles) or 24 months							
Reduce fluid			I		I		I		I
12 V auxiliary battery condition	For Europe	I	I	I	I	I	I	I	I
	Except Europet	Inspect every 15,000 km (10,000 miles) or 12 months							
All electrical system		I	I	I	I	I	I	I	I
Brake lines, hoses and connections		I	I	I	I	I	I	I	I
Brake pedal		I	I	I	I	I	I	I	I
Parking brake		I	I	I	I	I	I	I	I
Brake fluid		R	R	R	R	R	R	R	R
Brake discs and pads		I	I	I	I	I	I	I	I
Steering gear rack, linkage and boots		I	I	I	I	I	I	I	I
Driveshaft and boots		I	I	I	I	I	I	I	I
Tire (pressure & tread wear)		I	I	I	I	I	I	I	I
Front suspension ball joints		I	I	I	I	I	I	I	I

I : Inspect and if necessary, adjust, correct, clean or replace.
R : Replace or change.

MAINTENANCE INTERVALS		Number of months or driving distance, whichever comes first							
	Months	24	48	72	96	120	144	168	192
	Milesx1,000	20	40	60	80	100	120	140	160
	Kmx1,000	30	60	90	120	150	180	210	240
MAINTENANCE ITEM									
Bolt & nuts on chassis and body		I	I	I	I	I	I	I	I
Air conditioner refrigerant		I	I	I	I	I	I	I	I
Air conditioner compressor		I	I	I	I	I	I	I	I
Cabin air filter	For Europe	R	R	R	R	R	R	R	R
	Except Europet	Replace every 15,000 km (10,000 miles) or 12 months							
Pan-European eCall system battery (if equipped)		Replace every 4 years							
UAE eCall system battery (if equipped)		Replace every 4 years							

*1: When replacing or adding coolant, we recommend that you visit an authorized retailer of Genesis Branded products.

Maintenance under severe usage conditions

I : Inspect and if necessary, adjust, correct, clean or replace.
R : Replace or change.

Maintenance item	Maintenance operation	Maintenance intervals	Driving condition
Reducer fluid	R	Every 120,000 km (80,000 miles)	B, D, G, H
Steering gear rack, linkage and boots	I	Inspect more frequently depending on the condition	C, D, E, F, G
Front suspension ball joints	I	Inspect more frequently depending on the condition	B, C, D, E, F
Disc brakes and pads, calipers and rotors	I	Inspect more frequently depending on the condition	B, C, D, E, F, G, H, I, J
Driveshaft and boots	I	Inspect more frequently depending on the condition	B, C, D, E, F, G, H, I
Cabin air filter	R	Inspect more frequently depending on the condition	B, D, F

Severe driving conditions

A: Repeatedly driving short distance of less than 8 km (5 mi.) in normal temperature or less than 16 km (10 mi.) in freezing temperature
B: Driving on rough, dusty, muddy, unpaved, graveled or salt spread roads
C: Driving in areas using salt or other corrosive materials or in very cold weather
D: Driving in heavy dust conditions
E: Driving in heavy traffic area with the ambient temperature higher than 32 °C (90 °F) while consuming more than 50% of electric energy
F: Driving on uphill, downhill, or mountain roads repeatedly
G: Using for towing or camping, and driving with loads on the roof
H: Driving as patrol car, taxi, or other commercial use of vehicle towing
I: Frequently driving under high speed or rapid acceleration/deceleration
J: Frequently driving in stop-and-go conditions

EV special care (optional)

Maintenance of EV Special Care items are optional but recommended. It includes non-conductive treatments or procedures that do not affect or void the vehicle manufacturer's warranty.

I : Inspect and if necessary, adjust, correct, clean or replace.

R : Replace or change.

MAINTENANCE INTERVALS	Number of months or driving distance, whichever comes first									
	Months		**12**	**24**	**36**	**48**	**60**	**72**	**84**	**96**	**108**
	Milesx1,000		**10**	**20**	**30**	**40**	**50**	**60**	**70**	**80**	**90**
	Kmx1,000		**15**	**30**	**45**	**60**	**75**	**90**	**105**	**120**	**135**
MAINTENANCE ITEM											
High Voltage Battery	Insulation resistance check		I	I	I	I	I	I	I	I	I
	Voltage deviation check		I	I	I	I	I	I	I	I	I
Cooling System	Air-cooled	Coolant amount check	I	I	I	I	I	I	I	I	I
	Water cooling	Coolant amount check	I	I	I	I	I	I	I	I	I
		EWP operation status check	I	I	I	I	I	I	I	I	I
		3way valve operation check	I	I	I	I	I	I	I	I	I
DTC	Fault code check (Full DTC scanning)		I	I	I	I	I	I	I	I	I
Lower body	Battery lower part damage check		I	I	I	I	I	I	I	I	I
	High voltage cable damage check		I	I	I	I	I	I	I	I	I