Normal maintenance schedule

I: Inspect and if necessary, adjust, correct, clean or replace.

R: Replace or change.

MAINTENANCE INTERVALS		Number of months or driving distance, whichever comes first							
	Months	24	48	72	96	120	144	168	192
	mi. × 1,000	20	40	60	80	100	120	140	160
	km × 1,000	30	60	90	120	150	180	210	240
MAINTENANCE ITEM									
Cooling system		I	I	I	I	I	I	I	I
Coolant *1		At first, replace at 180,000 km (120,000 mi.) or 120 months after that, replace every 30,000 km (25,000 mi.) or 24 months							
Reducer fluid			I		I		I		I
12 V auxiliary battery condition	For Europe	I	I	I	I	I	I	I	I
	Except Europe	Inspect 15,000 km (10,000 mi.) or 12 months							
All electrical system		I	I	I	I	I	I	I	I
Brake lines, hoses and connections		I	I	I	I	I	I	I	I
Brake pedal		I	I	I	I	I	I	I	I
Parking brake		I	I	I	I	I	I	I	I
Brake fluid		R	R	R	R	R	R	R	R
Brake discs and pads		I	I	I	I	I	I	I	I
Steering gear rack, linkage and boots		I	I	I	I	I	I	I	I
Driveshaft and boots		I	I	I	I	I	I	I	I
Tire (pressure & tread wear)		I	I	I	I	I	I	I	I
Front suspension ball joints		I	I	I	I	I	I	I	I

MAINTENANCE INTERVALS	Number of months or driving distance, whichever comes first								
	Months	24	48	72	96	120	144	168	192
	mi. × 1,000	20	40	60	80	100	120	140	160
	km × 1,000	30	60	90	120	150	180	210	240
MAINTENANCE ITEM									
Bolt and nuts on chassis and body		I	I	I	I	I	I	I	I
Air conditioner refrigerant		I	I	I	I	I	I	I	I
Air conditioner compressor		I	I	I	I	I	I	I	I
Cabin air filter	For Europe	R	R	R	R	R	R	R	R
	Except Europe	Replace every 15,000 km (10,000 mi.) or 12 months							
Pan-European eCall system battery (if equipped)		Replace every 4 years							
UAE eCall system battery (if equipped)		Replace every 4 years							

*1: When replacing or adding coolant, we recommend that you visit an authorized retailer of Genesis Branded products.

Maintenance under severe usage conditions

I: Inspect and if necessary, adjust, correct, clean or replace

R: Replace

Maintenance item	Maintenance operation	Maintenance intervals	Driving condition
Reducer fluid	R	Every 120,000 km (80,000 mi.)	B, D, G, H
Steering gear rack, linkage and boots	I	Inspect more frequently depending on the condition	C, D, E, F, G
Front suspension ball joints	I	Inspect more frequently depending on the condition	B, C, D, E, F
Disc brakes and pads, calipers and rotors	I	Inspect more frequently depending on the condition	B, C, D, E, F, G, H, I, J
Driveshaft and boots	I	Inspect more frequently depending on the condition	B, C, D, E, F, G, H, I
Cabin air filter	R	Replace more frequently depending on the condition	B, D, F

Severe driving conditions

A: Repeatedly driving short distance of less than 8 km (5 mi.) in normal temperature or less than 16 km (10 mi.) in freezing temperature

B: Driving on rough, dusty, muddy, unpaved, graveled or salt spread roads

C: Driving in areas using salt or other corrosive materials or in very cold weather

D: Driving in heavy dust conditions

E: Driving in heavy traffic area with the ambient temperature higher than 32 °C (90 °F) while consuming more than 50 % of electric energy

F: Driving on uphill, downhill, or mountain roads repeatedly

G: Using for towing or camping, and driving with loads on the roof

H: Driving as patrol car, taxi, or other commercial use of vehicle towing

I: Frequently driving under high speed or rapid acceleration/deceleration

J: Frequently driving in stop-and-go conditions

EV special care (optional)

Maintenance of EV Special Care items are optional but recommended. It includes non-conductive treatments or procedures that do not affect or void the vehicle manufacturer's warranty.

EV Special Care

I: Inspect and if necessary, adjust, correct, clean or replace.

R: Replace or change.

Maintenance intervals	Number of months or driving distance, whichever comes first									
	Months		12	24	36	48	60	72	84	96	108
	mi.×1,000		10	20	30	40	50	60	70	80	90
	km×1,000		15	30	45	60	75	90	105	120	135
Maintenance item											
High Voltage Battery	Insulation resistance check		I	I	I	I	I	I	I	I	I
	Voltage deviation check		I	I	I	I	I	I	I	I	I
Cooling System	Air-cooled	Coolant amount check	I	I	I	I	I	I	I	I	I
	Water cooling	Coolant amount check	I	I	I	I	I	I	I	I	I
		EWP operation status check	I	I	I	I	I	I	I	I	I
		3way valve operation check	I	I	I	I	I	I	I	I	I
DTC	Fault code check (Full DTC scanning)		I	I	I	I	I	I	I	I	I
Lower body	Battery lower part damage check		I	I	I	I	I	I	I	I	I
	High voltage cable damage check		I	I	I	I	I	I	I	I	I