Normal maintenance schedule (except Europe, but including Russia)

I: Inspect and if necessary, adjust, correct, clean or replace.

R: Replace or change.

Maintenance intervals	Number of months or driving distance, whichever comes first								
	Months	12	24	36	48	60	72	84	96
	Miles×1,000	6	12	18	24	30	36	42	48
	km×1,000	10	20	30	40	50	60	70	80
Maintenance item									
Engine oil and engine oil filter*1*2		R	R	R	R	R	R	R	R
Drive belts*3			I		I		I		I
Fuel additives*4		Add every 10,000 km (6,000 miles) or 12 months							

*1: The engine oil level should be checked regularly and maintained properly. Operating with an insufficient amount of oil can damage the engine, and such damage is not covered by warranty.

*2: Never add any additives to the engine oil. Engine oil additives can change the properties of engine oil and may cause serious engine failure.

*3: Inspect drive belt tensioner, idler and alternator pulley and if necessary correct or replace.

*4: If good quality gasolines meet Europe Fuel standards (EN228) or equivalents including fuel additives is not available, one bottle of additive is recommended. Additives are available from your an authorized retailer of Genesis Branded products along with information on how to use them. Do not mix other additives.

i Information

- 2.5 T-GDI

  Requires <API SN PLUS (or above) Full synthetic> grade engine oil. If a lower grade engine oil (mineral oil including semi-synthetic) is used, replace the engine oil and engine oil filter as indicated in maintenance under severe usage conditions.

- 3.5 T-GDI
  - Except Middle East, Livia, Algeria, Iran, Morocco, Sudan, Tunisia, Egypt, India

    Requires <API SN PLUS (or above) Full synthetic> grade engine oil. If a lower grade engine oil (mineral oil including semi-synthetic) is used, replace the engine oil and engine oil filter as indicated in maintenance under severe usage conditions.
  - For Middle East, Livia, Algeria, Iran, Morocco, Sudan, Tunisia, Egypt, India

    Requires <API SN PLUS (or above) or ACEA A5/B5 Full synthetic or ILSAC GF-6> grade engine oil. If a lower grade engine oil (mineral oil including Semi-synthetic) is used, then the engine oil and engine oil filter must be replaced as indicated severe maintenance condition.

I: Inspect and if necessary, adjust, correct, clean, or replace.
R: Replace or change.

Maintenance intervals	Number of months or driving distance, whichever comes first								
	Months	12	24	36	48	60	72	84	96
	Miles×1,000	6	12	18	24	30	36	42	48
	km×1,000	10	20	30	40	50	60	70	80
Maintenance item									
Air cleaner filter	Except Middle East	I	I	R	I	I	R	I	I
	For Middle East	R	R	R	R	R	R	R	R
Spark plugs*1		Replace every 70,000 km (42,000 miles)							
Vapor hose and fuel filler cap							I		
Fuel tank air filter				I			R		
Fuel lines, hoses and connections							I		

*1: For your convenience, it can be replaced prior to it's interval when you do maintenance of other items.

i Information

Fuel filter is considered to be maintenance free but the quality of fuel used may impact the frequency of maintenance needed. If there are some important safety matters like fuel flow restriction, surging, loss of power, hard starting problem, etc. replace the fuel filter immediately regardless of maintenance schedule and consult an authorized retailer of Genesis Branded products for details.

General items

I: Inspect and if necessary, adjust, correct, clean, or replace.

R: Replace or change.

Maintenance intervals		Number of months or driving distance, whichever comes first							
	Months	12	24	36	48	60	72	84	96
	Miles×1,000	6	12	18	24	30	36	42	48
	km×1,000	10	20	30	40	50	60	70	80
Maintenance item									
Cooling system		I	I	I	I	I	I	I	I
Engine coolant*1		At first, replace at 200,000 km (120,000 miles) or 10 years: after that, replace every 40,000 km (24,000 miles) or 24 months							
Battery condition	Except Middle East	I	I	I	I	I	I	I	I
	For Middle East	Inspect every 10,000 km (6,000 miles) or 6 months							
Pan-European eCall system battery (if equipped) / ERA-GLONASS system battery (if equipped) / UAE eCall system battery (if equipped)		Replace every 4 years							
Brake lines, hoses and connections		I	I	I	I	I	I	I	I
Brake pedal			I		I		I		I
Parking brake			I		I		I		I
Brake fluid		I	I	I	R	I	I	I	R

*1: When adding coolant, use only deionized water or soft water for your vehicle and never mix hard water in the coolant filled at the factory. An improper coolant mixture can result in serious malfunction or engine damage. For your convenience, it can be replaced prior to it's interval when you do maintenance of other items.

I: Inspect and if necessary, adjust, correct, clean, or replace.
R: Replace or change.

Maintenance intervals		Number of months or driving distance, whichever comes first							
	Months	12	24	36	48	60	72	84	96
	Miles×1,000	6	12	18	24	30	36	42	48
	km×1,000	10	20	30	40	50	60	70	80
Maintenance item									
Disc brakes and pads		I	I	I	I	I	I	I	I
Steering gear rack, linkage and boots		I	I	I	I	I	I	I	I
Driveshaft and boots			I		I		I		I
Tire (pressure & tread wear)		I	I	I	I	I	I	I	I
Suspension ball joints		I	I	I	I	I	I	I	I
Air conditioner refrigerant		I	I	I	I	I	I	I	I
Air conditioner compressor		I	I	I	I	I	I	I	I
Cabin air filter		R	R	R	R	R	R	R	R
Automatic transmission fluid	For Middle East		I		I		I		I
	Except Middle East	No check, No service required							
Exhaust system			I		I		I		I
Front differential oil (AWD) / Rear differential oil*1							I		
Transfer case oil (AWD)		No check, No service required							
Electronic Limited Slip Differential (e-LSD) oil		No check, No service required							
Propeller shaft			I		I		I		I

*1: Front and rear differential oil should be changed anytime the front or rear differential has been submerged in water.