i Information

- As it is normal for engine oil to be consumed during driving, the engine oil level should be checked on regular basis.
- The engine oil change interval under normal operating conditions is based on the use of engine oil that meets the recommended engine specification for your vehicle. If any other type of engine oil is used, replace the engine oil according to the maintenance schedule under severe operating conditions.
- The vehicle may be equipped with the Oil Life Management System that predicts engine oil life based on the driver's driving history and alerts the driver to change engine oil.
  - If the deterioration of the engine oil increases depending on the driver's driving severity, the remaining oil life alert appears on the instrument cluster before the normal engine oil replacement interval. We recommend that the engine oil and filter be changed by an authorized retailer of Genesis Branded products.
  - Oil Life Management System works when the recommended engine oil is used. So, if recommended engine oil is not used, replace the engine oil according to the maintenance schedule under severe usage conditions.

    Also, check the amount of engine oil regularly as this system assumes that the engine oil is being filled normally.
  - Always reset the remaining engine oil life whenever the engine oil is changed. Otherwise, the indication of remaining Oil life in the Oil Life Management System may not be accurate.

    To reset the Oil Change Reminder, select "**RESET**" from the infotainment system screen. Then, select "**Yes**" when the message "**Has the engine oil been changed? Press [Yes] to reset the oil life.**" appears on the screen.
  - If there is no alert until the maximum maintenance interval, we recommend that vehicle be checked by an authorized retailer of Genesis Branded product.

Normal maintenance schedule (except Europe, but including Russia)

I: Inspect and if necessary, adjust, correct, clean or replace.

R: Replace or change.

Maintenance intervals	Number of months or driving distance, whichever comes first								
	Months	12	24	36	48	60	72	84	96
	Miles×1,000	6	12	18	24	30	36	42	48
	km×1,000	10	20	30	40	50	60	70	80
Maintenance item									
Engine oil and engine oil filter *1 *2 *3 *4	R	R	R	R	R	R	R	R	
Drive belts *5		I		I		I		I	
Fuel additives *6	Add every 10,000 km (6,000 mi.) or 12 months								

*1: The engine oil level should be checked regularly and maintained properly. Operating with an insufficient amount of oil can damage the engine, and such damage is not covered by warranty.

*2: Check the engine oil level and leak every 500 km (350 mi.) or before starting a long trip.

*3: 3.5 T-GDI/2.5 T-GDI

*4: Never add any additives to the engine oil. Engine oil additives can change the properties of engine oil and may cause serious engine failure.

*5: Inspect drive belt tensioner, idler and alternator pulley and if necessary correct or replace.

*6: If good quality gasolines meet Europe Fuel standards (EN228) or equivalents including fuel additives is not available, one bottle of additive is recommended. Additives are available from your an authorized retailer of Genesis Branded products along with information on how to use them. Do not mix other additives.

i Information

- 3.5 T-GDI
  - Except Middle East, Livia, Algeria, Iran, Morocco, Sudan, Tunisia, Egypt, India

    Requires <API SN PLUS (or above) Full synthetic> grade engine oil. If a lower grade engine oil (mineral oil including semi-synthetic) is used, replace the engine oil and engine oil filter as indicated in maintenance under severe usage conditions.
  - For Middle East, Livia, Algeria, Iran, Morocco, Sudan, Tunisia, Egypt, India

    Requires <API SN PLUS (or above) or ACEA A5/B5 Full synthetic or ILSAC GF-6> grade engine oil. If a lower grade engine oil (mineral oil including semi-synthetic) is used, replace the engine oil and engine oil filter as indicated in maintenance under severe usage conditions.
- 2.5 T-GDI

  Requires <API SN PLUS (or above) Full synthetic> grade engine oil. If a lower grade engine oil (mineral oil including semi-synthetic) is used, replace the engine oil and engine oil filter as indicated in maintenance under severe usage conditions.

I: Inspect and if necessary, adjust, correct, clean, or replace.
R: Replace or change.

Maintenance intervals	Number of months or driving distance, whichever comes first								
	Months	12	24	36	48	60	72	84	96
	Miles×1,000	6	12	18	24	30	36	42	48
	km×1,000	10	20	30	40	50	60	70	80
Maintenance item									
Air cleaner filter	Except Middle East	I	I	R	I	I	R	I	I
	For Middle East	R	R	R	R	R	R	R	R
Spark plugs *1		Replace every 70,000 km (42,000 mi.)							
Vapor hose and fuel filler cap							I		
Fuel tank air filter				I			R		
Fuel lines, hoses and connections							I		

*1: For your convenience, it can be replaced prior to it's interval when you do maintenance of other items.

I: Inspect and if necessary, adjust, correct, clean, or replace.
R: Replace or change.

Maintenance intervals	Number of months or driving distance, whichever comes first								
	Months	12	24	36	48	60	72	84	96
	Miles×1,000	6	12	18	24	30	36	42	48
	km×1,000	10	20	30	40	50	60	70	80
Maintenance item									
Cooling system		I	I	I	I	I	I	I	I
Engine coolant *1		At first, replace at 200,000 km (120,000 mi.) or 10 years, after that, replace every 40,000 km (24,000 mi.) or 24 months							
All electrical systems		I	I	I	I	I	I	I	I

Maintenance intervals	Number of months or driving distance, whichever comes first								
	Months	12	24	36	48	60	72	84	96
	Miles×1,000	6	12	18	24	30	36	42	48
	km×1,000	10	20	30	40	50	60	70	80
Maintenance item									
Battery condition	Except Middle East	I	I	I	I	I	I	I	I
	For Middle East	Inspect every 10,000 km (6,000 mi.) or 6 months							
ERA-GLONASS system battery (if equipped) / UAE eCall system battery (if equipped)		Replace every 4 years							
Brake lines, hoses and connections		I	I	I	I	I	I	I	I
Brake pedal			I		I		I		I
Parking brake			I		I		I		I
Brake fluid		I	I	I	R	I	I	I	R

*1: When adding coolant, use only deionized water or soft water for your vehicle and never mix hard water in the coolant filled at the factory. An improper coolant mixture can result in serious malfunction or engine damage. For your convenience, it can be replaced prior to it's interval when you do maintenance of other items.

I: Inspect and if necessary, adjust, correct, clean, or replace.

R: Replace or change.

Maintenance intervals	Number of months or driving distance, whichever comes first								
	Months	12	24	36	48	60	72	84	96
	Miles×1,000	6	12	18	24	30	36	42	48
	km×1,000	10	20	30	40	50	60	70	80
Maintenance item									
Disc brakes and pads		I	I	I	I	I	I	I	I
Steering gear rack, linkage and boots		I	I	I	I	I	I	I	I
Driveshaft and boots			I		I		I		I
Tire (pressure & tread wear)		I	I	I	I	I	I	I	I

Maintenance intervals		Number of months or driving distance, whichever comes first							
	Months	12	24	36	48	60	72	84	96
	Miles×1,000	6	12	18	24	30	36	42	48
	km×1,000	10	20	30	40	50	60	70	80
Maintenance item									
Suspension ball joints		I	I	I	I	I	I	I	I
Air conditioner refrigerant		I	I	I	I	I	I	I	I
Air conditioner compressor		I	I	I	I	I	I	I	I
Cabin air filter		R	R	R	R	R	R	R	R
Automatic transmission fluid	For Middle East		I		I		I		I
	Except Middle East	No check, No service required							
Exhaust system			I		I		I		I
Front differential oil (AWD) / Rear differential oil *1							I		I
Transfer case oil (AWD)		No check, No service required							
Electronic Limited Slip Differential (e-LSD) oil		No check, No service required							
Propeller shaft			I		I		I		I

*1: Front and rear differential oil should be changed anytime the front or rear differential has been submerged in water.

Maintenance under severe usage conditions (except Europe, but including Russia)

The following items must be serviced more frequently on the vehicles mainly used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

R: Replace

I: Inspect and if necessary, adjust, correct, clean, or replace

Maintenance item	Maintenance operation	Maintenance intervals	Driving condition
Engine oil and engine oil filter	R	Replace every 5,000 km (3,000 mi.) or 6 months	D, H, I, L
Air cleaner filter	R	Replace more frequently depending on the condition	C, E
Spark plugs	R	Replace more frequently depending on the condition	A, B, F, G, H, I, K
Steering gear rack, linkage and boots	I	Inspect more frequently depending on the condition	C, D, E, F, G
Suspension ball joints	I	Inspect more frequently depending on the condition	C, D, E, F, G
Disc brakes and pads, calipers and rotors	I	Inspect more frequently depending on the condition	C, D, E, G, H
Parking brake	I	Inspect more frequently depending on the condition	C, D, G, H
Driveshaft and boots	I	Inspect more frequently depending on the condition	C, D, E, F, G, H, I, J
Cabin air filter	R	Replace more frequently depending on the condition	C, E, G
Automatic transmission fluid	R	Replace every 100,000 km (60,000 mi.)	A, C, F, G, H, I, K
Front differential oil (AWD) / Rear differential oil	R	Replace every 120,000 km (80,000 mi.)	C, D, E, G, H, I, J
Transfer case oil (AWD)	-	No check, No service required	-
Electronic Limited Slip Differential (e-LSD) oil	-	No check, No service required	-
Propeller shaft	I	Inspect more frequently depending on the condition	C, D, E, F, G, H, I, J

Severe driving conditions

- A. Repeatedly driving short distance of less than 8 km (5 mi.) in normal temperature or less than 16 km (10 mi.) in freezing temperature
- B. Extensive engine idling or low speed driving for long distances
- C. Driving on rough, dusty, muddy, unpaved, graveled, or salt-spread roads

- D. Driving in areas using salt or other corrosive materials or in very cold weather
- E. Driving in heavy dust conditions
- F. Driving in heavy traffic area
- G. Driving on uphill, downhill, or mountain roads repeatedly
- H. Towing a trailer or using a camper, or driving with loads on the roof
- I. Driving for patrol car, taxi, or other commercial use of vehicle towing
- J. Frequently driving at high speeds or rapid acceleration/deceleration
- K. Frequently driving in stop-and-go conditions
- L. Using engine oil that is not recommended (mineral type, semi-synthetic, lower grade spec, etc.)

Normal maintenance schedule (for Europe)

I: Inspect and if necessary, adjust, correct, clean, or replace.

R: Replace or change.

Maintenance intervals	Number of months or driving distance, whichever comes first								
	Months	24	48	72	96	120	144	168	192
	Miles×1,000	20	40	60	80	100	120	140	160
	km×1,000	30	60	90	120	150	180	210	240
Maintenance item									
Engine oil and engine oil filter *1 *2 *3 *7	Replace every 10,000 km (6,500 mi.) or 12 months								
Drive belts *4	At first, inspect at 90,000 km (60,000 mi.) or 72 months, after that, every 30,000 km (20,000 mi.) or 24 months								
Fuel additives *5	Replace every 10,000 km (6,500 mi.) or 12 months								
Air cleaner filter	I	R	I	R	I	R	I	R	
Spark plugs *6	Replace every 70,000 km (45,500 mi.)								
Vapor hose and fuel filler cap		I		I		I		I	
Fuel tank air filter		I		I		I		I	
Fuel lines, hoses and connections		I		I		I		I	

*1: The engine oil level should be checked regularly and maintained properly. Operating with an insufficient amount of oil can damage the engine, and such damage is not covered by warranty.

*2: Check the engine oil level and leak every 500 km (350 mi.) or before starting a long trip.