Normal maintenance schedule (except Europe, but including Russia)

I : Inspect and if necessary, adjust, correct, clean or replace.

R : Replace or change.

MAINTENANCE INTERVALS	Number of months or driving distance, whichever comes first								
	Months	12	24	36	48	60	72	84	96
	Milesx1,000	6	12	18	24	30	36	42	48
	Kmx1,000	10	20	30	40	50	60	70	80
MAINTENANCE ITEM									
Engine oil and engine oil filter*1*2*5		R	R	R	R	R	R	R	R
Drive belts *3			I		I		I		I
Fuel additives *4		Add every 10,000 km (6,000 miles) or 12 months							
Intercooler, in/out hose		At first, Inspect at 10,000 km (6,000 miles) or 6 months After that, Inspect every 30,000 km (18,000 miles) or 24 months							
Air intake hose		At first, Inspect at 10,000 km (6,000 miles) or 12 months After that, Inspect every 30,000 km (18,000 miles) or 36 months							

*1: The engine oil level should be checked regularly and maintained properly. Operating with an insutticient amount of oil can damage the engine, and such damage is not covered by warranty.

*2: Check the engine oil level and leak every 500 km (350 miles) or before starting a long trip.

*3: Inspect drive belt tensioner, idler and alternator pulley and if necessary correct or replace.

*4:If good quality gasolines meet Europe Fuel standards (EN228) or equivalents including fuel additives is not available, one bottle of additive is recommended. Additives are available from your an authorized retailer of Genesis Branded products along with information on how to use them. Do not mix other additives.

*5: Never add any additives to the engine oil. Engine oil additives can change the properties of engine oil and may cause serious engine failure.

I : Inspect and if necessary, adjust, correct, clean or replace.
R : Replace or change.

MAINTENANCE INTERVALS	Number of months or driving distance, whichever comes first								
	Months	12	24	36	48	60	72	84	96
	Milesx1,000	6	12	18	24	30	36	42	48
	Kmx1,000	10	20	30	40	50	60	70	80
MAINTENANCE ITEM									
Air cleaner filter	Except Middle East	I	I	R	I	I	R	I	I
	For Middle East	R	R	R	R	R	R	R	R
Valve clearance **2		Inspect every 90,000 km (54,000 miles) or 72 months							
Spark plugs *1		Replace every 70,000 km (42,000 miles)							
Vapor hose and fuel filler cap							I		
Vacuum hose		I	I	I	I	I	I	I	I
Fuel tank air filter				I			R		
Fuel lines, hoses and connections							I		

*1: For your convenience, it can be replaced prior to it's interval when you do maintenance of other items.
*2: Inspect for excessive valve noise and/or engine vibration and adjust if necessary. We recommend that the system be checked by an authorized retailer of Genesis Branded products.

i Information

The fuel filter is considered to be maintenance free but the quality of fuel used may impact the frequency of maintenance needed. If there are some important safety matters like fuel flow restriction, surging, loss of power, hard starting problem, etc. replace the fuel filter immediately regardless of maintenance schedule and consult an authorized retailer of Genesis Branded products for details.

I : Inspect and if necessary, adjust, correct, clean or replace.
R : Replace or change.

MAINTENANCE INTERVALS		Number of months or driving distance, whichever comes first							
	Months	12	24	36	48	60	72	84	96
	Milesx1,000	6	12	18	24	30	36	42	48
	Kmx1,000	10	20	30	40	50	60	70	80
MAINTENANCE ITEM									
Cooling system		I	I	I	I	I	I	I	I
Engine coolant *1		At first, replace at 200,000 km (120,000 miles) or 10 years: after that, replace every 40,000 km (24,000 miles)							
Battery condition	Except Middle East	I	I	I	I	I	I	I	I
	For Middle East	Inspect every 10,000 km (6,000 miles) or 6 months							
All electrical system		I	I	I	I	I	I	I	I
ERA-GLONASS system battery		Replace every 3 years							
Brake lines, hoses and connections		I	I	I	I	I	I	I	I
Brake pedal			I		I		I		I
Parking brake			I		I		I		I
Brake fluid		I	I	I	R	I	I	I	R

*1: When adding coolant, use only deionized water or soft water for your vehicle and never mix hard water in the coolant filled at the factory. An improper coolant mixture can result in serious malfunction or engine damage. For your convenience, it can be replaced prior to it's interval when you do maintenance of other items.

I : Inspect and if necessary, adjust, correct, clean or replace.
R : Replace or change.

MAINTENANCE INTERVALS		Number of months or driving distance, whichever comes first							
	Months	12	24	36	48	60	72	84	96
	Milesx1,000	6	12	18	24	30	36	42	48
	Kmx1,000	10	20	30	40	50	60	70	80
MAINTENANCE ITEM									
Disc brakes and pads		I	I	I	I	I	I	I	I
Steering gear rack, linkage and boots		I	I	I	I	I	I	I	I
Driveshaft and boots			I		I		I		I
Tire (pressure & tread wear)		I	I	I	I	I	I	I	I
Front suspension ball joints		I	I	I	I	I	I	I	I
Air conditioner refrigerant		I	I	I	I	I	I	I	I
Air conditioner compressor		I	I	I	I	I	I	I	I
Cabin air filter		R	R	R	R	R	R	R	R
Automatic transmission fluid	For Middle East		I		I		I		I
	Except Middle East	No check, No service required							
Exhaust system			I		I		I		I
Front differential oil (AWD)*							I		
Rear differential oil*1*2							I		
							R		
Propeller shaft			I		I		I		I
Transfer case oil (AWD)		No check, No service required							

*1: Front/Rear differential oil should be changed anytime they have been submerged in water.
*2: When replacing differential oil with LSD (Limited Slip Differential), use only specified LSD oil.