





Enable Vi2 Camera

• A yellow icon indicates Vi1 camera is enabled, while a gray icon means Vi2 camera is enabled. Note: When using dual cameras, ensure both cameras have the same format. Inconsistent formats may cause the OSD to fail to appear. Reflashing firmware or restoring the default factory settings requires manually entering the following commands in Betaflight CLI: VTX_ON_OFF Mode command: Camera switch command: resource PINIO 1 CO resource PINIO 2 C14

set box user 1 name = VTX ON OFF aux 0 40 8 900 2100 0 0

set pinio_config = 1,1,1,1

set pinio_box = 40,41,255,255

Add Range

GPS

set pinio_config = 1,1,1,1

aux 1 41 9 900 2100 0 0

save

set pinio_box = 40,41,255,255

set box user 2 name = CAM SW



