CineLR 7 SONY相机 机架组装示意图 Frame Assembly Guide

1. 相机前固定板 CNC Camera front mounting plate CNC	x1
2. 底座 CNC Base CNC	x1
3. 相机底座 CNC Camera base plate CNC	x1
4. 相机升降架 CNC Camera lift mount CNC	x2
5. 相机后板 CNC Camera rear plate CNC	x1
6. 相机垫片A打印件 Camera spacer A TPU	x1
7. 相机垫片B打印件 Camera spacer B TPU	x1
8. 相机垫片C打印件 Camera spacer C TPU	x1
9. 橡皮筋 Rubber band	x2
10. M3*6 沉头内六角螺丝 M3*6 countersunk hex screw	x2
11. M3*7 内六角螺丝 M3*7 hex screw	x4
12. M3*6 内六角螺丝 M3*6 hex screw	x2
13.内六角塞打螺丝 ¢ 3*M2.5*3 (\$ 3*M2.5*3 hex shoulder screw	x2
14. M3*8 内六角螺丝 M3*8 hex screw	x4
15. 快装板螺丝 Screws for quick release	x1

附赠 Additional parts

Additional parts	
16. ^{橡皮筋} Rubber band	x2
17. M3*6 沉头内六角螺丝 M3*6 countersunk hex screw	x1
18. M3*7 内六角螺丝 M3*7 hex screw	x2
19. M3*6 内六角螺丝 M3*6 hex screw	x1
20. M3*8 内六角螺丝 M3*8 hex screw	x2
21. 快装板螺丝 Screws for quick release	x1

