

**Danfoss**



# Instruction Manual



VLT® 5000





## VLT® 5000 Series

### ■ Contents

<b>Safety</b>	4
Safety regulations	5
Warning against unintended start	5
Installation of mechanical brake	5
<b>Technical data</b>	6
General technical data	6
Electrical data	13
Fuses	33
<b>Dimensions</b>	41
Mechanical dimensions	41
<b>Installation</b>	44
Mechanical installation	44
Electrical installation - mains supply	58
Safety grounding	58
Extra protection (RCD)	58
RFI switch	58
Installation of motor cables	62
Connection of motor	62
Direction of motor rotation	62
Electrical installation - brake cable	63
Electrical installation - relay outputs	63
Electrical installation - 24 Volt external DC supply	63
Electrical installation - load sharing	63
Electrical installation - brake resistor temperature switch	64
Electrical installation - bus connection	64
Installation of control cables	65
Connection examples	68
<b>Operation of the VLT</b>	71
Control panel (LCP)	71
Control panel - display	71
Control panel - LEDs	72
Control panel - control keys	72
Quick Setup	75
Parameter selection	75
Menu mode	75
Manual initialization	77
<b>Programming</b>	79
Operation & Display	79



## VLT® 5000 Series

Load and motor	87
References and limits	100
Parameters - Inputs and outputs	109
Special functions	125
Parameters - Serial communication	141
Parameters - Technical functions and diagnostics	149
<b>Messages</b>	156
Trouble-shooting	156
Display - Status messages	157
Warnings and alarms	160
Warnings	161
<b>Examples of use</b>	168
Conveyor belt	168
Pump	169
Gantry Crane	170
Torque control, speed feedback	171
VLT 5000 controllers	172
PID for process control	174
PID for speed control	175
PID for torque controller (open loop)	176
<b>EC/EMC</b>	177
CE labelling	177
Electrical Installation	181
Electrical installation - EMC precautions	181
Electrical installation, selection of EMC-correct cables	184
<b>List of functions</b>	185
Setting of parameters	185
Local and remote control	188
Control with brake function	189
References - single references	190
References - multi-references	192
Automatic Motor Adaptation, AMA	196
Mechanical brake control	198
PID for process control	200
PID for speed control	201
Quick discharge	202
Flying start	204
Normal/high overload torque control, open loop	206
Programming of Torque limit and stop	206
Galvanic Isolation (PELV)	207
Extreme Running Conditions	209



---

## VLT® 5000 Series

---

Peak voltage on motor	210
Switching on the input	211
Motor thermal protection	215
Vibration and Shock	215
Air Humidity	215
Aggressive environments	216
Efficiency	217
Interference, Power factor	219
<b>Parameters</b>	220
<b>Miscellaneous</b>	229
<b>Index</b>	232

## VLT 5000 Series

Instruction Manual

Software version: 3.9x



This Instruction Manual can be used for all VLT 5000 Series adjustable frequency drives with software version 3.9x.

The software version number can be seen from parameter 624.

CE and C-tick labeling do not cover VLT 5001-5062, 525-600 V units.



The VLT Adjustable Frequency Drive contains dangerous voltages when connected to line voltage. After disconnecting from the line wait at least 15 minutes before touching any electrical components. Also make sure that other voltage inputs have been disconnected, such as external 24 VDC, load-sharing (linkage of DC intermediate circuit), as well as the motor connection for kinetic back-up. Only a competent electrician should carry out the electrical installation. Improper installation of the motor or the VLT may cause equipment failure, serious injury or death. Follow this manual and National Electrical Codes (NEC®) and local safety codes.



It is the responsibility of the user or the person installing the VLT to provide proper grounding, as well as motor overload and branch circuit protection according to the National Electrical Code (NEC®) and local codes.



By altitudes above 2000 m, please contact Danfoss Drives regarding PELV.

**NOTE**

Electrostatic Precaution; Electrostatic discharge (ESD). Many electronic components are sensitive to static electricity. Voltages so low that they cannot be felt, seen or heard, can reduce the life, affect performance, or completely destroy sensitive electronic components. When performing service, proper ESD equipment should be used to prevent possible damage from occurring.

**■ Safety regulations**

1. The frequency converter must be disconnected from mains if repair work is to be carried out. Check that the mains supply has been disconnected and that the necessary time has passed before removing motor and mains plugs.
2. The [STOP/RESET] key on the control panel of the frequency converter does not disconnect the equipment from mains and is thus not to be used as a safety switch.
3. Correct protective earthing of the equipment must be established, the user must be protected against supply voltage, and the motor must be protected against overload in accordance with applicable national and local regulations.
4. The earth leakage currents are higher than 3.5 mA.
5. Protection against motor overload is not included in the factory setting. If this function is desired, set parameter 128 to data value *ETR trip* or data value *ETR warning*.  
Note: The function is initialised at 1.16 x rated motor current and rated motor frequency. For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.
6. Do not remove the plugs for the motor and main supply while the frequency converter is connected to mains. Check that the mains supply has been disconnected and that the necessary time has expired before removing motor and mains plugs.
7. Please note that the frequency converter has more voltage inputs than L1, L2 and L3, when loadsharing (linking of DC intermediate circuit) and external 24 V DC have been installed. Check that all voltage inputs have been disconnected and that the necessary time has passed before repair work is commenced.

**■ Warning against unintended start**

1. The motor can be brought to a stop by means of digital commands, bus commands, references or a local stop, while the adjustable frequency drive is connected to the AC line. These stop functions are NOT sufficient to ensure that no unintended start occurs and should NOT be used for personal safety considerations.
2. While parameters are being changed, the motor may start. Consequently, the stop key "Stop/Reset" must always be activated, following which data can be modified.
3. A motor that has been stopped may start if faults occur in the electronics of the adjustable frequency drive, or if a temporary overload or a fault in the AC line supply or the motor connection ceases.

**■ Installation of mechanical brake**

Do not connect a mechanical brake to the output from the frequency converter before the relevant parameters for brake control are parameterised.

(Selection of output in parameter 319, 321, 323 or 326 and cut-in current and frequency in parameter 223 and 225).

**■ Use on isolated AC line**

See section *RFI Switch* regarding use on isolated AC line.

It is important to follow the recommendations regarding installation on IT line, since sufficient protection of the complete installation must be observed. Not taking care using relevant monitoring devices for IT line supply may result in damage.



## VLT® 5000 Series

### ■ General technical data

AC line supply (L1, L2, L3):

Supply voltage 200-240 V units	3 x 200/208/220/230/240 V ±10%
Supply voltage 380-500 V units	3 x 380/400/415/440/460/500 V ±10%
Supply voltage 525-600 V units	3 x 525/550/575/600 V ±10%
Supply voltage 525-690 V units	3 x 525/550/575/600/690 V ±10%
Supply frequency	48-62 Hz +/- 1 %

See the section on special conditions in the Design Guide

Max. imbalance of supply voltage:

VLT 5001-5011, 380-500 V and 525-600 V and VLT 5001-5006, 200-240 V	±2.0% of rated supply voltage
VLT 5016-5062, 380-500 V and 525-600 V and VLT 5008-5027, 200-240 V	±1.5% of rated supply voltage
VLT 5072-5500, 380-500 V and VLT 5032-5052, 200-240 V	±3.0% of rated supply voltage
VLT 5075-5250, 525-600 V	±3.0% of rated supply voltage
True Power factor ( $\lambda$ )	0.90 nominal at rated load
Displacement Power Factor ( $\cos \phi$ )	near unity (>0.98)
No. of switches on supply input L1, L2, L3	approx. 1 time/2 min.
Max. shortcircuit rating	100,000 A

VLT output data (U, V, W):

Output voltage	0-100% of supply voltage
Output frequency VLT 5001-5027, 200-240 V	0-132 Hz, 0-1000 Hz
Output frequency VLT 5032-5052, 200-240 V	0-132 Hz, 0-450 Hz
Output frequency VLT 5001-5052, 380-500 V	0-132 Hz, 0-1000 Hz
Output frequency VLT 5062-5302, 380-500 V	0-132 Hz, 0-450 Hz
Output frequency VLT 5352-5552, 380-500 V	0-132 Hz, 0-300 Hz
Output frequency VLT 5001-5011, 525-600 V	0-132 Hz, 0-700 Hz
Output frequency VLT 5016-5052, 525-600 V	0-132 Hz, 0-1000 Hz
Output frequency VLT 5062, 525-600 V	0-132 Hz, 0-450 Hz
Output frequency VLT 5042-5302, 525-690 V	0-132 Hz, 0-200 Hz
Output frequency VLT 5352-5602, 525-690 V	0-132 Hz, 0-150 Hz
Rated motor voltage, 200-240 V units	200/208/220/230/240 V
Rated motor voltage, 380-500 V units	380/400/415/440/460/480/500 V
Rated motor voltage, 525-600 V units	525/550/575 V
Rated motor voltage, 525-690 V units	525/550/575/690 V
Rated motor frequency	50/60 Hz
Switching on output	Unlimited
Ramp times	0.05-3600 sec.

Torque characteristics:

Starting torque, VLT 5001-5027, 200-240 V and VLT 5001-5552, 380-500 V	160% for 1 min.
Starting torque, VLT 5032-5052, 200-240 V	150% for 1 min.
Starting torque, VLT 5001-5062, 525-600 V	160% for 1 min.
Starting torque, VLT 5042-5602, 525-690 V	160% for 1 min.
Starting torque	180% for 0.5 sec.
Acceleration torque	100%
Overload torque, VLT 5001-5027, 200-240 V and VLT 5001-5552, 380-500 V, VLT 5001-5062, 525-600 V, and VLT 5042-5602, 525-690 V	160%



## VLT® 5000 Series

Overload torque, VLT 5032-5052, 200-240 V	150%
Arresting torque at 0 rpm (closed loop)	100%

The torque characteristics given are for the adjustable frequency drive at the high overload torque level (160%). At the normal overload torque (110%), the values are lower.

### Braking at high overload torque level

	Cycle time (s)	Braking duty cycle at 100% torque	Braking duty cycle at over torque (150/160%)
<b>200-240 V</b>			
5001-5027	120	Continuous	40%
5032-5052	300	10%	10%
<b>380-500 V</b>			
5001-5102	120	Continuous	40%
5122-5252	600	Continuous	10%
5302	600	40%	10%
5352-5552	600	40% <sup>1)</sup>	10% <sup>2)</sup>
<b>525-600 V</b>			
5001-5062	120	Continuous	40%
<b>525-690 V</b>			
5042-5352	600	40%	10%
5402-5602	600	40% <sup>3)</sup>	10% <sup>4)</sup>

1) VLT 5502 at 90% torque. At 100% torque the braking duty cycle is 13%. At mains rating 441-500 V 100% torque the braking duty cycle is 17%.

VLT 5552 at 80% torque. At 100% torque the braking duty cycle is 8%.

2) Based on 300 second cycle:

For VLT 5502 the torque is 145%.

For VLT 5552 the torque is 130%.

3) VLT 5502 at 80% torque.

VLT 5602 at 71% torque.

4) Based on 300 second cycle.

For VLT 5502 the torque is 128%.

For VLT 5602 the torque is 114%.

Technical data

### Control card, digital inputs:

Number of programmable digital inputs	8
Terminal nos.	16, 17, 18, 19, 27, 29, 32, 33
Voltage level	0-24 V DC (PNP positive logics)
Voltage level, logical '0'	< 5 V DC
Voltage level, logical '1'	>10 V DC
Maximum voltage on input	28 V DC
Input resistance, $R_i$	2 k $\Omega$
Scanning time per input	3 msec.

*Reliable galvanic isolation: All digital inputs are galvanically isolated from the supply voltage (PELV). In addition, the digital inputs can be isolated from the other terminals on the control card by connecting an external 24 V DC supply and opening switch 4. VLT 5001-5062, 525-600 V do not meet PELV.*

### Control card, analog inputs:

No. of programmable analog voltage inputs/thermistor inputs	2
Terminal nos.	53, 54
Voltage level	0 - ±10 V DC (scalable)
Input resistance, $R_i$	10 k $\Omega$
No. of programmable analog current inputs	1
Terminal no.	60
Current range	0/4 - ±20 mA (scalable)



## VLT® 5000 Series

Input resistance, $R_i$	200 $\Omega$
Resolution	10 bit + sign
Accuracy on input	Max. error 1% of full scale
Scanning time per input	3 msec.
Terminal no. ground	55

*Reliable galvanic isolation: All analog inputs are galvanically isolated from the supply voltage (PELV)\* as well as other inputs and outputs.*

\* VLT 5001-5062, 525-600 V do not meet PELV.

### Control card, pulse/encoder input:

No. of programmable pulse/encoder inputs	4
Terminal nos.	17, 29, 32, 33
Max. frequency on terminal 17	5 kHz
Max. frequency on terminals 29, 32, 33	20 kHz (PNP open collector)
Max. frequency on terminals 29, 32, 33	65 kHz (Push-Pull)
Voltage level	0-24 V DC (PNP positive logics)
Voltage level, logical '0'	< 5 V DC
Voltage level, logical '1'	>10 V DC
Maximum voltage on input	28 V DC
Input resistance, $R_i$	2 k $\Omega$
Scanning time per input	3 msec.
Resolution	10 bit + sign
Accuracy (100-1 kHz), terminals 17, 29, 33	Max. error: 0.5% of full scale
Accuracy (1-5 kHz), terminal 17	Max. error: 0.1% of full scale
Accuracy (1-65 kHz), terminals 29, 33	Max. error: 0.1% of full scale

*Reliable galvanic isolation: All pulse/encoder inputs are galvanically isolated from the supply voltage (PELV)\*. In addition, pulse and encoder inputs can be isolated from the other terminals on the control card by connecting an external 24 V DC supply and opening switch 4.*

\* VLT 5001-5062, 525-600 V do not meet PELV.

### Control card, digital/pulse and analog outputs:

No. of programmable digital and analog outputs	2
Terminal nos.	42, 45
Voltage level at digital/pulse output	0 - 24 V DC
Minimum load to ground (terminal 39) at digital/pulse output	600 $\Omega$
Frequency ranges (digital output used as pulse output)	0-32 kHz
Current range at analog output	0/4 - 20 mA
Maximum load to ground (terminal 39) at analog output	500 $\Omega$
Accuracy of analog output	Max. error: 1.5% of full scale
Resolution on analog output.	8 bit

*Reliable galvanic isolation: All digital and analog outputs are galvanically isolated from the supply voltage (PELV)\*, as well as other inputs and outputs.*

\* VLT 5001-5062, 525-600 V do not meet PELV.

### Control card, 24 V DC supply

Terminal nos.	12, 13
Max. load (short-circuit protection)	200 mA



## VLT® 5000 Series

Terminal nos. ground	20, 39
----------------------	--------

*Reliable galvanic isolation: The 24 V DC supply is galvanically isolated from the supply voltage (PELV)\*, but has the same potential as the analog outputs.*

\* VLT 5001-5062, 525-600 V do not meet PELV.

### Control card, RS 485 serial communication:

Terminal nos.	68 (TX+, RX+), 69 (TX-, RX-)
---------------	------------------------------

*Reliable galvanic isolation: Full galvanic isolation.*

### Relay outputs: <sup>1)</sup>

No. of programmable relay outputs	2
Terminal nos., control card (resistive load only)	4-5 (make)
Max. terminal load (AC1) on 4-5, control card	50 V AC, 1 A, 50 VA
Max. terminal load (DC1 (IEC 947)) on 4-5, control card	25 V DC, 2 A / 50 V DC, 1 A, 50 W
Max. terminal load (DC1) on 4-5, control card for UL/cUL applications	30 V AC, 1 A / 42.5 V DC, 1A
Terminal nos., power card (resistive and inductive load)	1-3 (break), 1-2 (make)
Max. terminal load (AC1) on 1-3, 1-2, power card	250 V AC, 2 A, 500 VA
Max. terminal load (DC1 (IEC 947)) on 1-3, 1-2, power card	25 V DC, 2 A / 50 V DC, 1A, 50 W
Min. terminal load (AC/DC) on 1-3, 1-2, power card	24 V DC, 10 mA / 24 V AC, 100 mA

1) Rated values for up to 300,000 operations.

At inductive loads, the number of operations are reduced by 50%, alternatively the current can be reduced by 50%, thus the 300,000 operations are maintained.

Technical data

### Brake resistor terminals (only SB, EB, DE and PB units):

Terminal nos.	81, 82
---------------	--------

### External 24 Volt DC supply:

Terminal nos.	35, 36
Voltage range	24 V DC ±15% (max. 37 V DC for 10 sec.)
Max. voltage ripple	2 V DC
Power consumption	15 W - 50 W (50 W for start-up, 20 msec.)
Min. pre-fuse	6 Amp

*Reliable galvanic isolation: Full galvanic isolation if the external 24 V DC supply is also of the PELV type.*



## VLT® 5000 Series

Cable lengths, cross-sections and connectors:

Max. motor cable length, screened cable	150 m
Max. motor cable length, unscreened cable	300 m
Max. motor cable length, screened cable VLT 5011 380-500 V	100 m
Max. motor cable length, screened cable VLT 5011 525-600 V and VLT 5008, normal overload mode, 525-600 V	50 m
Max. brake cable length, screened cable	20 m
Max. loadsharing cable length, screened cable	25 m from drive to DC bar.

*Max. cable cross-section for motor, brake and loadsharing, see Electrical data*

Max. cable cross-section for 24 V external DC supply	
- VLT 5001-5027 200-240 V; VLT 5001-5102 380-500 V; VLT 5001-5062 525-600 V	4 mm <sup>2</sup> /10 AWG
- VLT 5032-5052 200-240 V; VLT 5122-5552 380-500 V; VLT 5042-5602 525-690 V	2.5 mm <sup>2</sup> /12 AWG
Max. cross-section for control cables	1.5 mm <sup>2</sup> /16 AWG
Max. cross-section for serial communication	1.5 mm <sup>2</sup> /16 AWG

*If UL/cUL is to be complied with, cable with temperature class 60/75°C must be used*

*(VLT 5001 - 5062 380 - 500 V, 525 - 600 V and VLT 5001 - 5027 200 - 240V).*

*If UL/cUL is to be complied with, cable with temperature class 75°C must be used*

*(VLT 5072 - 5552 380 - 500 V, VLT 5032 - 5052 200 - 240 V, VLT 5042 - 5602 525 - 600 V).*

*Connectors are for use of both copper and aluminium cables, unless other is specified.*

Accuracy of display readout (parameters 009-012):

Motor current [6] 0-140% load	Max. error: ±2.0% of rated output current
Torque % [7], -100 - 140% load	Max. error: ±5% of rated motor size
Output [8], power HP [9], 0-90% load	Max. error: ±5% of rated output

Control characteristics:

Frequency range	0 - 1000 Hz
Resolution on output frequency	±0.003 Hz
System response time	3 msec
Speed, control range (open-loop)	1:100 of synchro. speed
Speed, control range (closed-loop)	1:1000 of synchro. speed
Speed, accuracy (open-loop)	< 1500 rpm: max. error ± 7.5 rpm
Speed, accuracy (closed-loop)	< 1500 rpm: max. error ± 1.5 rpm
Torque control accuracy (open-loop)	0-150 rpm: max. error ± 20% of rated torque
Torque control accuracy (speed feedback)	Max. error ± 5% of rated torque

*All control characteristics are based on a 4-pole asynchronous motor*

Externals:

Enclosure (dependent on power size)	Chassis, Nema1, Nema12
Vibration test	0.7 g RMS 18-1000 Hz random. 3 directions for 2 hours (IEC 68-2-34/35/36)
Max. relative humidity	93 % (IEC 68-2-3) for storage/transport
Max. relative humidity	95 % non condensing (IEC 721-3-3; class 3K3) for operation
Aggressive environment (IEC 721 - 3 - 3)	Uncoated class 3C2
Aggressive environment (IEC 721 - 3 - 3)	Coated class 3C3
Ambient temperature Chassis, NEMA 1 (high overload torque 160%)	Max. 45°C (24-hour average max. 40°C)
Ambient temperature Chassis, NEMA 1 (normal overload torque 110%)	Max. 40°C (24-hour average max. 35°C)
Ambient temperature NEMA 12 (high overload torque 160%)	Max. 40°C (24-hour average max. 35°C)



## VLT® 5000 Series

Ambient temperature NEMA 12 (normal overload torque 110%)	Max. 40°C (24-hour average max. 35°C)
Ambient temperature NEMA 1/NEMA 121VLT 5011 500 V	Max. 40°C (24-hour average max. 35°C)
Ambient temperature NEMA 12 VLT 5042-5602, 525-690 V; and 5122-5552, 380-500 V (high overload torque 160%)	Max. 45°C (24-hour average max. 40°C)

*Derating for high ambient temperature, see the Design Guide*

Min. ambient temperature in full operation	0°C
Min. ambient temperature at reduced performance	-10°C
Temperature during storage/transport	-25 - +65/70°C
Max. altitude above sea level	1000 m

*Derating for altitude over 1000 m above sealevel, see the Design Guide*

EMC standards applied, Emission	EN 61000-6-3, EN 61000-6-4, EN 61800-3, EN 55011 EN 61000-6-2, EN 61000-4-2, EN 61000-4-3, EN 61000-4-4
EMC standards applied, Immunity	EN 61000-4-5, EN 61000-4-6, VDE 0160/1990.12

*VLT 5001-5062, 525 - 600 V do not comply with EMC or Low Voltage Directives.*

Technical data



---

## VLT® 5000 Series

---

### VLT 5000 Series protection:

---

- Electronic motor thermal protection against overload.
- Temperature monitoring of heat-sink ensures that the drive cuts out if the temperature reaches 90°C for Chassis and Nema 1. For NEMA 12 cut-out temperature is 80°C. An overtemperature can only be reset when the temperature of the heat-sink has fallen below 60°C.

For the units mentioned below, the limits are as follows:

- VLT 5122, 380-500 V, cuts out at 75°C and can be reset if the temperature has fallen below 60°C.
- VLT 5152, 380-500 V, cuts out at 80°C and can be reset if the temperature has fallen below 60°C.
- VLT 5202, 380-500 V, cuts out at 95°C and can be reset if the temperature has fallen below 65°C.
- VLT 5252, 380-500 V, cuts out at 95°C and can be reset if the temperature has fallen below 65°C.
- VLT 5302, 380-500 V, cuts out at 105°C and can be reset if the temperature has fallen below 75°C.
- VLT 5352-5552, 380-500 V, cut out at 85°C and can be reset if the temperature has fallen below 60°C.
- VLT 5042-5122, 525-690 V, cut out at 75°C and can be reset if the temperature has fallen below 60°C.
- VLT 5152, 525-690 V, cuts out at 80°C and can be reset if the temperature has fallen below 60°C.
- VLT 5202-5352, 525-690 V, cut out at 100°C and can be reset if the temperature has fallen below 70°C.
- VLT 5402-5602, 525-690 V, cut out at 75°C and can be reset if the temperature has fallen below 60°C.


- The drive is protected against short-circuiting on motor terminals U, V, W.
- The drive is protected against earth fault on motor terminals U, V, W.
- Monitoring of the intermediate circuit voltage ensures that the drive cuts out if the intermediate circuit voltage gets too high or too low.
- If a motor phase is missing, the drive cuts out, see parameter 234 *Motor phase monitor*.
- If there is a mains fault, the drive is able to carry out a controlled deramping.
- If a mains phase is missing, the drive will cut out when a load is placed on the motor.

## VLT® 5000 Series

### ■ Electrical data


### ■ Bookstyle and Compact, Mains supply 3 x 200 - 240 V

According to international requirements



Max. cable cross-section to motor,  
brake and loadsharing [ $\text{mm}^2$ ]/[AWG]<sup>2</sup>)

	VLT type	5001	5002	5003	5004	5005	5006
Output current	I <sub>VLT,N</sub> [A]	3.7	5.4	7.8	10.6	12.5	15.2
	I <sub>VLT, MAX (60 s)</sub> [A]	5.9	8.6	12.5	17	20	24.3
Output (240 V)	S <sub>VLT,N</sub> [kVA]	1.5	2.2	3.2	4.4	5.2	6.3
Typical shaft output	P <sub>VLT,N</sub> [kW]	0.75	1.1	1.5	2.2	3.0	3.7
Typical shaft output	P <sub>VLT,N</sub> [HP]	1	1.5	2	3	4	5



Max. cable cross-section to motor,  
brake and loadsharing [ $\text{mm}^2$ ]/[AWG]<sup>2</sup>)

4/10      4/10      4/10      4/10      4/10      4/10      4/10

Rated input current	(200 V) I <sub>L,N</sub> [A]	3.4	4.8	7.1	9.5	11.5	14.5
Max. cable cross-section power [ $\text{mm}^2$ ]/[AWG] <sup>2</sup> )		4/10	4/10	4/10	4/10	4/10	4/10
Max. pre-fuses	[-]/UL <sup>1)</sup> [A]	16/10	16/10	16/15	25/20	25/25	35/30
Efficiency <sup>3)</sup>		0.95	0.95	0.95	0.95	0.95	0.95
Weight IP 20 EB Bookstyle	[kg]	7	7	7	9	9	9.5
Weight IP 20 EB Compact [kg]		8	8	8	10	10	10
Weight IP 54 Compact [kg]		11.5	11.5	11.5	13.5	13.5	13.5
Power loss at max. load.	[W]	58	76	95	126	172	194
Enclosure		IP 20/ IP54					

1. For type of fuse see section *Fuses*.

2. American Wire Gauge.

3. Measured using 30 m screened motor cables at rated load and rated frequency.

Technical data

**■ Compact, AC line supply 3 x 200-240 V**

According to international requirements	VLT type	5008	5011	5016	5022	5027
Normal overload torque (110 %):						
Output current	I <sub>VLT,N</sub> [A]	32	46	61.2	73	88
	I <sub>VLT, MAX (60 s)</sub> [A]	35.2	50.6	67.3	80.3	96.8
Output (240 V)	S <sub>VLT,N</sub> [kVA]	13.3	19.1	25.4	30.3	36.6
Typical shaft output	P <sub>VLT,N</sub> [kW]	7.5	11	15	18.5	22
Typical shaft output	P <sub>VLT,N</sub> [HP]	10	15	20	25	30
High overload torque (160 %):						
Output current	I <sub>VLT,N</sub> [A]	25	32	46	61.2	73
	I <sub>VLT, MAX (60 s)</sub> [A]	40	51.2	73.6	97.9	116.8
Output (240 V)	S <sub>VLT,N</sub> [kVA]	10	13	19	25	30
Typical shaft output	P <sub>VLT,N</sub> [kW]	5.5	7.5	11	15	18.5
Typical shaft output	P <sub>VLT,N</sub> [HP]	7.5	10	15	20	25
Max. cable cross-section to motor, brake and load sharing [mm <sup>2</sup> /AWG] <sup>2)</sup> 5)	IP 54	16/6	16/6	35/2	35/2	50/0
	IP 20	16/6	35/2	35/2	35/2	50/0
Min. cable cross-section to motor, brake and load sharing <sup>4)</sup> [mm <sup>2</sup> /AWG] <sup>2)</sup>		10/8	10/8	10/8	10/8	16/6
Rated input current (200 V) I <sub>L,N</sub> [A]						
Max. cable cross-section, power [mm <sup>2</sup> ]/[AWG] <sup>2)</sup> 5)	IP 54	16/6	16/6	35/2	35/2	50/0
	IP 20	16/6	35/2	35/2	35/2	50/0
Max. pre-fuses [-]/UL <sup>1)</sup> [A]	50	60	80	125	125	
Efficiency <sup>3)</sup>	0.95	0.95	0.95	0.95	0.95	0.95
Weight IP 20 EB	[kg]	21	25	27	34	36
Weight IP 54	[kg]	38	40	53	55	56
Power loss at max. load.						
- high overload torque (160 %)	[W]	340	426	626	833	994
- normal overload torque (110 %)	[W]	426	545	783	1042	1243
Enclosure		IP 20/ IP 54				

1. For type of fuse, see section *Fuses*.

2. American Wire Gauge.

3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.

4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals to comply with IP 20. Always comply with national and local regulations on min. cable cross-section.

5. Aluminum cables with cross-section above 0.054 in<sup>2</sup> [35 mm<sup>2</sup>] must be connected by use of an Al-Cu connector.

**■ Compact, AC line supply 3 x 200-240 V**

According to international requirements

	VLT type	5032	5042	5052
<b>Normal overload torque (110 %):</b>				
Output current	I <sub>VLT,N</sub> [A] (200-230 V)	115	143	170
	I <sub>VLT, MAX</sub> (60 s) [A] (200-230 V)	127	158	187
	I <sub>VLT,N</sub> [A] (231-240 V)	104	130	154
	I <sub>VLT, MAX</sub> (60 s) [A] (231-240 V)	115	143	170
Output	S <sub>VLT,N</sub> [kVA] (208 V)	41	52	61
	S <sub>VLT,N</sub> [kVA] (230 V)	46	57	68
	S <sub>VLT,N</sub> [kVA] (240 V)	43	54	64
Typical shaft output	[HP] (208 V)	40	50	60
Typical shaft output	[kW] (230 V)	30	37	45
<b>High overload torque (160 %):</b>				
Output current	I <sub>VLT,N</sub> [A] (200-230 V)	88	115	143
	I <sub>VLT, MAX</sub> [A] (200-230 V)	132	173	215
	I <sub>VLT,N</sub> [A] (231-240 V)	80	104	130
	I <sub>VLT, MAX</sub> [A] (231-240 V)	120	285	195
Output	S <sub>VLT,N</sub> [kVA] (208 V)	32	41	52
	S <sub>VLT,N</sub> [kVA] (230 V)	35	46	57
	S <sub>VLT,N</sub> [kVA] (240 V)	33	43	54
Typical shaft output	[HP] (208 V)	30	40	50
	[kW] (230 V)	22	30	37
Max. cable cross-section to motor and load sharing	[mm <sup>2</sup> ] <sup>1,4,6</sup> [AWG] <sup>2,4,6</sup>		120 300 mcm	
Max. cable cross-section to brake	[mm <sup>2</sup> ] <sup>1,4,6</sup> [AWG] <sup>2,4,6</sup>		25 4	
<b>Normal overload torque (110 %):</b>				
Rated input current	I <sub>L,N</sub> [A] (230 V)	101.3	126.6	149.9
<b>Normal overload torque (150 %):</b>				
Rated input current	I <sub>L,N</sub> [A] (230 V)	77,9	101.3	126.6
Max. cable cross-section power supply	[mm <sup>2</sup> ] <sup>1,4,6</sup> [AWG] <sup>2,4,6</sup>		120 300 mcm	
Min. cable cross-section to motor, power	[mm <sup>2</sup> ] <sup>1,4,6</sup> [AWG] <sup>2,4,6</sup>		6 8	
supply, brake and load sharing				
Max. pre-fuses (line) [-]/UL	[A] <sup>1</sup>	150/15 0	200/200	250/250
Efficiency <sup>3</sup>			0,96-0,97	
Power loss	Normal overload [W]	1089	1361	1612
	High overload [W]	838	1089	1361
Weight	IP 00 [kg]	101	101	101
Weight	IP 20 Nema1 [kg]	101	101	101
Weight	IP 54 Nema12 [kg]	104	104	104
Enclosure		IP 00 / Nema 1 (IP 20) / IP 54		

 1. For type of fuse, see section *Fuses*.

2. American Wire Gauge.

3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.

4. Max. cable cross-section is the maximum possible cable cross-section allowed to be fitted on the terminals. Min. cable cross-section is the minimum allowed cross-section. Always comply with national and local regulations on min. cable cross-section.

5. Weight without shipping container.

6. Connection stud: M8 Brake: M6.

## VLT® 5000 Series

### ■ Bookstyle and Compact, Mains supply 3 x 380 - 500 V

According to international requirements	VLT type	5001	5002	5003	5004
Output current	$I_{VLT,N}$ [A] (380-440 V)	2.2	2.8	4.1	5.6
	$I_{VLT, MAX}$ (60 s) [A] (380-440 V)	3.5	4.5	6.5	9
	$I_{VLT,N}$ [A] (441-500 V)	1.9	2.6	3.4	4.8
	$I_{VLT, MAX}$ (60 s) [A] (441-500 V)	3	4.2	5.5	7.7
Output	$S_{VLT,N}$ [kVA] (380-440 V)	1.7	2.1	3.1	4.3
	$S_{VLT,N}$ [kVA] (441-500 V)	1.6	2.3	2.9	4.2
Typical shaft output	$P_{VLT,N}$ [kW]	0.75	1.1	1.5	2.2
Typical shaft output	$P_{VLT,N}$ [HP]	1	1.5	2	3
Max. cable cross-section to motor, brake and loadsharing [mm <sup>2</sup> ] / [AWG] <sup>2</sup> )		4/10	4/10	4/10	4/10

	Rated input current	$I_{L,N}$ [A] (380 V)	2.3	2.6	3.8	5.3
		$I_{L,N}$ [A] (460 V)	1.9	2.5	3.4	4.8
	Max. cable cross-section, power [mm <sup>2</sup> ] / [AWG] <sup>2</sup> )		4/10	4/10	4/10	4/10
	Max. pre-fuses [-]/UL <sup>1)</sup> [A]		16/6	16/6	16/10	16/10
	Efficiency <sup>3)</sup>		0.96	0.96	0.96	0.96
	Weight IP 20 EB Bookstyle [kg]		7	7	7	7.5
	Weight IP 20 EB Compact [kg]		8	8	8	8.5
	Weight IP 54 Compact [kg]		11.5	11.5	11.5	12
	Power loss at max. load	[W]	55	67	92	110
	Enclosure		IP 20/ IP 54	IP 20/ IP 54	IP 20/ IP 54	IP 20/ IP 54


1. For type of fuse see section *Fuses*.

2. American Wire Gauge.


3. Measured using 30 m screened motor cables at rated load and rated frequency.

**Bookstyle and Compact, Mains supply 3 x 380 - 500 V**

According to international requirements



	VLT type 5005	5006	5008	5011
Output current				
I <sub>VLT,N</sub> [A] (380-440 V)	7.2	10	13	16
I <sub>VLT, MAX</sub> (60 s) [A] (380-440 V)	11.5	16	20.8	25.6
I <sub>VLT,N</sub> [A] (441-500 V)	6.3	8.2	11	14.5
I <sub>VLT, MAX</sub> (60 s) [A] (441-500 V)	10.1	13.1	17.6	23.2
Output				
S <sub>VLT,N</sub> [kVA] (380-440 V)	5.5	7.6	9.9	12.2
S <sub>VLT,N</sub> [kVA] (441-500 V)	5.5	7.1	9.5	12.6
Typical shaft output	P <sub>VLT,N</sub> [kW]	3.0	4.0	5.5
Typical shaft output	P <sub>VLT,N</sub> [HP]	4	5	7.5
Max. cable cross-section to motor, brake and loadsharing [mm <sup>2</sup> ] / [AWG] <sup>2</sup> )		4/10	4/10	4/10



Rated input current	I <sub>L,N</sub> [A] (380 V)	7	9.1	12.2	15.0
	I <sub>L,N</sub> [A] (460 V)	6	8.3	10.6	14.0
Max. cable cross-section power [mm <sup>2</sup> ] / [AWG] <sup>2</sup> )		4/10	4/10	4/10	4/10
Max. pre-fuses [-/UL <sup>1)</sup> [A]		16/15	25/20	25/25	35/30
Efficiency <sup>3)</sup>		0.96	0.96	0.96	0.96
Weight IP 20 EB Bookstyle [kg]		7.5	9.5	9.5	9.5
Weight IP 20 EB Compact [kg]		8.5	10.5	10.5	10.5
Weight IP 54 EB Compact [kg]		12	14	14	14
Power loss at max. load.	[W]	139	198	250	295
Enclosure		IP 20/ IP 54	IP 20/ IP 54	IP 20/ IP 54	IP 20/ IP 54

1. For type of fuse see section *Fuses*.

2. American Wire Gauge.

3. Measured using 30 m screened motor cables at rated load and rated frequency.

**■ Compact, AC line supply 3 x 380-500 V**

According to international requirements

	VLT type	5016	5022	5027
Normal overload torque (110 %):				
Output current	I <sub>VLT,N</sub> [A] (380-440 V)	32	37.5	44
	I <sub>VLT, MAX</sub> (60 s) [A] (380-440 V)	35.2	41.3	48.4
	I <sub>VLT,N</sub> [A] (441-500 V)	27.9	34	41.4
Output	I <sub>VLT, MAX</sub> (60 s) [A] (441-500 V)	30.7	37.4	45.5
	S <sub>VLT,N</sub> [kVA] (380-440 V)	24.4	28.6	33.5
	S <sub>VLT,N</sub> [kVA] (441-500 V)	24.2	29.4	35.8
Typical shaft output	P <sub>VLT,N</sub> [kW]	15	18.5	22
Typical shaft output	P <sub>VLT,N</sub> [HP]	20	25	30
High overload torque (160 %):				
Output current	I <sub>VLT,N</sub> [A] (380-440 V)	24	32	37.5
	I <sub>VLT, MAX</sub> (60 s) [A] (380-440 V)	38.4	51.2	60
	I <sub>VLT,N</sub> [A] (441-500 V)	21.7	27.9	34
Output	I <sub>VLT, MAX</sub> (60 s) [A] (441-500 V)	34.7	44.6	54.4
	S <sub>VLT,N</sub> [kVA] (380-440 V)	18.3	24.4	28.6
	S <sub>VLT,N</sub> [kVA] (441-500 V)	18.8	24.2	29.4
Typical shaft output	P <sub>VLT,N</sub> [kW]	11	15	18.5
Typical shaft output	P <sub>VLT,N</sub> [HP]	15	20	25
Max. cable cross-section to motor, brake and load sharing [mm <sup>2</sup> ] / [AWG] <sup>2)</sup>	IP 54	16/6	16/6	16/6
	IP 20	16/6	16/6	35/2
Min. cable cross-section to motor, brake and load sharing [mm <sup>2</sup> ] / [AWG] <sup>2) 4)</sup>		10/8	10/8	10/8
Rated input current	I <sub>L,N</sub> [A] (380 V)	32	37.5	44
	I <sub>L,N</sub> [A] (460 V)	27.6	34	41
Max. cable cross-section, power [mm <sup>2</sup> ] / [AWG]	IP 54	16/6	16/6	16/6
	IP 20	16/6	16/6	35/2
Max. pre-fuses	[ - / UL <sup>1)</sup> [A]	63/40	63/50	63/60
Efficiency <sup>3)</sup>		0.96	0.96	0.96
Weight IP 20 EB	[kg]	21	22	27
Weight IP 54	[kg]	41	41	42
Power loss at max. load.				
- high overload torque (160 %)	[W]	419	559	655
- normal overload torque (110 %)	[W]	559	655	768
Enclosure	IP 20/ IP 54	IP 20/ IP 54	IP 20/ IP 54	IP 20/ IP 54

 1. For type of fuse, see section *Fuses*.

2. American Wire Gauge.

3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.

4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals to comply with IP 20. Always comply with national and local regulations on min. cable cross-section.

**Compact, AC line supply 3 x 380-500 V**

According to international requirements

VLT type      5032      5042      5052



Normal overload torque (110 %):				
Output current	I <sub>VLT,N</sub> [A] (380-440 V)	61	73	90
	I <sub>VLT, MAX</sub> (60 s) [A] (380-440 V)	67.1	80.3	99
	I <sub>VLT,N</sub> [A] (441-500 V)	54	65	78
	I <sub>VLT, MAX</sub> (60 s) [A] (441-500 V)	59.4	71.5	85.8
Output	S <sub>VLT,N</sub> [kVA] (380-440 V)	46.5	55.6	68.6
	S <sub>VLT,N</sub> [kVA] (441-500 V)	46.8	56.3	67.5
Typical shaft output	P <sub>VLT,N</sub> [kW]	30	37	45
Typical shaft output	P <sub>VLT,N</sub> [HP]	40	50	60
High overload torque (160 %):				
Output current	I <sub>VLT,N</sub> [A] (380-440 V)	44	61	73
	I <sub>VLT, MAX</sub> (60 s) [A] (380-440 V)	70.4	97.6	116.8
	I <sub>VLT,N</sub> [A] (441-500 V)	41.4	54	65
	I <sub>VLT, MAX</sub> (60 s) [A] (441-500 V)	66.2	86	104
Output	S <sub>VLT,N</sub> [kVA] (380-440 V)	33.5	46.5	55.6
	S <sub>VLT,N</sub> [kVA] (441-500 V)	35.9	46.8	56.3
Typical shaft output	P <sub>VLT,N</sub> [kW]	22	30	37
Typical shaft output	P <sub>VLT,N</sub> [HP]	30	40	50
Max. cable cross-section to motor, brake and load sharing [mm <sup>2</sup> ] / [AWG] <sup>2)</sup> 5)	IP 54	35/2	35/2	50/0
	IP 20	35/2	35/2	50/0
Min. cable cross-section to motor, brake and load sharing [mm <sup>2</sup> ] / [AWG] <sup>2)</sup> 4)		10/8	10/8	16/6
Rated input current	I <sub>L,N</sub> [A] (380 V)	60	72	89
	I <sub>L,N</sub> [A] (460 V)	53	64	77
Max. cable cross-section power [mm <sup>2</sup> ] / [AWG] <sup>2)</sup> 5)	IP 54	35/2	35/2	50/0
	IP 20	35/2	35/2	50/0
Max. pre-fuses	[ - ] / UL <sup>1)</sup> [A]	80/80	100/100	125/125
Efficiency <sup>3)</sup>		0.96	0.96	0.96
Weight IP 20 EB	[kg]	28	41	42
Weight IP 54	[kg]	54	56	56
Power loss at max. load.				
- high overload torque (160 %)	[W]	768	1065	1275
- normal overload torque (110 %)	[W]	1065	1275	1571
Enclosure	IP 20/ IP 54	IP 20/ IP 54	IP 20/ IP 54	IP 20/ IP 54

 1. For type of fuse, see section *Fuses*.

2. American Wire Gauge.

3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.

4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals to comply with IP 20. Always comply with national and local regulations on min. cable cross-section.

 5. Aluminum cables with cross-section above 0.054 in<sup>2</sup> [35 mm<sup>2</sup>] must be connected by use of an Al-Cu connector.


Technical data

## VLT® 5000 Series

### Compact, AC line supply 3 x 380-500 V

According to international requirements	VLT type	5062	5072	5102
Normal overload torque (110 %):				
Output current	$I_{VLT,N}$ [A] (380-440 V)	106	147	177
	$I_{VLT, MAX}$ (60 s) [A] (380-440 V)	117	162	195
	$I_{VLT,N}$ [A] (441-500 V)	106	130	160
	$I_{VLT, MAX}$ (60 s) [A] (441-500 V)	117	143	176
Output	$S_{VLT,N}$ [kVA] (380-440 V)	80.8	102	123
	$S_{VLT,N}$ [kVA] (441-500 V)	91.8	113	139
Typical shaft output	$P_{VLT,N}$ [kW] (400 V)	55	75	90
	$P_{VLT,N}$ [HP] (460 V)	75	100	125
	$P_{VLT,N}$ [kW] (500 V)	75	90	110
High overload torque (160 %):				
Output current	$I_{VLT,N}$ [A] (380-440 V)	90	106	147
	$I_{VLT, MAX}$ (60 s) [A] (380-440 V)	135	159	221
	$I_{VLT,N}$ [A] (441-500 V)	80	106	130
	$I_{VLT, MAX}$ (60 s) [A] (441-500 V)	120	159	195
Output	$S_{VLT,N}$ [kVA] (380-440 V)	68.6	73.0	102
	$S_{VLT,N}$ [kVA] (441-500 V)	69.3	92.0	113
Typical shaft output	$P_{VLT,N}$ [kW] (400 V)	45	55	75
	$P_{VLT,N}$ [HP] (460 V)	60	75	100
	$P_{VLT,N}$ [kW] (500 V)	55	75	90
Max. cable cross-section to motor, brake and load sharing [ $\text{mm}^2$ ]/[AWG] <sup>2)</sup>	IP 54	50/0 <sup>5)</sup>	150/300 mcm <sup>6)</sup>	150/300 mcm <sup>6)</sup>
	IP 20	50/0 <sup>5)</sup>	120/250 mcm <sup>5)</sup>	120/250 mcm <sup>5)</sup>
Min. cable cross-section to motor, brake and load sharing [ $\text{mm}^2$ ]/[AWG] <sup>4)</sup>		16/6	25/4	25/4
Rated input current	$I_{L,N}$ [A] (380 V)	104	145	174
	$I_{L,N}$ [A] (460 V)	104	128	158
Max. cable cross-section power [ $\text{mm}^2$ ]/[AWG] <sup>2)</sup>	IP 54	50/0 <sup>5)</sup>	150/300 mcm	150/300 mcm
	IP 20	50/0 <sup>5)</sup>	120/250 mcm <sup>5)</sup>	120/250 mcm <sup>5)</sup>
Max. pre-fuses	[A]	160/150	225/225	250/250
Efficiency <sup>3)</sup>		>0.97	>0.97	>0.97
Weight IP 20 EB	[kg]	43	54	54
Weight IP 54	[kg]	60	77	77
Power loss at max. load.				
- high overload torque (160 %)	[W]	1122	1058	1467
- normal overload torque (110 %)	[W]	1322	1467	1766
Enclosure		IP20/ IP 54	IP20/ IP 54	IP20/ IP 54

1. For type of fuse, see section *Fuses*.

2. American Wire Gauge.

3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.

4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals to comply with IP 20. Always comply with national and local regulations on min. cable cross-section.

5. Aluminum cables with cross-section above 0.054 in<sup>2</sup> [35 mm<sup>2</sup>] must be connected by use of an Al-Cu connector.  
used.

6. Brake and load sharing: 95 mm<sup>2</sup> / AWG 3/0



## VLT® 5000 Series

### ■ Compact, AC line supply 3 x 380-500 V

According to international requirements	VLT type	5122	5152	5202	5252	5302
<b>Normal overload current (110%):</b>						
Output current	$I_{VLT,N}$ [A] (380-440 V)	212	260	315	395	480
	$I_{VLT, MAX}$ (60 s) [A] (380-440 V)	233	286	347	434	528
	$I_{VLT,N}$ [A] (441-500 V)	190	240	302	361	443
	$I_{VLT, MAX}$ (60 s) [A] (441-500 V)	209	264	332	397	487
Output	$S_{VLT,N}$ [kVA] (400 V)	147	180	218	274	333
	$S_{VLT,N}$ [kVA] (460 V)	151	191	241	288	353
	$S_{VLT,N}$ [kVA] (500 V)	165	208	262	313	384
Typical shaft output	[kW] (400 V)	110	132	160	200	250
	[HP] (460 V)	150	200	250	300	350
	[kW] (500 V)	132	160	200	250	315
<b>High overload torque (160 %):</b>						
Output current	$I_{VLT,N}$ [A] (380-440 V)	177	212	260	315	395
	$I_{VLT, MAX}$ (60 s) [A] (380-440 V)	266	318	390	473	593
	$I_{VLT,N}$ [A] (441-500 V)	160	190	240	302	361
	$I_{VLT, MAX}$ (60 s) [A] (441-500 V)	240	285	360	453	542
Output	$S_{VLT,N}$ [kVA] (400 V)	123	147	180	218	274
	$S_{VLT,N}$ [kVA] (460 V)	127	151	191	241	288
	$S_{VLT,N}$ [kVA] (500 V)	139	165	208	262	313
Typical shaft output	[kW] (400 V)	90	110	132	160	200
	[HP] (460 V)	125	150	200	250	300
	[kW] (500 V)	110	132	160	200	250
Max. cable cross-section to motor	[mm <sup>2</sup> ] <sup>4,6</sup> 2 x 70 [AWG] <sup>2,4,6</sup> 2 x 2/0				2 x 185 2 x 350 mcm	
Max. cable cross-section to load sharing and brake	[mm <sup>2</sup> ] <sup>4,6</sup> 2 x 70 [AWG] <sup>2,4,6</sup> 2 x 2/0				2 x 185 2 x 350 mcm	
<b>Normal overload current (110%):</b>						
Rated input current	$I_{L,N}$ [A] (380-440 V)	208	256	317	385	467
	$I_{L,N}$ [A] (441-500 V)	185	236	304	356	431
<b>High overload torque (160 %):</b>						
Rated input current	$I_{L,N}$ [A] (380-440 V)	174	206	256	318	389
	$I_{L,N}$ [A] (441-500 V)	158	185	236	304	356
Max. cable cross-section power supply	[mm <sup>2</sup> ] <sup>4,6</sup> 2 x 70 [AWG] <sup>2,4,6</sup> 2 x 2/0				2 x 185 2 x 350 mcm	
Max. pre-fuses (line) [-]/UL	[A] <sup>1</sup> 300/ 300	350/	450/	500/	630/ 600	
Efficiency <sup>3</sup>	0.98					
Power loss	Normal overload [W]	2619	3309	4163	4977	6107
	High overload [W]	2206	2619	3309	4163	4977
Weight	IP 00 [kg]	82	91	112	123	138
Weight	IP 21/NEMA 1 [kg]	96	104	125	136	151
Weight	IP 54/NEMA 12 [kg]	96	104	125	136	151
Enclosure	IP 00, IP 21/NEMA 1 and IP 54/NEMA 12					

1. For type of fuse, see section *Fuses*.
2. American Wire Gauge.
3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.
4. Max. cable cross-section is the maximum possible cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section.
5. Weight without shipping container.
6. Connection bolt power supply and motor: M10; Brake and load sharing: M8

Technical data



## VLT® 5000 Series

### ■ Compact, AC line supply 3 x 380-500 V

According to international requirements	VLT type 5352	5452	5502	5552
<b>Normal overload current (110%):</b>				
Output current	I <sub>VLT,N</sub> [A] (380-440 V) 600 I <sub>VLT, MAX (60 s)</sub> [A] (380-440 V) 660 I <sub>VLT,N</sub> [A] (441-500 V) 540 I <sub>VLT, MAX (60 s)</sub> [A] (441-500 V) 594	658 724 590 649	745 820 678 746	800 880 730 803
Output	S <sub>VLT,N</sub> [kVA] (400 V) 416 S <sub>VLT,N</sub> [kVA] (460 V) 430 S <sub>VLT,N</sub> [kVA] (500 V) 468	456 470 511	516 540 587	554 582 632
Typical shaft output	[kW] (400 V) 315 [HP] (460 V) 450 [kW] (500 V) 355	355 500 400	400 550/600 500	450 600 530
<b>High overload torque (160 %):</b>				
Output current	I <sub>VLT,N</sub> [A] (380-440 V) 480 I <sub>VLT, MAX (60 s)</sub> [A] (380-440 V) 720 I <sub>VLT,N</sub> [A] (441-500 V) 443 I <sub>VLT, MAX (60 s)</sub> [A] (441-500 V) 665	600 900 540 810	658 987 590 885	695 1042 678 1017
Output	S <sub>VLT,N</sub> [kVA] (400 V) 333 S <sub>VLT,N</sub> [kVA] (460 V) 353 S <sub>VLT,N</sub> [kVA] (500 V) 384	416 430 468	456 470 511	482 540 587
Typical shaft output	[kW] (400 V) 250 [HP] (460 V) 350 [kW] (500 V) 315	315 450 355	355 500 400	400 550 500
Max. cable cross-section to motor and load sharing	[mm <sup>2</sup> ] <sup>4,6</sup> 4x240 [AWG] <sup>2,4,6</sup> 4x500 mcm			
Max. cable cross-section to brake	[mm <sup>2</sup> ] <sup>4,6</sup> 2x185 [AWG] <sup>2,4,6</sup> 2x350 mcm			
<b>Normal overload current (110%):</b>				
Rated input current	I <sub>L,N</sub> [A] (380-440 V) 590 I <sub>L,N</sub> [A] (441-500 V) 531	647 580	733 667	787 718
<b>High overload torque (160 %):</b>				
Rated input current	I <sub>L,N</sub> [A] (380-440 V) 472 I <sub>L,N</sub> [A] (441-500 V) 436	590 531	647 580	684 667
Max. cable cross-section power supply	[mm <sup>2</sup> ] <sup>4,6</sup> 4x240 [AWG] <sup>2,4,6</sup> 4x500 mcm			
Max. pre-fuses (line) [-]/UL	[A] <sup>1</sup> 700/700	900/900	900/900	900/900
Efficiency <sup>3</sup>	0,98			
Power loss	Normal overload [W] 7630 High overload [W] 6005	7701 6960	8879 7691	9428 7964
Weight	IP 00 [kg] 221	234	236	277
Weight	IP 21/NEMA 1 [kg] 263	270	272	313
Weight	IP 54/NEMA 12 [kg] 263	270	272	313
Enclosure	IP 00, IP 21/NEMA 1 and IP 54/NEMA 12			

1. For type of fuse, see section *Fuses*.

2. American Wire Gauge.

3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.

4. Max. cable cross-section is the maximum possible cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section.


5. Weight without shipping container.

6. Connection bolt power supply, motor and load sharing: M10 (compression lug), 2xM8 (box lug), M8 (brake)


**■ Compact, AC line supply 3 x 525-600 V**

According to international requirements

VLT type 5001 5002 5003 5004


**Normal overload torque (110 %):**

Output current	$I_{VLT,N}$ [A] (550 V)	2.6	2.9	4.1	5.2
	$I_{VLT, MAX}$ (60 s) [A] (550 V)	2.9	3.2	4.5	5.7
	$I_{VLT,N}$ [A] (575 V)	2.4	2.7	3.9	4.9
	$I_{VLT, MAX}$ (60 s) [A] (575 V)	2.6	3.0	4.3	5.4
Output	$S_{VLT,N}$ [kVA] (550 V)	2.5	2.8	3.9	5.0
	$S_{VLT,N}$ [kVA] (575 V)	2.4	2.7	3.9	4.9
Typical shaft output	$P_{VLT,N}$ [kW]	1.1	1.5	2.2	3
Typical shaft output	$P_{VLT,N}$ [HP]	1.5	2	3	4
<b>High overload torque (160%):</b>					
Output current	$I_{VLT,N}$ [A] (550 V)	1.8	2.6	2.9	4.1
	$I_{VLT, MAX}$ (60 s) [A] (550 V)	2.9	4.2	4.6	6.6
	$I_{VLT,N}$ [A] (575 V)	1.7	2.4	2.7	3.9
	$I_{VLT, MAX}$ (60 s) [A] (575 V)	2.7	3.8	4.3	6.2
Output	$S_{VLT,N}$ [kVA] (550 V)	1.7	2.5	2.8	3.9
	$S_{VLT,N}$ [kVA] (575 V)	1.7	2.4	2.7	3.9
Typical shaft output	$P_{VLT,N}$ [kW]	0.75	1.1	1.5	2.2
Typical shaft output	$P_{VLT,N}$ [HP]	1	1.5	2	3
Max. cable cross-section to motor, brake and load sharing [mm²]/[AWG²]		4/10	4/10	4/10	4/10


**Normal overload torque (110 %):**

Rated input current	$I_{L,N}$ [A] (550 V)	2.5	2.8	4.0	5.1
	$I_{L,N}$ [A] (600 V)	2.2	2.5	3.6	4.6
<b>High overload torque (160%):</b>					
Rated input current	$I_{L,N}$ [A] (550 V)	1.8	2.5	2.8	4.0
	$I_{L,N}$ [A] (600 V)	1.6	2.2	2.5	3.6
Max. cable cross-section, power [mm²]/[AWG²]		4/10	4/10	4/10	4/10
Max. pre-fuses	[ - ] / UL <sup>1)</sup> [A]	3	4	5	6
Efficiency <sup>3)</sup>		0.96	0.96	0.96	0.96
Weight IP 20 EB	[kg]	10.5	10.5	10.5	10.5
Power loss at max. load.	[W]	63	71	102	129
Enclosure		IP 20/Nema 1			

 1. For type of fuses, see section *Fuses*.

2. American Wire Gauge.

3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.

**Compact, AC line supply 3 x 525-600 V**

According to international requirements

VLT type 5005 5006 5008 5011

**Normal overload torque (110 %):**

Output current	$I_{VLT,N}$ [A] (550 V)	6.4	9.5	11.5	11.5
	$I_{VLT, MAX}$ (60 s) [A] (550 V)	7.0	10.5	12.7	12.7
	$I_{VLT,N}$ [A] (575 V)	6.1	9.0	11.0	11.0
	$I_{VLT, MAX}$ (60 s) [A] (575 V)	6.7	9.9	12.1	12.1
Output	$S_{VLT,N}$ [kVA] (550 V)	6.1	9.0	11.0	11.0
	$S_{VLT,N}$ [kVA] (575 V)	6.1	9.0	11.0	11.0
Typical shaft output	$P_{VLT,N}$ [kW]	4	5.5	7.5	7.5
Typical shaft output	$P_{VLT,N}$ [HP]	5	7.5	10.0	10.0

**High overload torque (160%):**

Output current	$I_{VLT,N}$ [A] (550 V)	5.2	6.4	9.5	11.5
	$I_{VLT, MAX}$ (60 s) [A] (550 V)	8.3	10.2	15.2	18.4
	$I_{VLT,N}$ [A] (575 V)	4.9	6.1	9.0	11.0
	$I_{VLT, MAX}$ (60 s) [A] (575 V)	7.8	9.8	14.4	17.6
Output	$S_{VLT,N}$ [kVA] (550 V)	5.0	6.1	9.0	11.0
	$S_{VLT,N}$ [kVA] (575 V)	4.9	6.1	9.0	11.0
Typical shaft output	$P_{VLT,N}$ [kW]	3	4	5.5	7.5
Typical shaft output	$P_{VLT,N}$ [HP]	4	5	7.5	10

 Max. cable cross-section to motor,  
brake and load sharing [ $\text{mm}^2$ ]/[AWG]<sup>2)</sup>
**Normal overload torque (110 %):**

Rated input current	$I_{L,N}$ [A] (550 V)	6.2	9.2	11.2	11.2
	$I_{L,N}$ [A] (600 V)	5.7	8.4	10.3	10.3

**High overload torque (160%):**

Rated input current	$I_{L,N}$ [A] (550 V)	5.1	6.2	9.2	11.2
	$I_{L,N}$ [A] (600 V)	4.6	5.7	8.4	10.3
Max. cable cross-section, power [ $\text{mm}^2$ ]/[AWG] <sup>2)</sup>		4/10	4/10	4/10	4/10
Max. pre-fuses	[A] UL <sup>1)</sup>	8	10	15	20
Efficiency <sup>3)</sup>		0.96	0.96	0.96	0.96
Weight IP 20 EB	[kg]	10.5	10.5	10.5	10.5
Power loss at max. load.	[W]	160	236	288	288
Enclosure		IP 20/Nema 1			

 1. For type of fuses, see section *Fuses*.

2. American Wire Gauge.

3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.

**■ Compact, AC line supply 3 x 525-600 V**

According to international requirements



	VLT type 5016	5022	5027
<u>Normal overload torque (110 %):</u>			
Output current	I <sub>VLT,N</sub> [A] (550 V) 23	28	34
	I <sub>VLT, MAX</sub> (60 s) [A] (550 V) 25	31	37
	I <sub>VLT,N</sub> [A] (575 V) 22	27	32
	I <sub>VLT, MAX</sub> (60 s) [A] (575 V) 24	30	35
Output	S <sub>VLT,N</sub> [kVA] (550 V) 22	27	32
	S <sub>VLT,N</sub> [kVA] (575 V) 22	27	32
Typical shaft output	P <sub>VLT,N</sub> [kW] 15	18.5	22
Typical shaft output	P <sub>VLT,N</sub> [HP] 20	25	30
<u>High overload torque (160 %):</u>			
Output current	I <sub>VLT,N</sub> [A] (550 V) 18	23	28
	I <sub>VLT, MAX</sub> (60 s) [A] (550 V) 29	37	45
	I <sub>VLT,N</sub> [A] (575 V) 17	22	27
	I <sub>VLT, MAX</sub> (60 s) [A] (575 V) 27	35	43
Output	S <sub>VLT,N</sub> [kVA] (550 V) 17	22	27
	S <sub>VLT,N</sub> [kVA] (575 V) 17	22	27
Typical shaft output	P <sub>VLT,N</sub> [kW] 11	15	18.5
Typical shaft output	P <sub>VLT,N</sub> [HP] 15	20	25
Max. cable cross-section to motor, brake and load sharing [mm <sup>2</sup> ] / [AWG] <sup>2)</sup>	16	16	35
	6	6	2
Min. cable cross-section to motor, brake and load sharing [mm <sup>2</sup> ] / [AWG] <sup>4)</sup>	0.5	0.5	10
	20	20	8
<u>Normal overload torque (110 %):</u>			
Rated input current	I <sub>L,N</sub> [A] (550 V) 22	27	33
	I <sub>L,N</sub> [A] (600 V) 21	25	30
<u>High overload torque (160 %):</u>			
Rated input current	I <sub>L,N</sub> [A] (550 V) 18	22	27
	I <sub>L,N</sub> [A] (600 V) 16	21	25
Max. cable cross-section, power [mm <sup>2</sup> ] / [AWG] <sup>2)</sup>	16	16	35
	6	6	2
Max. pre-fuses	[·] / UL <sup>1)</sup> [A] 30	35	45
Efficiency <sup>3)</sup>	0.96	0.96	0.96
Weight IP 20 EB	[kg] 23	23	30
Power loss at max. load	[W] 576	707	838
Enclosure	IP 20/Nema 1		

 1. For type of fuse, see section *Fuses*.

2. American Wire Gauge.

3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.

4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals to comply with IP 20. Always comply with national and local regulations on min. cable cross-section.



Technical data

**Compact, AC line supply 3 x 525-600 V**

According to international requirements

	VLT type 5032	5042	5052	5062
<b>Normal overload torque (110 %):</b>				
Output current	$I_{VLT,N}$ [A] (550 V) 43	54	65	81
	$I_{VLT, MAX}$ (60 s) [A] (550 V) 47	59	72	89
	$I_{VLT,N}$ [A] (575 V) 41	52	62	77
	$I_{VLT, MAX}$ (60 s) [A] (575 V) 45	57	68	85
Output	$S_{VLT,N}$ [kVA] (550 V) 41	51	62	77
	$S_{VLT,N}$ [kVA] (575 V) 41	52	62	77
Typical shaft output	$P_{VLT,N}$ [kW] 30	37	45	55
Typical shaft output	$P_{VLT,N}$ [HP] 40	50	60	75
<b>High overload torque (160 %):</b>				
Output current	$I_{VLT,N}$ [A] (550 V) 34	43	54	65
	$I_{VLT, MAX}$ (60 s) [A] (550 V) 54	69	86	104
	$I_{VLT,N}$ [A] (575 V) 32	41	52	62
	$I_{VLT, MAX}$ (60 s) [A] (575 V) 51	66	83	99
Output	$S_{VLT,N}$ [kVA] (550 V) 32	41	51	62
	$S_{VLT,N}$ [kVA] (575 V) 32	41	52	62
Typical shaft output	$P_{VLT,N}$ [kW] 22	30	37	45
Typical shaft output	$P_{VLT,N}$ [HP] 30	40	50	60
Max. cable cross-section to motor, brake and load sharing [ $\text{mm}^2$ ]/[AWG] <sup>2)</sup> 5)	35	50	50	50
	2	1/0	1/0	1/0
Min. cable cross-section to motor, brake and load sharing [ $\text{mm}^2$ ]/[AWG] <sup>4)</sup>	10	16	16	16
	8	6	6	6
<b>Normal overload torque (110 %):</b>				
Rated input current	$I_{L,N}$ [A] (550 V) 42	53	63	79
	$I_{L,N}$ [A] (600 V) 38	49	58	72
<b>High overload torque (160 %):</b>				
Rated input current	$I_{L,N}$ [A] (550 V) 33	42	53	63
	$I_{L,N}$ [A] (600 V) 30	38	49	58
Max. cable cross-section power [ $\text{mm}^2$ ]/[AWG] <sup>2)</sup> 5)	35	50	50	50
	2	1/0	1/0	1/0
Max. pre-fuses	[ $\text{-}/\text{UL}^1$ ] [A] 60	75	90	100
Efficiency <sup>3)</sup>	0.96	0.96	0.96	0.96
Weight IP 20 EB	[kg] 30	48	48	48
Power loss at max. load	[W] 1074	1362	1624	2016
Enclosure	IP 20/Nema 1			


1. For type of fuse, see section *Fuses*.
2. American Wire Gauge.
3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.
4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals to comply with IP 20. Always comply with national and local regulations on min. cable cross-section.
5. Aluminum cables with cross-section above 0.054 in<sup>2</sup> [35 mm<sup>2</sup>] must be connected by use of an Al-Cu connector.

**■ Compact, AC line supply 3 x 550-600 V**

According to international requirements	VLT type 5075	5100	5125
Normal overload torque (110 %):			
Output current	I <sub>VLT,N</sub> [A] (550 V) 104	131	151
	I <sub>VLT, MAX</sub> (60 s) [A] (550 V) 114	144	166
	I <sub>VLT,N</sub> [A] (575 V) 99	125	144
	I <sub>VLT, MAX</sub> (60 s) [A] (575 V) 109	138	158
Output	S <sub>VLT,N</sub> [kVA] (550 V) 99	125	144
	S <sub>VLT,N</sub> [kVA] (575 V) 99	124	143
Typical shaft output P <sub>VLT,N</sub> [kW]			
	75	90	11
Typical shaft output P <sub>VLT,N</sub> [HP]			
	100	125	150
High overload torque (160 %):			
Output current	I <sub>VLT,N</sub> [A] (550 V) 81	104	131
	I <sub>VLT, MAX</sub> (60 s) [A] (550 V) 130	166	210
	I <sub>VLT,N</sub> [A] (575 V) 77	99	125
	I <sub>VLT, MAX</sub> (60 s) [A] (575 V) 123	158	200
Output	S <sub>VLT,N</sub> [kVA] (550 V) 77	99	125
	S <sub>VLT,N</sub> [kVA] (575 V) 77	99	124
Typical shaft output (380-440 V) P <sub>VLT,N</sub> [kW]			
	55	75	90
Typical shaft output (380-440 V) P <sub>VLT,N</sub> [HP]			
	75	100	125
Max. cross-section of copper cable to motor, brake and load sharing (380-440 V) [mm <sup>2</sup> ] [AWG]			
	120	120	120
	4/0	4/0	4/0
Max. cross-section of copper cable to motor, brake and load sharing (441-500 V) [mm <sup>2</sup> ] [AWG]			
	185	185	185
	300 mcm	300 mcm	300 mcm
Min. cable cross-section to motor, brake and load sharing <sup>4)</sup> [mm <sup>2</sup> / AWG]			
	6	6	6
	8	8	8

1. For type of fuse, see section *Fuses*.
2. American Wire Gauge.
3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.
4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section.
5. Connection stud 1 x M8/2 x M8.

Technical data



**Compact, AC line supply 3 x 550-600 V**

According to international requirements	VLT type	5075	5100	5125
Max input current 110% I <sub>L,MAX</sub> [A] (550 V)	101	128	147	
I <sub>L,MAX</sub> [A] (575 V)	92	117	134	
Max input current 160% I <sub>L,MAX</sub> [A] (550 V)	79	101	128	
I <sub>L,MAX</sub> [A] (575 V)	72	92	117	
Max. cross-section of copper cable to power [mm <sup>2</sup> ]	120	120	120	
Max. cross-section of aluminum cable to power [mm <sup>2</sup> ]	185	185	185	
Max. cross-section of copper cable to power [AWG]	4/0	4/0	4/0	
Max. cross-section of aluminum cable to power [AWG]	300 mcm	300 mcm	300 mcm	
Min. cable cross-section to motor, brake and load sharing <sup>4)</sup> [mm <sup>2</sup> / AWG] <sup>2)</sup> 5)	6/8	6/8	6/8	
Max. pre-fuses (line power) [-]/UL <sup>1)</sup> [A]	125	175	200	
Integral pre-fuses (softcharge circuit) [-]/UL <sup>6)</sup> [A]	15/15	15/15	15/15	
Integral pre-fuses (softcharge resistors) [-]/UL <sup>7)</sup> [A]	12/12	12/12	12/12	
Integral pre-fuses (SMPS) [-]/UL <sup>8)</sup> [A]	5	5	5	
Efficiency	0.96-0.97			
Weight IP 00	[kg]	109	109	109
Weight Nema 1 EB	[kg]	121	121	121
Power loss at max. load [W]		2560	3275	3775
Enclosure				IP 00/Nema 1 (IP 20)

1. For type of fuse, see section Fuses.  
 2. American Wire Gauge.  
 3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.  
 4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section.  
 5. Connection stud 1 x M8/2 x M8.  
 6. If UL/cUL is to be complied with, AC Littelfuse type KLK, Danfoss ordering no. 176F1147 must be used.  
 7. If UL/cUL is to be complied with, DC Littelfuse type KLKD, Danfoss ordering no. 176F1192 must be used.  
 8. If UL/cUL is to be complied with, Bussmann type KTK-5, Danfoss ordering no. 175L3437 must be used.

**Compact, AC line supply 3 x 550-600 V**

According to international requirements	VLT type 5150	5200	5250
<b>Normal overload torque (110 %):</b>			
Output current	I <sub>VLT,N</sub> [A] (550 V) 201	253	289
	I <sub>VLT, MAX (60 s)</sub> [A] (550 V) 221	278	318
	I <sub>VLT,N</sub> [A] (575 V) 192	242	289
	I <sub>VLT, MAX (60 s)</sub> [A] (575 V) 211	266	318
Output	S <sub>VLT,N</sub> [kVA] (550 V) 191	241	275
	S <sub>VLT,N</sub> [kVA] (575 V) 191	241	288
<b>Typical shaft output P<sub>VLT,N</sub> [kW]</b>			
	132	160	200
<b>Typical shaft output P<sub>VLT,N</sub> [HP]</b>			
	200	250	300
<b>High overload torque (160 %):</b>			
Output current	I <sub>VLT,N</sub> [A] (550 V) 151	201	253
	I <sub>VLT, MAX (60 s)</sub> [A] (550 V) 242	322	405
	I <sub>VLT,N</sub> [A] (575V) 144	192	242
	I <sub>VLT, MAX (60 s)</sub> [A] (575 V) 230	307	387
Output	S <sub>VLT,N</sub> [kVA] (550 V) 144	191	241
	S <sub>VLT,N</sub> [kVA] (575 V) 143	191	241
<b>Typical shaft output P<sub>VLT,N</sub> [kW]</b>			
	110	132	160
<b>Typical shaft output P<sub>VLT,N</sub> [HP]</b>			
	150	200	250
Max. cross-section of copper cable to motor, brake and loads haring [mm <sup>2</sup> ] AWG	2x120 2x4/0	2x120 2x4/0	2x120 2x4/0
Max. cross-section of copper cable to motor, brake and loads haring [mm <sup>2</sup> ] AWG	2x185 2x300 mcm	2x185 2x300 mcm	2x185 2x300 mcm
Min. cable cross-section to motor, brake and load sharing <sup>4)</sup> [mm <sup>2</sup> ] AWG	2x6 2x8	2x6 2x8	2x6 2x8

1. For type of fuse, see section *Fuses*.
2. American Wire Gauge.
3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.
4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section.
5. Connection stud 1 x M8/2 x M8.

Technical data

**Compact AC line supply 3 x 550-600 V**

According to international requirements	VLT type	5150	5200	5250
Max input current 110% I <sub>L,MAX</sub> [A] (550 V)	196	246	281	
I <sub>L,MAX</sub> [A] (575 V)	179	226	270	
Max input current 160% I <sub>L,MAX</sub> [A] (550 V)	147	196	246	
I <sub>L,MAX</sub> [A] (575 V)	134	179	226	
Max. cross-section of copper cable to power [mm <sup>2</sup> ]	2 x 120	2 x 120	2 x 120	
Max. cross-section of aluminum cable to power [mm <sup>2</sup> ]	2 x 185	2 x 185	2 x 185	
Max. cross-section of copper cable to power [AWG]	2 x 4/0	2 x 4/0	2 x 4/0	
Max. cross-section of aluminum cable to power [AWG]	2 x 300 mcm	2 x 300 mcm	2 x 300 mcm	
Min. cable cross-section to motor, brake and load sharing <sup>4)</sup> [mm <sup>2</sup> / AWG] <sup>2)</sup> 5)	6/8	6/8	6/8	
Max. pre-fuses (line power) [-]/UL <sup>1)</sup> [A]	250	350	400	
Integral pre-fuses (softcharge circuit) [-]/UL <sup>6)</sup> [A]	30/30	30/30	30/30	
Integral pre-fuses (softcharge resistors) [-]/UL <sup>7)</sup> [A]	12/12	12/12	12/12	
Integral pre-fuses (SMPS) [-]/UL <sup>8)</sup> [A]	5	5	5	
Efficiency	0.96-0.97			
Weight IP 00	[kg]	146	146	146
Weight Nema 1 EB	[kg]	161	161	161
Power loss at max. load [W]		5030	6340	7570
Enclosure				IP 00/Nema 1 (IP 20)


1. For type of fuse, see section *Fuses*.  
 2. American Wire Gauge.  
 3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.  
 4. Min. cable cross-section is the smallest cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section.  
 5. Connection stud 1 x M8/2 x M8.  
 6. If UL/cUL is to be complied with, AC Littelfuse type KLK, Danfoss ordering no. 176F1147 must be used.  
 7. If UL/cUL is to be complied with, DC Littelfuse type KLKD, Danfoss ordering no. 176F1192 must be used.  
 8. If UL/cUL is to be complied with, Bussmann type KTK-5, Danfoss ordering no. 175L3437 must be used.

**■ AC line supply 3 x 525-690 V**

According to international requirements

VLT type 5042 5052 5062 5072 5102

<b>Normal overload torque (110 %):</b>					
Output current	I <sub>VLT,N</sub> [A] (525-550 V)	56	76	90	113
	I <sub>VLT, MAX (60 s)</sub> [A] (525-550 V)	62	84	99	124
	I <sub>VLT,N</sub> [A] (551-690 V)	54	73	86	108
	I <sub>VLT, MAX (60 s)</sub> [A] (551-690 V)	59	80	95	119
Output	S <sub>VLT,N</sub> [kVA] (550 V)	53	72	86	108
	S <sub>VLT,N</sub> [kVA] (575 V)	54	73	86	108
	S <sub>VLT,N</sub> [kVA] (690 V)	65	87	103	129
Typical shaft output	[kW] (550 V)	37	45	55	75
	[HP] (575 V)	50	60	75	100
	[kW] (690 V)	45	55	75	90
<b>High overload torque (160 %):</b>					
Output current	I <sub>VLT,N</sub> [A] (525-550 V)	48	56	76	90
	I <sub>VLT, MAX (60 s)</sub> [A] (525-550 V)	77	90	122	135
	I <sub>VLT,N</sub> [A] (551-690 V)	46	54	73	86
	I <sub>VLT, MAX (60 s)</sub> [A] (551-690 V)	74	86	117	129
Output	S <sub>VLT,N</sub> [kVA] (550 V)	46	53	72	86
	S <sub>VLT,N</sub> [kVA] (575 V)	46	54	73	86
	S <sub>VLT,N</sub> [kVA] (690 V)	55	65	87	103
Typical shaft output	[kW] (550 V)	30	37	45	55
	[HP] (575 V)	40	50	60	75
	[kW] (690 V)	37	45	55	75
Max. cable cross-section to motor	[mm <sup>2</sup> ] <sup>4,6</sup> 2 x 70 [AWG] <sup>2,4,6</sup> 2 x 2/0				
Max. cable cross-section to load sharing and brake	[mm <sup>2</sup> ] <sup>4,6</sup> 2 x 70 [AWG] <sup>2,4,6</sup> 2 x 2/0				
<b>Normal overload torque (110 %):</b>					
Rated input current	I <sub>L,N</sub> [A] (550 V)	60	77	89	110
	I <sub>L,N</sub> [A] (575 V)	58	74	85	106
	I <sub>L,N</sub> [A] (690 V)	58	77	87	109
<b>High overload torque (160 %):</b>					
Rated input current	I <sub>L,N</sub> [A] (550 V)	53	60	77	89
	I <sub>L,N</sub> [A] (575 V)	51	58	74	85
	I <sub>L,N</sub> [A] (690 V)	50	58	77	87
Max. cable cross-section power supply	[mm <sup>2</sup> ] <sup>4,6</sup> 2 x 70 [AWG] <sup>2,4,6</sup> 2 x 2/0				
Max. pre-fuses (line) [-]/UL	[A] <sup>1</sup>	125	160	200	200
Efficiency <sup>3</sup>		0.97	0.97	0.98	0.98
Power loss	Normal overload [W]	1458	1717	1913	2262
	High overload [W]	1355	1459	1721	1913
Weight	IP 00 [kg]		82		
Weight	IP 21/NEMA 1 [kg]		96		
Weight	IP 54/NEMA 12 [kg]		96		
Enclosure	IP 00, IP 21/NEMA 1 and IP 54/NEMA 12				



1. For type of fuse, see section Fuses.

2. American Wire Gauge.

3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.

4. Max. cable cross-section is the maximum possible cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section.

5. Weight without shipping container.

6. Connection bolt power supply and motor: M10; Brake and load sharing: M8


**■ AC line supply 3 x 525-690 V**

According to international requirements

VLT type 5122 5152 5202 5252 5302 5352

**Normal overload torque (110 %):**

Output current	$I_{VLT,N}$ [A] (525-550 V)	162	201	253	303	360	418
	$I_{VLT, MAX}$ (60 s) [A] (525-550 V)	178	221	278	333	396	460
	$I_{VLT,N}$ [A] (551-690 V)	155	192	242	290	344	400
	$I_{VLT, MAX}$ (60 s) [A] (551-690 V)	171	211	266	319	378	440



Output	$S_{VLT,N}$ [kVA] (550 V)	154	191	241	289	343	398
	$S_{VLT,N}$ [kVA] (575 V)	154	191	241	289	343	398
	$S_{VLT,N}$ [kVA] (690 V)	185	229	289	347	411	478

Typical shaft output	[kW] (550 V)	110	132	160	200	250	315
	[HP] (575 V)	150	200	250	300	350	400
	[kW] (690 V)	132	160	200	250	315	400

High overload torque (160 %):							
Output current	$I_{VLT,N}$ [A] (525-550 V)	137	162	201	253	303	360
	$I_{VLT, MAX}$ (60 s) [A] (525-550 V)	206	243	302	380	455	540
	$I_{VLT,N}$ [A] (551-690 V)	131	155	192	242	290	344
	$I_{VLT, MAX}$ (60 s) [A] (551-690 V)	197	233	288	363	435	516


Output	$S_{VLT,N}$ [kVA] (550 V)	131	154	191	241	289	343
	$S_{VLT,N}$ [kVA] (575 V)	130	154	191	241	289	343
	$S_{VLT,N}$ [kVA] (690 V)	157	185	229	289	347	411

Typical shaft output	[kW] (550 V)	90	110	132	160	200	250
	[HP] (575 V)	125	150	200	250	300	350
	[kW] (690 V)	110	132	160	200	250	315

Max. cable cross-section to motor	[mm <sup>2</sup> ] <sup>4,6</sup> 2 x 70	2 x 185				
	[AWG] <sup>2,4,6</sup> 2 x 2/0	2 x 350 mcm				

Max. cable cross-section to load sharing and brake	[mm <sup>2</sup> ] <sup>4,6</sup> 2 x 70	2 x 185				
	[AWG] <sup>2,4,6</sup> 2 x 2/0	2 x 350 mcm				

Normal overload torque (110 %):							
Rated input current	$I_{L,N}$ [A] (550 V)	158	198	245	299	355	408
	$I_{L,N}$ [A] (575 V)	151	189	234	286	339	390
	$I_{L,N}$ [A] (690 V)	155	197	240	296	352	400



High overload torque (160 %):							
Rated input current	$I_{L,N}$ [A] (550 V)	130	158	198	245	299	355
	$I_{L,N}$ [A] (575 V)	124	151	189	234	286	339
	$I_{L,N}$ [A] (690 V)	128	155	197	240	296	352

Max. cable cross-section power supply	[mm <sup>2</sup> ] <sup>4,6</sup> 2 x 70	2 x 185				
	[AWG] <sup>2,4,6</sup> 2 x 2/0	2 x 350 mcm				

Max. pre-fuses (line) [-]/ UL	[A] <sup>1</sup>	315	350	350	400	500	550
----------------------------------	------------------	-----	-----	-----	-----	-----	-----

Efficiency <sup>3</sup>	0,98						
Power loss	Normal overload [W]	3114	3612	4292	5155	5821	6149

	High overload [W]	2664	2952	3451	4275	4875	5185
--	-------------------	------	------	------	------	------	------

Weight	IP 00 [kg]	82	91	112	123	138	151
--------	------------	----	----	-----	-----	-----	-----

Weight	IP 21/NEMA 1 [kg]	96	104	125	136	151	165
--------	-------------------	----	-----	-----	-----	-----	-----

Enclosure	IP 00, IP 21/NEMA 1 and IP 54/NEMA 12						
-----------	---------------------------------------	--	--	--	--	--	--

1. For type of fuse, see section *Fuses*.
2. American Wire Gauge.
3. Measured using 100 ft [30 m] shielded motor cables at rated load and rated frequency.
4. Max. cable cross-section is the maximum possible cable cross-section allowed to be fitted on the terminals. Always comply with national and local regulations on min. cable cross-section.
5. Weight without shipping container.
6. Connection bolt power supply and motor: M10; Brake and load sharing: M8



## VLT® 5000 Series

### ■ Fuses

#### UL compliance

To comply with UL/cUL approvals, pre-fuses according to the table below must be used.

#### 200-240 V

VLT	Bussmann	SIBA	Littel fuse	Ferraz-Shawmut
5001	KTN-R10	5017906-010	KLN-R10	ATM-R10 or A2K-10R
5002	KTN-R10	5017906-010	KLN-R10	ATM-R10 or A2K-10R
5003	KTN-R25	5017906-016	KLN-R15	ATM-R15 or A2K-15R
5004	KTN-R20	5017906-020	KLN-R20	ATM-R20 or A2K-20R
5005	KTN-R25	5017906-025	KLN-R25	ATM-R25 or A2K-25R
5006	KTN-R30	5012406-032	KLN-R30	ATM-R30 or A2K-30R
5008	KTN-R50	5014006-050	KLN-R50	A2K-50R
5011	KTN-R60	5014006-063	KLN-R60	A2K-60R
5016	KTN-R85	5014006-080	KLN-R80	A2K-80R
5022	KTN-R125	2028220-125	KLN-R125	A2K-125R
5027	KTN-R125	2028220-125	KLN-R125	A2K-125R
5032	KTN-R150	2028220-160	L25S-150	A25X-150
5042	KTN-R200	2028220-200	L25S-200	A25X-200
5052	KTN-R250	2028220-250	L25S-250	A25X-250

#### 380-500 V

	Bussmann	SIBA	Littel fuse	Ferraz-Shawmut
5001	KTS-R6	5017906-006	KLS-R6	ATM-R6 or A6K-6R
5002	KTS-R6	5017906-006	KLS-R6	ATM-R6 or A6K-6R
5003	KTS-R10	5017906-010	KLS-R10	ATM-R10 or A6K-10R
5004	KTS-R10	5017906-010	KLS-R10	ATM-R10 or A6K-10R
5005	KTS-R15	5017906-016	KLS-R16	ATM-R16 or A6K-16R
5006	KTS-R20	5017906-020	KLS-R20	ATM-R20 or A6K-20R
5008	KTS-R25	5017906-025	KLS-R25	ATM-R25 or A6K-25R
5011	KTS-R30	5012406-032	KLS-R30	A6K-30R
5016	KTS-R40	5012406-040	KLS-R40	A6K-40R
5022	KTS-R50	5014006-050	KLS-R50	A6K-50R
5027	KTS-R60	5014006-063	KLS-R60	A6K-60R
5032	KTS-R80	2028220-100	KLS-R80	A6K-180R
5042	KTS-R100	2028220-125	KLS-R100	A6K-100R
5052	KTS-R125	2028220-125	KLS-R125	A6K-125R
5062	KTS-R150	2028220-160	KLS-R150	A6K-150R
5072	FWH-220	2028220-200	L50S-225	A50-P225
5102	FWH-250	2028220-250	L50S-250	A50-P250
5122*	FWH-300/170M3017	2028220-315	L50S-300	A50-P300
5152*	FWH-350/170M3018	2028220-315	L50S-350	A50-P350
5202*	FWH-400/170M4012	206xx32-400	L50S-400	A50-P400
5252*	FWH-500/170M4014	206xx32-500	L50S-500	A50-P500
5302*	FWH-600/170M4016	206xx32-600	L50S-600	A50-P600
5352	170M4017	2061032,700		6.9URD31D08A0700
5452	170M6013	2063032,900		6.9URD33D08A0900
5502	170M6013	2063032,900		6.9URD33D08A0900
5552	170M6013	2063032,900		6.9URD33D08A0900

\* Circuit Breakers manufactured by General Electric, Cat. No. SKHA36AT0800, with rating plugs listed below can be used to meet UL-requirements:

5122	rating plug No.	SRPK800 A 300
5152	rating plug No.	SRPK800 A 400
5202	rating plug No.	SRPK800 A 400
5252	rating plug No.	SRPK800 A 500
5302	rating plug No.	SRPK800 A 600

Technical data



## VLT® 5000 Series

### 525-600 V

	Bussmann	SIBA	Littel fuse	Ferraz-Shawmut
5001	KTS-R3	5017906-004	KLS-R003	A6K-3R
5002	KTS-R4	5017906-004	KLS-R004	A6K-4R
5003	KT-R5	5017906-005	KLS-R005	A6K-5R
5004	KTS-R6	5017906-006	KLS-R006	A6K-6R
5005	KTS-R8	5017906-008	KLS-R008	A6K-8R
5006	KTS-R10	5017906-010	KLS-R010	A6K-10R
5008	KTS-R15	5017906-016	KLS-R015	A6K-15R
5011	KTS-R20	5017906-020	KLS-R020	A6K-20R
5016	KTS-R30	5017906-030	KLS-R030	A6K-30R
5022	KTS-R35	5014006-040	KLS-R035	A6K-35R
5027	KTS-R45	5014006-050	KLS-R045	A6K-45R
5032	KTS-R60	5014006-063	KLS-R060	A6K-60R
5042	KTS-R75	5014006-080	KLS-R075	A6K-80R
5052	KTS-R90	5014006-100	KLS-R090	A6K-90R
5062	KTS-R100	5014006-100	KLS-R100	A6K-100R

### 525-600 V (UL) and 525-690 V (CE) drives

	Bussmann	SIBA	FERRAZ-SHAWMUT
5042	170M3013	2061032,125	6.6URD30D08A0125
5052	170M3014	2061032,16	6.6URD30D08A0160
5062	170M3015	2061032,2	6.6URD30D08A0200
5072	170M3015	2061032,2	6.6URD30D08A0200
5102	170M3016	2061032,25	6.6URD30D08A0250
5122	170M3017	2061032,315	6.6URD30D08A0315
5152	170M3018	2061032,35	6.6URD30D08A0350
5202	170M4011	2061032,35	6.6URD30D08A0350
5252	170M4012	2061032,4	6.6URD30D08A0400
5302	170M4014	2061032,5	6.6URD30D08A0500
5352	170M5011	2062032,55	6.6URD32D08A550
5402	170M4017	2061032,700	6.9URD31D08A0700
5502	170M6013	2063032,900	6.9URD33D08A0900
5602	170M6013	2063032,900	6.9URD33D08A0900

KTS-fuses from Bussmann may substitute KTN for 240 V drives.

FWH-fuses from Bussmann may substitute FWX for 240 V drives.

KLSR fuses from LITTEL FUSE may substitute KLNR fuses for 240 V drives.

L50S fuses from LITTEL FUSE may substitute L25S fuses for 240 V drives.

A6KR fuses from FERRAZ SHAWMUT may substitute A2KR for 240 V drives.

A50X fuses from FERRAZ SHAWMUT may substitute A25X for 240 V drives.

### Non UL compliance

If UL/cUL is not to be complied with, we recommend the above mentioned fuses or:

VLT 5001-5027	200-240 V	type gG
VLT 5032-5052	200-240 V	type gR
VLT 5001-5062	380-500 V	type gG
VLT 5072-5102	380-500 V	type gR
VLT 5122-5302	380-500 V	type gG
VLT 5352-5552	380-500 V	type gR
VLT 5001-5062	525-600 V	type gG

Not following the recommendation may result in unnecessary damage of the drive in case of malfunction. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100000 A<sub>rms</sub> (symmetrical), 500/600 V maximum.

**■ Brake resistors, VLT 5001 - 5052 / 200 - 240 V**
**Standard brake resistors**

VLT	10% duty cycle			40% duty cycle		
	Resistance [ohm]	Power [kW]	Code No.	Resistance [ohm]	Power [kW]	Code No.
5001	145	0.065	175U1820	145	0.260	175U1920
5002	90	0.095	175U1821	90	0.430	175U1921
5003	65	0.250	175U1822	65	0.80	175U1922
5004	50	0.285	175U1823	50	1.00	175U1923
5005	35	0.430	175U1824	35	1.35	175U1924
5006	25	0.8	175U1825	25	3.00	175U1925
5008	20	1.0	175U1826	20	3.50	175U1926
5011	15	1.8	175U1827	15	5.00	175U1927
5016	10	2.8	175U1828	10	9.0	175U1928
5022	7	4.0	175U1829	7	10.0	175U1929
5027	6	4.8	175U1830	6	12.7	175U1930
5032	4.7	6	175U1954	Not available	Not available	Not available
5042	3.3	8	175U1955	Not available	Not available	Not available
5052	2.7	10	175U1956	Not available	Not available	Not available

See Instruction MI.90.FX.YY for further information.

Technical data

**Flatpack brake resistors for horizontal conveyors**

VLT type	Motor [kW]	Resistor [ohm]	Size	Order number	Max. duty cycle [%]
5001	0.75	150	150 Ω 100 W	175U1005	14.0
5001	0.75	150	150 Ω 200 W	175U0989	40.0
5002	1.1	100	100 Ω 100 W	175U1006	8.0
5002	1.1	100	100 Ω 200 W	175U0991	20.0
5003	1.5	72	72 Ω 200 W	175U0992	16.0
5004	2.2	47	50 Ω 200 W	175U0993	9.0
5005	3	35	35 Ω 200 W	175U0994	5.5
5005	3	35	72 Ω 200 W	2 x 175U0992 <sup>1</sup>	12.0
5006	4	25	50 Ω 200 W	2 x 175U0993 <sup>1</sup>	11.0
5008	5.5	20	40 Ω 200 W	2 x 175U0996 <sup>1</sup>	6.5
5011	7.5	13	27 Ω 200 W	2 x 175U0995 <sup>1</sup>	4.0

1. Order 2 pcs.

Mounting frame for 2 resistors broad (wide bookstyle)

Mounting angle for flatpack resistor 100 W 175U0011

175U0003

Mounting angle for flatpack resistor 200 W 175U0009

See Instruction MI.50.BX.YY for further information.

Mounting frame for 1 resistor narrow (slim bookstyle)

175U0002

Mounting frame for 2 resistors narrow (slim bookstyle)

175U0004



## VLT® 5000 Series

- Ordering numbers, Brake resistors, VLT 5001 -  
5552 / 380 - 500 V

### Standard brake resistors

VLT	10% duty cycle			40% duty cycle		
	Resistance [ohm]	Power [kW]	Code No.	Resistance [ohm]	Power [kW]	Code No.
5001	620	0.065	175U1840	620	0.260	175U1940
5002	425	0.095	175U1841	425	0.430	175U1941
5003	310	0.250	175U1842	310	0.80	175U1942
5004	210	0.285	175U1843	210	1.35	175U1943
5005	150	0.430	175U1844	150	2.0	175U1944
5006	110	0.60	175U1845	110	2.4	175U1945
5008	80	0.85	175U1846	80	3.0	175U1946
5011	65	1.0	175U1847	65	4.5	175U1947
5016	40	1.8	175U1848	40	5.0	175U1948
5022	30	2.8	175U1849	30	9.3	175U1949
5027	25	3.5	175U1850	25	12.7	175U1950
5032	20	4.0	175U1851	20	13.0	175U1951
5042	15	4.8	175U1852	15	15.6	175U1952
5052	12	5.5	175U1853	12	19.0	175U1953
5062	9.8	15	175U2008	9.8	38.0	175U2008
5072	7.3	13	175U0069	5.7	38.0	175U0068
5102	5.7	15	175U0067	4.7	45.0	175U0066
5122 <sup>2)</sup>	3.8	22	175U1960			
5152 <sup>2)</sup>	3.2	27	175U1961			
5202 <sup>2)</sup>	2.6	32	175U1962			
5252 <sup>2)</sup>	2.1	39	175U1963			
5302 <sup>2)</sup>	1.65	56	2 x 175U1061 <sup>1)</sup>			
5352-5552 <sup>2)</sup>	1.3	72	2 x 175U1062 <sup>1) 3)</sup>			

1. Order 2 pcs. Connect in parallel.
2. Resistors selected for 300 second cycle.
3. Rating fulfilled up to VLT 5452, the torque is reduced for VLT 5502 and VLT 5552.

See *Instruction MI.90.FX.YY* for further information.



## VLT® 5000 Series

### Flatpack brake resistors for horizontal conveyors

VLT type	Motor [kW]	Resistor [ohm]	Size	Order number	Max. duty cycle [%]
5001	0.75	630	620 Ω 100 W	175U1001	14.0
5001	0.75	630	620 Ω 200 W	175U0982	40.0
5002	1.1	430	430 Ω 100 W	175U1002	8.0
5002	1.1	430	430 Ω 200 W	175U0983	20.0
5003	1.5	320	310 Ω 200 W	175U0984	16.0
5004	2.2	215	210 Ω 200 W	175U0987	9.0
5005	3	150	150 Ω 200 W	175U0989	5.5
5005	3	150	300 Ω 200 W	2 x 175U0985 <sup>1</sup>	12.0
5006	4	120	240 Ω 200 W	2 x 175U0986 <sup>1</sup>	11.0
5008	5.5	82	160 Ω 200 W	2 x 175U0988 <sup>1</sup>	6.5
5011	7.5	65	130 Ω 200 W	2 x 175U0990 <sup>1</sup>	4.0

1. Order 2 pcs.

Mounting angle for flatpack resistor 100 W 175U0011.

Mounting angle for flatpack resistor 200 W 175U0009.

Mounting frame for 1 resistor narrow (slim bookstyle) 175U0002.

Mounting frame for 2 resistors narrow (slim bookstyle) 175U0004.

Mounting frame for 2 resistors broad (wide bookstyle) 175U0003.

See *Instruction MI.50.BX.YY* for further information.

For 525-600 V and 525-690 V please contact Danfoss.

Technical data



## VLT® 5000 Series

### ■ Ordering numbers, Brake resistors, VLT 5001 - 5250 / 550 - 600 V

#### Standard brake resistors

VLT	10% duty cycle			40% duty cycle <sup>4</sup>		
	Resistance [ohm] <sup>2</sup>	Power [kW]	Code No.	Resistance [ohm] <sup>2</sup>	Power [kW]	Code No.
5001 <sup>3</sup>	797.0	0.11	*1)	797.0	0.44	*1)
5002 <sup>3</sup>	534.0	0.16	*1)	534.0	0.64	*1)
5003 <sup>3</sup>	398.0	0.22	*1)	398.0	0.88	*1)
5004 <sup>3</sup>	267.0	0.32	*1)	267.0	1.28	*1)
5005 <sup>3</sup>	199.0	0.44	*1)	199.0	1.75	*1)
5006 <sup>3</sup>	149.0	0.58	*1)	149.0	2.33	*1)
5008 <sup>3</sup>	107.0	0.80	*1)	107.0	3.21	*1)
5011 <sup>3</sup>	80.0	1.09	*1)	80.0	4.38	*1)
5016 <sup>3</sup>	53.4	1.60	*1)	53.4	6.42	*1)
5022 <sup>3</sup>	39.8	2.19	*1)	39.8	8.75	*1)
5027 <sup>3</sup>	32.0	2.70	*1)	32.0	10.80	*1)
5032 <sup>3</sup>	26.7	3.21	*1)	26.7	12.84	*1)
5042 <sup>3</sup>	19.9	4.38	*1)	19.9	17.51	*1)
5052 <sup>3</sup>	16.0	5.40	*1)	16.0	21.59	*1)
5062 <sup>3</sup>	13.3	6.56	*1)	13.3	26.26	*1)
5075 <sup>5</sup>	11.0	8.16	*1)			
5100 <sup>5</sup>	8.2	10.88	*1)			
5125 <sup>5</sup>	6.8	13.60	*1)			
5150 <sup>5</sup>	5.6	16.32	*1)			
5200 <sup>5</sup>	4.3	21.77	*1)			
5250 <sup>5</sup>	3.3	27.21	*1)			

1) No Danfoss part number. Resistors must be ordered from another vendor according to specifications. See instruction MI.90.FX.YY for further information.

2) Tolerance +/- 5%

3) 10% Duty Cycle, 120 second period

4) 40% Duty Cycle, 120 second period

5) 10% Duty Cycle, 300 second period

### ■ Ordering numbers, Harmonic filters

Harmonic filters are used to reduce mains harmonics

- AHF 010: 10% current distortion
- AHF 005: 5% current distortion

### 380-415 V, 50Hz

I <sub>AHF,N</sub>	Typical [kW]	Motor Used	Danfoss ordering number		VLT 5000
			AHF 005	AHF 010	
10 A	4, 5.5		175G6600	175G6622	5006, 5008
19 A	7.5		175G6601	175G6623	5011
26 A	11		175G6602	175G6624	5016
35 A	15, 18.5		175G6603	175G6625	5022, 5027
43 A	22		175G6604	175G6626	5032
72 A	30, 37		175G6605	175G6627	5042, 5052
101 A	45, 55		175G6606	175G6628	5062, 5072
144 A	75		175G6607	175G6629	5102
180 A	90		175G6608	175G6630	5122
217 A	110		175G6609	175G6631	5152
289 A	132, 160		175G6610	175G6632	5202, 5252
324 A			175G6611	175G6633	
370 A	200		175G6688	175G6691	5302
Higher ratings can be achieved by paralleling the filter units					
434 A	250		Two 217 A units		5352
578 A	315		Two 289 A units		5452
613 A	355		289 A and 324 A units		5502
648 A	400		Two 324 A units		5552

Technical data

Please note that the matching of the typical Danfoss frequency converter and filter is pre-calculated based on 400 V and assuming typical motor load (4 or 2 pole motor): VLT 5000 series is based on a max. 160 % torque application. The pre-calculated filter current may be different than the input current ratings of VLT 5000 as stated in the respective operating instructions, as these numbers are based on different operating conditions.

### 440-480 V, 60Hz

I <sub>AHF,N</sub>	Typical [HP]	Motor Used	Danfoss ordering number		VLT 5000
			AHF 005	AHF 010	
19 A	10, 15		175G6612	175G6634	5011, 5016
26 A	20		175G6613	175G6635	5022
35 A	25, 30		175G6614	175G6636	5027, 5032
43 A	40		175G6615	175G6637	5042
72 A	50, 60		175G6616	175G6638	5052, 5062
101 A	75		175G6617	175G6639	5072
144 A	100, 125		175G6618	175G6640	5102, 5122
180 A	150		175G6619	175G6641	5152
217 A	200		175G6620	175G6642	5202
289 A	250		175G6621	175G6643	5252
324 A	300		175G6689	175G6692	5302
370 A	350		175G6690	175G6693	5352
Higher ratings can be achieved by paralleling the filter units					
506 A	450		217 A and 289 A units		5452
578 A	500		Two 289 A units		5502
648 A	600		Two 324 A units		5552

Please note that the matching of the typical Danfoss frequency converter and filter is pre-calculated based on 480 V and assuming typical motor load (4 or 2 pole motor): VLT 5000 series is based on a max. 160 % torque application. The pre-calculated filter current may be different than the input current ratings of VLT 5000 as stated in the respective operating instructions, as these numbers are based on different operating conditions.



## VLT® 5000 Series

### 500 V, 50 Hz

I <sub>AHF,N</sub>	Typical [kW]	Motor Used	Danfoss ordering number		VLT 5000
			AHF 005	AHF 010	
10 A	4, 5.5		175G6644	175G6656	5006, 5008
19 A	7.5, 11		175G6645	175G6657	5011, 5016
26 A	15, 18.5		175G6646	175G6658	5022, 5027
35 A	22		175G6647	175G6659	5032
43 A	30		175G6648	175G6660	5042
72 A	37, 45		175G6649	175G6661	5052, 5062
101 A	55, 75		175G6650	175G6662	5062, 5072
144 A	90, 110		175G6651	175G6663	5102, 5122
180 A	132		175G6652	175G6664	5152
217 A	160		175G6653	175G6665	5202
289 A	200		175G6654	175G6666	5252
324 A	250		175G6655	175G6667	5302
Higher ratings can be achieved by paralleling the filter units					
434 A	315		Two 217 A units		5352
469 A	355		180 A and 289 A units		5452
578 A	400		Two 289 A units		5502
648 A	500		Two 324 A units		5552

Please note that the matching of the typical Danfoss frequency converter and filter is pre-calculated based on 500 V and assuming typical motor load. VLT 5000 series is based on a 160 % torque application. The pre-calculated filter current may be varying from the input current ratings of VLT 5000 as stated in the respective operating instructions, as these numbers are based on different operating conditions. For further combinations, please consult MG.80.BX.YY.

### 690 V, 50 Hz

I AHF,N	Typical motor used (kW)	Ordering no. AHF 005	Ordering no. AHF 010	VLT 5000 160%	VLT 5000 110%
43	37, 45	130B2328	130B2293	5042, 5042	5042
72	55, 75	130B2330	130B2295	5062, 5072	5052, 5062
101	90	130B2331	130B2296	5102	5072
144	110, 132	130B2333	130B2298	5122, 5152	5102, 5122
180	160	130B2334	130B2299	5202	5152
217	200	130B2335	130B2300	5252	5202
289	250	130B2331 & 130B2333	130B2301	5302	5252
324	315	130B2333 & 130B2334	130B2302	5352	5302
370	400	130B2334 & 130B2335	130B2304		5352
469	500	130B2333 & 2 x 130B2334	130B2299 & 130B2301	5502	5402
578	560	3 x 130B2334	2 x 130B2301	5602	5502
613	630	3 x 130B2335	130B2301 & 130B2302		5602



## VLT® 5000 Series

### ■ Mechanical dimensions

All the below listed measurements are in mm.








	A	B	C	D	a	b	ab/be	Type
<b>Bookstyle IP 20</b>								
5001 - 5003 200 - 240 V	395	90	260		384	70	100	A
5001 - 5005 380 - 500 V								
5004 - 5006 200 - 240 V	395	130	260		384	70	100	A
5006 - 5011 380 - 500 V								
<b>Compact IP 00</b>								
5032 - 5052 200 - 240 V	800	370	335		780	270	225	B
5122 - 5152 380 - 500 V	1046	408	373 <sup>1)</sup>		1001	304	225	J
5202 - 5302 380 - 500 V	1327	408	373 <sup>1)</sup>		1282	304	225	J
5352 - 5552 380 - 500 V	1547	585	494 <sup>1)</sup>		1502	304	225	I
5042 - 5152 525 - 690 V	1046	408	373 <sup>1)</sup>		1001	304	225	J
5202 - 5352 525 - 690 V	1327	408	373 <sup>1)</sup>		1282	304	225	J
5402 - 5602 525 - 690 V	1547	585	494 <sup>1)</sup>		1502	304	225	I
<b>Compact IP 20</b>								
5001 - 5003 200 - 240 V	395	220	160		384	200	100	C
5001 - 5005 380 - 500 V								
5004 - 5006 200 - 240 V								
5006 - 5011 380 - 500 V	395	220	200		384	200	100	C
5001 - 5011 525 - 600 V (IP 20 and Nema 1)								
5008 200 - 240 V								
5016 - 5022 380 - 500 V	560	242	260		540	200	200	D
5016 - 5022 525 - 600 V (Nema 1)								
5011 - 5016 200 - 240 V								
5027 - 5032 380 - 500 V	700	242	260		680	200	200	D
5027 - 5032 525 - 600 V (Nema 1)								
5022 - 5027 200 - 240 V								
5042 - 5062 380 - 500 V	800	308	296		780	270	200	D
5042 - 5062 525 - 600 V (Nema 1)								
5072 - 5102 380 - 500 V	800	370	335		780	330	225	D
<b>Compact Nema 1/IP20/IP21</b>								
5032 - 5052 200 - 240 V	954	370	335		780	270	225	E
5122 - 5152 380 - 500 V	1208	420	373 <sup>1)</sup>		1154	304	225	J
5202 - 5302 380 - 500 V	1588	420	373 <sup>1)</sup>		1535	304	225	J
5352 - 5552 380 - 500 V	2000	600	494 <sup>1)</sup>		-	-	225	H
5042 - 5152 525 - 690 V	1208	420	373 <sup>1)</sup>		1154	304	225	J
5202 - 5352 525 - 690 V	1588	420	373 <sup>1)</sup>		1535	304	225	J
5402 - 5602 525 - 690 V	2000	600	494 <sup>1)</sup>		-	-	225	H
<b>Compact IP 54/Nema 12</b>								
5001 - 5003 200 - 240 V	460	282	195	85	260	258	100	F
5001 - 5005 380 - 500 V								
5004 - 5006 200 - 240 V								
5006 - 5011 380 - 500 V	530	282	195	85	330	258	100	F
5008 - 5011 200 - 240 V								
5016 - 5027 380 - 500 V	810	350	280	70	560	326	200	F
5016 - 5027 200 - 240 V								
5032 - 5062 380 - 500 V	940	400	280	70	690	375	200	F
5032 - 5052 200 - 240 V	937	495	421	-	830	374	225	G
5072 - 5102 380 - 500 V	940	400	360	70	690	375	225	F
5122 - 5152 380 - 500 V	1208	420	373 <sup>1)</sup>	-	1154	304	225	J
5202 - 5302 380 - 500 V	1588	420	373 <sup>2)</sup>		1535	304	225	J
5352 - 5552 380 - 500 V	2000	600	494 <sup>1)</sup>	-	-	-	225	H
5042 - 5152 525 - 690 V	1208	420	373 <sup>1)</sup>	-	1154	304	225	J
5202 - 5352 525 - 690 V	1588	420	373 <sup>1)</sup>		1535	304	225	J
5402 - 5602 525 - 690 V	2000	600	494 <sup>1)</sup>	-	-	-	225	H

ab: Minimum space above enclosure'

be: Minimum space below enclosure


1) With disconnect, add 44 mm.

Dimensions


**■ Mechanical dimensions, cont.**

**Type A, IP20/Bookstyle**

**Type D, IP20/NEMA 1**

**Type B, IP00/Chassis  
With option and enclosure IP20**

**Type E, IP20/NEMA 1 with terminals**

**Type F, IP54/NEMA 12**

**Type C, IP20/NEMA 1**

**Type G, IP54/NEMA 12**

175ZA577.12


■ Mechanical dimensions (cont.)



Type H, IP 20, IP 54



Type I, IP 00



Type J, IP 00, IP 21, IP 54

Dimensions

### Mechanical installation

#### ■ Mechanical installation



Please pay attention to the requirements that apply to integration and field mounting kit, see the below list. The information given in the list must be observed to avoid serious damage or injury, especially when installing large units.

The frequency converter *must* be installed vertically.

The frequency converter is cooled by means of air circulation. For the unit to be able to release its cooling air, the *minimum* distance over and below the unit must be as shown in the illustration below.

To protect the unit from overheating, it must be ensured that the ambient temperature *does not rise above the max. temperature stated for the frequency converter* and that the 24-hour average temperature *is not exceeded*. The max. temperature and 24-hour average can be seen from the *General Technical Data*.


If the ambient temperature is in the range of 45°C -55°C, derating of the frequency converter will become relevant, see *Derating for ambient temperature*.

The service life of the frequency converter will be reduced if derating for ambient temperature is not taken into account.

#### ■ Installation of VLT 5001-5602

All frequency converters must be installed in a way that ensures proper cooling.




##### Cooling



All Bookstyle and Compact units require a minimum space above and below the enclosure.

### Side by side/flange by flange

All frequency converters can be mounted side by side/flange by flange.






## VLT® 5000 Series

	d [mm]	Comments
Bookstyle		
VLT 5001-5006, 200-240 V	100	
VLT 5001-5011, 380-500 V	100	Installation on a plane, vertical surface (no spacers)
Compact (all enclosure types)		
VLT 5001-5006, 200-240 V	100	
VLT 5001-5011, 380-500 V	100	
VLT 5001-5011, 525-600 V	100	Installation on a plane, vertical surface (no spacers)
VLT 5008-5027, 200-240 V	200	
VLT 5016-5062, 380-500 V	200	
VLT 5072-5102, 380-500 V	225	Installation on a plane, vertical surface (no spacers)
VLT 5016-5062, 525-600 V	200	
VLT 5032-5052, 200-240 V	225	
VLT 5122-5302, 380-500 V	225	Installation on a plane, vertical surface (no spacers)
VLT 5042-5352, 525-690 V	225	IP 54 filter mats must be changed when they are dirty.
VLT 5352-5552, 380-500 V	225	IP 00 above and below enclosure
VLT 5402-5602, 525-690 V	225	IP 21/IP 54 only above enclosure

Installation


- Installation of VLT 5352-5552 380-500 V and VLT 5402-5602 525-690 V Compact Nema 1 (IP 21) and IP 54
- Cooling**



All units in the above-mentioned series require a minimum space of 8.85 inches/225 mm above the enclosure and must be installed on a flat level surface. This applies to both NEMA 1 (IP 20) and NEMA 12 units. Gaining access requires a minimum space of 22.8 inches/579 mm in front of the adjustable frequency drive.

Filter mats in NEMA 12 units have to be changed when they are dirty.

#### Side-by-side



Compact NEMA 1 (IP 20) and NEMA 12

All NEMA 1 (IP 20) and NEMA 12 units in the above-mentioned series can be installed side by side without any space between them, since these units do not require cooling on the sides.

#### ■ IP 00 VLT 5350 - 5500 380 - 500 V

The IP 00 unit is designed for installation in a cabinet when installed according to the instructions in the VLT

5350 - 5500 Installation Guide, MG.56.AX.YY. Please note, that the same conditions as for Nema 1 / IP 54 (Nema12) must be fulfilled.

**Electrical installation****■ Electrical installation**

The voltage on the adjustable frequency drive is dangerous when the unit is connected to mains. Incorrect installation of the motor or the adjustable frequency drive may lead to material damage or serious injury or it may be fatal. Consequently, the instructions in this manual as well as national and local rules and safety regulations must be complied with.  
Touching the electrical parts may be fatal, even after the mains supply has been disconnected.

Using VLT 5001-5006, 200-240 V and 380-500 V: wait at least 4 minutes.

Using VLT 5008-5052, 200-240 V: wait at least 15 minutes.

Using VLT 5008-5062, 380-500 V: wait at least 15 minutes.

Using VLT 5072-5302, 380-500 V: wait at least 20 minutes.

Using VLT 5350-5500, 380-500 V: wait at least 15 minutes.

Using VLT 5001-5005, 525-600 V: wait at least 4 minutes.


Using VLT 5006-5022, 525-600 V: wait at least 15 minutes.

Using VLT 5027-5250, 525-600 V: wait at least 30 minutes.

**NOTE**


It is the user's or certified electrician's responsibility to ensure correct earthing and protection in accordance with applicable national and local norms and standards.

All terminals for the control cables are located under the protective cover of the adjustable frequency drive. The protective cover (see drawing) can be removed by means of a pointed object - a screwdriver or similar.




Installation


Once the protective cover has been removed, the actual EMC-correct installation can start. See drawings in the section, *EMC correct installation*.

**■ Electrical installation, power cables**



**Bookstyle**  
VLT 5001-5006 200-240 V  
VLT 5001-5011 380-500 V




**Compact IP 20/Nema 1**




**Compact IP 54**  
VLT 5001-5006 200-240 V  
VLT 5001-5011 380-500 V  
VLT 5001-5011 525-600 V





**Compact IP 20/Nema 1**  
VLT 5008-5027 200-240 V  
VLT 5016-5062 380-500 V  
VLT 5016-5062 525-600 V



Compact IP 54  
VLT 5008-5027 200-240 V  
VLT 5016-5062 380-500 V




Compact IP 00/NEMA 1 (IP 20)  
VLT 5032-5052 200-240 V




Installation

## VLT® 5000 Series




Compact IP 20  
VLT 5072-5102 380-500 V



Compact IP 54  
VLT 5072-5102 380-500 V


Compact IP 21/IP 54 with disconnect and fuse  
VLT 5122-5152 380-500 V, VLT 5042-5152 525-690 V  
NOTE: The RFI switch has no function in the 525-690 V drives

## VLT® 5000 Series




**Compact IP 21/IP 54 with disconnect and fuse**  
**VLT 5202-5302 380-500 V, VLT 5202-5352 525-690 V**


Note: The RFI switch has no function in the 525-690 V drives



**Compact IP 00 with disconnect and fuse**  
**VLT 5352-5552 380-500 V, VLT 5402-5602 525-690 V**




**Compact IP 00 with disconnect and fuse**  
**VLT 5202-5302 380-500 V, VLT 5202-5352 525-690 V**




**Compact IP 00 without disconnect and fuse**  
**VLT 5352-5552 380-500 V, VLT 5402-5602 525-690 V**

Installation




176FA257.10


**Compact IP 21/IP 54 without disconnect and fuse**  
**VLT 5352-5552 380-500 V, VLT 5402-5602, 525-690 V**  
 Note: The RFI switch has no function in the 525-690 V drives.




**Position of earth terminals, IP 00**



**Position of earth terminals, IP 21/ IP 54**

**■ Electrical installation, power cables**



175ZA085.13




175ZA115.11

**Bookstyle**  
**VLT 5001-5006 200-240 V**  
**VLT 5001-5011 380-500 V**

**Compact IP 54**  
**VLT 5001-5006 200-240 V**  
**VLT 5001-5011 380-500 V**  
**VLT 5001-5011 525-600 V**




**Compact IP 00/NEMA 1**  
**VLT 5008-5027 200-240 V**  
**VLT 5016-5102 380-500 V**  
**VLT 5016-5062 525-600 V**




Installation

**Danfoss**


## VLT® 5000 Series




**Compact IP 00/NEMA 1 (IP20)  
VLT 5032-5052 200-240 V**




**Compact IP 54**  
**VLT 5032-5052 200-240 V**




**Compact IP 54**  
**VLT 5072-5102 380-500 V**

**■ Electrical installation, power cables**



**Compact IP 00/Nema 1 (IP 20)**  
**VLT 5125-5250 380-500 V**  
**VLT 5150-5250 550-600 V**



**Compact IP 54**  
**VLT 5125-5250 380-500 V**




**Compact IP 00/Nema 1 (IP 20)**  
**VLT 5125-5250 380-500 V**  
**VLT 5150-5250 550-600 V**




**Compact IP 54**  
**VLT 5125-5250 380-500 V**

Installation

**■ Electrical installation, power cables**


**Compact IP 00/Nema 1 (IP 20)/IP 54  
without disconnector and mains fuses  
VLT 5300 - 5500 380 - 500 V**



**Compact IP 00/Nema 1 (IP 20)/IP 54  
with disconnector and mains fuses  
VLT 5300 - 5500 380 - 500 V**

## VLT® 5000 Series

### ■ Tightening-up torques and screw sizes

The table shows the torque required when fitting terminals to the adjustable frequency drive. For VLT 5001-5027 200-240 V, VLT 5001-5102 380-500 V and VLT 5001-5062 525-600 V, the cables must be fastened with screws. For VLT 5032-5052 200-240 V, VLT 5122-5552 380-500 V, VLT 5042-5602 525-690 V, the cables must be fastened with bolts. These figures apply to the following terminals:

Line terminals	Nos. 91, 92, 93 L1, L2, L3
Motor terminals	Nos. 96, 97, 98 U, V, W
Ground terminal	No. 94, 95, 99
Brake resistor terminals	81, 82
Load sharing	88, 89

VLT type 200-240 V	Torque [Nm]	Screw/ Bolt size	Tool
5001-5006	0,6	M3	Slotted screw
5008	IP 20	1,8	Slotted screw
5008-5011	IP 54	1,8	Slotted screw
5011-5022	IP 20	3	4 mm Allen wrench
5016-5022 <sup>3)</sup>	IP 54	3	4 mm Allen wrench
5027		6	4 mm Allen wrench
5032-5052		11,3	M8 (bolt and stud)
<b>380-500 V</b>			
5001-5011	0,6	M3	Slotted screw
5016-5022	IP 20	1,8	Slotted screw
5016-5027	IP 54	1,8	Slotted screw
5027-5042	IP 20	3	4 mm Allen wrench
5032-5042 <sup>3)</sup>	IP 54	3	4 mm Allen wrench
5052-5062		6	5 mm Allen wrench
5072-5102	IP 20	15	6 mm Allen wrench
	IP 54 <sup>2)</sup>	24	8 mm Allen wrench
5122-5302 <sup>4)</sup>		19	16 mm wrench
5352-5552 <sup>5)</sup>		19	M10 bolt (compression lug)
<b>525-600 V</b>			
5001-5011	0,6	M3	Slotted screw
5016-5027		1,8	Slotted screw
5032-5042		3	4 mm Allen wrench
5052-5062		6	5 mm Allen wrench
<b>525-690 V</b>			
5042-5352 <sup>4)</sup>		19	M10 bolt
5402-5602 <sup>5)</sup>		19	M10 bolt (compression lug)

1) Brake terminals: 3,0 Nm, Nut: M6

2) Brake and load sharing: 14 Nm, M6 Allen screw


3) IP 54 with RFI - Line terminals 6 Nm, Screw: M6 - 5 mm Allen wrench

4) Load sharing and brake terminals: 9,5 Nm; Bolt M8

5) Brake terminals: 9,5 Nm; Bolt M8.

### ■ Electrical installation - mains supply

Connect the three mains phases to terminals L<sub>1</sub>, L<sub>2</sub>, L<sub>3</sub>.



### ■ High voltage test

A high voltage test can be carried out by short-circuiting terminals U, V, W, L<sub>1</sub>, L<sub>2</sub> and L<sub>3</sub> and energizing by max. 2.15 kV DC for one second between this short-circuit and the chassis.



#### NOTE

The RFI switch must be closed (position ON) when high voltage tests are carried out (see section *RFI Switch*).

The line power and motor connection must be interrupted if the leakage currents are too high when high voltage tests are carried out on the entire installation.

### ■ Safety grounding



#### NOTE

The adjustable frequency drive has a high leakage current and must be grounded appropriately for safety reasons. Use a ground terminal (see section *Electrical installation, power cables*), which enables reinforced grounding.

Apply national safety regulations.

### ■ Motor thermal protection

The electronic thermal relay in UL-approved frequency converters has received the UL-approval for single motor protection when parameter 128 has been set for *ETR Trip* and parameter 105 has been programmed to the rated motor current (see motor nameplate).

### ■ Extra protection (RCD)

ELCB relays, multiple protective earthing or earthing can be used as extra protection, provided that local safety regulations are complied with.

In the case of an earth fault, a DC content may develop in the faulty current.

If ELCB relays are used, local regulations must be observed. Relays must be suitable for protection of 3-phase equipment with a bridge rectifier and for a brief discharge on power-up.

See also the section *Special Conditions* in the Design Guide.

### ■ RFI switch

#### Mains supply isolated from earth:

If the frequency converter is supplied from an isolated mains source (IT mains) or TT/TN-S mains with grounded leg, the RFI switch is recommended to be turned off (OFF)<sup>1)</sup>. For further reference, see IEC 364-3. In case optimum EMC performance is needed, parallel motors are connected or the motor cable length is above 25 m, it is recommended to set the switch in ON position.

In OFF position, the internal RFI capacities (filter capacitors) between the chassis and the intermediate circuit are cut off to avoid damage to the intermediate circuit and to reduce the earth capacity currents (according to IEC 61800-3).

Please also refer to the application note *VLT on IT mains*, MN.90.CX.02. It is important to use isolation monitors that are capable for use together with power electronics (IEC 61557-8).

<sup>1)</sup> Not possible with 5042-5602, 525-690 V units.



#### NOTE

The RFI switch is not to be operated with mains connected to the unit. Check that the mains supply has been disconnected before operating the RFI switch.




#### NOTE

Open RFI switch is only allowed at factory set switching frequencies.


**NOTE**

The RFI switch connects the capacitors galvanically to earth.


The red switches are operated by means of e.g. a screwdriver. They are set in the OFF position when they are pulled out and in ON position when they are pushed in. Factory setting is ON.

**Mains supply connected to earth:**


The RFI switch must be in ON position in order for the frequency converter to comply with the EMC standard.

**Position of RFI switches****Bookstyle IP 20**


VLT 5001 - 5006 200 - 240 V  
VLT 5001 - 5011 380 - 500 V

**Compact IP 20/NEMA 1**

VLT 5001 - 5006 200 - 240 V  
VLT 5001 - 5011 380 - 500 V  
VLT 5001 - 5011 525 - 600 V

**Compact IP 20/NEMA 1**


VLT 5008 200 - 240 V  
VLT 5016 - 5022 380 - 500 V  
VLT 5016 - 5022 525 - 600 V



Installation

**Compact IP 20/NEMA 1**


VLT 5011 - 5016 200 - 240 V  
VLT 5027 - 5032 380 - 500 V  
VLT 5027 - 5032 525 - 600 V




**Compact IP 20/NEMA 1**  
VLT 5022 - 5027 200 - 240 V  
VLT 5042 - 5102 380 - 500 V  
VLT 5042 - 5062 525 - 600 V




**Compact IP 54**  
VLT 5008 - 5011 200 - 240 V  
VLT 5016 - 5027 380 - 500 V




**Compact IP 54**  
VLT 5001 - 5006 200 - 240 V  
VLT 5001 - 5011 380 - 500 V



**Compact IP 54**  
VLT 5016 - 5027 200 - 240 V  
VLT 5032 - 5062 380 - 500 V



**Compact IP 54**  
**VLT 5072 - 5102 380 - 500 V**



Installation

**All enclosure types**  
**VLT 5122-5552 380 - 500 V**

### ■ Installation of motor cables



#### NOTE

If an unscreened cable is used, some EMC requirements are not complied with. If the EMC specifications regarding emission are to be complied with, the motor cable must be screened, unless otherwise stated for the RFI filter in question. It is important to keep the motor cable as short as possible so as to reduce the noise level and leakage currents to a minimum. The motor cable screen must be connected to the metal cabinet of the adjustable frequency drive and to the metal cabinet of the motor. The screen connections are to be made with the biggest possible surface (cable clamp). This is enabled by different installation devices in the different adjustable frequency drives.


Installation with twisted screen ends (pigtails) is to be avoided, since these spoil the screening effect at higher frequencies.

If it is necessary to break the screen to install a motor isolator or motor contactor, the screen must be continued at the lowest possible HF impedance.

The adjustable frequency drive has been tested with a given length of cable and a given cross-section of that cable. If the cross-section is increased, the cable capacitance — and thus the leakage current — increases, and the cable length must be reduced correspondingly.

### ■ Connection of motor



All types of 3-phased asynchronous standard motors can be used with the VLT 5000 Series.



Normally, small motors are star-connected (200/400 V, Δ/Y).

Large motors are delta-connected (400/690 V, Δ/Y).

### ■ Direction of motor rotation



The factory setting is for clockwise rotation with the frequency transformer output connected as follows.


Terminal 96 connected to U-phase

Terminal 97 connected to V-phase

Terminal 98 connected to W-phase

The direction of motor rotation can be changed by switching two phases in the motor cable.

### ■ Parallel coupling of motors



Adjustable frequency drives are able to control several motors connected in parallel. If the motors are to have different rpm values, the motors must have different rated rpm values. Motor rpm is changed simultaneously, which means that the ratio between the rated rpm values is maintained across the range.

The total current consumption of the motors is not to exceed the maximum rated output current  $I_{VLT,N}$  for the adjustable frequency drive.

Problems may arise at the start and at low rpm values if the motor sizes are widely different. This is because the relatively high ohmic resistance in small motors calls for a higher voltage at the start and at low rpm values.

In systems with motors connected in parallel, the electronic thermal relay (ETR) of the adjustable frequency drive cannot be used as motor protection for the individual motor. Consequently, additional motor protection is required, such as thermistors in each motor (or individual thermal relays) suitable for adjustable frequency drive use.

Please note that the individual motor cable for each motor must be summed and is not to exceed the total motor cable length permitted.

### ■ Electrical installation - brake cable

(Only standard with brake and extended with brake.  
Typecode: SB, EB, DE, PB).

No.	Function
81, 82	Brake resistor terminals

The connection cable to the brake resistor must be screened. Connect the screen by means of cable clamps to the conductive back plate at the frequency converter and to the metal cabinet of the brake resistor.

Size the brake cable cross-section to match the brake torque. See also Brake instructions, MI.90.FX.YY and MI.50.SX.YY for further information regarding safe installation.



#### NOTE

Please note that voltages up to 1099 V DC, depending on the supply voltage, may occur on the terminals.

### ■ Electrical installation - relay outputs

Torque: 0.5 - 0.6 Nm

Screw size: M3

No.	Function
1-3	Relay output, 1+3 break, 1+2 make See parameter 323 of the Operating Instructions. See also <i>General technical data</i> .
4, 5	Relay output, 4+5 make See parameter 326 of the Operating Instructions. See also <i>General technical data</i> .

### ■ Electrical installation - 24 Volt external DC supply

(Only extended versions. Typecode: PS, PB, PD, PF, DE, DX, EB, EX).

Torque: 4.4-5.3 In-lbs

Screw size: M3

No.	Function
35, 36	24 V external DC supply

External 24 V DC supply can be used as low-voltage supply to the control card and any option cards installed. This enables full operation of the LCP (incl. parameter setting) without connection to mains. Please note that a warning of low voltage will be given when 24 V DC has been connected; however, there will be no tripping. If 24 V external DC supply is connected or switched on at the same time as the mains supply, a time of min. 200 msec. must be set in parameter 120 *Start delay*.

A pre-fuse of min. 6 Amp, slow-blow, can be fitted to protect the external 24 V DC supply. The power consumption is 15-50 W, depending on the load on the control card.



#### NOTE

Use 24 V DC supply of type PELV to ensure correct galvanic isolation (type PELV) on the control terminals of the adjustable frequency drive.

Installation

### ■ Electrical installation - load sharing

(Only extended with type code EB, EX, DE, DX).

No.	Function
88, 89	Load sharing

**Terminals for load sharing**

175ZA/99.10	
88	89
-	+


The connection cable must be shielded and the max. length from the adjustable frequency drive to the DC bar is 25 meters / 81 feet.

Load sharing enables linking of the DC intermediate circuits of several adjustable frequency drives.


**NOTE**

Please note that voltages up to 1099 V DC may occur on the terminals.

Load sharing calls for extra equipment. For further information, please consult Load Sharing Instructions MI.50.NX.XX.


**■ Fan Supply**

Torque 4.4-5.3 In-lbs

Screwszie: M3

Drive supplied by external DC	103
	102
	101
	100
AC supply for Fan	

Drive supplied by AC line	103
	102
	101
	100
AC supply for Fan	

Available in VLT 5122-5552, 380-500 V; 5042-5602, 525-690 V; 5032-5052, 20-240 V in all enclosure types.

Only for IP 54 units in the power range VLT 5016-5102, 380-500 V and VLT 5008-5027, 200-240 V AC. If the drive is supplied by the DC bus (loadsharing), the internal fans are not supplied with AC power. In this case they must be supplied with an external AC supply.

**■ Electrical installation - brake resistor temperature switch**

Torque: 0.5-0.6 Nm


Screw size: M3

No.	Function
106, 104, 105	Brake resistor temperature switch.


**NOTE**

This function is only available on VLT 5032-5052, 200-240 V; VLT 5122-5552, 380-500 V; and VLT 5042-5602, 525-690 V.


If the temperature of the brake resistor gets too high and the thermal switch drops out, the adjustable frequency drive will stop braking. The motor will start coasting. A KLIXON switch must be installed that is 'normally closed'. If this function is not used, 106 and 104 must be short-circuited together.


**■ Electrical installation - bus connection**

In accordance with the RS 485 (2-conductor) norm, the serial bus connection is connected to terminals 68/69 on the adjustable frequency drive (signals P and N). Signal P is the positive potential (TX+,RX+), while signal N is the negative potential (TX-,RX-).

If more than one adjustable frequency drive is to be connected to a given master, use parallel connections.

175ZA079.11




In order to avoid potential equalizing currents in the shield, the cable shield can be grounded via terminal 61, which is connected to the frame via an RC link.

#### Bus termination

The bus must be terminated by a resistor network at both ends. For this purpose, set switches 2 and 3 on the control card for "ON".

#### ■ DIP Switches 1-4

The dipswitch is located on the control card. It is used for serial communication, terminals 68 and 69. The switching position shown is the factory setting.



Switch 1 has no function.

Switches 2 and 3 are used for terminating an RS-485 interface, serial communication.

Switch 4 is used for separating the common potential for the internal 24 V DC supply from the common potential of the external 24 V DC supply.



#### NOTE



Please note that when switch 4 is in the "OFF" position, the external 24 V DC supply is galvanically isolated from the adjustable frequency drive.

#### ■ Installation of control cables


Tightening-up torque: 0.5-0.6 Nm

Screw size: M3

See section *earthing of braided screened/armoured control cables*.



175HA379.10



175HA380.10

No.	Function
12, 13	Voltage supply to digital inputs For the 24 V DC to be usable for the digital inputs, switch 4 on the control card must be closed. position "ON".
16-33	Digital inputs/encoder inputs
20	Ground for digital inputs
39	Ground for analogue/digital outputs
42, 45	Analogue/digital outputs for indicating frequency, reference, current and torque
50	Supply voltage to potentiometer and thermistor 10 V DC
53, 54	Analogue reference input, voltage 0 - ±10 V
55	Ground for analogue reference inputs
60	Analogue reference input, current 0/4-20 mA
61	Termination for serial communication. See section <i>Bus connection</i> . This terminal is normally not to be used.
68, 69	RS 485 interface, serial communication. Where the VLT frequency converter is connected to a bus, switches 2 and 3 (switches 1- 4) must be closed on the first and the

Installation




---

## VLT® 5000 Series

---

last VLT frequency converter. On the remaining VLT frequency converters, switches 2 and 3 must be open. The factory setting is closed (position "ON").

---

**■ Electrical installation**


Installation

**Conversion of analogue inputs**

Current input signal to voltage input

 0-20 mA  $\Rightarrow$  0-10 V


 4-20 mA  $\Rightarrow$  2-10 V

Connect 510 ohms resistor between input terminal 53 and 55 and adjust minimum and maximum values in parameters 309, and 310 or 54 and 55 and adjust minimum and maximum values in parameters 312 and 313.


**■ Connection examples**

Digital inputs	Terminal no. parameter	16 300	17 301	18 302	19 303	27 304	29 305	32 306	33 307
<b>Value:</b>									
No function	(NO OPERATION)	[0]	[0]	[0]	[0]		[0]	[0]	[0]
Reset	(RESET)	[1]*	[1]				[1]	[1]	[1]
Coasting stop, inverse	(COAST INVERSE)						[0]*		
Reset and coasting stop, inverse	(COAST & RESET INVERS)						[1]		
Quick-stop, inverse	(QSTOP INVERSE)						[2]		
DC-braking, inverse	(DCBRAKE INVERSE)						[3]		
Stop inverse	(STOP INVERSE)	[2]	[2]				[4]	[2]	[2]
Start	(START)						[1]*		
Latched start	(LATCHED START)						[2]		
Reversing	(REVERSING)						[1]*		
Start reversing	(START REVERSE)						[2]		
Only start clockwise, on	(ENABLE START FWD.)	[3]	[3]				[3]	[3]	
Only start anti-clockwise, on	(ENABLE START REV)	[3]	[3]				[4]	[3]	
Jog	(JOGGING)	[4]	[4]				[5]*	[4]	[4]
Preset reference, on	(PRESET REF. ON)	[5]	[5]				[5]	[5]	[5]
Preset reference, lsb	(PRESET REF. SEL. LSB)	[5]					[7]	[6]	
Preset reference, msb	(PRESET REF. MSB)	[6]					[8]	[6]	
Freeze reference	(FREEZE REFERENCE)	[7]	[7]*				[9]	[7]	[7]
Freeze output	(FREEZE OUTPUT)	[8]	[8]				[10]	[8]	[8]
Speed up	(SPEED UP)	[9]					[11]	[9]	
Speed down	(SPEED DOWN)		[9]				[12]	[9]	
Choice of Setup, lsb	(SETUP SELECT LSB)	[10]					[13]	[10]	
Choice of Setup, msb	(SETUP SELECT MSB)		[10]				[14]	[10]	
Choice of Setup, msb/speed up	(SETUP MSB/SPEED UP)						[11]		*
Choice of Setup, lsb/speed down	(SETUP LSB/SPEED DOWN)						[11]		*
Catch-up	(CATCH UP)	[11]					[15]	[12]	
Slow-down	(SLOW DOWN)		[11]				[16]		[12]
Ramp 2	(RAMP 2)	[12]	[12]				[17]	[13]	[13]
Mains failure inverted	(MAINS FAILURE INVERSE)	[13]	[13]				[18]	[14]	[14]
Pulse reference	(PULSE REFERENCE)		[23]				[28] <sup>1</sup>		
Pulse feedback	(PULSE FEEDBACK)							[24]	
Encoder feedback input, A	(ENCODER INPUT 2A)								[25]
Encoder feedback input, B	(ENCODER INPUT 2B)								[24]
Safety interlock	(SAFETY INTERLOCK)		[24]				[5]		
Data change lock	(PROGRAMMING LOCK)	[29]	[29]				[29]	[29]	[29]


1) If this function is selected for terminal 29, the same function for terminal 17 will not be valid, even if it has been selected to be active.

**■ Two wire start/stop**



- Start/stop using terminal 18.  
Parameter 302 = *Start* [1]
- Quick-stop using terminal 27.  
Parameter 304 = *Coasting stop inverted* [0]

**■ Setup change**


- Selection of setup using terminals 32 and 33.  
Parameter 306 = *Selection of setup, lsb* [10]  
Parameter 307 = *Selection of setup, msb* [10]  
Parameter 004 = *Multi-setup* [5].


**■ Pulse start/stop**


- Stop inverted by means of terminal 16.  
Parameter 300 = *Stop inverted* [2]
- Pulse start using terminal 18.  
Parameter 302 = *Pulse start* [2]
- Jog by means of terminal 29.  
Parameter 305 = *Jog* [5]

**■ Digital speed up/down**


- Speed up and down using terminals 32 and 33.  
Parameter 306 = *Speed up* [9]  
Parameter 307 = *Speed down* [9]  
Parameter 305 = *Freeze reference* [7].


Installation

**■ Potentiometer reference**


Parameter 308 = Reference [1]

Parameter 309 = Terminal 53, min. scaling


Parameter 310 = Terminal 53, max. scaling

**■ Encoder connection**


Parameter 306 = Encoder input B [24]

Parameter 307 = Encoder input A [25]


If an encoder is connected that only has one output to Encoder input A [25], Encoder input B [24] must be set to No function [0].

**■ Two-wire transmitter**


Parameter 314 = Reference [1], Feedback [2]

Parameter 315 = Terminal 60, min. scaling

Parameter 316 = Terminal 60, max. scaling

**■ Current reference with speed feedback**


Parameter 100 = Speed control, closed loop

Parameter 308 = Feedback [2]

Parameter 309 = Terminal 53, min. scaling

Parameter 310 = Terminal 53, max. scaling

Parameter 314 = Reference [1]

Parameter 315 = Terminal 60, min. scaling

Parameter 316 = Terminal 60, max. scaling

### ■ Control panel (LCP)

The front of the adjustable frequency drive features a control panel - LCP (Local Control Panel), which makes up a complete interface for operation and monitoring of the VLT 5000 Series.


The control panel is detachable and can - as an alternative - be installed up to 3 meters away from the adjustable frequency drive, e.g. on a front panel, by means of a mounting kit option.

The functions of the control panel can be divided into three groups:

- display
- keys for changing program parameters
- keys for local operation

All data are indicated by means of a 4-line alpha-numeric display, which in normal operation is able to show 4 measurements and 3 operating conditions continuously. During programming, all the information required for quick, effective parameter Setup of the adjustable frequency drive will be displayed. As a supplement to the display, there are three LEDs for voltage (power or 24 V external), warning and alarm.


All program parameters of the adjustable frequency drive can be changed immediately from the control panel, unless this function has been blocked via parameter 018.



DANFOSS  
1757A004.10

### ■ Control panel - display

The LCD-display has rear lighting and a total of 4 alpha-numeric lines together with a box that shows the direction of rotation (arrow) and the chosen Setup as well as the Setup in which programming is taking place if that is the case.



**1st line** shows up to 3 measurements continuously in normal operating status or a text which explains the 2nd line.

**2nd line** shows a measurement with related unit continuously, regardless of status (except in the case of alarm/warning).


**3rd line** is normally blank and is used in the menu mode to show the selected parameter number or parameter group number and name.

**4th line** is used in operating status for showing a status text or in data change mode for showing the mode or value of the selected parameter.

An arrow indicates the direction of rotation of the motor. Furthermore, the Setup which has been selected as the Active Setup in parameter 004 is shown. When programming another Setup than the Active Setup, the number of the Setup which is being programmed will appear to the right. This second Setup number will flash.

### ■ Control panel - LEDs

At the bottom of the control panel is a red alarm LED and a yellow warning LED, as well as a green voltage LED.




If certain threshold values are exceeded, the alarm and/or warning LED lights up together with a status and alarm text on the control panel.


The voltage LED is activated when the adjustable frequency drive receives voltage, or 24 V external supply; at the same time the rear lighting of the display will be on.

### ■ Control panel - control keys

The control keys are divided into functions. This means that the keys between display and indicator lamps are used for parameter Setup, including choice of display indication during normal operation.



Keys for local control are found under the indicator LEDs.



### ■ Control key functions

**[DISPLAY / STATUS]** is used for selecting the mode of display or for changing back to Display mode from either the Quick menu mode or the Menu mode.

**[QUICK MENU]** is used for programming the parameters that belong under the Quick menu mode. It is possible to switch directly between Quick menu mode and Menu mode.

**[MENU]** is used for programming all parameters. It is possible to switch directly between Menu mode and Quick menu mode.

**[CHANGE DATA]** is used for changing the parameter selected either in the Menu mode or the Quick menu mode.

**[CANCEL]** is used if a change of the selected parameter is not to be carried out.

**[OK]** is used for confirming a change of the parameter selected.

**[+/-]** is used for selecting parameter and for changing the chosen parameter or for changing the read out in line 2.

**[<>]** is used for selecting group and to move the cursor when changing numerical parameters.

**[STOP / RESET]** is used for stopping the motor connected or for resetting the adjustable frequency drive after a drop-out (trip). Can be selected via parameter 014 to be active or inactive. If stop is activated, line 2 will flash, and [START] must be activated.

**[JOG]** overrides the output frequency to a preset frequency while the key is kept down. Can be selected via parameter 015 to be active or inactive.

**[FWD / REV]** changes the direction of rotation of the motor, which is indicated by means of the arrow on the display although only in Local. Can be selected via parameter 016 to be active or inactive.

**[START]** is used for starting the adjustable frequency drive after stop via the "Stop" key. Is always active, but cannot override a stop command given via the terminal strip.

#### NOTE



If the keys for local control have been selected as active, they will remain active both when the frequency has been set for *Local Control* and for *Remote Control* via parameter 002, although with the exception of the [STOP / RESET] key.

tion of [Fwd/rev], which is only active in Local operation.


**NOTE**

If no external stop function has been selected and the [Stop] key has been selected as inactive, the motor can be started and can only be stopped by disconnecting the voltage to the motor.

**■ Control panel - display read-outs**

The display read-out state can be varied - see the list below - depending on whether the adjustable frequency drive is in normal operation or is being programmed.

**■ Display mode**

In normal operation, up to 4 different operating variables can be indicated continuously: 1.1 and 1.2 and 1.3 and 2, and in line 4 the present operating status or alarms and warnings that have arisen.



Operating variable:	Unit:
Reference	[%]
Reference	[unit]
Feedback	[unit]
Frequency	[Hz]
Frequency x scaling	[ - ]
Motor current	[A]
Torque	[%]
Power	[kW]
Power	[HP]
Output energy	[kWh]
Motor voltage	[V]
DC-link voltage	[V]
Motor thermal load	[%]
VLT thermal load	[%]
Hours run	[Hours]
Input status, dig. Input	[Binary code]
Input status, analog terminal 53	[V]
Input status, analog terminal 54	[V]
Input status, analog terminal 60	[mA]
Pulse reference	[Hz]
External reference	[%]
Status word	[Hex]
Brake effect/2 min.	[kW]
Brake effect/sec.	[kW]
Heat sink temp.	[°C]
Alarm word	[Hex]
Control word	[Hex]
Warning word 1	[Hex]
Extended status word	[Hex]
Communication option card warning	[Hex]
RPM	[min⁻¹]
RPM x scaling	[ - ]
LCP Display text	[ - ]

Operating variables 1.1 and 1.2 and 1.3 in the first line, and operating variable 2 in the second line are selected via parameter 009, 010, 011 and 012.

**■ Display mode - selection of read-outstate**


There are three options in connection with the choice of read-out state in the Display mode - I, II and III. The choice of read-out state determines the number of operating variables read out.

Read-out state:	I:	II:	III:
Line 1	Description for operating variable in line 2	Data value for 3 operating variables in line 1	Description for 3 operating variables in line 1

The table below gives the units linked to the variables in the first and second line of the display.

- Read-out state I:


This read-out state is standard after starting up or after initialisation.



Line 2 gives the data value of an operating variable with related unit, and line 1 provides a text which explains line 2, cf. table. In the example, Frequency has been selected as variable via parameter 009. During normal operation another variable can immediately be read out by using the [+/-] keys.

- Read-out state II:

Switching between read-out states I and II is effected by pressing the [DISPLAY / STATUS] key.



In this state, data values for four operating values are shown at the same time, giving the related unit, cf. table. In the example, Reference, Torque, Current and Frequency are selected as variables in the first and second line.

- Read-out state III:


This read-out state can be held as long as the [DISPLAY/STATUS] key is pressed. When the key is released, the system switches back to Read-out state II, unless the key is pressed for less than approx. 1 sec., in which case the system always reverts to Read-out state I.



This is where parameter names and units for operating variables in the first and second line are given - operating variable 2 remains unchanged.

- Display state IV:

This display state can be produced during operation if another setup is to be changed without stopping the adjustable frequency drive. This function is activated in parameter 005, *Programming Setup*.



The selected programming setup number will flash to the right of the active setup.

## ■ Parameter Setup

The VLT 5000 Series can be used for practically all assignments, which is why the number of parameters is quite large. Also, this series offers a choice between two programming modes - a Menu mode and a Quick menu mode.

The former provides access to all parameters. The latter takes the user through a few parameters which make it possible in most cases to start operating the adjustable frequency drive.

Regardless of the mode of programming, a change of a parameter will take effect and be visible both in the Menu mode and in the Quick menu mode.

## ■ Structure for the Quick menu mode versus the Menu mode

In addition to having a name, each parameter is linked up with a number which is the same regardless of the programming mode. In the Menu mode, the parameters are divided into groups, with the first digit of the parameter number (from the left) indicating the group number of the parameter in question.

- The quick menu takes the user through a number of parameters that may be enough to get the motor to run nearly optimally, if the factory setting for the other parameters takes the desired control functions into account, as well as the configuration of signal inputs/outputs (control terminals).

- The Menu mode makes it possible to select and change all parameters at the user's option. However, some parameters will be "missing", depending on the choice of configuration (parameter 100), e.g. open loop hides all the P.I.D. parameters.

### ■ Quick Setup

The Quick Setup starts with pressing the [QUICK MENU] key, which brings out the following read-out on the display:



At the bottom of the display, the parameter number and name are given together with the status/value of the first parameter under Quick Setup. The first time the [Quick Menu] key is pressed after the unit has been switched on, the read-outs always start at pos. 1 - see table below.


### ■ Parameter selection

The selection of parameter is effected by means of the [+/-] keys. The following parameters are accessible:

Pos.:	No.:	Parameter:	Unit:
1	001	Language	
2	102	Motor output	[kW]
3	103	Motor voltage	[V]
4	104	Motor frequency	[Hz]
5	105	Motor current	[A]
6	106	Rated motor speed	[rpm]
7	107	Automatic motor adaptation, AMA	
8	204	Minimum reference	[Hz]
9	205	Maximum reference	[Hz]
10	207	Ramp-up time 1	[sec.]
11	208	Ramp-down time 1	[sec.]
12	002	Local/remote control	
13	003	Local reference	

### ■ Menu mode

The Menu mode is started by pressing the [MENU] key, which produces the following read-out on the display:



Line 3 on the display shows the parameter group number and name.


### ■ Parameter selection

In the Menu mode the parameters are divided into groups. Selection of parameter group is effected by means of the [<>] keys.

The following parameter groups are accessible:

Group no.	Parameter group:
0	Operation & Display
1	Load & Motor
2	References & Limits
3	Inputs & Outputs
4	Special functions
5	Serial communication
6	Technical functions
7	Application Options
8	Fieldbus Profile
9	Fieldbus Communication

When the desired parameter group has been selected, each parameter can be chosen by means of the [+/-] keys:



The 3rd line of the display shows the parameter number and name, while the status/value of the selected parameter are shown in line 4.

### ■ Changing data


Regardless of whether a parameter has been selected under the Quick menu or the Menu mode, the procedure for changing data is the same.

Pressing the [CHANGE DATA] key gives access to changing the selected parameter, following which the underlining in line 4 will flash on the display.

The procedure for changing data depends on whether the selected parameter represents a numerical data value or a text value.

#### ■ Changing a text value



If the selected parameter is a text value, the text value is changed by means of the [+/-] keys.



The bottom display line shows the text value that will be entered (saved) when acknowledgement is given [OK].

#### ■ Change of group of numeric data values

If the chosen parameter represents a numeric data value, the chosen data value is changed by means of the [+/-] keys.




The chosen data value is indicated by the digit flashing.


The bottom display line shows the data value that will be entered (saved) when signing off with [OK].

#### ■ Infinitely variable change of numeric data value

If the chosen parameter represents a numeric data value, a digit is first selected by means of the [<>] keys.



Then the chosen digit is changed infinitely variably by means of the [+/-] keys:



The chosen digit is indicated by the digit flashing. The bottom display line shows the data value that will be entered (saved) when signing off with [OK].

#### ■ Changing of data value, step-by-step

Certain parameters can be changed step by step or infinitely variably. This applies to Motor power (parameter 102), Motor voltage (parameter 103) and Motor frequency (parameter 104).

The parameters are changed both as a group of numeric data values and as numeric data values infinitely variably.

#### ■ Read out and programming of indexed parameters

Parameters are indexed when placed in a rolling stack. Parameter 615 - 617 contain a historical log which can be read out. Choose the actual parameter, press the [CHANGE DATA] key and use the [+] and [-] keys to scroll through the log of values. During the read out line 4 of the display will flash.

If a bus option is mounted in the drive, the programming of parameter 915 - 916 needs to be carried through in the following way:

Choose the actual parameter, press the [CHANGE DATA] key and use the [+] and [-] keys to scroll through the different indexed values. To change the value of the parameter, select the indexed value and press the [CHANGE DATA] key. Using the [+] and [-] keys the

value to be changed will flash. To accept the new setting, press [OK], to abort, press [CANCEL].

### ■ Manual initialization

The adjustable frequency drive can be initialized to factory settings in two ways.

#### Initialization by parameter 620

##### - Recommended initialization

- Select parameter 620
- Press [CHANGE]
- Select “Initialization”
- Press the [OK] key
- Cut off the mains supply and wait until the display turns off.
- Reconnect the mains supply - the adjustable frequency drive is now reset.

This parameter initializes all except:

500	Serial communication address
501	Baud rate for serial communication
601-605	Operating data
615-617	Fault logs

#### Manual initialization

- Disconnect from mains and wait until the display turns off.
- Press the following keys at the same time:  
[Display/status]  
[Change data]  
[OK]
- Reconnecting the mains supply while pressing the keys.
- Release the keys
- The adjustable frequency drive has now been programmed for the factory setting.

This parameter initializes all except:


600-605	Operating data
---------	----------------



#### NOTE

Settings for serial communication and fault logs are reset.

## ■ Menu structure



175ZA446.11

## ■ Operation & Display

<b>001</b>	<b>Language</b>
<b>(LANGUAGE)</b>	
<b>Value:</b>	
★ English (ENGLISH)	[0]
German (DEUTSCH)	[1]
French (FRANCAIS)	[2]
Danish (DANSK)	[3]
Spanish (ESPAÑOL)	[4]
Italian (ITALIANO)	[5]

### Function:

The choice in this parameter defines the language to be used on the display.

### Description of choice:

There is a choice of *English* [0], *German* [1], *French* [2], *Danish* [3], *Spanish* [4] and *Italian* [5].

<b>002</b>	<b>Local/remote control</b>
<b>(OPERATION SITE)</b>	
<b>Value:</b>	
★ Remote control (REMOTE)	[0]
Local control (LOCAL)	[1]

### Function:

There is a choice of two methods of controlling the adjustable frequency drive.

### Description of choice:

If *Remote control* [0] is selected, the adjustable frequency drive can be controlled via:

1. The control terminals or the serial communication port.
2. The [START] key. However, this cannot overrule Stop commands (also start-disable) entered via the digital inputs or the serial communication port.
3. The [STOP], [JOG] and [RESET] keys, provided that these are active (see parameter 014, 015 and 017).

If *Local control* [1] is selected, the adjustable frequency drive can be controlled via:

1. The [START] key. However, this cannot overrule Stop commands on the digital terminals (if [2] or [4] has been selected in parameter 013).
2. The [STOP], [JOG] and [RESET] keys, provided that these are active (see parameter 014, 015 and 017).
3. The [FWD/REV] key, provided that this has been activated in parameter 016 and that in parameter 013 a choice of [1] or [3] has been made.
4. Via P003 the local reference can be controlled by means of the "Arrow up" and "Arrow down" keys.
5. An external control command that can be connected to terminal 16, 17, 19, 27, 29, 32 or 33. However, [2] or [4] must be selected in parameter 013.

See also section *Shift between local and remote control*.

<b>003</b>	<b>Local reference</b>
<b>(LOCAL REFERENCE)</b>	
<b>Value:</b>	

Par. 013 set for [1] or [2]:

0 - f<sub>MAX</sub>

★ 50 Hz

Par. 013 set for [3] or [4] and par. 203 = [0] set for:

Ref<sub>MIN</sub> - Ref<sub>MAX</sub>

★ 0.0

### Function:

This parameter allows manual setting of the desired reference value (speed or reference for the selected configuration, depending on the choice made in parameter 013).

The unit follows the configuration selected in parameter 100, provided *Process control, closed-loop* [3] or *Torque control, open-loop* [4] has been selected.

### Description of choice:

*Local* [1] must be selected in parameter 002 for this parameter to be used.

The set value is saved in the case of a voltage drop-out, see parameter 019.

In this parameter, Data Change Mode is not exited automatically (after time out).

Local reference cannot be set via the serial communication port.



**Warning:** Since the value set is retained after the power has been cut, the motor may start without warning when the power is reinstated; if parameter 019 is changed to *Auto restart*, use saved ref. [0].

#### 004 Active Setup (ACTIVE SETUP)

##### Value:

Factory Setup (FACTORY SETUP)	[0]
★ Setup 1 (SETUP 1)	[1]
Setup 2 (SETUP 2)	[2]
Setup 3 (SETUP 3)	[3]
Setup 4 (SETUP 4)	[4]
MultiSetup (MULTI SETUP)	[5]

##### Function:

This parameter defines the Setup number to control the functions of the frequency converter.

All parameters can be programmed in four individual parameter Setups, Setup 1 - Setup 4. In addition, there is a Factory Setup, which cannot be modified.

##### Description of choice:

*Factory Setup* [0] contains the data set at the works. Can be used as a data source if the other Setups are to be returned to a known state.

Parameter 005 and 006 allow copying from one Setup to one or all the other Setups.

*Setups 1-4* [1]-[4] are four individual Setups that can be selected individually.

*Multi-Setup* [5] is used by remote-switching between Setups. Terminals 16/17/29/32/33 as well as the serial communication port can be used for switching between Setups.

#### 005 Programming Setup (EDIT SETUP)

##### Value:

Factory Setup (FACTORY SETUP)	[0]
Setup 1 (SETUP 1)	[1]
Setup 2 (SETUP 2)	[2]
Setup 3 (SETUP 3)	[3]
Setup 4 (SETUP 4)	[4]
★ Active Setup (ACTIVE SETUP)	[5]

##### Function:

The choice is of the Setup in which programming (change of data) is to occur during operation (applies both via the control panel and via the serial communication port). The 4 Setups can be programmed independently of the Setup selected as the active Setup (selected in parameter 004).

##### Description of choice:

The *Factory Setup* [0] contains the data set at the works and can be used as a data source if the other Setups are to be returned to a known state.

*Setups 1-4* [1]-[4] are individual Setups which can be used as required. They can be programmed freely, regardless of the Setup selected as the active Setup and thus controlling the functions of the adjustable frequency drive.



##### NOTE

If a general change of data or a copying to the active Setup is effected, this immediately affects the functioning of the unit.

#### 006 Copying of Setups (SETUP COPY)

##### Value:

★ No copying (NO COPY)	[0]
Copy to Setup 1 from # (COPY TO SETUP 1)	[1]
Copy to Setup 2 from # (COPY TO SETUP 2)	[2]
Copy to Setup 3 from # (COPY TO SETUP 3)	[3]
Copy to Setup 4 from # (COPY TO SETUP 4)	[4]
Copy to Setup all from # (COPY TO ALL)	[5]

# = the Setup selected in parameter 005

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

**Function:**

A copy is made from the Setup selected in parameter 005 to one of the other Setups or to all the other Setups simultaneously. The setup copying function does not copy parameter 001, 004, 005, 500 and 501.

Copying is only possible in Stop Mode (motor stopped on a Stop command).

**Description of choice:**

The copying starts when the desired copying function has been entered and confirmed by pressing the [OK] key.

The display indicates when copying is in progress.

**007 LCP copy  
(LCP COPY)**
**Value:**

- |   |     |
|---|-----|
| ★ No copying (NO COPY)                                    | [0] |
| Upload all parameters (UPLOAD ALL PARAM)                  | [1] |
| Download all parameters (DOWNLOAD ALL)                    | [2] |
| Download power-independent par.<br>(DOWNLOAD SIZE INDEP.) | [3] |

**Function:**

LCP copy is used if it is desired to use the integrated copying function of the control panel. The control panel is detachable. You can therefore easily copy parameter value(s) from one to another.

**Description of choice:**

Select *Upload all parameters* [1] if all parameter values are to be transmitted to the control panel.

Select *Download all parameters* [2] if all transmitted parameter values are to be copied to the adjustable frequency drive on which the control panel has been mounted.

Select *Download power-independent par.* [3] if only the power-independent parameters are to be downloaded. This is used if downloading to an adjustable frequency drive that has a different rated power than the one from where the parameter Setup originates.

Please note that the power-dependent parameter 102-106 must be programmed after copying.


**NOTE**

Uploading/Downloading can only be carried out in the Stop mode.

**008 Display scaling of motor frequency  
(FREQUENCY SCALE)**
**Value:**

0.01 - 500.00 ★ 1

**Function:**

This parameter chooses the factor to be multiplied by the motor frequency,  $f_m$ , for presentation in the display, when parameters 009-012 have been set for Frequency x Scaling [5].

**Description of choice:**

Set the desired scaling factor.

**009 Display line 2 (DISPLAY LINE 2)**
**Value:**

- |  |      |
|--|------|
| No readout (NONE)                                    | [0]  |
| Reference [%] (REFERENCE [%])                        | [1]  |
| Reference [unit] (REFERENCE [UNIT])                  | [2]  |
| Feedback [unit] (FEEDBACK [UNIT])                    | [3]  |
| ★ Frequency [Hz] (FREQUENCY [Hz])                    | [4]  |
| Frequency x Scaling [-]<br>(FREQUENCY X SCALE)       | [5]  |
| Motor current [A] (MOTOR CURRENT [A])                | [6]  |
| Torque [%] (TORQUE [%])                              | [7]  |
| Power [kW] (POWER [kW])                              | [8]  |
| Power [HP] (POWER [hp] [US])                         | [9]  |
| Output energy [kWh]<br>(OUTPUT ENERGY [kWh])         | [10] |
| Motor voltage [V] (MOTOR VOLTAGE [V])                | [11] |
| DC link voltage [V] (DC LINK VOLTAGE [V])            | [12] |
| Thermal load, motor [%]<br>(MOTOR THERMAL [%])       | [13] |
| Thermal load, VLT [%] (VLT THERMAL [%])              | [14] |
| Hours run [Hours] (RUNNING HOURS)                    | [15] |
| Digital input [Binary code]<br>(DIGITAL INPUT [BIN]) | [16] |
| Analog input 53 [V] (ANALOG INPUT 53 [V])            | [17] |

Analog input 54 [V] (ANALOG INPUT 54 [V])	[18]
Analog input 60 [mA] (ANALOG INPUT 60 [mA])	[19]
Pulse reference [Hz] (PULSE REF. [Hz])	[20]
External reference [%] (EXTERNAL REF [%])	[21]
Status word [Hex] (STATUS WORD [HEX])	[22]
Brake effect/2 min. [KW] (BRAKE ENERGY/2 min)	[23]
Brake effect/sec. [kW] (BRAKE ENERGY/s)	[24]
Heat sink temp. [°C] (HEATSINK TEMP [°C])	[25]
Alarm word [Hex] (ALARM WORD [HEX])	[26]
Control word [Hex] (CONTROL WORD [HEX])	[27]
Warning word 1 [Hex] (WARNING WORD 1 [HEX])	[28]
Warning word 2 [Hex] (WARNING WORD 2 [HEX])	[29]
Communication option card warning (Comm opt warn [hex])	[30]
RPM [min <sup>-1</sup> ] (MOTOR RPM [RPM])	[31]
RPM x scaling [-] (MOTOR RPM x SCALE)	[32]
LCP Display text (FREE PROG. ARRAY)	[33]

**Function:**

This parameter allows a choice of the data value to be displayed in line 2 of the display.

Parameters 010-012 enable the use of three additional data values to be displayed in line 1.

**Description of choice:**

No readout switches of the readout.

**Reference [%]** corresponds to the total reference (sum of digital/analog/preset/bus/freeze ref./catch-up and slow-down).

**Reference [unit]** gives the status value of terminals 17/29/53/54/60 using the unit stated on the basis of configuration in parameter 100 (Hz, Hz and rpm).

**Feedback [unit]** gives the status value of terminal 33/53/60 using the unit/scale selected in parameter 414, 415 and 416.

**Frequency [Hz]** gives the motor frequency, i.e. the output frequency from the adjustable frequency drive.

**Frequency x Scaling [-]** corresponds to the present motor frequency  $f_m$  (without resonance dampening) multiplied by a factor (scaling) set in parameter 008.

**Motor current [A]** states the phase current of the motor measured as effective value.

**Torque [%]** gives the current motor load in relation to the rated motor torque.

**Power [kW]** states the actual power consumed by the motor in kW.

**Power [HP]** states the actual power consumed by the motor in HP.

**Output energy [kWh]** states the energy consumed by the motor since the latest reset was made in parameter 618.

**Motor voltage [V]** states the voltage supplied to the motor.

**DC link voltage [V]** states the intermediate circuit voltage in the adjustable frequency drive.

**Thermal load, motor [%]** states the calculated/estimated thermal load on the motor. 100% is the cut-out limit.

**Thermal load, VLT [%]** states the calculated/estimated thermal load on the adjustable frequency drive. 100% is the cut-out limit.

**Hours run [Hours]** states the number of hours that the motor has run since the latest reset in parameter 619.

**Digital input [Binary code]** states the signal states from the 8 digital terminals (16, 17, 18, 19, 27, 29, 32 and 33) Input 16 corresponds to the bit at the far left. '0' = no signal, '1' = connected signal.

**Analog input 53 [V]** states the signal value on terminal 53.

**Analog input 54 [V]** states the signal value on terminal 54.

**Analog input 60 [V]** states the signal value on terminal 60.

**Pulse reference [Hz]** states the possible frequency in Hz connected to the terminals 17 or 29.

**External reference [%]** gives the sum of the external reference as a percentage (the sum of analog/pulse/bus).

**Status word [Hex]** gives the status word sent via the serial communication port in Hex code from the adjustable frequency drive.

**Brake power/2 min. [KW]** states the brake power transferred to an external brake resistor. The mean power is calculated continuously for the latest 120 seconds.

It is assumed that a resistor value has been entered in parameter 401.

**Brake power/sec. [kW]** states the present brake power transferred to an external brake resistor. Stated as an instantaneous value.

It is assumed that a resistor value has been entered in parameter 401.

**Heat sink temp. [°C]** states the present heat sink temperature of the adjustable frequency drive. The cut-out limit is  $90 \pm 5^\circ\text{C}$ ; cutting back in occurs at  $60 \pm 5^\circ\text{C}$ .

**Alarm word [Hex]** indicates one or several alarms in a Hex code. See *Alarm word*.

**Control word. [Hex]** indicates the control word for the adjustable frequency drive. See Serial communication in the Design Guide.

**Warning word 1. [Hex]** indicates one or more warnings in a Hex code. See *Warning word*.

**Warning word 2. [Hex]** indicates one or more status states in a Hex code. See *Warning word*.

**Communication option card warning [Hex]** gives a warning word if there is a fault on the communication bus. Is only active if communication options have been installed. Without communication options, 0 Hex is displayed.

**RPM [min<sup>-1</sup>]** indicates the motor speed. In speed closed loop, the value is measured. In other modes the value is calculated based on the motor slip.

**RPM x scaling [-]** indicates the motor RPM multiplied by a factor set in parameter 008.

**LCP display text** shows the text programmed in parameter 553 *Display text 1* and 554 *Display text 2* via LCP or the serial communication port. Not possible in parameter 011-012.

Display text 1 is only shown in full length if par 011 and 012 are set to None [0].

<b>010</b>	<b>Display line 1.1 (DISPLAY LINE 1.1)</b>
<b>011</b>	<b>Display line 1.2 (DISPLAY LINE 1.2)</b>
<b>012</b>	<b>Display line 1.3 (DISPLAY LINE 1.3)</b>

#### Value:

See parameter 009.

#### Function:

Parameter 010 - 012 enable a choice of three different data values to be shown on the display, line 1 position 1, line 1 position 2 and line 1 position 3, respectively. For display read-outs, press the [DISPLAY/STATUS] button.

The reading can be switched off.

#### Description of choice:

The factory setting for each parameter is the following:

Par. 010	Reference [%]
Par. 011	Motor current [A]
Par. 012	Power [kW]

#### 013 Local Control/Configuration as parameter 100

#### (LOCAL CTRL/CONFIG.)

#### Value:

Local not active (DISABLE)	[0]
LCP control and open loop. (LCP CTRL/OPEN LOOP)	[1]
LCP digital control and open loop. (LCP+DIG CTRL/OP.LOOP)	[2]
LCP control/as parameter 100. (LCP CTRL/AS P100)	[3]
★ LCP digital control/as parameter 100. (LCP+DIG CTRL/AS P100)	[4]

#### Function:

This is where the desired function is to be selected if Local control has been chosen in parameter 002. See also the description of parameter 100.

#### Description of choice:

If *Local not active* [0] is selected, a possible setting of *Local reference via parameter 003* is blocked.

It is only possible to change to *Local not active* [0] from one of the other setting options in parameter 013, when the adjustable frequency drive has been set to *Remote control* [0] in parameter 002.

*LCP control and open loop* [1] is used when the speed is to be adjustable (in Hz) via parameter 003, when the adjustable frequency drive has been set to *Local control* [1] in parameter 002.

If parameter 100 has not been set to *Speed control open loop* [0], switch to *Speed control open loop* [0]

*LCP digital control and open loop* [2] functions as *LCP control and open loop* [1], the only difference being that when parameter 002 has been set to *Local operation* [1], the motor is controlled via the digital inputs, according to the list in section *Shift between local and remote control*.

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

LCP control/as parameter 100 [3] is selected if the reference is to be set via parameter 003.

LCP digital control/as parameter 100 [4] functions as LCP control/as parameter 100 [3], although, when parameter 002 has been set to *Local operation* [1], the motor may be controlled via the digital inputs in accordance with the list in section *Shift between local and remote control*.



#### NOTE

Shift from Remote control to LCP digital control and open loop:

The present motor frequency and direction of rotation must be maintained. If the present direction of rotation does not correspond to the reversing signal (negative reference), the motor frequency  $f_M$  will be set at 0 Hz.

Shift from LCP digital control and open loop to Remote control:

The selected configuration (parameter 100) will be active. Shifts are effected without any abrupt movement.

Shift from Remote control to LCP control/as parameter 100 or LCP digital control/as parameter 100.

The present reference will be maintained. If the reference signal is negative, the local reference will be set at 0.

Shift from LCP control/as parameter 100 or LCP remote control as parameter 100 to Remote control.

The reference will be replaced by the active reference signal from the remote control.

#### 014 Local stop (LOCAL STOP)

##### Value:

- |                   |     |
|-------------------|-----|
| Disable (DISABLE) | [0] |
| ★ Enable (ENABLE) | [1] |

##### Function:

This parameter disables/enables the local stop function from the LCP.

This key is used when parameter 002 has been set for *Remote control* [0] or *Local* [1].

#### Description of choice:

If *Disable* [0] is selected, the [STOP] key will be inactive.

#### NOTE

If *Enable* is selected, the [STOP] key overrules all Start commands.

#### 015 Local jog (LOCAL JOGGING)

##### Value:

- |                          |     |
|--------------------------|-----|
| ★ Not possible (DISABLE) | [0] |
| Possible (ENABLE)        | [1] |

##### Function:

This parameter enables/disables the local jog function on the LCP.

The key is used when parameter 002 has been set for *Remote control* [0] or *Local* [1].

#### Description of choice:

If *Disable* [0] is selected, the [JOG] key will be inactive.

#### 016 Local reversing (LOCAL REVERSING)

##### Value:

- |                          |     |
|--------------------------|-----|
| ★ Not possible (DISABLE) | [0] |
| Possible (ENABLE)        | [1] |

##### Function:

This parameter enables/disables the reversing function on the LCP.

This key can only be used if parameter 002 has been set to *Local operation* [1] and parameter 013 to *LCP control* [3].

#### Description of choice:

If *Disable* [0] is selected, the [FWD/REV] key will be inactive.

See parameter 200.

**017 Local reset of trip (LOCAL RESET)**
**Value:**

- |                        |     |
|------------------------|-----|
| Not possible (DISABLE) | [0] |
| ★ Possible (ENABLE)    | [1] |

**Function:**

In this parameter, the reset function can be selected/removed from the keyboard.

This key can be used when parameter 002 has been set for *Remote control* [0] or *Local control* [1].

**Description of choice:**

If *Disable* [0] is selected in this parameter, the [RESET] key will be inactive.


**NOTE**

Only select *Disable* [0] if an external reset signal has been connected via the digital inputs.

**018 Lock for data change**
**(DATA CHANGE LOCK)**
**Value:**

- |                           |     |
|---------------------------|-----|
| ★ Not locked (NOT LOCKED) | [0] |
| Locked (LOCKED)           | [1] |

**Function:**

In this parameter, the software can "lock" the control, which means that data changes cannot be made via LCP (however, this is still possible via the serial communication port).

**Description of choice:**

If *Locked* [1] is selected, data changes cannot be made.

**019 Operating state at Power up, local control**
**(POWER UP ACTION)**
**Value:**

- |   |     |
|---|-----|
| Auto restart, use saved ref. (AUTO RE-START)      | [0] |
| ★ Forced stop, use saved ref. (LOCAL=STOP)        | [1] |
| Forced stop, set ref. to 0<br>(LOCAL=STOP, REF=0) | [2] |

**Function:**

Setting of the operating mode when the mains voltage is reconnected.

This function can only be active in connection with *Local control* [1] in parameter 002.

**Description of choice:**

*Auto restart, use saved ref.* [0] is selected if the unit is to start up with the same local reference (set in parameter 003) and the same start/stop conditions (given via the [START/STOP] keys) that the adjustable frequency drive had before it was switched off.

*Forced stop, use saved ref.* [1] is used if the unit is to remain stopped when the mains voltage is connected, until the [START] key is pressed. After the start command, the local reference used is set in parameter 003.

*Forced stop, set ref. to 0* [2] is selected if the unit is to remain stopped when the mains voltage is connected. Local reference (parameter 003) is reset.


**NOTE**

In remote controlled operation (parameter 002), the start/stop condition at power up will depend on the external control signals. If *Pulse start* [2] is selected in parameter 302, the motor will remain stopped at power-up.

**027 Warning readout line**
**(WARNING READOUT)**
**Value:**

- |                       |     |
|-----------------------|-----|
| ★ Warning in line 1/2 | [0] |
| Warning in line 3/4   | [1] |

**Function:**

In this parameter it is decided in which line the warning is to appear in display mode. In programming mode (Menu or Quick menu) the warning will appear in line 1/2 to avoid disturbance of the programming.

**Description of choice:**

Select the readout line.

---

**■ Load and motor**

<b>100 Configuration (CONFIG. MODE)</b>	
<b>Value:</b>	
★ Speed control, open loop (SPEED OPEN LOOP)	[0]
Speed control, closed loop (SPEED CLOSED LOOP)	[1]
Process control, closed loop (PROCESS CLOSED LOOP)	[3]
Torque control, open loop (TORQUE OPEN LOOP)	[4]
Torque control, speed feedback (TORQUE CONTROL SPEED)	[5]

**Function:**

This parameter is used for selecting the configuration to which the adjustable frequency drive is to be adapted. This makes adaptation to a given application simple, because the parameters that are not used in the given configuration are covered up (not active). By changing between the different application configurations, bumpless transfer (frequency only) is ensured.

**Description of choice:**

If Speed control, open loop [0] is selected, a normal speed control (without feedback signal) is obtained, but with automatic slip compensation, ensuring a nearly constant speed at varying loads.

Compensations are active, but may be disabled as required in parameter group 100.

If Speed control, closed loop [1] is selected, a full holding torque is obtained at 0 rpm, in addition to increased speed accuracy. A feedback signal must be provided and the PID regulator must be set.

If Process control, closed loop [3] is selected, the internal process regulator will be activated, thereby enabling accurate control of a process with respect to a given process signal. The process signal can be set using the actual process unit or as a percentage. A feedback signal must be supplied from the process, and the process setpoint must be adjusted.

If Torque control, open loop [4] is selected, the speed is regulated and the torque is kept constant. This is done without a feedback signal, since VLT 5000 ac-

curately calculates the torque on the basis of the current measurement.

If Torque control, speed feedback [5] is selected, an encoder speed feedback signal must be connected to the digital terminals 32/33.

Parameter 205 *Maximum reference* and parameter 415 *Maximum feedback* must be adapted to the application if [1], [3], [4] or [5] is selected.

**101 Torque characteristics  
(TORQUE CHARACT)**
**Value:**

★ High-constant torque (H-CONSTANT TORQUE)	[1]
High-variable torque low (H-VAR.TORQ.: LOW)	[2]
High-variable torque medium (H-VAR.TORQ.: MEDIUM)	[3]
High-variable torque high (H-VAR.TORQ.: HIGH)	[4]
High-special motor characteristics (H-SPEC.MOTOR CHARACT)	[5]
High-variable torque with low starting torque (H-VT LOW W. CT-START)	[6]
High-variable torque with medium starting torque (H-VT MED W. CT-START)	[7]
High-variable torque with high starting torque (H-VT HIGH W. CT-START)	[8]
Normal-constant torque (N-CONSTANT TORQUE)	[11]
Normal-variable torque low (N-VAR.TORQ.: LOW)	[12]
Normal-variable torque medium (N-VAR.TORQ.: MEDIUM)	[13]
Normal-variable torque high (N-VAR.TORQ.: HIGH)	[14]
Normal-special motor characteristics (N-SPEC.MOTOR CHARACT)	[15]
Normal-variable torque with low constant starting torque (N-VT LOW W. CT-START)	[16]

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

Normal-variable torque with medium constant starting torque (N-VT MED W. CT-START)	[17]
Normal-variable torque with high constant starting torque (N-VT HIGH W. CT-START)	[18]

**Function:**

In this parameter, the principle for adjusting the U/f characteristics of the adjustable frequency drive to the torque characteristics of the load is selected. By changing between the different torque characteristics, bumpless transfer (voltage only) is ensured.

**Description of choice:**

**NOTE**


For VLT 5001-5006, 200-240 V, VLT 5001-5011, 380-500 V, and VLT 5011, 550-600 V, it is only possible to choose torque characteristics from [1] to [8].

If a high torque characteristic [1]-[5] is selected, the adjustable frequency drive is able to provide 160% torque. If a normal torque characteristic [11]-[15] is selected, the adjustable frequency drive is able to provide 110% torque. The normal mode is used for oversize motors.

Please note that the torque can be limited in parameter 221.

If *Constant torque* is selected, a load-dependent U/f characteristic is obtained in which the output voltage is increased in the case of an increasing load (current) so as to maintain constant magnetization of the motor. Select *Variable torque low*, *Variable torque medium* or *Variable torque high* if the load is variable (centrifugal pumps, fans).

Select *High-variable torque with low* [6], *medium* [7] or *high* [8] starting torque if a higher breakaway torque is required other than that obtainable with the three first-mentioned characteristics, see fig. below.



Choose the torque characteristics giving the most reliable operation, the lowest possible energy consumption and the lowest acoustic noise.

Select *Special motor characteristics* if a special U/f setting is required to match the motor in question. Set the break points in parameters 422-432.


**NOTE**

Slip compensation is not active if a variable torque or special motor characteristics are used.

**102 Motor power (MOTOR POWER)**
**Value:**

0.18 kW (0.18 KW)	[18]
0.25 kW (0.25 KW)	[25]
0.37 kW (0.37 KW)	[37]
0.55 kW (0.55 KW)	[55]
0.75 kW (0.75 KW)	[75]
1.1 kW (1.10 KW)	[110]
1.5 kW (1.50 KW)	[150]
2.2 kW (2.20 KW)	[220]
3 kW (3.00 KW)	[300]
4 kW (4.00 KW)	[400]
5.5 kW (5.50 KW)	[550]
7.5 kW (7.50 KW)	[750]
11 kW (11.00 KW)	[1100]
15 kW (15.00 KW)	[1500]
18.5 kW (18.50 KW)	[1850]
22 kW (22.00 KW)	[2200]
30 kW (30.00 KW)	[3000]

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

		<b>103 Motor voltage (MOTOR VOLTAGE)</b>	
37 kW (37.00 KW)	[3700]	<b>Value:</b>	
45 kW (45.00 KW)	[4500]	200 V	[200]
55 kW (55.00 KW)	[5500]	208 V	[208]
75 kW (75.00 KW)	[7500]	220 V	[220]
90 kW (90.00 KW)	[9000]	230 V	[230]
110 kW (110.00 KW)	[11000]	240 V	[240]
132 kW (132.00 KW)	[13200]	380 V	[380]
160 kW (160.00 KW)	[16000]	400 V	[400]
200 kW (200.00 KW)	[20000]	415 V	[415]
250 kW (250.00 KW)	[25000]	440 V	[440]
280 kW (280.00 KW)	[28000]	460 V	[460]
315 kW (315.00 KW)	[31500]	480 V	[480]
355 kW (355.00 KW)	[35500]	500 V	[500]
400 kW (400.00 KW)	[40000]	550 V	[550]
450 kW (450.00 KW)	[45000]	575 V	[575]
500 kW (500.00 KW)	[50000]	660 V	[660]
530 kW (530.00 KW)	[53000]	690 V	[690]
560 kW (560.00 KW)	[56000]		
630 kW (630.00 KW)	[63000]		

Depends on the unit.

Depends on the unit

#### Function:

Selects the kW value that corresponds to the rated power of the motor.

A rated kW value has been selected from the factory that depends on the unit size.

#### Description of choice:

Select a value that equals the nameplate data on the motor. There are 4 possible undersizes or 1 oversize in comparison with the factory setting.

Also, alternatively it is possible to set the value for motor power as an infinitely variable value.

The set value automatically changes the values of the motor parameters in parameter 108-118.



#### NOTE

If the setting in parameter 102-109 is changed, parameter 110-118 will return to factory setting. If using special motor characteristics a change in parameter 102-109 affects parameter 422.

#### Function:

Select a value that equals the nameplate data on the motor.

#### NOTE

The motor will always see the peak voltage, corresponding to the connected supply voltage. In case of regenerative operation, the voltage can be higher.

#### Description of choice:

Select a value that equals the nameplate data on the motor, regardless of the AC line voltage of the adjustable frequency drive. Furthermore, it is also possible to set the value of the motor voltage at an infinitely variable rate.

The value set automatically changes values for the motor parameters in parameters 108-118.

For 87 Hz operation with 230/400 V motors, set the nameplate data for 230 V. Adapt parameter 202 *Output frequency high limit* and parameter 205 *Maximum reference* to the 87 Hz application.

**NOTE**

If a delta connection is used, the rated motor frequency for the delta connection must be selected.

**NOTE**

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to the factory setting. If using special motor characteristics, a change in parameter 102-109 affects parameter 422.

**104 Motor frequency  
(MOTOR FREQUENCY)****Value:**

- |                 |      |
|-----------------|------|
| ★ 50 Hz (50 HZ) | [50] |
| 60 Hz (60 HZ)   | [60] |

Max. motor frequency 1000 Hz.

**Function:**

This is where the rated motor frequency  $f_{M,N}$  is selected (nameplate data).

**Description of choice:**

Select a value that equals the nameplate data on the motor.

It is also possible to set the value for motor frequency at an infinitely variable rate, see chapter *Operation of the adjustable frequency drive*.

If a value different from 50 Hz or 60 Hz is selected, it is necessary to correct parameters 108 and 109.

For 87 Hz operation with 230/400 V motors, set the nameplate data for 230 V. Adapt parameter 202 *Output frequency high limit* and parameter 205 *Maximum reference* to the 87 Hz application.

**NOTE**

If a delta connection is used, the rated motor frequency for the delta connected must be selected.

**NOTE**

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to the factory setting. If using special

motor characteristics, a change in parameter 102-109 affects parameter 422.

**105 Motor current (MOTOR CURRENT)****Value:**

0.01 -  $I_{VLT,MAX}$  [0.01 - XXX.X]

Depends on the choice of motor.

**Function:**

The rated motor current  $I_{M,N}$  forms part of the adjustable frequency drive calculations i.a. of torque and motor thermal protection.

**Description of choice:**

Select a value that equals the nameplate data on the motor.

Enter the value in Ampere.

**NOTE**

It is important to enter the correct value, since this forms part of the VVC<sup>plus</sup> control feature.

**NOTE**

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to factory setting. If using special motor characteristics a change in parameter 102-109 affects parameter 422.

**106 Rated motor speed  
(MOTOR NOM. SPEED)****Value:**

100 - 60000 rpm (rpm) [100 - 60000]

Depends on the choice of motor.

**Function:**

This is where the value is selected that corresponds to the rated motor speed  $n_{M,N}$ , which can be seen from the nameplate data.

**Description of choice:**

The rated motor speed  $n_{M,N}$  is used i.a. for calculating the optimal slip compensation.

**NOTE**

It is important to enter the correct value, since this forms part of the VVC<sup>plus</sup> control feature. The max. value equals  $f_{M,N} \times 60$ . Set  $f_{M,N}$  in parameter 104.

**NOTE**

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to factory setting. If using special motor characteristics a change in parameter 102-109 affects parameter 422.

Select *Optimisation on, Rs [2]* if a reduced test is to be carried out, in which only the ohmic resistance in the system is determined.

**NOTE**

It is important to set motor parameters 102-106 correctly, since these form part of the AMA algorithm. In most applications, correct entering of motor parameters 102-106 is sufficient. For optimum dynamic motor adaptation, an AMA must be carried out.

Motor adaptation may take up to 10 minutes, depending on the output of the motor in question.

**NOTE**

There must not be any externally generating torque during automatic motor adaptation.

**NOTE**

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to factory setting. If using special motor characteristics a change in parameter 102-109 affects parameter 422.

**107 Automatic motor adaptation, AMA****(AUTO MOTOR ADAPT)****Value:**

- ★ Adaptation off (OFF) [0]
- Adaptation on, Rs and Xs (ENABLE (RS,XS)) [1]
- Adaptation on, Rs (ENABLE (RS)) [2]

**Function:**

If this function is used, the adjustable frequency drive automatically sets the necessary control parameters (parameters 108/109) with the motor stationary. Automatic motor adaptation ensures optimum use of the motor.

For the best possible adaptation of the adjustable frequency drive, it is recommended to run AMA on a cold motor.

The AMA function is activated by pressing the [START] key after selecting [1] or [2].

See also section *Automatic motor adaptation*.

The section *Automatic motor adaption, AMA, via VLT software dialog* shows how automatic motor adaptation can be activated by means of VLT Software Dialog.

After a normal sequence, the display will read "ALARM 21". Press the [STOP/RESET] key. The adjustable frequency drive is now ready for operation.

**Description of choice:**

Select *Enable, Rs and Xs [1]* if the adjustable frequency drive is to be able to carry out automatic motor adaptation of both the stator resistance Rs and the stator reactance Xs.

**108 Stator resistor (STATOR RESIST)****Value:**

- ★ Depends on the choice of motor

**Function:**

After setting motor data in parameters 102-106, a number of adjustments of various parameters are made automatically, including the stator resistance Rs. A manually entered Rs must apply to a cold motor. The shaft performance can be improved by fine-tuning Rs and Xs, see procedure below.

**Description of choice:**

Rs can be set as follows:

1. Automatic motor adaptation, where the adjustable frequency drive measures on the motor to determine the value. All compensations are reset to 100%.

2. The values are stated by the motor supplier.
3. The values are obtained by means of manual measurements:
  - $R_s$  can be calculated by measuring the resistance  $R_{\text{PHASE-to-PHASE}}$  between two phase terminals. If  $R_{\text{PHASE-to-PHASE}}$  is lower than 1-2 ohm (typically motors >4-5.5 kW, 400 V), a special ohm-meter should be used (Thomson bridge or similar).  $R_s = 0.5 \times R_{\text{PHASE-to-PHASE}}$
4. The factory settings of  $R_s$ , selected by the adjustable frequency drive itself on the basis of the motor nameplate data, are used.


**NOTE**

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to factory setting. If using special motor characteristics a change in parameter 102-109 affects parameter 422.

-  $X_s$  can be calculated by connecting a motor to line power and measuring the phase-to-phase voltage  $U_L$  as well as the idling current  $I_0$ .

Alternatively, these values can be recorded during operation in idle running state at the rated motor frequency  $f_{M,N}$ , slip compensation (par. 115) = 0% and load compensation at high speed (par. 114) = 100%.

$$X_s = \frac{U_L}{\sqrt{3} \times I_0}$$

4. The factory settings of  $X_s$ , selected by the adjustable frequency drive itself on the basis of the motor nameplate data, are used.


**NOTE**

If the setting in parameter 102-109 is changed, the parameters 110-118 will return to the factory setting. If using special motor characteristics, a change in parameter 102-109 affects parameter 422.

**109 Stator reactance**
**(STATOR REACT.)**
**Value:**

★ depends on the choice of motor

**Function:**

After setting motor data in parameters 102-106, a number of adjustments of various parameters are made automatically, including the stator reactance  $X_s$ . The shaft performance can be improved by fine-tuning  $R_s$  and  $X_s$ , see procedure below.

**Description of choice:**

$X_s$  can be set as follows:

1. Automatic motor adaptation, where the adjustable frequency drive measures on the motor to determine the value. All compensations are reset to 100%.
2. The values are stated by the motor supplier.
3. These values are obtained by means of manual measurements:


**110 Motor magnetizing, 0 rpm**
**(MOT. MAGNETIZING)**
**Value:**

0 - 300 %

★ 100 %

**Function:**

This parameter can be used if a different thermal load on the motor is desired when running at low speed. This parameter is used in connection with parameter 111.


**Description of choice:**

Enter a value stated as a percentage of the rated magnetizing current.

Too low setting may lead to a reduced torque on the motor shaft.

**111 Min. frequency normal magnetizing  
(MIN FR NORM MAGN)**
**Value:**


0.1 - 10.0 Hz      ★ 1.0 Hz

**Function:**

This parameter is used in connection with parameter 110. See drawing in parameter 110.

**Description of choice:**

Set the required frequency (for normal magnetizing current). If the frequency is set lower than the motor slip frequency, parameters 110 and 111 are of no significance.


**113 Load compensation at low speed  
(LO SPD LOAD COMP)**
**Value:**

0 - 300 %      ★ 100 %

**Function:**

This parameter enables compensation of voltage in relation to load when the motor is running at low speed.

**Description of choice:**

Optimum U/f characteristics are obtained, i.e. compensation for the load at low speed. The frequency range within which *Load compensation at low speed* is active, depends on the motor size.

This function is active for:

Motor size	Change-over
0.5 kW - 7.5 kW	< 10 Hz
11 kW - 45 kW	< 5 Hz
55 kW - 355 kW	< 3-4 Hz

**114 Load compensation at high speed  
(HI SPD LOAD COMP)**
**Value:**

0 - 300 %      ★ 100 %

**Function:**

This parameter enables compensation of voltage in relation to load when the motor is running at high speed.

**Description of choice:**

In *Load compensation at high speed* it is possible to compensate for the load from the frequency where *Load compensation at low speed* stopped working to max. frequency.

This function is active for:

Motor size	Change-over
0.5 kW - 7.5 kW	>10 Hz
11 kW - 45 kW	>5 Hz
55 kW - 355 kW	>3-4 Hz

**115 Slip compensation  
(SLIP COMPENSAT.)**
**Value:**

-500 - 500 %      ★ 100 %

**Function:**

Slip compensation is calculated automatically, i.e. on the basis of the rated motor speed  $n_{M,N}$ .

In parameter 115, slip compensation can be adjusted in detail, which compensates for tolerances in the value of  $N_{M,N}$ .

This function is not active together with *Variable torque* (parameter 101 - variable torque graphs), *Torque control*, *Speed feedback* and *Special motor characteristics*.

**Description of choice:**

Enter a %-value of the rated motor frequency (parameter 104).

**116 Slip compensation time constant  
(SLIP TIME CONST.)**
**Value:**

0.05 - 5.00 sec. ★ 0.50 sec.

**Function:**

This parameter determines the slip compensation reaction speed.

**Description of choice:**

A high value results in slow reaction. Conversely, a low value results in quick reaction.

If low-frequency resonance problems are encountered, the time set must be longer.

**117 Resonance dampening  
(RESONANCE DAMP.)**
**Value:**

0 - 500 % ★ 100 %

**Function:**

High-frequency resonance problems can be eliminated by setting parameters 117 and 118.

**Description of choice:**

For less resonance oscillation, the value of parameter 118 must be increased.

**118 Resonance dampening time constant  
(DAMP.TIME CONST.)**
**Value:**

5 - 50 ms ★ 5 ms

**Function:**

High-frequency resonance problems can be eliminated by setting parameters 117 and 118.

**Description of choice:**

Choose the time constant that provides the best damping.

**119 High starting torque  
(HIGH START TORQ.)**
**Value:**

0.0 - 0.5 sec. ★ 0.0 sec.

**Function:**

In order to secure a high starting torque, approx.  $2 \times I_{VLT,N}$  for max. 0.5 sec. is allowed. However, the current is limited by the protection limit of the adjustable frequency drive (inverter).

**Description of choice:**

Set the necessary time in which a high starting torque is desired.

**120 Start delay (START DELAY)**
**Value:**

0.0 - 10.0 sec. ★ 0.0 sec.

**Function:**

This parameter enables a delay of the starting time. The adjustable frequency drive begins with the start function selected in parameter 121.

**Description of choice:**

Set the desired time until acceleration is to begin.

**121 Start function (START FUNCTION)**
**Value:**

DC hold in start delay time  
(DC HOLD/DELAY TIME) [0]

DC brake in start delay time  
(DC BRAKE/DELAY TIME) [1]

★ Coasting in start delay time  
(COAST/DELAY TIME) [2]

Start frequency/voltage clockwise. [3]

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

**(CLOCKWISE OPERATION)**

Start frequency/voltage in reference direction

**(HORIZONTAL OPERATION)** [4]

VVC<sup>plus</sup> clockwise

**(VVC+ CLOCKWISE)** [5]

**Function:**

This is where the desired state during start delay (parameter 120) is selected.

**Description of choice:**

Select *DC hold in the start delay time* [0] so as to energize the motor with a DC holding current (parameter 124) in the start delay time.

Select *DC brake in the start delay time* [1] so as to energize the motor with a DC braking current (parameter 125) in the start delay time.

Select *Coasting in the start delay time* [2] and the motor will not be controlled by the adjustable frequency drive during the start delay time (inverter off).

*Start frequency/voltage clockwise* [3] and *VVC<sup>plus</sup> clockwise* [5] is typically used in hoisting applications. *Start frequency/voltage in reference direction* [4] is used especially in applications with counterweight.

Select *Start frequency/voltage clockwise* [3] so as to have the function described in parameter 130 and 131 in the start delay time.

The output frequency will equal the setting of the start frequency in parameter 130, and the output voltage will equal the setting of the start voltage in parameter 131. Regardless of the value assumed by the reference signal, the output frequency will equal the setting of the start frequency in parameter 130 and the output voltage will correspond to the setting of the start voltage in parameter 131.

This functionality is used typically in hoisting applications.

This is used especially in applications with a cone armature motor, where the start is to be clockwise, followed by rotation in the reference direction.

Select *Start frequency/voltage in reference direction* [4] in order to obtain the function described in parameters 130 and 131 during the start delay time. The motor will always rotate in the reference direction.

If the reference signal equals zero (0) parameter 130 *Start frequency* will be ignored and the output frequency will equal zero (0). The output voltage will corre-

spond to the setting of the start voltage in parameter 131 *Start voltage*.

Select *VVC<sup>plus</sup> clockwise* [5] so as to have only the function described in parameter 130 *Start frequency* in the start delay time. The start voltage will be calculated automatic. Notice that this function only uses the start frequency in the start delay time.

Regardless of the value assumed by the reference signal, the output frequency will equal the setting of the start frequency in parameter 130.

**122 Function at stop**
**(FUNCTION AT STOP)**
**Value:**

★ Coasting (COAST)	[0]
DC hold (DC-HOLD)	[1]
Motor check (MOTOR CHECK)	[2]
Pre-magnetizing (PREMAGNETIZING)	[3]

**Function:**

Here it is possible to select the function of the adjustable frequency drive after a stop command or when the frequency has been ramped down to 0 Hz. See parameter 123 with respect to activation of this parameter regardless of whether the stop command is active.

**Description of choice:**

Select *Coasting* [0] if the adjustable frequency drive is to 'let go' of the motor (inverter closed).

Select *DC hold* [1] when a DC holding current set in parameter 124 is to be activated.

Select *Motor check* [2] if the adjustable frequency drive is to check whether or not a motor has been connected.

Select *Pre-magnetizing* [3]. The magnetic field is built up in the motor while it remains stopped. This ensures that the motor can produce torque as quickly as possible on starting.

**123 Min. frequency for activating function at stop**
**(MIN.F. FUNC.STOP)**
**Value:**

0.0 - 10.0 Hz ★ 0.0 Hz

**Function:**

This parameter sets the frequency at which the function selected in parameter 122 is to be activated.

**Description of choice:**

Enter the desired frequency.


**NOTE**

If parameter 123 is set higher than parameter 130, the start delay function (parameters 120 and 121) will be skipped.


**NOTE**

If parameter 123 is set too high, and DC hold has been chosen in parameter 122, the output frequency will jump to the value in parameter 123 without ramping up. This may cause an overcurrent warning/alarm.

**124 DC holding current  
(DC-HOLD CURRENT)**
**Value:**

$$(OFF) - \frac{I_{VLT, N}}{I_{M, N}} \times 100 \% \quad \star 50 \%$$

**Function:**

This parameter is used to uphold the motor function (holding torque) or to pre-heat the motor.


**NOTE**

The maximum value depends on the rated motor current. If the DC holding current is active, the adjustable frequency drive has a switching frequency of 4 kHz.

**Description of choice:**

This parameter can only be used if *DC hold* [1] has been selected in parameter 121 or 122. Set it as a percentage value in relation to the rated motor current  $I_{M,N}$  set in parameter 105.

100% DC holding current corresponds to  $I_{M,N}$ .



Warning: 100% supply for too long may damage the motor.

VLT 5122-5552, 380-500 V and VLT 5042-5602, 525-690 V work with a reduced DC current rated as 80% of  $I_{VLT,N}$  at 110% overload.

**125 DC braking current  
(DC BRAKE CURRENT)**
**Value:**

$$0 \text{ (OFF)} - \frac{I_{VLT, N}}{I_{M, N}} \times 100 \% \quad \star 50 \%$$

**Function:**

This parameter is used for setting the DC brake current that is activated upon a stop when the DC brake frequency set in parameter 127 has been reached, or if the DC brake inverse is active via digital terminal 27 or via a serial communication port. The DC braking current will be active for the duration of the DC braking time set in parameter 126.


**NOTE**

The maximum value depends on the rated motor current. If the DC braking current is active, the adjustable frequency drive has a switching frequency of 4.5 kHz.

**Description of choice:**

To be set as a percentage value of the rated motor current  $I_{M,N}$  set in parameter 105.

100% DC braking current corresponds to  $I_{M,N}$ .



Warning: 100% supply for too long may damage the motor.

VLT 5122-5552, 380-500 V and VLT 5042-5602, 525-690 V work with a reduced DC current rated as 80% of  $I_{VLT,N}$  at 110% overload.

**126 DC braking time  
(DC BRAKING TIME)**
**Value:**

$$0.0 \text{ (OFF)} - 60.0 \text{ sec.} \quad \star 10.0 \text{ sec.}$$

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

**Function:**

This parameter is for setting the DC braking time for which the DC braking current (parameter 125) is to be active.

**Description of choice:**

Set the desired time.

**127 DC brake cut-in frequency**
**(DC BRAKE CUT-IN)**
**Value:**

0.0 - parameter 202      ★ 0.0 Hz (OFF)

**Function:**

This parameter is for setting the DC brake cut-in frequency at which the DC braking current (parameter 125) is to be active, in connection with a stop command.

**Description of choice:**

Set the desired frequency.

**128 Motor thermal protection**
**(MOT.THERM PROTEC)**
**Value:**

★ No protection (NO PROTECTION)	[0]
Thermistor warning (THERMISTOR WARN)	[1]
Thermistor trip (THERMISTOR TRIP)	[2]
ETR Warning 1 (ETR WARNING1)	[3]
ETR Trip 1 (ETR TRIP1)	[4]
ETR Warning 2 (ETR WARNING2)	[5]
ETR Trip 2 (ETR TRIP2)	[6]
ETR Warning 3 (ETR WARNING3)	[7]
ETR Trip 3 (ETR TRIP3)	[8]
ETR Warning 4 (ETR WARNING 4)	[9]
ETR Trip 4 (ETR TRIP4)	[10]

**Function:**

The adjustable frequency drive is able to monitor the motor temperature in two different ways:

- Via a thermistor sensor connected to one of the analog inputs, terminals 53 and 54 (parameters 308 and 311).

- Calculation of the thermal load, based on the current load and the time. This is compared with the rated motor current  $I_{M,N}$  and the rated motor frequency  $f_{M,N}$ . The calculations made take into account the need for a lower load at lower speeds because of less cooling from the fan.

ETR functions 1-4 do not start calculating the load until there is a switch-over to the Setup in which they were selected. This enables the use of the ETR function, even where two or several motors alternate. For the North American market: The ETR functions provide class 10 or 20 motor overload protection in accordance with NEC.

**Description of choice:**

Select *No protection* if no warning or tripping is required when the motor is overloaded.

Select *Thermistor warning* if a warning is desired when the connected thermistor - and thus the motor - gets too hot.


Select *Thermistor trip* if cutting out (trip) is desired when the connected thermistor - and thus the motor - overheats.

Select *ETR Warning 1-4*, if a warning is to come up on the display when the motor is overloaded according to the calculations.

Select *ETR Trip 1-4* if tripping is desired when the motor is overloaded according to the calculations.

The adjustable frequency drive can also be programmed to give off a warning signal via one of the digital outputs, in which case the signal is given both for warning and for trip (thermal warning).

★ = factory setting, () = display text, [] = value for use in communication via serial communication port


**129 External motor fan  
(MOTOR EXTERN FAN)**
**Value:**


- No (NO) [0]  
 Yes (YES) [1]

**Function:**

This parameter informs the frequency converter whether the motor has an external separately supplied fan (external ventilation), indicating that derating at low speed is unnecessary.

**Description of choice:**

If Yes [1] is selected, the graph below is followed if the motor frequency is lower. If the motor frequency is higher, the time will still derate as if no fan had been installed.


**130 Start frequency (START FREQUENCY)**
**Value:**

- 0.0 - 10.0 Hz  0.0 Hz

**Function:**

This parameter allows setting of the output frequency at which the motor is to start.

The output frequency 'leaps' to the set value. This parameter can be used e.g. for hoist applications (cone rotor motors).

**Description of choice:**

Set the desired start frequency.

It is assumed that the start function in parameter 121 has been set to [3] or [4] and that a start delay time has been set in parameter 120; also, a reference signal must be present.

**NOTE**

If parameter 123 is set higher than parameter 130, the start delay function (parameters 120 and 121) will be skipped.

**131 Initial voltage (INITIAL VOLTAGE)**
**Value:**

- 0.0 - parameter 103  0.0 Volt

**Function:**

Some motors, such as cone rotor motors, need extra voltage/starting frequency (boost) when starting, so as to disengage the mechanical brake.

For this purpose use parameters 130/131.

**Description of choice:**

Set the desired value required to disengage the mechanical brake.

It is assumed that the start function in parameter 121 has been set to [3] or [4] and that a start delay time has been set in parameter 120; also, a reference signal must be present.

**145 Minimum DC brake time  
(DC BRK MIN. TIME)**
**Value:**

- 0 - 10 sec.  0 sec.

\* = factory setting, () = display text, [] = value for use in communication via serial communication port



---

## VLT® 5000 Series

---

**Function:**

If a minimum DC brake time is necessary before a new start is possible, this parameter can be set.

**Description of choice:**

Select the desired time.

---

**■ References and limits**
**200 Output frequency range/direction**
**(OUT FREQ RNG/ROT)**
**Value:**

- ★ Only clockwise, 0-132 Hz  
(132 Hz CLOCK WISE) [0]
- Both directions, 0-132 Hz  
(132 Hz BOTH DIRECT.) [1]
- Only clockwise, 0-1000 Hz  
(1000 Hz CLOCK WISE) [2]
- Both directions, 0-1000 Hz  
(1000 Hz BOTH DIRECT.) [3]
- Only counter clockwise, 0-132 Hz  
(132 Hz COUNTERCLOCK) [4]
- Only counter clockwise, 0-1000 Hz  
(1000 Hz COUNTERCLOCK) [5]

**Function:**

This parameter guarantees protection against unwanted reversing. Furthermore, the maximum output frequency can be selected that is to apply, regardless of the settings of other parameters.


**NOTE**

The output frequency of the adjustable frequency drive can never assume a value higher than 1/10 of the switching frequency, see parameter 411.

Is not to be used together with *Process control, closed loop* (parameter 100).


**Description of choice:**

Select the desired direction as well as output frequency.

Note that if *Clockwise, 0-132 Hz* [0], *Clockwise, 0-1000 Hz* [2], *Counter clockwise, 0-132 Hz* [4] or *Counter clockwise, 0-1000 Hz* [5] is selected, the output frequency will be limited to the range  $f_{MIN} - f_{MAX}$ .

If *Both directions, 0-132 Hz* [1] or *Both directions, 0-1000 Hz* [3] is selected, the output frequency will be limited to the range  $\pm f_{MAX}$  (the minimum frequency is of no significance).

Example:



Parameter 200 Output frequency range/direction = both directions.

**201 Output frequency low limit ( $F_{MIN}$ )**
**(OUT FREQ LOW LIM)**
**Value:**

0.0 -  $f_{MAX}$  ★ 0.0 Hz

**Function:**

In this parameter, a minimum motor frequency limit can be selected that corresponds to the minimum frequency at which the motor is to run.

The minimum frequency can never be higher than the maximum frequency,  $f_{MAX}$ .

If *Both directions* has been selected in parameter 200, the minimum frequency is of no significance.

**Description of choice:**

A value from 0.0 Hz to the max. frequency selected in parameter 202 ( $f_{MAX}$ ) can be chosen.

**202 Output frequency high limit ( $F_{MAX}$ )**
**(OUT FREQ HI LIM)**
**Value:**

$f_{MIN} - 132/1000$  Hz (parameter 200) ★ depends on unit

**Function:**

In this parameter, a maximum motor frequency can be selected that corresponds to the highest frequency at which the motor is to run. The factory setting is 132 Hz for VLT 5001-5027 200-240 V, VLT 5001-5102 380-500 V, VLT 5001-5062 525-600 V. For VLT

5032-5052 200-240 V, VLT 5122-5552 380-500 V and  
5042-5602 525-690 V the factory setting is 66 Hz.

See also parameter 205.

**NOTE**

The output frequency of the adjustable frequency drive can never assume a value higher than 1/10 of the switching frequency.

**Description of choice:**

A value from f<sub>MIN</sub> to the choice made in parameter 200 can be selected.

**NOTE**

If the maximum motor frequency is set at more than 500 Hz, parameter 446 must be set at 60° AVM [0] switching pattern.

**203 Reference/feedback area  
(REF/FEEDB. RANGE)****Value:**

- |                           |     |
|---------------------------|-----|
| ★ Min - Max (MIN - MAX)   | [0] |
| - Max - + Max (-MAX+-MAX) | [1] |

**Function:**

This parameter decides whether the reference signal and the feedback signal are to be positive or can be both positive and negative.

The minimum limit may be a negative value, unless Speed control, closed loop has been selected (parameter 100).

Choose Min - Max [0] if Process control, closed loop has been selected in parameter 100.

**Description of choice:**

Choose the desired range.

**204 Minimum reference  
(MIN. REFERENCE)****Value:**

- |                           |         |
|---------------------------|---------|
| -100,000.000 - RefMAX     | ★ 0.000 |
| Depends on parameter 100. |         |

**Function:**

The Minimum reference gives the minimum value that can be assumed by the sum of all references. Minimum reference is only active if Min - Max [0] has been set in parameter 203; however, it is always active in Process control, closed loop (parameter 100).

**Description of choice:**

Is only active when parameter 203 has been set to Min - Max [0].

Set the desired value.

The unit follows the choice of configuration in parameter 100.

Speed control, open loop:	Hz
Speed control, closed loop:	rpm
Torque control, open loop:	Nm
Torque control, speed feedback:	Nm
Process control, closed loop:	Process units (par. 416)

Special motor characteristics, activated in parameter 101, use the unit selected in parameter 100.

**205 Maximum reference  
(MAX. REFERENCE)****Value:**

- |                      |          |
|----------------------|----------|
| RefMIN - 100,000.000 | ★ 50.000 |
|----------------------|----------|

**Function:**

The Maximum reference gives the highest value that can be assumed by the sum of all references. If closed loop has been selected in parameter 100, the maximum reference cannot be set higher than the maximum feedback (parameter 415).

**Description of choice:**

Set the desired value.

The unit follows the choice of configuration in parameter 100.

Speed control, open loop:	Hz
Speed control, closed loop:	rpm
Torque control, open loop:	Nm
Torque control, speed feedback:	Nm
Process control, closed loop:	Process units (par. 416)

Special motor characteristics, activated in parameter 101, use the unit selected in parameter 100.

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

**206 Ramp type (RAMP TYPE)**
**Value:**

- |                                     |     |
|-------------------------------------|-----|
| ★ Linear (LINEAR)                   | [0] |
| Sinusoidal (S1)                     | [1] |
| Sin <sup>2</sup> (S2)               | [2] |
| Sin <sup>3</sup> (S3)               | [3] |
| Sin <sup>2</sup> filter (S2 FILTER) | [4] |

**Function:**


There is a choice of 4 different ramp types.

**Description of choice:**

Select the desired ramp type, depending on requirements concerning acceleration/deceleration.

The ramp is recalculated if the reference is changed during ramping, resulting in an increase of the ramping time.

Selection S<sup>2</sup> filter [4] is not recalculated if the reference is changed during ramping.



**207 Ramp-up time 1**
**(RAMP UP TIME 1)**
**Value:**

0.05 - 3600 sec.      ★ depends on unit

**Function:**

The ramp-up time is the acceleration time from 0 Hz to the rated motor frequency  $f_{M,N}$  (parameter 104) or the rated motor speed  $n_{M,N}$  (if *Speed control, closed loop* has been selected in parameter 100). This presupposes that the output current does not reach the torque limit (to be set in parameter 221).

that the output current does not reach the torque limit (to be set in parameter 221).


**Description of choice:**

Program the desired ramp-up time.

**208 Ramp-down time 1**
**(RAMP DOWN TIME 1)**
**Value:**

0.05 - 3600 sec.      ★ depends on unit

**Function:**

The ramp-down time is the deceleration time from the rated motor frequency  $f_{M,N}$  (parameter 104) to 0 Hz or from the rated motor speed  $n_{M,N}$ , provided there is no over-voltage in the inverter because of regenerative operation of the motor, or if the generated current reaches the torque limit (to be set in parameter 222).

**Description of choice:**

Program the desired ramp-down time.

**209 Ramp-up time 2**
**(RAMP UP TIME 2)**
**Value:**

0.05 - 3600 sec.      ★ depends on unit

**Function:**

See description of parameter 207.

**Description of choice:**

Program the desired ramp-up time.

Switching from ramp 1 to ramp 2 is effected via a signal on digital input terminal 16, 17, 29, 32 or 33.

**210 Ramp-down time 2**
**(RAMP DOWN TIME 2)**
**Value:**

0.05 - 3600 sec. ★ depends on unit

**Function:**

See description of parameter 208.

**Description of choice:**

Program the desired ramp-down time.


Switching from ramp 1 to ramp 2 is effected via a signal on digital input terminal 16, 17, 29, 32 or 33.

**211 Jog ramp time (JOG RAMP TIME)**
**Value:**

0.05 - 3600 sec. ★ depends on unit

**Function:**

The jog ramp time is the acceleration/deceleration time from 0 Hz to the rated motor frequency  $f_{M,N}$  (parameter 104). It is assumed that the output current is not higher than the torque limit (set in parameter 221).



The jog ramp time starts if a jog signal is given via the control panel, the digital inputs or the serial communication port.

**Description of choice:**

Set the desired ramp time.

**212 Quick stop ramp-down time**
**(Q STOP RAMP TIME)**
**Value:**

0.05 - 3600 sec. ★ depends on unit

**Function:**

The ramp-down time is the deceleration time from the rated motor frequency to 0 Hz, provided no over-voltage arises in the inverter because of generating operation of the motor or if the generated current becomes higher than the torque limit (set in parameter 222). Quick-stop is activated by means of a signal on digital input terminal 27, or via the serial communication port.

**Description of choice:**

Program the desired ramp-down time.

**213 Jog frequency (JOG FREQUENCY)**
**Value:**

0.0 - parameter 202 ★ 10.0 Hz

**Function:**

The jog frequency  $f_{JOG}$  is the fixed output frequency at which the adjustable frequency drive is running when the jog function is activated.

**Description of choice:**

Set the desired frequency.

**214 Reference function**
**(REF FUNCTION)**
**Value:**

★ Sum. (SUM) [0]

Relative (RELATIVE) [1]

External/preset (EXTERNAL/PRESET) [2]

**Function:**

It is possible to define how the preset references are to be added to the other references. For this purpose, *Sum* or *Relative* is used. It is also possible - by using the *External/preset* function - to select whether a shift between external references and preset references is desired.

**Description of choice:**

If *Sum* [0] is selected, one of the adjusted preset references (parameters 215-218) is added as a percentage of the maximum possible reference.

If *Relative* [1] is selected, one of the adjusted preset references (parameters 215-218) is added to the ex-

★ = factory setting, () = display text, [] = value for use in communication via serial communication port


ternal references as a percentage of the actual reference.

In addition, it is possible to use parameter 308 to select whether the signals on terminals 54 and 60 are to be added to the sum of the active references.

If *External/preset [2]* is selected, it is possible to shift between external references or preset references via terminal 16, 17, 29, 32 or 33 (parameter 300, 301, 305, 306 or 307). Preset references will be a percentage value of the reference range.

External reference is the sum of the analog references, pulses and bus references. See also drawings in section *Handling of multi-references*.

Par. 204 Min. reference	Increase [Hz/V]	Frequency by 4.0 V	Par. 215 Preset ref.	Par. 214 Reference type = Sum [0]	Par. 214 Reference type = Relative [1]
1) 0	5	20 Hz	15 %	Output frequency $00+20+7.5 = 27.5$ Hz	Output frequency $00+20+3 = 23.0$ Hz
2) 10	4	16 Hz	15 %	$10+16+6.0 = 32.0$ Hz	$10+16+2.4 = 28.4$ Hz
3) 20	3	12 Hz	15 %	$20+12+4.5 = 36.5$ Hz	$20+12+1.8 = 33.8$ Hz
4) 30	2	8 Hz	15 %	$30+8+3.0 = 41.0$ Hz	$30+8+1.2 = 39.2$ Hz
5) 40	1	4 Hz	15 %	$40+4+1.5 = 45.5$ Hz	$40+4+0.6 = 44.6$ Hz



#### NOTE

If *Sum* or *Relative* is selected, one of the preset references will always be active. If the preset references are to be without influence, they should be set to 0 % (as in the factory setting).

The example shows how to calculate the output frequency if using *Preset references* together with *Sum* and *Relative* in parameter 214.

Parameter 205 *Maximum reference* has been set to 50 Hz.

#### Function:

Four different preset references can be programmed in parameters 215-218.

The preset reference is stated as a percentage of the value *RefMAX* or as a percentage of the other external references, depending on the choice made in parameter 214. If a *RefMIN • 0* has been programmed, the preset reference as a percentage will be calculated on the basis of the difference between *Ref MAX* and *RefMIN*, following which the value is added to *Ref MIN*.

#### Description of choice:

Set the fixed reference(s) that is/are to be the options.

To use the fixed references, it is necessary to have selected *Preset ref. enable* on terminal 16, 17, 29, 32 or 33.

Choices between fixed references can be made by activating terminal 16, 17, 29, 32 or 33 - see the table below.

#### 215 Preset reference 1 (PRESET REF. 1)

#### 216 Preset reference 2 (PRESET REF. 2)

#### 217 Preset reference 3 (PRESET REF. 3)

#### 218 Preset reference 4 (PRESET REF. 4)

#### Value:

-100.00 % - +100.00 %


★ 0.00%

of the reference range/external reference

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

Terminals 17/29/33 preset ref. msb	Terminals 16/29/32 preset ref. lsb	
0	0	Preset ref. 1
0	1	Preset ref. 2
1	0	Preset ref. 3
1	1	Preset ref. 4

See drawings in section *Handling of multi-references*.


**219 Catch up/slow downvalue**
**(CATCH UP/SLW DWN)**
**Value:**

0.00-100% of the current reference      0.00%


**Function:**

This parameter enables the entry of a percentage value (relative) which will either be added to or deducted from the actual reference.

**Description of choice:**

If Catch up has been selected via one of the terminals 16, 29 or 32 (parameters 300, 305 and 306), the percentage (relative) value selected in parameter 219 will be added to the total reference.

If Slow down has been selected via one of the terminals 17, 29 or 33 (parameters 301, 305 and 307), the percentage (relative) value selected in parameter 219 will be deducted from the total reference.


**Description of choice:**

See also parameter 409 for further details.

In order to protect the motor from reaching pull-out torque, the factory setting is 1.6 x the rated motor torque (calculated value).

If a synchronous motor is used, the torque limit must be increased in relation to the factory setting.

If a setting in parameters 101-106 is changed, parameters 221/222 are not automatically reversed to the factory setting.

**221 Torque limit for motor mode**
**(TORQ LIMIT MOTOR)**
**Value:**

0.0 % - xxx.x % of  $T_{M,N}$       160 % of  $T_{M,N}$

**Function:**

This function is relevant for all application configurations; speed, process and torque control.

This is where to set the torque limit for motor operation. The torque limiter is active in the frequency range up to the rated motor frequency (parameter 104).

In the oversynchronous range, where the frequency is higher than the rated motor frequency, this function acts as a current limiter.

See fig. below.

**222 Torque limit for generating operation**
**(TORQ LIMIT GENER)**
**Value:**

0.0 % - xxx.x % of  $T_{M,N}$       160 %

The max. torque depends on the unit and the motor size selected.


**Function:**

This function is relevant for all application configurations; speed, process and torque control.

This is where to set the torque limit for generating operation. The torque limiter is active in the frequency range up to the rated motor frequency (parameter 104).

In the oversynchronous range, where the frequency is higher than the rated motor frequency, this function acts as a current limiter.

See fig. for parameter 221 as well as parameter 409 for further details.


**Description of choice:**

If Resistor brake [1] has been selected in parameter 400, the torque limit is changed to 1.6 x the rated motor torque.

**223 Warning: Low current  
(WARN. CURRENT LO)**
**Value:**

0.0 - parameter 224      ★ 0.2 A

**Function:**

When the motor current is below the limit,  $I_{LOW}$  programmed in this parameter, the display indicates CURRENT LOW.

The signal outputs can be programmed to transmit a status signal via terminal 42 or 45 as well as via relay output 01 or 04 (parameter 319, 321, 323 or 326).

**Description of choice:**

The lower signal limit  $I_{LOW}$  of the motor current must be programmed within the normal working range of the adjustable frequency drive.

**224 Warning: High current  
(WARN. CURRENT HI)**
**Value:**

Parameter 223 -  $I_{VLT,MAX}$       ★  $I_{VLT,MAX}$

**Function:**

If the motor current gets above the limit programmed in this parameter,  $I_{HIGH}$ , the display will indicate CURRENT HIGH.

The signal outputs can be programmed to transmit a status signal via terminal 42 or 45 and via relay output 01 or 04 (parameter 319, 321, 323 or 326).

**Description of choice:**

The upper signal limit of the motor current,  $I_{HIGH}$ , must be programmed within the normal working range of the adjustable frequency drive.

**225 Warning: Low frequency  
(WARN. FREQ. LOW)**
**Value:**

0.0 - parameter 226      ★ 0.0 Hz

**Function:**

When the motor frequency is below the limit programmed in this parameter,  $f_{LOW}$ , the display indicates FREQUENCY LOW.

The signal outputs can be programmed to transmit a status signal via terminal 42 or 45 and via relay output 01 or 04 (parameter 319, 321, 323 or 326).

**Description of choice:**

The lower signal limit of the motor frequency,  $f_{LOW}$ , is to be programmed within the normal working range of the adjustable frequency drive.  
See drawing at parameter 223.

**226 Warning: High frequency  
(WARN. FREQ. HIGH)**
**Value:**

parameter 225 - parameter 202      ★ 132.0 Hz

**Function:**

When the motor frequency is above the limit programmed in this parameter,  $f_{HIGH}$ , the display will indicate FREQUENCY HIGH.

The signal outputs can be programmed to transmit a status signal via terminal 42 or 45 and via relay output 01 or 04 (parameter 319, 321, 323 or 326).

**Description of choice:**

The upper signal limit of the motor frequency,  $f_{HIGH}$ , must be programmed within the normal working range of the adjustable frequency drive.

See drawing at parameter 223.

**227 Warning: Low feedback  
(WARN. FEEDB. LOW)**
**Value:**

-100,000.000 - parameter 228.      ★ -4000.000

**Function:**

If the connected feedback signal gets below the value set in this parameter, the signal outputs can be programmed to transmit a status signal via terminal 42 or 45 and via relay output 01 or 04 (parameter 319, 321, 323 or 326).

**Description of choice:**

Set the desired value.

**228 Warning: High feedback  
(WARN. FEEDB HIGH)**
**Value:**

parameter 227 - 100,000.000      ★ 4000.000

**Function:**

If the connected feedback signal gets above the value set in this parameter, the signal outputs can be programmed to transmit a status signal via terminal 42 or 45 and via relay output 01 or 04 (parameter 319, 321, 323 or 326).

**Description of choice:**

Set the desired value.

**229 Frequency bypass, bandwidth  
(FREQ BYPASS B.W.)**
**Value:**

0 (OFF) - 100%      ★ 0 (OFF) %

**Function:**

Some systems call for some output frequencies to be avoided because of resonance problems in the system.

In parameters 230-233 these output frequencies can be programmed for bypassing (Frequency bypass). In this parameter (229), a bandwidth can be defined on either side of these frequency bypasses.

The frequency bypass function is not active if par. 002 is set to Local and par. 013 is set to LCP ctrl/Open loop or LCP+dig ctrl/Open loop.

**Description of choice:**

The bypass bandwidth is set as a percentage of the bypass frequency which is selected in parameter 230-233.

The bypass bandwidth indicates max. variation of the bypass frequency.

Example: A bypass frequency of 100 Hz and a bypass bandwidth of 1% are selected. In this case the bypass frequency can vary between 99.5 Hz and 100.5 Hz i.e. 1% of 100 Hz.

<b>230</b>	<b>Frequency bypass 1 (FREQ. BYPASS 1)</b>
<b>231</b>	<b>Frequency bypass 2 (FREQ. BYPASS 2)</b>
<b>232</b>	<b>Frequency bypass 3 (FREQ. BYPASS 3)</b>
<b>233</b>	<b>Frequency bypass 4 (FREQ. BYPASS 4)</b>

**Value:**

0.0 - parameter 200      ★ 0.0 Hz

**Function:**

Some systems call for some output frequencies to be avoided because of resonance problems in the system.

**Description of choice:**

Enter the frequencies to be avoided.

See also parameter 229.

<b>234</b>	<b>Motor phase monitor</b>
	<b>(MOTOR PHASE MON)</b>

**Value:**

- |                   |     |
|-------------------|-----|
| ★ Enable (ENABLE) | [0] |
| Disable (DISABLE) | [1] |

**Function:**

In this parameter it is possible to select monitoring of the motor phases.

**Description of choice:**

If *Enable* is selected, the adjustable frequency drive will react on a missing motor phase which will result in alarm 30, 31 or 32.

If *Disable* is selected, **no** alarm is given if a motor phase is missing. The motor can be damaged/overheated if it runs on only two phases. It is therefore recommended to keep the missing motor phase function ENABLED.

**■ Parameters - Inputs and outputs**

Digital inputs	Terminal no. parameter	16 300	17 301	18 302	19 303	27 304	29 305	32 306	33 307
<b>Value:</b>									
No function	(NO OPERATION)	[0]	[0]	[0]	[0]		[0]	[0]	[0]
Reset	(RESET)	[1]*	[1]				[1]	[1]	[1]
Coasting stop, inverse	(COAST INVERSE)					[0]*			
Reset and coasting stop, inverse	(COAST & RESET INVERS)					[1]			
Quick-stop, inverse	(QSTOP INVERSE)					[2]			
DC-braking, inverse	(DCBRAKE INVERSE)					[3]			
Stop inverse	(STOP INVERSE)	[2]	[2]			[4]	[2]	[2]	[2]
Start	(START)					[1]*			
Latched start	(LATCHED START)					[2]			
Reversing	(REVERSING)					[1]*			
Start reversing	(START REVERSE)					[2]			
Only start clockwise, on	(ENABLE START FWD.)	[3]	[3]			[3]	[3]		
Only start anti-clockwise, on	(ENABLE START REV)	[3]	[3]			[4]		[3]	
Jog	(JOGGING)	[4]	[4]			[5]*	[4]	[4]	
Preset reference, on	(PRESET REF. ON)	[5]	[5]			[5]	[5]	[5]	
Preset reference, lsb	(PRESET REF. SEL. LSB)	[5]				[7]	[6]		
Preset reference, msb	(PRESET REF. MSB)	[6]				[8]		[6]	
Freeze reference	(FREEZE REFERENCE)	[7]	[7]*			[9]	[7]	[7]	
Freeze output	(FREEZE OUTPUT)	[8]	[8]			[10]	[8]	[8]	
Speed up	(SPEED UP)	[9]				[11]	[9]		
Speed down	(SPEED DOWN)		[9]			[12]		[9]	
Choice of Setup, lsb	(SETUP SELECT LSB)	[10]				[13]	[10]		
Choice of Setup, msb	(SETUP SELECT MSB)		[10]			[14]		[10]	
Choice of Setup, msb/speed up	(SETUP MSB/SPEED UP)					[11]			*
Choice of Setup, lsb/speed down	(SETUP LSB/SPEED DOWN)					[11]			*
Catch-up	(CATCH UP)	[11]				[15]	[12]		
Slow-down	(SLOW DOWN)		[11]			[16]		[12]	
Ramp 2	(RAMP 2)	[12]	[12]			[17]	[13]	[13]	
Mains failure inverted	(MAINS FAILURE INVERSE)	[13]	[13]			[18]	[14]	[14]	
Pulse reference	(PULSE REFERENCE)		[23]			[28] <sup>1</sup>			
Pulse feedback	(PULSE FEEDBACK)						[24]		
Encoder feedback input, A	(ENCODER INPUT 2A)						[25]		
Encoder feedback input, B	(ENCODER INPUT 2B)						[24]		
Safety interlock	(SAFETY INTERLOCK)		[24]			[5]			
Data change lock	(PROGRAMMING LOCK)	[29]	[29]			[29]	[29]	[29]	

1) If this function is selected for terminal 29, the same function for terminal 17 will not be valid, even if it has been selected to be active.

\* = factory setting, () = display text, [] = value for use in communication via serial communication port

**300 Terminal 16, input  
(DIGITAL INPUT 16)**

**Function:**

In this and the following parameters it is possible to choose between the different possible functions related to the inputs on terminals 16-33.

The function options are shown in the table on page 111. The maximum frequency for terminal 16, 17, 18 and 19 is 5 kHz. The maximum frequency for terminals 29, 32 and 33 is 65 kHz.

**Description of choice:**

**No function** is selected if the frequency converter is not to react to signals transmitted to the terminal.

Reset zeroes the frequency converter after an alarm; however, not all alarms can be reset.

Coasting stop inverse is used for making the frequency converter let go of the motor to make it coast freely to stop. Logic '0' leads to coasting stop and reset.

**Reset and coasting stop inverse**, is used for activating coasting stop at the same time as reset. Logic '0' leads to coasting stop and reset

Quick-stop **inverse** is used for stopping the motor in accordance with the quick-stop ramp (set in parameter 212). Logic '0' leads to a quick-stop.

DC braking **inverse** is used for stopping the motor by energizing it with a DC voltage for a given time, see parameters 125-127.

Please note that this function is only active if the value of parameters 126-127 is different from 0. Logic '0' leads to DC braking.

Stop **inverse** is activated by interrupting the voltage to the terminal. This means that if the terminal has no voltage, the motor cannot run. The stop will be effected in accordance with the selected ramp (parameters 207/208/209/210).



None of the above-mentioned stop commands (start-disable) are to be used as disconnection switch in connection with repairs. Cut mains instead.




**NOTE**

It must be noted that when the frequency converter is at the torque limit and has re-

ceived a stop command, it will only stop if terminal 42, 45, 01 or 04 has been connected to terminal 27. The data choice on terminal 42, 45, 01 or 04 must be *Torque limit and stop* [27].

Start, is selected if a start/stop (operating command, group 2) command is desired. Logic '1' = start, logic '0' = stop.



Latched start - if a pulse is applied for min. 3 ms, the motor will start, provided no stop command (operating command, group 2). The motor stops if Stop inverse is activated briefly.

Reversing is used for changing the direction of rotation of the motor shaft. Logic "0" will not lead to reversing. Logic "1" will lead to reversing. The reversing signal only changes the direction of rotation; it does not activate the start function.

Reversing requires that *Both directions* has been selected in parameter 200.

Is not active if *Process control, closed loop*, *Torque control open loop* or *Torque control, speed feedback* has been selected.

**Start reversing**, is used for start/stop (operating command, group 2) and for reversing with the same signal. No signal is allowed on terminal 18 at the same time. Acts as latch start reversing, provided latch start has been chosen for terminal 18.

Is not active if *Process control, closed loop* has been selected.

Start clockwise only, on is used if the motor shaft is only to be able to rotate clockwise when starting. Should not be used with *Process control, closed loop*.

Start anti-clockwise only, is used if the motor shaft is to rotate anti-clockwise when started.

Should not be used with *Process control, closed loop*.

Jog is used for overriding the output frequency to the jog frequency set in parameter 213. The ramp time can be set in parameter 211. Jog is not active if a stop command has been given (start-disable). Jog overrides stop (operating command, group 2).

Preset reference, **on** is used for shifting between external reference and preset reference. It is assumed that *External/preset* [2] has been selected in parameter 214. Logic '0' = external references active; logic '1' = one of the four preset references is active in accordance with the table below.

**Preset reference, lsb and Preset reference, msb** enables a choice of one of the four preset references, in accordance with the table below.

	Preset ref. msb	Preset ref. lsb
Preset ref. 1	0	0
Preset ref. 2	0	1
Preset ref. 3	1	0
Preset ref. 4	1	1

Freeze reference - freezes the actual reference. The frozen reference is now the point of enable/condition for *Speed up* and *Speed down* to be used.

If speed up/down is used, the speed change always follows ramp 2 (parameters 209/210) in the range 0 - *Ref MAX*.

Freeze output - freezes the actual motor frequency (Hz). The frozen motor frequency is now the point of enable/condition for *Speed up* and *Speed down* to be used.

If speed up/down is used, the speed change always follows ramp 2 (parameters 209/210) in the range 0 - *f<sub>M,N</sub>*.



#### NOTE

If *Freeze output* is active, the frequency converter cannot be stopped via terminals 18 and 19, but only via terminal 27 (to be programmed for *Coasting stop, inverse* [0] or *Reset and coasting stop, inverse* [1]).

After **Freeze output**, the PID integrators are reset.

**Speed up and Speed down** are selected if digital control of the up/down speed is desired (motor potentiometer). This function is only active if *Freeze reference* or *Freeze output* has been selected. As long as there is a logic '1' on the terminal selected for speed up, the reference or the output frequency will increase. Follow ramp 2 (parameter 209) in the range 0 - *f<sub>MIN</sub>*.

As long as there is a logic '1' on the terminal selected for speed down, the reference or the output frequency will be reduced. Follow ramp 2 (parameter 210) in the range 0 - *f<sub>MIN</sub>*.

Pulses (logic '1' minimum high for 3 ms and a minimum pause of 3 ms) will lead to a change of speed of 0.1% (reference) or 0.1 Hz (output frequency).

Example:

	Terminal (16)	(17)	Freeze ref./ Freeze output
No speed change	0	0	1
Speed down	0	1	1
Speed up	1	0	1
Speed down	1	1	1

The speed reference frozen via the control panel can be changed even if the frequency converter has stopped. The frozen reference will be remembered in case of a mains drop-out.

**Selection of Setup, lsb and Selection of Setup, msb** enables a choice of one of the four Setups; however, this presupposes that parameter 004 has been set at *Multi Setup*.

**Selection of Setup, msb/Speed up and Selection of Setup, lsb/Speed down** - together with the use of *Freeze reference* or *Freeze output* - enable up/down speed change.

The selection of Setup occurs in accordance with the below verification table:

	Selection of Setup (32)msb	(33)lsb	Freeze ref/ Freeze output
Setup 1	0	0	0
Setup 2	0	1	0
Setup 3	1	0	0
Setup 4	1	1	0
No speed change	0	0	1
Speed down	0	1	1
Speed up	1	0	1
Speed down	1	1	1

Catch-up/Slow-down is selected if the reference value is to be increased or reduced by a programmable percentage value set in parameter 219.

	Slow-down	Catch-up
Unchanged speed	0	0
Reduced by %-value	1	0
Increased by %-value	0	1
Reduced by %-value	1	1

**Ramp 2** is selected if a change between ramp 1 (parameters 207-208) and ramp 2 (209-210) is desired. Logic '0' leads to ramp 1, while logic '1' leads to ramp 2.

Mains failure **inverted** is to be selected if parameter 407 *Mains failure* and/or parameter 408 *Quick discharge* is to be activated. Mains failure inverted is active in the logical '0' situation.  
See also Mains fault/quick discharge on page 66, if required.

**NOTE**

The frequency converter can be totally damaged by repeating the Quick discharge function on the digital input with mains voltage connected to the SYSTEM.

Pulse reference is selected if a pulse sequence (frequency) of 0 Hz is used, corresponding to Ref<sub>MIN</sub>, parameter 204. The frequency is set in parameter 327, corresponding to Ref<sub>MAX</sub>.

Pulse feedback is selected if a pulse sequence (frequency) is selected as a feedback signal.

**Select Encoder feedback, input A**, if encoder feedback is to be used after choosing Speed control, closed loop or Torque control, speed feedback in parameter 100. Set Pulse/rpm in parameter 329.

**Select Encoder feedback, input B**, if encoder feedback is to be used with a 90° pulse to register the direction of rotation.

Safety interlock has the same function as *Coasting stop, inverse*, but *Safety interlock* generates the alarm message "external fault" on the display when the selected terminal is logic "0". The alarm message will also be active via digital outputs 42/45 and relay outputs 01/04 if programmed for *Safety interlock*. The alarm can be reset using a digital input or the [OFF/STOP] key.

Data change lock is selected if data changes to parameters are not to be made via the control unit; however, it will still be possible to carry out data changes via the bus.

**301 Terminal 17, input  
(DIGITAL INPUT 17)****Value:**

See parameter 300.

**Function:**

This parameter allows a choice between the different options on terminal 17.

The functions are shown in the table at the beginning of the section *Parameters - Inputs and Outputs*. Maximum frequency for terminal 17 is 5 kHz.

**Description of choice:**

See parameter 300.

**302 Terminal 18 Start, input  
(DIGITAL INPUT 18)****Value:**

See parameter 300.

**Function:**

This parameter allows a choice between the different options on terminal 18. The enabled functions are shown in the table at the beginning of the section *Parameters - Inputs and Outputs*.

Maximum frequency for terminal 18 is 5 kHz.

**Description of choice:**

See parameter 300.

**303 Terminal 19, input  
(DIGITAL INPUT 19)****Value:**

See parameter 300.

**Function:**

This parameter allows a choice between the different options on terminal 19. The functions are shown in the table at the beginning of the section *Parameters - Inputs and Outputs*.

Maximum frequency for terminal 19 is 5 kHz.

**Description of choice:**

See parameter 300.

**304 Terminal 27, input  
(DIGITAL INPUT 27)**
**Value:**

See parameter 300.

**Function:**

This parameter allows a choice between the different options on terminal 27.

Functions are shown in the table at the beginning of the section *Parameters - Inputs and Outputs*.

Maximum frequency for terminal 27 is 5 kHz.

**Description of choice:**

See parameter 300.

**305 Terminal 29, input  
(DIGITAL INPUT 29)**
**Value:**

See parameter 300.

**Function:**

This parameter allows a choice between the different options on terminal 29. The functions are shown in the table at the beginning of the section *Parameters - Inputs and Outputs*.

Maximum frequency for terminal 29 is 65 kHz.

**Description of choice:**

See parameter 300.

**306 Terminal 32, input  
(DIGITAL INPUT 32)**
**Value:**

See parameter 300.

**Function:**

This parameter allows a choice between the different options on terminal 32. The functions are shown in the table at the beginning of the section *Parameters - Inputs and Outputs*.

Maximum frequency for terminal 32 is 65 kHz.

**Description of choice:**

See parameter 300.

**307 Terminal 33, input  
(DIGITAL INPUT 33)**
**Value:**

See parameter 300.

**Function:**

This parameter allows a choice between the different options on terminal 33. The functions are shown in the table at the beginning of the section *Parameters - Inputs and Outputs*.

Maximum frequency for terminal 33 is 65 kHz.

**Description of choice:**

See parameter 300.

Analog inputs	terminal no. parameter	53(voltage) 308	54(voltage) 311	60(current) 314
<b>Value:</b>				
No operation	(NO OPERATION)	[0]	[0] ★	[0]
Reference	(REFERENCE)	[1] ★	[1]	[1] ★
Feedback signal	(FEEDBACK)	[2]	[2]	[2]
Torque limit	(TORQUE LIMIT CTRL)	[3]	[2]	[3]
Thermistor	(THERMISTOR INPUT)	[4]	[3]	
Relative reference	(RELATIVE REFERENCE)	[4]	[4]	[4]
Max. torque frequency	(MAX. TORQUE FREQ.)	[5]		

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

MG.51.C5.22 - VLT® is a registered Danfoss trademark.

**308 Terminal 53, analog input voltage  
(AI [V ] 53 FUNCT.)**
**Function:**

This parameter allows a choice of the desired option on terminal 53.

Scaling of the input signal is effected in parameters 309 and 310.

**Description of choice:**

*No operation.* Is selected if the adjustable frequency drive is not to react to signals connected to the terminal.

*Reference.* Is selected to enable change of reference by means of an analog reference signal.

If other inputs are connected, these are added up, taking account of their signs.

*Feedback signal.* Is selected if closed-loop control with an analog signal is used.


*Torque limit.* Is used if the torque limit value set in parameter 221 is to be changed by means of an analog signal.

*Thermistor.* Is selected if a motor-integrated thermistor (according to DIN44080/81) should stop the adjustable frequency drive in case of motor overtemperature. The cut-out value is  $> 3 \text{ k}\Omega$ . The thermistor is connected to terminal 50 and the actual input selected (53 or 54).


**NOTE**

If the temperature of the motor is utilized through a thermistor via the adjustable frequency drive, the following must be noted:

If there are short circuits between the motor winding and the thermistor, PELV is not complied with. In order to comply with PELV, the thermistor must be utilized externally.



If a motor features a thermal switch instead, this can also be connected to the input. If motors run in parallel, the thermistors/thermal switches can be connected in series (total resistance  $< 3 \text{ k}\Omega$ ). Parameter 128 must be programmed for *Thermistor warning* [1] or *Thermistor trip* [2].

*Relative reference* is selected if a relative adjustment of the reference sum is required.

This function is only active if *Relative* has been selected (parameter 214). The relative reference on terminal 54/60 is a percentage of the full range of the terminal in question. This will be added to the sum of the other references. If several relative references have been selected (preset reference 215-218, 311 and 314), these will be added first, following which this sum will be added to the sum of the active references.


**NOTE**

If *Reference* or *Feedback signal* has been selected on more than one terminal, these signals will be added with signs.

*Max. torque frequency.* This is only used in *Torque control, open-loop* (parameter 100) for limiting the output frequency. Selected if the max. output frequency is to be controlled by an analog input signal. The frequency range goes from *Output frequency low limit* (parameter 201) to *Output frequency high limit* (parameter 202).

**309 Terminal 53, min. scaling  
(AI 53 SCALE LOW)**
**Value:**

0.0 - 10.0 Volt

★ 0.0 Volt

**Function:**

This parameter is used for setting the signal value that corresponds to the maximum reference value set in parameter 204.

**Description of choice:**

Set the desired voltage value.

See also section *Handling of single references*.

**310 Terminal 53, max. scaling****(AI 53 SCALE HIGH)****Value:**

0.0 - 10.0 Volt      ★ 10.0 Volt

**Function:**

This parameter is used for setting the signal value that corresponds to the maximum reference value set in parameter 205.

**Description of choice:**

Set the desired voltage value.

See also section *Handling of single references*.

**311 Terminal 54, analog input voltage****(AI [V] 54 FUNCT.)****Value:**

See description of parameter 308

**Function:**

This parameter chooses between the different functions available for the input, terminal 54.

Scaling of the input signal is effected in parameters 312 and 313.

**Description of choice:**

See description of parameter 308.

**312 Terminal 54, min. scaling****(AI 54 SCALE LOW)****Value:**

0.0 - 10.0 Volt      ★ 0.0 Volt

**Function:**

This parameter is used for setting the scaling value that corresponds to the minimum reference value set in parameter 204.

**Description of choice:**

Set the desired voltage value.

See also section *Handling of single references*.

**313 Terminal 54, max. scaling****(AI 54 SCALE HIGH)****Value:**

0.0 - 10.0 Volt      ★ 10.0 Volt

**Function:**

This parameter is used for setting the signal value that corresponds to the maximum reference value set in parameter 205.

**Description of choice:**

Set the desired voltage value.

See also section *Handling of single references*.

**314 Terminal 60, analog input current****(AI [mA] 60 FUNCT)****Value:**

See description of parameter 308

**Function:**

This parameter allows a choice between the different functions available for the input, terminal 60.

Scaling of the input signal is effected in parameters 315 and 316.

**Description of choice:**

See description of parameter 308.

**315 Terminal 60, min. scaling****(AI 60 SCALE LOW)****Value:**

0.0 - 20.0 mA      ★ 4 mA

**Function:**

This parameter determines the value of the reference signal that is to correspond to the minimum reference value set in parameter 204.

If the timeout function of parameter 317 is used, the value must be set at >2 mA.

**Description of choice:**

Set the desired current value.

See also section *Handling of single references*.

**316 Terminal 60, max. scaling****(AI 60 SCALE HIGH)****Value:**

0.0 - 20.0 mA      ★ 20.0 mA

**Function:**

This parameter sets the value of the reference signal that is to correspond to the maximum reference value set in parameter 205.

**Description of choice:**

Set the desired current value.

See also section *Handling of single references*.

**317 Time out****(LIVE ZERO TIME O)****Value:**

0 - 99 sec.      ★ 10 sec.

**Function:**

If the signal value of the reference signal connected to the input, terminal 60, falls below 50% of the value set in parameter 315 for a period longer than the time set in parameter 317, the function selected in parameter 318 will be activated.

**Description of choice:**

Set the desired time.

**318 Function after time out  
(LIVE ZERO FUNCT.)****Value:**

★ Off (OFF)	[0]
Freeze output frequency (FREEZE OUTPUT FREQ.)	[1]
Stop (STOP)	[2]
Jog (JOGGING)	[3]
Max. speed (MAX SPEED)	[4]
Stop and trip (STOP AND TRIP)	[5]

**Function:**

This parameter allows a choice of the function to be activated if the input signal on terminal 60 drops below 2 mA, provided parameter 315 has been set higher than 2 mA and that the preset time for time-out (parameter 317) has been exceeded.

If more time-outs occur at the same time the adjustable frequency drive will give the following priority to the time-out function:

1. Parameter 318 *Function after time out*
2. Parameter 346 *Function after encoder loss*
3. Parameter 514 *Bus time interval function*

**Description of choice:**

The output frequency of the adjustable frequency drive can be:

- frozen at the present value
- overruled to stop
- overruled to jog frequency
- overruled to max. frequency
- overruled to stop with subsequent trip.



## VLT® 5000 Series

Outputs	terminal no.	42	45	01(re-lay)	04 (re-lay)
	parameter	319	321	323	326
Value:					
No function	(NO OPERATION)	[0]	[0]	[0]	[0]
Control ready	(CONTROL READY)	[1]	[1]	[1]	[1]
Ready signal	(UNIT READY)	[2]	[2]	[2]	[2]
Ready - remote control	(UNIT READY/REM CTRL)	[3]	[3]	[3]	[3]
Enable, no warning	(ENABLE/NO WARNING)	[4]	[4]	[4]	[4]
Running	(VLT RUNNING)	[5]	[5]	[5]	[5]
Running, no warning	(RUNNING/NO WARNING)	[6]	[6]	[6]	[6]
Running within range, no warning	(RUN IN RANGE/NO WARN)	[7]	[7]	[7]	[7]
Running at reference value, no warning	(RUN ON REF/NO WARN)	[8]	[8]	[8]	[8]
Fault	(ALARM)	[9]	[9]	[9]	[9]
Fault or warning	(ALARM OR WARNING)	[10]	[10]	[10]	[10]
Torque limit	(TORQUE LIMIT)	[11]	[11]	[11]	[11]
Out of current range	(OUT OF CURRENT RANGE)	[12]	[12]	[12]	[12]
Over I low	(ABOVE CURRENT,LOW)	[13]	[13]	[13]	[13]
Under I high	(BELOW CURRENT,HIGH)	[14]	[14]	[14]	[14]
Out of frequency range	(OUT OF FREQ RANGE)	[15]	[15]	[15]	[15]
Over f low	(ABOVE FREQUENCY LOW)	[16]	[16]	[16]	[16]
Under f high	(BELOW FREQUENCY HIGH)	[17]	[17]	[17]	[17]
Out of feedback range	(OUT OF FDBK RANGE)	[18]	[18]	[18]	[18]
Over feedback low	(ABOVE FDBK, LOW)	[19]	[19]	[19]	[19]
Under feedback high	(BELOW FDBK, HIGH)	[20]	[20]	[20]	[20]
Thermal warning	(THERMAL WARNING)	[21]	[21]	[21]	[21]
Ready - no thermal warning	(READY & NOTHERM WARN)	[22]	[22]	[22]	[22]
Ready - remote control - no therm. warn.	(REM RDY & NO THERMWAR)	[23]	[23]	[23]	[23]
Ready - mains voltage within range	(RDY NO OVER/UNDERVOL)	[24]	[24]	[24]	[24]
Reversing	(REVERSE)	[25]	[25]	[25]	[25]
Bus ok	(BUS OK)	[26]	[26]	[26]	[26]
Torque limit and stop	(TORQUE LIMIT AND STOP)	[27]	[27]	[27]	[27]
Brake, no brake warning	(BRAKE NO BRAKE WARNING)	[28]	[28]	[28]	[28]
Brake ready, no fault	(BRAKE RDY (NO FAULT))	[29]	[29]	[29]	[29]
Brake fault	(BRAKE FAULT (IGBT))	[30]	[30]	[30]	[30]
Relay 123	(RELAY 123)	[31]	[31]	[31]	[31]
Mechanical brake control	(MECH. BRAKE CONTROL)	[32]	[32]	[32]	[32]
Control word bit 11/12	(CTRL WORD BIT 11/12)			[33]	[33]
Extended mechanical brake control	(EXT. MECH. BRAKE)	[34]	[34]	[34]	[34]
Safety interlock	(SAFETY INTERLOCK)	[35]	[35]	[35]	[35]

\* = factory setting, () = display text, [] = value for use in communication via serial communication port

MG.51.C5.22 - VLT® is a registered Danfoss trademark.

## VLT® 5000 Series

Outputs	terminal no.	42	45	01(relay)	04 (relay)
	parameter	319	321	323	326
<b>Value:</b>					
0-100 Hz ⇒ 0-20 mA	(0-100 Hz = 0-20 mA)	[36]	[36]		
0-100 Hz ⇒ 4-20 mA	(0-100 Hz = 4-20 mA)	[37]	[37]		
0-100 Hz ⇒ 0-32000 p	(0-100 Hz = 0-32000P)	[38]	[38]		
0 - f <sub>MAX</sub> ⇒ 0-20 mA	(0-FMAX = 0-20 mA)	[39]	[39]		
0 - f <sub>MAX</sub> ⇒ 4-20 mA	(0-FMAX = 4-20 mA)	[40]	[40]		
0 - f <sub>MAX</sub> ⇒ 0-32000 p	(0-FMAX = 0-32000P)	[41]	[41]		
RefMIN - RefMAX ⇒ 0-20 mA	(REF MIN-MAX = 0-20 mA)	[42]	[42]		
RefMIN - RefMAX ⇒ 4-20 mA	(REF MIN-MAX = 4-20 mA)	[43]	[43]		
RefMIN - RefMAX ⇒ 0-32000 p	(REF MIN-MAX = 0-32000P)	[44]	[44]		
FBMIN - FBMAX ⇒ 0-20 mA	(FB MIN-MAX = 0-20 mA)	[45]	[45]		
FBMIN - FBMAX ⇒ 4-20 mA	(FB MIN-MAX = 4-20 mA)	[46]	[46]		
FBMIN - FBMAX ⇒ 0-32000 p	(FB MIN-MAX = 0-32000P)	[47]	[47]		
0 - I <sub>MAX</sub> ⇒ 0-20 mA	(0-IMAX = 0-20 mA)	[48]	[48]		
0 - I <sub>MAX</sub> ⇒ 4-20 mA	(0-IMAX = 4-20 mA)	[49]	[49]		
0 - I <sub>MAX</sub> ⇒ 0-32000 p	(0-IMAX = 0-32000P)	[50]	[50]		
0 - T <sub>LIM</sub> ⇒ 0-20 mA	(0-TLIM = 0-20 mA)	[51]	[51]		
0 - T <sub>LIM</sub> ⇒ 4-20 mA	(0-TLIM = 4-20 mA)	[52]	[52]		
0 - T <sub>LIM</sub> ⇒ 0-32000 p	(0-TLIM = 0-32000P)	[53]	[53]		
0 - T <sub>NOM</sub> ⇒ 0-20 mA	(0-TNOM = 0-20 mA)	[54]	[54]		
0 - T <sub>NOM</sub> ⇒ 4-20 mA	(0-TNOM = 4-20 mA)	[55]	[55]		
0 - T <sub>NOM</sub> ⇒ 0-32000 p	(0-TNOM = 0-32000P)	[56]	[56]		
0 - P <sub>NOM</sub> ⇒ 0-20 mA	(0-PNOM = 0-20 mA)	[57]	[57]		
0 - P <sub>NOM</sub> ⇒ 4-20 mA	(0-PNOM = 4-20 mA)	[58]	[58]		
0 - P <sub>NOM</sub> ⇒ 0-32000 p	(0-PNOM = 0-32000P)	[59]	[59]		
0 - SyncRPM ⇒ 0-20 mA	(0-SYNCRPM = 0-20 mA)	[60]	[60]		
0 - SyncRPM ⇒ 4-20 mA	(0-SYNCRPM = 4-20 mA)	[61]	[61]		
0 - SyncRPM ⇒ 0-32000 p	(0-0-SYNCRPM = 0-32000 p)	[62]	[62]		
0 - RPM at FMAX ⇒ 0-20 mA	(0-RPMFMAX = 0-20 mA)	[63]	[63]		
0 - RPM at FMAX ⇒ 4-20 mA	(0-RPMFMAX = 4-20 mA)	[64]	[64]		
0 - RPM at FMAX ⇒ 0-32000 p	(0-RPMFMAX = 0-32000 p)	[65]	[65]		

<b>319      Terminal 42, output</b>	
<b>(AO 42 FUNCT.)</b>	

**Function:**

This output can act both as a digital and an analogue output. If used as a digital output (data value [0]-[65]), a 24 V DC signal is transmitted; if used as an analogue output either a 0-20 mA signal, a 4-20 mA signal or a pulse output is transmitted.

**Description of choice:**

*Control ready*, the frequency converter is ready for use; the control card receives supply voltage.

*Ready signal*, the frequency converter control card is receiving a supply signal and the frequency converter is ready for operation.

*Ready, remote control*, the frequency converter control card is receiving a supply signal and parameter 002 has been set to *remote control*.

*Enable, no warning*, the frequency converter is ready for use; no start or stop command has been given (start/disable). No warning.

*Running* is active when there is a start command or the output frequency is above 0.1 Hz. Is also active during ramp down.

*Running, no warning*, the output frequency is higher than the frequency set in parameter 123. A start command has been given. No warning.

*Runs in range, no warning*, runs within the programmed current/frequency ranges set in parameters 223-226.

*Runs on reference, no warning, speed according to reference. No warning.*

*Fault, output is activated by alarm.*

*Fault or warning, the output is activated by alarm or warning.*

*Torque limit, the torque limit in parameter 221 has been exceeded.*

*Out of current range, the motor current is outside the range programmed in parameters 223 and 224.*

*Over I low, the motor current is higher than set in parameter 223.*

*Under I high, the motor current is lower than set in parameter 224.*

*Out of frequency range, the output frequency is outside the frequency range programmed in parameters 225 and 226.*

*Over f low, the output frequency is higher than the value set in parameter 225.*

*Under f high, the output frequency is lower than the value set in parameter 226.*

*Out of feedback range, the feedback signal is outside the range programmed in parameters 227 and 228.*

*Over feedback low, the feedback signal is higher than the value set in parameter 227.*

*Under feedback high, the feedback signal is lower than the value set in parameter 228.*

*Thermal warning, above the temperature limit in either the motor, the frequency converter, the brake resistor or the thermistor.*

*Ready - no thermal warning, the frequency converter is ready for use, the control card receives supply voltage and there are no control signals on the inputs. No over-temperature.*

*Ready - remote control - no thermal warning , the frequency converter is ready for use and set at remote control, the control card receives supply voltage. No over-temperature.*

*Ready - mains voltage within range, the frequency converter is ready for use, the control card receives supply voltage and there are no control signals on the inputs. The mains voltage is within the permitted voltage range (see chapter 8).*

*Reversing. Logic '1' = relay activated, 24 V DC on the output when the direction of rotation of the motor is clockwise. Logic '0' = relay not activated, no signal on the output, when the direction of rotation of the motor is anti-clockwise.*

*Bus-ok, active communication (no time-out) via the serial communication port.*

*Torque limit and stop is used in connection with coasting stop (terminal 27), where it is possible to give a stop even if the frequency converter is at the torque limit. The signal is inverted, i.e. a logic '0' when the frequency converter has received a stop signal and is at the torque limit.*

*Brake, no brake warning, the brake is active and there are no warnings.*

*Brake ready, no fault, the brake is ready for operation and there are no faults.*

*Brake fault, the output is a logical "1" when the brake IGBT has short-circuited. This function is used to protect the frequency converter if there is a fault on the brake modules. To avoid a potential fire in the brake resistor, the output/relay can be used to cut out the supply voltage from the frequency converter.*

*Relay 123, if Fieldbus profile [0] has been selected in parameter 512, the relay is activated. If either OFF1, OFF2 or OFF3 (bit in the control word) is logic '1'.*

*Mechanical brake control, enables control of an external mechanical brake, see also section Mechanical brake control.*

*Control word bits 11/12, relay controlled via bits 11/12 in serial control word. Bit 11 relates to relay 01 and bit 12 to relay 04. If parameter 514 Bus time interval function is active, relays 01 and 04 will be voltage-free. See section on Serial communication in the Design Guide.*

*Extended mechanical brake control, enables control of an external mechanical brake, see also section Mechanical brake control.*

*Safety interlock The output is active when Safety interlock has been selected on an input and the input is a logic "1".*

*0-100 Hz  $\Rightarrow$  0-20 mA and*

*0-100 Hz  $\Rightarrow$  4-20 mA and*

*0-100 Hz  $\Rightarrow$  0-32000 p, a pulse output signal proportional to the output frequency in the range 0-100 Hz.*

0- $f_{MAX}$  ⇒ 0-20 mA and

0- $f_{MAX}$  ⇒ 4-20 mA and

0- $f_{MAX}$  ⇒ 0-32000 p, an output signal proportional to the output frequency range in the range 0 -  $f_{MAX}$  (parameter 202).

$Ref_{MIN}$  -  $Ref_{MAX}$  ⇒ 0-20 mA and

$Ref_{MIN}$  -  $Ref_{MAX}$  ⇒ 4-20 mA and

$Ref_{MIN}$  -  $Ref_{MAX}$  ⇒ 0-32000 p, an output signal proportional to the reference value in the interval  $Ref_{MIN}$  -  $Ref_{MAX}$  (parameters 204/205) is obtained.

$B_{MIN}$  -  $B_{MAX}$  ⇒ 0-20 mA and

$B_{MIN}$  -  $B_{MAX}$  ⇒ 4-20 mA and

$B_{MIN}$  -  $B_{MAX}$  ⇒ 0-32000 p, an output signal proportional to the feedback value in the interval  $B_{MIN}$  -  $B_{MAX}$  (parameters 414/415) is obtained.

0 -  $I_{VLT, MAX}$  ⇒ 0-20 mA or

0 -  $I_{VLT, MAX}$  ⇒ 4-20 mA and

0 -  $I_{VLT, MAX}$  ⇒ 0-32000 p, an output signal proportional to the output current in the interval 0 -  $I_{VLT, MAX}$  is obtained.  $I_{VLT, MAX}$  depends on the settings in parameter 101 and 103 and can be seen from the *Technical data* ( $I_{VLT, MAX}$  (60 s)).

0 -  $M_{LIM}$  ⇒ 0-20 mA and

0 -  $M_{LIM}$  ⇒ 4-20 mA and

0 -  $M_{LIM}$  ⇒ 0-32000 p, an output proportional to the output torque in the interval 0 -  $T_{LIM}$  (parameter 221) is obtained. 20 mA corresponds to the value set in parameter 221.

0 -  $M_{NOM}$  ⇒ 0-20 mA and

0 -  $M_{NOM}$  ⇒ 4-20 mA and

0 -  $M_{NOM}$  ⇒ 0-32000 p, an output signal proportional to the output torque of the motor. 20 mA corresponds to the rated torque for the motor.

0 -  $P_{NOM}$  ⇒ 0-20 mA and

0 -  $P_{NOM}$  ⇒ 4-20 mA and

0 -  $P_{NOM}$  ⇒ 0-32000 p, 0 -  $P_{NOM}$  ⇒ 0-32000 p, an output signal proportional to the rated motor output is obtained. 20 mA corresponds to the value set in parameter 102.

0 -  $SyncRPM$  ⇒ 0-20 mA and

0 -  $SyncRPM$  ⇒ 4-20 mA and

0 -  $SyncRPM$  ⇒ 0-32000 p, an output signal proportional to the synchronous motor RPM is obtained.

0 -  $RPM$  at  $F_{MAX}$  ⇒ 0-20 mA and

0 -  $RPM$  at  $F_{MAX}$  ⇒ 4-20 mA and

0 -  $RPM$  at  $F_{MAX}$  ⇒ 0-32000 p, n output signal proportional to the synchronous motor RPM at  $F_{MAX}$  (parameter 202) is obtained.

### 320 Terminal 42, output, pulse scaling (AO 42 PULS SCALE)

#### Value:

1 - 32000 Hz


★ 5000 Hz

#### Function:

This parameter allows scaling of the pulse output signal.

#### Description of choice:

Set the desired value.



### 321 Terminal 45, output (AO 45 FUNCT.)

#### Value:

See description for parameter 319.

#### Function:

This output can function both as a digital and an analog output. Used as a digital output (data value [0]-[35]) it generates a 24 V (max. 40 mA) signal; on the analog outputs (data value [36]-[59]) there is a choice of 0-20 mA, 4-20 mA or a scalable pulse output.

#### Description of choice:

See description for parameter 319.

**322 Terminal 45, output, pulse scaling  
(AO 45 PULS SCALE)**
**Value:**

1 - 32000 Hz      ★ 5000 Hz

**Function:**

This parameter allows scaling of the pulse output signal.

**Description of choice:**

Set the desired value.

**Description of choice:**

Enter the desired value (can be set at intervals of 0.02 sec.).

**323 Relay 01, output  
(RELAY 1-3 FUNCT.)**
**Value:**

See description of parameter 319.


**Function:**

This output activates a relay switch.  
Relay switch 01 can be used for bringing status and warnings. The relay is activated when the conditions for the relevant data values have been fulfilled.  
Activation/deactivation can be delayed in parameter 324/325.

**Description of choice:**

See description of parameter 319.

Connections - see the below drawing.


**324 Relay 01, ON delay  
(RELAY 1-3 ON DL)**
**Value:**

0.00 - 600.00.      ★ 0.00 sec.

**Function:**

This parameter allows a delay of the cut-in time of relay 01 (terminals 01-02).

**325 Relay 01, OFF delay  
(RELAY 1-3 OFF DL)**
**Value:**

0.00 - 600.00      ★ 0.00 sec.

**Function:**

This parameter makes it possible to delay the cut-out time of relay 01 (terminals 01-03).

**Description of choice:**

Enter the desired value (can be set at intervals of 0.02 sec.).

**326 Relay 04, output  
(RELAY 4-5 FUNCT.)**
**Value:**

See description of parameter 319.


**Function:**

This output activates a relay switch.  
Relay switch 04 can be used for bringing status and warnings. The relay is activated when the conditions for the relevant data values have been fulfilled.

**Description of choice:**

See description of parameter 319.

Connections - see the below drawing.


**327 Pulse reference, max. frequency  
(PULSE REF MAX)**
**Value:**

100 - 65000 Hz at terminal 29  
100 - 5000 Hz at terminal 17      ★ 5000 Hz

**Function:**

In this parameter, the signal value is set that corresponds to the maximum reference value set in parameter 205. Setting of this parameter affects an internal filter constant, i.e. at 100 Hz = 5 sec; 1 kHz = 0.5 sec. and at 10 kHz = 50 msec. To avoid a too long filter time constant at low pulse resolution, the reference (parameter 205) and this parameter can be multiplied by the same factor and in this way use the lower reference range.

**Description of choice:**

Set the desired pulse reference.

**328 Pulse feedback, max. frequency**
**(PULSE FEEDB MAX)**
**Value:**

100 - 65000 Hz at terminal 33      25000 Hz

**Function:**

This is where to set the feedback value that is to correspond to the maximum feed back value.

**Description of choice:**

Set the desired feedback value.

**329 Encoder feedback pulse/rev.**
**(ENCODER PULSES)**
**Value:**

128 pulses /rev. (128)	[128]
256 pulses /rev. (256)	[256]
512 pulses /rev. (512)	[512]
1024 pulses /rev. (1024)	[1024]
2048 pulses /rev. (2048)	[2048]
4096 pulses /rev. (4096)	[4096]

This value can also be set between 1-4096 pulses/rev.


**Function:**

This is where to set the encoder pulses per revolution that correspond to the motor rpm.

This parameter is only available in *Speed control, closed loop* and in *Torque control, speed feedback* (parameter 100).

**Description of choice:**

Read the correct value from the encoder. Pay attention to the speed limitation (rpm) for a given number of pulses/rpm, see the drawing below:



The encoder used is to be of the Open Collector PNP 0/24 V DC type (max. 20 kHz) or a Push-Pull circuit 0/24 V DC (max. 65 kHz).

**330 Freeze reference/output function**
**(FREEZE REF/OUTP.)**
**Value:**

No operation (NO OPERATION)	[0]
Freeze reference (FREEZE REFERENCE)	[1]
Freeze output (FREEZE OUTPUT)	[2]

**Function:**

In this parameter it is possible to freeze either the reference or the output.

**Description of choice:**

*Freeze reference* [1] freezes the actual reference. The frozen reference is now the basis for *Speed up* and *Speed down*.

*Freeze output* [2] freezes the actual motor frequency (Hz). The frozen frequency is now the basis for *Speed up* and *Speed down*.


**NOTE**

If *Freeze output* is active, the adjustable frequency drive cannot be stopped via terminals 18 and 19, but only via terminal 27 (to be programmed for *Coasting stop, in-*

verse [0] or Reset and coasting stop, in-  
verse [1].

After *Freeze output*, the PID integrators are reset.

#### **345 Encoder loss timeout**

##### (ENC LOSS TIMEOUT)

###### **Value:**

0 - 60 sec. ★ 1 sec.

###### **Function:**

If the encoder signal is interrupted from terminal 32 or 33 the function selected in parameter 346 will be activated.

If the encoder feedback signal is different from the output frequency +/- 3 x nominal motor slip the encoder loss function will be activated.

An encoder loss timeout can occur even if the encoder works all right. Check the motor parameter in group 100 if no error can be found on the encoder.

The Encoder loss function is only active in *Speed control, closed loop* [1] and *Torque control, speed feed-back* [5], see parameter 100 *Configuration*.

###### **Description of choice:**

Set the required time.

#### **346 Encoder loss function**

##### (ENC. LOSS FUNC)

###### **Value:**

★ Off (OFF)	[0]
Freeze output frequency (FREEZE OUTPUT FREQ.)	[1]
Jog (JOGGING)	[3]
Max. speed (MAX SPEED)	[4]
Stop and trip (STOP AND TRIP)	[5]
Select Setup 4 (SELECT SETUP 4)	[7]

###### **Function:**

In this parameter the function can be activated if the encoder signal is disconnected from terminal 32 or 33.

If more time-outs occur at the same time the adjustable frequency drive will give the following priority to the time-out function:

1. Parameter 318 *Function after time out*
2. Parameter 346 *Function after encoder loss*
3. Parameter 514 *Bus time interval function*.

###### **Description of choice:**

The output frequency of the adjustable frequency drive can be:

- frozen at the present value
- overruled to jog frequency
- overruled to max. frequency
- overruled to stop with subsequent trip
- overruled to Setup 4.

#### **357 Terminal 42, Output minimum scaling**

##### (out 42 scal min)

#### **359 Terminal 45, Output minimum scaling**

##### (out 45 scal min)

###### **Value:**

000 - 100% ★ 0%



###### **Function:**

These parameters are to scale the minimum output of the selected analog/pulse signal on terminals 42 and 45.

###### **Description of choice:**

The minimum value is to be scaled as a percentage of the maximum signal value, i.e. 0mA (or 0 Hz) is desired at 25% of the maximum output value, and then 25% is programmed.

The value can never be higher than the corresponding setting of *Output maximum scaling* if this value is below 100%.


**358 Terminal 42, Output maximum scaling**

(out 42 scal max)

**360 Terminal 45, Output maximum scaling**

(out 45 scal max)

**Value:**

000 - 500% ★ 100%

**Function:**

These parameters are to scale the maximum output of the selected analogue/pulse signal on terminals 42 and 45.

**Description of choice:**

Set the value to the desired maximum value of the current signal output.

**Maximum value:**

The output can be scaled to give a lower current than 20 mA at full scale or 20 mA at an output below 100% of the maximum signal value.

If 20 mA is the desired output current at a value between 0 - 100% of the full-scale output, program the percentage value in the parameter, i.e. 50% = 20 mA. If a current between 4 and 20 mA is desired at maximum output (100%), the percentage value to program in the drive is calculated as:

$$\frac{20 \text{ mA}}{\text{desired maximum current}} \times 100\%,$$

i.e.  $10 \text{ mA} \approx \frac{20}{10} \times 100\% \approx 200\%$

A similar scaling is possible on the pulse output. The value (pulse scale value) in parameter 320 (output 42) and 321 (output 45) is the basis of the scaling. If the pulse scale value is the desired output at a value between 0 - 100% of the full scale output, program the percentage, i.e. 50% for pulse scale value at 50% output.

If a pulse frequency between 0,2 x pulse scale value and pulse scale value, the percentage is calculated as follows:

$$\frac{\text{Pulse scale value (par. 320 or 321)}}{\text{Desired pulse frequency}} \times 100\%$$

i.e.

$$2000 \text{ Hz} \approx \frac{5000 \text{ Hz}}{2000 \text{ Hz}} \times 100\% \approx 250\%$$

**361 Encoder loss threshold**

(ENCODER MAX ERR.)

**Value:**

0 - 600% ★ 300%

**Function:**

This parameter adjusts the threshold level for detection of encoder loss in speed closed loop mode. The value equals a percentage of the nominal slip of the motor.

**Description of choice:**

Set the desired threshold level.

### ■ Special functions

400 Brake function/overvoltage control (BRAKE FUNCTION)	
<b>Value:</b>	
★ Off (OFF)	[0]
Resistor brake (RESISTOR)	[1]
Overvoltage control (OVERVOLTAGE CONTROL)	[2]
Overvoltage control and stop (OVERVOLT CTRL. & STOP)	[3]

#### Function:

The factory setting is *Off* [0] for VLT 5001-5027 200-240 V, VLT 5001-5102 380-500 V and VLT 5001-5062 525-600 V. For VLT 5032-5052 200-240 V, 5122-5552 380-500 V and VLT 5042-5602 525-690 V the factory setting is *Overvoltage control* [2].

*Resistor brake* [1] is used for programming the adjustable frequency drive for connection of a brake resistor. The connection of a brake resistor allows a higher intermediate circuit voltage during braking (generating operation).

The *Resistor brake* [1] function is only active in units with an integral dynamic brake (SB and EB units).

*Overvoltage control* (excl. brake resistor) can be selected as an alternative. This function is active for all units (ST, SB and EB).

The function ensures that a trip can be avoided if the intermediate circuit voltage increases. This is done by increasing the output frequency to limit the voltage from the intermediate circuit. This is a very useful function, e.g. if the ramp-down time is too short, since tripping of the adjustable frequency drive is avoided. In this situation, the ramp-down time is extended.



#### NOTE

Please note that the ramp-down time is extended in the case of overvoltage control, which in some applications may not be appropriate.

#### Description of choice:

Select *Resistor brake* [1] if a brake resistor is part of the system.

Select *Overvoltage control* [2] if the overvoltage control function is required in all cases - also if stop is pressed.

The adjustable frequency drive will not stop in the case of a stop command when the overvoltage control is active.

Select *Overvoltage control and stop* [3] if the overvoltage control function is not required during ramp-down after stop has been pressed.



Warning: If Overvoltage control [2] is used at the same time as the supply voltage to the adjustable frequency drive is close to or above the maximum limit, there is a risk that the motor frequency will increase and that, consequently, the adjustable frequency drive will not stop the motor when stop is pressed. If the supply voltage is higher than:

- 264 V for 200-240 V units
- 550 V for 380-500 V units
- 660 V for 525-600 V units
- 759 V for 525-690 V units

Overvoltage control and stop [3] should be selected so that the motor can be stopped.

401 Brake resistor, ohm (BRAKE RES. (OHM))	
<b>Value:</b>	

Depends on the unit

★ Depends on the unit

#### Function:

This parameter gives the ohmic value of the brake resistor. This value is used for monitoring the power to the brake resistor provided this function has been selected in parameter 403.

#### Description of choice:

Set the present resistor value.

402 Braking energy limit, kW (BR.POWER. LIM.KW)	
<b>Value:</b>	

Depends on the unit

★ Depends on the unit

**Function:**

This parameter gives the monitoring limit of the power transmitted to the brake resistor.

**Description of choice:**

The monitoring limit is determined as a product of the maximum duty cycle (120 sec.) that will occur and the maximum power of the brake resistor at that duty cycle according to the following formula.

$$\text{For 200-240 V units: } P = \frac{397^2}{R} \times \frac{t}{120}$$

$$\text{For 380 - 500 V units: } P = \frac{822^2}{R} \times \frac{t}{120}$$

$$\text{For 525 - 600 V units: } P = \frac{958^2}{R} \times \frac{t}{120}$$

$$\text{For 525 - 690 V units: } P = \frac{1084^2}{R} \times \frac{t}{120}$$

ing depends on the accuracy of the resistor ohmic value (better than  $\pm 20\%$ ).


**NOTE**

The power dissipation during quick discharge does not form part of the power monitoring function.

**Description of choice:**

Select whether this function is to be active (*Warning/Alarm*) or inactive (*Off*).

**404 Brake check**
**(BRAKE TEST)**
**Value:**

★ Off (OFF)	[0]
Warning (WARNING)	[1]
Trip (TRIP)	[2]

**403 Power monitoring**
**(POWER MONITORING)**
**Value:**

Off (OFF)	[0]
★ Warning (Warning)	[1]
Trip (Trip)	[2]

**Function:**

This parameter allows monitoring of the power transmitted to the brake resistor. The power is calculated on the basis of the resistor ohm value (parameter 401), the intermediate circuit voltage and the resistor running time. If the power transmitted over 120 sec. exceeds 100% of the monitoring limit (parameter 402) and *Warning* [1] has been selected, a warning will come up on the display. The warning will disappear if the power goes below 80%. If the calculated power exceeds 100% of the monitoring limit and *Trip* [2] has been selected in parameter 403 *Power monitoring*, the adjustable frequency drive will cut out while giving an alarm. If power monitoring has been selected as *Off* [0] or *Warning* [1], the brake function will remain active, even if the monitoring limit has been exceeded. This may lead to thermal overload of the resistor. It is also possible to have a warning via the relay/digital outputs. The typical measuring accuracy of the power monitor-

**Function:**

In this parameter a testing and monitoring function can be integrated which will give a warning or an alarm. On power-up it will be tested whether the brake resistor is disconnected. The test of whether the brake resistor is disconnected is carried out during braking, while the test of whether the IGBT is disconnected is carried out when there is no braking. A warning or trip disconnects the brake function.

The testing sequence is as follows:

1. If the intermediate circuit voltage is higher than the brake starting voltage, discontinue the brake check.
2. If the intermediate circuit voltage is unstable, discontinue the brake check.
3. Carry out a brake test.
4. If the intermediate circuit voltage is lower than the starting voltage, discontinue the brake check.
5. If the intermediate circuit voltage is unstable, discontinue the brake check.
6. If the braking power is higher than 100%, discontinue the brake check.

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

7. If the intermediate circuit voltage is higher than the intermediate circuit voltage -2% before the brake test, discontinue the brake check and give off a warning or alarm.
8. Brake check OK.

**Description of choice:**

If *Off* [0] is selected, this function will still monitor whether the brake resistor and the brake IGBT short-circuit during operation, in which case it will give off a warning. If *Warning* [1] is selected, the brake resistor and brake IGBT will be monitored with respect to short-circuiting. In addition, on power-up it will be checked whether the brake resistor has been disconnected.


**NOTE**

A warning in connection with *Off* [0] or *Warning* [1] can only be removed by disconnecting the mains supply and turning it back on, provided the fault has been corrected. Please note that in connection with *Off* [0] or *Warning* [1] the adjustable frequency drive will continue even if a fault has been found.

In the case of *Trip* [2], the adjustable frequency drive will cut out while giving an alarm (trip locked) if the brake resistor has short-circuited or been disconnected or if the brake IGBT has short-circuited.

**405 Reset function (RESET MODE)**
**Value:**

★ Manual reset (MANUAL RESET)	[0]
Automatic reset x 1 (AUTOMATIC X 1)	[1]
Automatic reset x 2 (AUTOMATIC X 2)	[2]
Automatic reset x 3 (AUTOMATIC X 3)	[3]
Automatic reset x 4 (AUTOMATIC X 4)	[4]
Automatic reset x 5 (AUTOMATIC X 5)	[5]
Automatic reset x 6 (AUTOMATIC X 6)	[6]
Automatic reset x 7 (AUTOMATIC X 7)	[7]
Automatic reset x 8 (AUTOMATIC X 8)	[8]
Automatic reset x 9 (AUTOMATIC X 9)	[9]
Automatic reset x 10 (AUTOMATIC X 10)	[10]

**Function:**

This parameter makes it possible to select the reset function desired after tripping.

After reset, the adjustable frequency drive can be restarted.

**Description of choice:**

If *Manual reset* [0] is selected, reset must be effected via the [RESET] key or via the digital inputs.

If the adjustable frequency drive is to carry out an automatic reset (1-10 times) after tripping, select data value [1]-[10].


**NOTE**

The internal AUTOMATIC RESET counter is reset 10 minutes after the first AUTOMATIC RESET has occurred.



Warning: The motor may start without warning.

**406 Automatic restart time**
**(AUT RESTART TIME)**
**Value:**

0 - 10 sec.      ★ 5 sec.

**Function:**

This parameter allows setting of the time from tripping until the automatic reset function begins.

It is assumed that automatic reset has been selected in parameter 405.

**Description of choice:**

Set the desired time.

**407 Mains failure**
**(MAINS FAILURE)**
**Value:**

★ No function (NO FUNCTION)	[0]
Controlled ramp-down (CONTROL RAMP DOWN)	[1]
Controlled ramp-down and trip (CTRL. RAMP DOWN-TRIP)	[2]

Coasting (COASTING)	[3]
Kinetic back-up (KINETIC BACKUP)	[4]
Controlled alarm suppression (ctrl alarm supp)	[5]

**Function:**

Using the mains failure function, it is possible to ramp down the load to 0 Hz if the mains supply to the adjustable frequency drive fails.

In parameter 450 *Mains voltage during mains fault*, the voltage limit must be set at which the *Mains fault* function is to be active.

This function can also be activated by selecting *Mains failure inverted* on a digital input.

When *Kinetic backup* [4] is selected, the ramp function in parameter 206-212 is deactivated.

Controlled ramp down and kinetic back up have limited performance above 70% load.

**Description of choice:**

Select *No function* [0] if this function is not required. If *Controlled ramp-down* [1] is selected, the motor will ramp via the quick-stop ramp set in parameter 212. If the supply voltage is re-established during ramp-down, the adjustable frequency drive will start up again. If *Controlled ramp-down and trip* [2] is selected, the motor will ramp via the quick-stop ramp set in parameter 212.

At 0 Hz the adjustable frequency drive will trip (ALARM 36, mains failure). If the supply voltage is re-established during ramp-down, the adjustable frequency drive will continue the quick-stop ramp and trip. If *Coasting* [3] is selected, the adjustable frequency drive will turn off the inverters and the motor will start coasting. Parameter 445 *Flying motor* must be active, so that if the supply voltage is re-established, the adjustable frequency drive will be able to catch the motor and start up again.

If *Kinetic back-up* [4] is selected, the adjustable frequency drive will try to utilise the energy from the load to maintain a constant intermediate circuit voltage. If the supply voltage is re-established, the adjustable frequency drive will start up again.

If *Controlled alarm suppression* [5] is selected, the adjustable frequency drive will trip if there is a mains failure and the unit is not stopped by OFF1, OFF2 or OFF3 via the Profibus. Only active with Fieldbus profile (par. 512) selected and Profibus installed.

**408 Quick discharge  
(QUICK DISCHARGE)**
**Value:**

- |                          |     |
|--------------------------|-----|
| ★ Not possible (DISABLE) | [0] |
| Possible (ENABLE)        | [1] |

**Function:**

The option is given of quickly discharging the intermediate circuit capacitors by means of an external resistor.

**Description of choice:**

This function is only active in extended units, since it requires the connection of external 24 V DC and a brake resistor or discharge resistor; otherwise, the data selection is limited to *Disable* [0].

This function can be activated by selecting a digital input signal for *Mains failure inverted*. Select *Disable* if this function is not required. Select *Enable* and connect 24 V DC external supply and a brake/discharge resistor.

See section *Quick discharge*.

**409 Trip delay torque  
(TRIP DELAY TORQ.)**
**Value:**

- |                   |       |
|-------------------|-------|
| 0 - 60 sec. (OFF) | ★ OFF |
|-------------------|-------|

**Function:**

When the adjustable frequency drive registers that the output torque has increased up to the torque limits (parameters 221 and 222) in the set time, cutting out is effected when that time has passed.

**Description of choice:**

Select how long the adjustable frequency drive is to be able to run at the torque limit before cutting out. 60 sec. = OFF means that the time is infinite; however, the thermal monitoring will still be active.

**410 Trip delay-inverter  
(INVFAULT DELAY)**
**Value:**

- |             |                           |
|-------------|---------------------------|
| 0 - 35 sec. | ★ Depends on type of unit |
|-------------|---------------------------|

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

**Function:**

When the adjustable frequency drive registers an overvoltage in the set time, cutting out is effected after that time has passed.

**Description of choice:**

Select how long the adjustable frequency drive is to be able to run at overvoltage before cutting out.


**NOTE**

If this value is reduced from the factory setting, the unit may report a fault when the mains voltage is turned on.

**411 Switching frequency**
**(SWITCH FREQ.)**
**Value:**

★ Depends on the unit output.

**Function:**

The set value determines the switching frequency of the inverter. If the switching frequency is changed, this may help to minimise possible acoustic noise from the motor.


**NOTE**

The output frequency of the adjustable frequency drive can never assume a value higher than 1/10 of the switching frequency.

**Description of choice:**

When the motor is running, the switching frequency is adjusted in parameter 411 until the frequency has been obtained at which the motor is as low-noise as possible.

See also parameter 446 - switching pattern.


**NOTE**

Switching frequencies higher than 3.0 kHz (4.5 kHz for 60°C AVM) lead to automatic derating of the maximum output of the adjustable frequency drive.

**412 Output frequency dependent switching frequency**
**(VAR CARRIER FREQ)**
**Value:**

★ Not possible (DISABLE) [0]

Possible (ENABLE) [1]

**Function:**

This function makes it possible to increase the switching frequency at a falling output frequency. Used in applications with square torque characteristics (centrifugal pumps and fans) in which the load declines depending on the output frequency. However, the maximum switching frequency is determined by the value set in parameter 411.

**Description of choice:**

Select *Not possible* [0] if a permanent switching frequency is desired.

Set the switching frequency in parameter 411. If *Possible* [1] is selected the switching frequency will decline at an increasing output frequency.

**413 Overmodulation function**
**(OVERMODUL)**
**Value:**

Off (OFF) [0]

★ On (ON) [1]

**Function:**

This parameter allows connection of the overmodulation function for the output voltage.

**Description of choice:**

*Off* means that there is no overmodulation of the output voltage, which means that torque ripple on the motor shaft is avoided. This can be a good feature, e.g. on grinding machines.

*On* means that an output voltage can be obtained which is greater than the mains voltage (up to 15%).

**414 Minimum feedback**
**(MIN. FEEDBACK)**
**Value:**

-100,000.000 - Max. feedback      ★ 0.000

**Function:**

Parameters 414 and 415 are used to scale the display text to make it show the feedback signal as the actual unit proportional to the signal on the input. This value will be displayed if *Feedback [unit]* [3] has been selected in one of parameters 009-012 and in the display mode. Choose the feedback signal unit in parameter 416.

Used together with *Speed control, closed-loop*; *Process control, closed-loop* and *Torque control speed feedback*, (parameter 100).

**Description of choice:**

Is only active when parameter 203 has been set to *Min-Max* [0].

Set the value to be shown on the display when *Minimum feedback is obtained on the selected feedback input* (parameter 308 or 314).

The minimum value can be limited by the choice of configuration (parameter 100) and reference/feedback range (parameter 203).

If *Speed control, closed-loop* [1] has been selected in parameter 100, minimum feedback cannot be set under 0.

**415 Maximum feedback**
**(MAX. FEEDBACK)**
**Value:**

Min. feedback - 100,000.000      ★ 1,500.000

**Function:**

This value should be 10% higher than par. 205 *Maximum reference*, to keep the adjustable frequency drive from integrating as a response to a possible offset fault.

For further description, see parameter 414.

**Description of choice:**

Set the value to be shown on the display when *Maximum feedback is obtained on the selected feedback*

*input (parameter 308 or 314). The maximum value can be limited by the choice of configuration (parameter 100).*

**416 Reference/feedback unit**
**(REF/FEEDB. UNIT)**
**Value:**

NO UNIT [0]

★ % [1]

PPM [2]

RPM [3]

bar [4]

CYCLE/min [5]

PULSE/s [6]

UNITSS/s [7]

UNITS/min [8]

UNITS/h [9]

°C [10]

Pa [11]

l/s [12]

m³ /s [13]

l/min [14]

m³ /min [15]

l/h [16]

m³ /h [17]

kg/s [18]

kg/min [19]

kg/h [20]

t/min [21]

t/h [22]

m [23]

N m [24]

m/s [25]

m/min [26]

°F [27]

in wg [28]

gal/s [29]

ft³ /s [30]

gal/min [31]

ft³ /min [32]

gal/h [33]

ft <sup>3</sup> /h	[34]
lb/s	[35]
lb/min	[36]
lb/h	[37]
lb ft	[38]
ft/s	[39]
ft/min	[40]

**Function:**

Choose among different units to be shown on the display.

This unit is also used directly in *Process control, closed loop* as a unit for *Minimum/Maximum reference* (parameters 204/205) and i.

The possibility of choosing a unit in parameter 416 will depend on the choices made in the following parameters:

Par. 002 *Local/remote control*.

Par. 013 *Local control/config.* as par. 100.

Par. 100 *Configuration*.

**Select parameter 002 as Remote control**

If parameter 100 is selected as *Speed control, open loop* or *Torque control, open loop*, the unit selected in parameter 416 can be used in displays (par. 009-12 *Feedback [unit]*) of process parameters.

The process parameter to be displayed can be connected in the form of an external analog signal to terminal 53 (par. 308: *Feedback signal*) or terminal 60 (par. 314: *Feedback signal*), as well as in the form of a pulse signal on terminal 33 (par. 307: *Pulse feedback*).

Note: The reference can only be shown in Hz (*Speed control, open loop*) or Nm (*Torque control, open loop*).

If par. 100 is selected as *Speed control, closed loop*, parameter 416 is not active, since both reference and feedback are always shown as RPM.

If parameter 100 is selected as *Process control, closed loop*, the unit selected in parameter 416 will be used when displaying both reference (par. 009-12: *Reference [unit]*) and feedback (par. 009-12: *Feedback [unit]*).

Scaling of the display indication as a function of the selected range (par. 309/310, 312/313, 315/316, 327 and 328) for a connected, external signal is effected for a reference in parameters 204 and 205 and for feedback in parameters 414 and 415.

**Select parameter 002 as Local control**

If parameter 013 is chosen as *LCP control and open loop* or *LCP digital control and open loop*, the reference will be given in Hz, regardless of the choice made in parameter 416. A feedback or process signal connected to terminal 53, 60 or 33 (pulse), will, however, be displayed in the form of the unit selected in parameter 416. If parameter 013 is chosen as *LCP control/as par. 100 or LCP digital control/as par. 100*, the unit will be as described above under parameter 002, Remote-control.


**NOTE**

The above applies to display of *Reference [unit]* and *Feedback [unit]*. If *Reference [%]* or *Feedback [%]* is selected, the value displayed will be in the form of a percentage of the selected range.

**Description of choice:**

Select the desired unit for the reference/feedback signal.

**417 Speed PID proportional gain**
**(SPEED PROP GAIN)**
**Value:**

0.000 (OFF) - 0.150

★ 0.015

**Function:**

Proportional gain indicates how many times the fault (deviation between the feedback signal and the set-point) is to be amplified. Used together with *Speed control, closed loop* (parameter 100).

**Description of choice:**

Quick control is obtained at high amplification, but if the amplification is too high, the process may become unstable in the case of overshoot.

**418 Speed PID integral time**
**(SPEED INT. TIME)**
**Value:**

2.00 - 999.99 ms (1000 = OFF)

★ 8 ms

**Function:**

The integral time determines how long the PID regulator takes to correct the error. The greater the error, the quicker the gain increases. The integral time results in a delay of the signal and thus has a dampening effect. Used together with *Speed control, closed loop* (parameter 100).

**Description of choice:**

Quick control is obtained through a short integral time. However, if this time is too short, it can make the process unstable.

If the integral time is long, major deviations from the required reference may occur, since the process regulator will take long to regulate if an error has occurred.

**419 Speed PID differential time  
(SPEED DIFF. TIME)**
**Value:**

0.00 (OFF) - 200.00 ms      ★ 30 ms

**Function:**

The differentiator does not react to a constant error. It only provides a gain if the error changes. The quicker the error changes, the stronger the gain from the differentiator will be.

The gain is proportional to the speed at which errors change.

Used together with *Speed control, closed loop* (parameter 100).

**Description of choice:**

Select the desired gain limit.

**420 Speed PID D-gain limit  
(SPEED D-GAIN LIMIT)**
**Value:**

5.0 - 50.0      ★ 5.0

**Function:**

It is possible to set a limit for the gain provided by the differentiator. Since the D-gain increases at higher frequencies, limiting the gain may be useful.

This enables obtaining a pure D-link at low frequencies and a constant D-link at higher frequencies.

Used together with *Speed control, closed loop* (parameter 100).

**Description of choice:**


Select the desired gain limit.

**421 Speed PID lowpass filter time  
(SPEED FILT. TIME)**
**Value:**

5 - 200 ms      ★ 10 ms

**Function:**

Oscillations on the feedback signal are damped by a lowpass filter so as to reduce their influence on control. This might be an advantage, e.g. if there is a great amount of noise on the system. See drawing. Used together with *Speed control, closed loop* and *Torque control, speed feedback* (parameter 100).



**Description of choice:**

If a time constant ( $\tau$ ) e.g. of 100 ms is programmed, the cut-off frequency for the lowpass filter will be  $1/\tau = 10$  RAD/sec., corresponding to  $(10/2 \times \pi) = 1.6$  Hz. This means that the PID regulator will only regulate a feedback signal that varies by a frequency of less than 1.6 Hz. If the feedback signal varies by a higher frequency than 1.6 Hz, the PID regulator will not react.

**422 U 0 voltage at 0 Hz  
(U0 VOLTAGE (0HZ))**
**Value:**

0.0 - parameter 103 ★ 20.0 volt


**Function:**

Parameters 422-432 can be used together with Special motor characteristics (par. 101). It is possible to make a U/f characteristic on the basis of six definable voltages and frequencies. Change of motor nameplate data (parameter 102 - 106) affects parameter 422.

**Description of choice:**

Set the desired voltage at 0 Hz.

See the below drawing.


**423 U 1 voltage  
(U1 VOLTAGE)**
**Value:**

0.0 - U<sub>VLT,MAX</sub> Factory setting of par. 103

**Function:**

This parameter sets the Y-value of the 1st break point.

**Description of choice:**

Set the voltage desired at the F1 frequency set in parameter 424.

See drawing for parameter 422.

**424 F 1 frequency  
(F1 FREQUENCY)**
**Value:**

0.0 - par. 426 Factory setting of par. 104

**Function:**

This parameter sets the X-value of the 1st break point.

**Description of choice:**

Set the frequency desired at the U1 voltage set in parameter 423.

See drawing for parameter 422.

**425 U 2 voltage  
(U2 VOLTAGE)**
**Value:**

0.0 - U<sub>VLT,MAX</sub> Factory setting of par. 103

**Function:**

This parameter sets the Y-value of the 2nd break point.

**Description of choice:**

Set the voltage desired at the F2 frequency set in parameter 426.

See drawing for parameter 422.

**426 F 2 frequency  
(F2 FREQUENCY)**
**Value:**

par. 424 - par. 428 Factory setting of par. 104

**Function:**

This parameter sets the X-value of the 2nd break point.

**Description of choice:**

Set the frequency desired at the U2 voltage set in parameter 425.

See drawing for parameter 422.

**427 U 3 voltage  
(U3 VOLTAGE)**
**Value:**

0.0 - U<sub>VLT,MAX</sub> Factory setting of par. 103

**Function:**

This parameter sets the Y-value of the 3rd break point.

**Description of choice:**

Set the voltage desired at the F3 frequency set in parameter 428.

See drawing for parameter 422.

**428 F 3 frequency**
**(F3 FREQUENCY)**
**Value:**

par. 426 - par. 430      Factory setting of par. 104

**Function:**

This parameter sets the X-value of the 3rd break point.

**Description of choice:**

Set the frequency desired at the U3 voltage set in parameter 427.

See drawing for parameter 422.

**429 U 4 voltage**
**(U4 VOLTAGE)**
**Value:**

0.0 - UVLT,MAX      Factory setting of par. 103

**Function:**

This parameter sets the Y-value of the 4th break point.

**Description of choice:**

Set the voltage desired at the F4 frequency set in parameter 430.

See drawing for parameter 422.

**430 F 4 frequency**
**(F4 FREQUENCY)**
**Value:**

par. 428 - par. 432      Factory setting of par. 104

**Function:**

This parameter sets the X-value of the 4th break point.

**Description of choice:**

Set the frequency desired at the U4 voltage set in parameter 429.

See drawing for parameter 422.

**431 U 5 voltage**
**(U5 VOLTAGE)**
**Value:**

0.0 - UVLT, MAX      Factory setting of par. 103

**Function:**

This parameter sets the Y-value of the 5th break point.

**Description of choice:**

Set the voltage desired at the F5 frequency set in parameter 432.

**432 F 5 frequency**
**(F5 FREQUENCY)**
**Value:**

par. 430 - 1000 Hz      Factory setting of par. 104

**Function:**

This parameter sets the X-value of the 5th break point.

This parameter is not limited by parameter 200.

**Description of choice:**

Set the frequency desired at the U5 voltage set in parameter 431.

See drawing for parameter 422.

**433 Torque control, open loop proportional gain**
**(TOR-OL PROP. GAIN)**
**Value:**

0 (Off) - 500%      ★ 100%

**Function:**

The proportional gain indicates how many times the error (the deviation between feedback signal and set point) is to be applied.

Used together with *Torque control, open loop* (parameter 100).

**Description of choice:**

Fast control is obtained with a high gain, but if the gain is too high, the process may become unstable.

<b>434</b>	<b>Torque control, open loop Integration time</b>
<b>(TOR-OL INT.TIME)</b>	

**Value:**

0.002 - 2.000 sec.      ★ 0.02 sec.

**Function:**

The integrator provides an increasing gain if there is a constant error between reference and current measuring signal. The greater the error, the quicker the gain increases. The integral time is the time required by the integrator to reach the same gain as the proportional gain.

Used together with *Torque control, open loop* (parameter 100).

**Description of choice:**

Fast control is obtained if the integral time is short. However, this time may become too short, in which case the process may become unstable.

<b>437</b>	<b>Process PID Normal/inverse control</b>
<b>(PROC NO/INV CTRL)</b>	

**Value:**

Normal (NORMAL)	[0]
★ Inverse (INVERSE)	[1]

**Function:**

It is possible to choose whether the process regulator is to increase/reduce the output frequency. This is done by having a difference between the reference signal and the feedback signal.

Used together with *Process control, closed-loop* (parameter 100).

**Description of choice:**

If the adjustable frequency drive is to reduce the output frequency in case the feedback signal increases, select *Normal* [0].

If the adjustable frequency drive is to increase the output frequency in case the feedback signal increases, select *Inverse* [1].

<b>438</b>	<b>Process PID anti windup</b>
<b>(PROC ANTI WINDUP)</b>	

**Value:**

Off (DISABLE)	[0]
★ On (ENABLE)	[1]

**Function:**

It is possible to select whether the process regulator is to continue regulating on an error even if it is not possible to increase/reduce the output frequency.

Used together with *Process control, closed loop* (parameter 100).

**Description of choice:**

The factory setting is *Enable* [1], which means that the integration link is adjusted in relation to the actual output frequency if either the current limit or the max./min. frequency has been reached. The process regulator will not engage again until either the error is zero or its sign has changed.

Select *Disable* [0] if the integrator is to continue integrating on an error, even if it is not possible to remove the fault by such control.


**NOTE**

If *Disable* [0] is selected, it will mean that when the error changes its sign, the integrator will first have to integrate down from the level obtained as a result of the former error, before any change to the output frequency occurs.

<b>439</b>	<b>Process PID start frequency</b>
<b>(PROC START VALUE)</b>	

**Value:**

fMIN - fMAX (parameter 201 and 202)	★ parameter 201
-------------------------------------	-----------------

**Function:**

When the start signal comes, the adjustable frequency drive will react in the form of *Speed control, open loop* following the ramp. Only when the programmed start frequency has been obtained, will it change over to *Process control, closed loop*. In addition, it is possible to set a frequency that corresponds to the speed

at which the process normally runs, which will enable the required process conditions to be reached sooner. Used together with *Process control, closed loop* (parameter 100).

**Description of choice:**

Set the required start frequency.


**NOTE**

If the adjustable frequency drive is running at the current limit before the desired start frequency is obtained, the process regulator will not be activated. For the regulator to be activated anyway, the start frequency must be lowered to the required output frequency. This can be done during operation.

**440 Process PID proportional gain  
(PROC. PROP. GAIN)**
**Value:**

0.00 - 10.00 ★ 0.01

**Function:**

The proportional gain indicates the number of times the error between the set point and the feedback signal is to be applied.

Used together with *Process control, closed loop* (parameter 100).

**Description of choice:**

Quick control is obtained by a high gain, but if the gain is too high, the process may become unstable.

**441 Process PID integral time  
(PROC. INTEGR. T.)**
**Value:**

0.01 - 9999.99 sec. (OFF) ★ OFF

**Function:**

The integrator provides an increasing gain at a constant error between the set point and the feedback signal. The greater the error, the quicker the gain will increase. The integral time is the time needed by the

integrator to reach the same gain as the proportional gain.

The gain is proportional to the speed at which the error changes.

Used together with *Process control, closed loop* (parameter 100).

**Description of choice:**

Quick control is obtained at a short integral time. However, this time may become too short, which can make the process unstable.

If the integral time is long, major deviations from the required set point may occur, since the process regulator will take a long time to regulate in relation to a given error.

**442 Process PID differentiation time  
(PROC. DIFF. TIME)**
**Value:**

0.00 (OFF) - 10.00 sec. ★ 0.00 sec.

**Function:**

The differentiator does not react to a constant error. It only provides a gain when the error changes. The quicker the error changes, the stronger the gain from the differentiator.

The gain is proportional to the speed at which the error changes.

Used together with *Process control, closed loop* (parameter 100).

**Description of choice:**

Quick control is obtained with a long differentiation time. However, this time may become too long, which can make the process unstable.

**443 Process PID diff. gain limit  
(PROC. DIFF. GAIN)**
**Value:**

5.0 - 50.0 ★ 5.0

**Function:**

It is possible to set a limit for the differentiator gain. The differentiator gain will increase if there are fast changes, which is why it can be beneficial to limit this gain, thereby obtaining a pure differentiator gain at

slow changes and a constant differentiator gain where quick changes to the error occur.

Used together with *Process control, closed loop* (parameter 100).

**Description of choice:**

Select a limit to differentiator gain as required.

**444 Process PID lowpass filter time**
**(PROC FILTER TIME)**
**Value:**

0.01 - 10.00      ★ 0.01

**Function:**

Oscillations on the feedback signal are damped by the lowpass filter in order to reduce their impact on the process control. This can be an advantage e.g. if there is a lot of noise on the signal.

Used together with *Process control, closed loop* (parameter 100).

**Description of choice:**

Select the desired time constant ( $\tau$ ). If a time constant ( $\tau$ ) of 100 ms is programmed, the break frequency for the lowpass filter will be  $1/0.1 = 10$  RAD/sec., corresponding to  $(10/2 \times \pi) = 1.6$  Hz.

The process regulator will thus only regulate a feedback signal that varies by a frequency lower than 1.6 Hz. If the feedback signal varies by a higher frequency than 1.6 Hz, the Process regulator will not react.

**445 Flying start**
**(FLYING START)**
**Value:**

★ Off (DISABLE) [0]  
On (ENABLE) [1]

**Function:**

This function makes it possible to 'catch' a motor, which is spinning freely because of a mains drop-out.

**Description of choice:**

Select *Disable* if this function is not required. Select *Enable* if the adjustable frequency drive is to be able to 'catch' and control a spinning motor.

**446 Switching pattern**
**(SWITCH PATTERN)**
**Value:**

60° AVM (60° AVM) [0]  
★ SFAVM (SFAVM) [1]

**Function:**

Choose between two different switching patterns: 60° AVM and SFAVM.

**Description of choice:**

Select 60° AVM if the option of using a switching frequency up to 14/10 kHz is required. Derating of the rated output current  $I_{VLT.N}$  is effected from a switching frequency of 4.5 kHz.

Select SFAVM if the option of using a switching frequency up to 5/10 kHz is required. Derating of the rated output current  $I_{VLT.N}$  is effected from a switching frequency of 3.0 kHz.

**447 Torque, speed feedback Torque compensation**
**(TOR-SF COMP.)**
**Value:**

-100 - 100%      ★ 0%

**Function:**

This parameter is only used if *Torque control, speed feedback* [5] has been selected in parameter 100. Torque compensation is used in connection with calibration of the frequency converter. By adjusting parameter 447, *Torque compensation*, the output torque can be calibrated.

See section *Setting of parameters, torque regulation, speed feedback*.

**Description of choice:**

Set the required value.

<b>448</b>	<b>Torque, speed feedback Gear ratio with encoder</b>
<b>(TOR-SF GEARRATIO)</b>	

**Value:**

0.001 - 100.000      ★ 1.000

**Function:**

This parameter is only used if *Torque control, speed feedback* [5] has been selected in parameter 100. If an encoder has been fitted to the gearshaft, a gear ratio must be set - otherwise the adjustable frequency drive will not be able to calculate the output frequency correctly.

For a gear ratio of 1:10 (gearing down of motor rpm), set the parameter value to 10.

If the encoder has been fitted directly on the motor shaft, set the gear ratio to 1.00.

**Description of choice:**

Set the required value.

<b>449</b>	<b>Torque, speed feedback Friction loss</b>
<b>(TOR-SF FRIC. LOSS)</b>	

**Value:**

0.00 - 50.00% of rated motor torque      ★ 0.00%

**Function:**

This parameter is only used if *Torque control, speed feedback* [5] has been selected in parameter 100.

Set the friction loss as a fixed percentage loss of rated torque. In motor operation, the friction loss will be added to the torque, while in generating operation it will be deducted from the torque.

See section *Setting of parameters, torque regulation, speed feedback*.

**Description of choice:**

Set the required value.

<b>450</b>	<b>AC line voltage at AC line fault</b>
<b>(MAINS FAIL VOLT.)</b>	

**Value:**

180-240 V for 200-240 V units	★ 180
342-500 V for 380-500 V units	★ 342
473-600 V for 525-600 V units	★ 495
473-690 V for 525-690 V units	★ 495

**Function:**

Set the voltage level at which parameter 407 AC Line fault is to be activated. The voltage level for activating the AC line fault functions must be lower than the rated AC line voltage supplied to the adjustable frequency drive. As a rule of thumb, parameter 450 can be set to 10% below the rated AC line voltage.

**Description of choice:**

Set the level for activating AC line fault functions.


**NOTE**

If this value is set at too high a level, the AC line fault function set in parameter 407 can be activated, even if the AC line voltage is present.

<b>453</b>	<b>Speed closed loop gear ratio</b>
<b>(SPEED GEARRATIO)</b>	

**Value:**

0.01 - 100.00      ★ 1.00

**Function:**

This parameter is only used if *Speed control, closed loop* [1] has been selected in parameter 100 Configuration.

If the feedback has been fitted to the gearshaft, a gear ratio must be set - otherwise the adjustable frequency drive will not be able to detect an encoder loss.

For a gear ratio of 1:10 (gearing down of motor rpm), set the parameter value to 10.

If the encoder has been fitted directly on the motor shaft, set the gear ratio to 1.00.

Please note, that this parameter only has influence on the encoder loss function.

**Description of choice:**

Set the required value.

**454 Dead time compensation  
(DEADTIME COMP.)**
**Value:**

Off (OFF)	[0]
★ On (ON)	[1]

**Function:**

The active inverter dead time compensation which is part of the VLT 5000 control algorithm (VVC+) is causing instability at standstill when working in closed-loop control. The purpose of this parameter is switching off the active dead time compensation to avoid instability.

**Description of choice:**

Select *Off* [0] to inactivate the dead time compensation.

Select *On* [1] to activate the dead time compensation.

**455 Frequency range monitor  
(MON. FREQ. RANGE)**
**Value:**

Disable	[0]
★ Enable	[1]

**Function:**

This parameter is used if warning 35 *Out of frequency range* must be turned off in the display in process control closed loop. This parameter does not affect the extended status word.

**Description of choice:**

Select *Enable* [1] to enable the readout in the display if warning 35 *Out of frequency range* occurs. Select *Disable* [0] to disable the readout in the display if warning 35 *Out of frequency range* occurs.

**457 Phase loss function  
(Phase loss funct)**
**Value:**

★ Trip (Trip)	[0]
Warning (Warning)	[1]

**Function:**

Select the function which is to be activated if the mains imbalance becomes too high or if a phase is missing.

**Description of choice:**

At *Trip* [0] the adjustable frequency drive will stop the motor within a few seconds (depending on drive size). At *Warning* [1] only a warning will be exported when a mains failure occurs, but in severe cases, other extreme conditions might result in a trip.


**NOTE**

If *Warning* has been selected, the life expectancy of the drive will be reduced when the mains failure persists.


**NOTE**

At phase loss, the internal cooling fans of some drive types cannot be powered. In order to avoid overheating, an external power supply can be connected.

IP00/IP20/NEMA

- VLT 5032-5052, 200-240 V
- VLT 5122-5552, 380-500 V
- VLT 5042-5602, 525-690 V
- IP54
- VLT 5006-5052, 200-240 V
- VLT 5016-5552, 380-500 V
- VLT 5042-5602, 525-690 V

See also *Electrical Installation*.

**483 Dynamic DC link compensation  
(DC link comp.)**
**Value:**

Off	[0]
★ On	[1]

**Function:**

The adjustable frequency drive includes a feature, which ensures that the output voltage is independent of any voltage fluctuation in the DC link, e.g. caused by fast fluctuation in the mains supply voltage. The benefit is a very steady torque on motor shaft (low torque ripple) under most mains conditions.



---

## VLT® 5000 Series

---

**Description of choice:**

In some cases this dynamic compensation can cause resonance's in the DC link and should then be disabled. Typical cases are where a line choke or a passive harmonic filter (e.g. filters AHF005/010) is mounted in the mains supply to the frequency converter to suppress harmonics. Can also occur on mains with low short circuit ratio.

---

**■ Parameters - Serial communication**
**500 Address**
**(BUS ADDRESS)**
**Value:**

Parameter 500 Protocol = FC protocol [0]

0 - 126

★ 1

Parameter 500 Protocol = MODBUS RTU [2]

1 - 247

★ 1

**Function:**

This parameter allows the allocation of an address to each adjustable frequency drive in a serial communication network.

**Description of choice:**

The individual adjustable frequency drive must be allocated a unique address.

If the number of units connected (adjustable frequency drives + master) is higher than 31, a repeater must be used.

Parameter 500 Address cannot be selected via the serial communication, but must be preset via the control unit.

**501 Baudrate**
**(BAUDRATE)**
**Value:**

300 Baud (300 BAUD) [0]

600 Baud (600 BAUD) [1]

1200 Baud (1200 BAUD) [2]

2400 Baud (2400 BAUD) [3]

4800 Baud (4800 BAUD) [4]

★ 9600 Baud (9600 BAUD) [5]

**Function:**

This parameter is for programming the speed at which data is to be transmitted via the serial connection.

Baud rate is defined as the number of bits transferred per second.

**Description of choice:**

The transmission speed of the adjustable frequency drive is to be set at a value that corresponds to the transmission speed of the PLC/PC. Parameter 501

cannot be selected via the serial port, RS 485. The data transmission time proper, which is determined by the set baud rate, is only part of the total communication time.

**502 Coasting**
**(COASTING SELECT)**
**503 Quick-stop**
**(Q STOP SELECT)**
**504 DC-brake**
**(DC BRAKE SELECT)**
**505 Start**
**(START SELECT)**
**507 Selection of Setup**
**(SETUP SELECT)**
**508 Selection of speed**
**(PRES.REF. SELECT)**
**Value:**

Digital input (DIGITAL INPUT) [0]

Bus (SERIAL PORT) [1]

Logic and (LOGIC AND) [2]

★ Logic or (LOGIC OR) [3]

**Function:**

Parameters 502-508 allow a choice between controlling the adjustable frequency drive via the terminals (digital input) and/or via the bus.

If *Logic and* or *Bus* is selected, the command in question can only be activated if transmitted via the serial communication port. In the case of *Logic and*, the command must additionally be activated via one of the digital inputs.

**Description of choice:**

*Digital input* [0] is selected if the control command in question is only to be activated via a digital input.

*Bus* [1] is selected if the control command in question is only to be activated via a bit in the control word (serial communication).

*Logic and* [2] is selected if the control command in question is only to be activated when a signal is transmitted (active signal = 1) via both a control word and a digital input.

Digital input 505-508	Bus	Control com- mand
0	0	0
0	1	0
1	0	0
1	1	1

*Logic or [3]* is selected if the control command in question is to be activated when a signal is given (active signal = 1) either via a control word or via a digital input.

Digital input 505-508	Bus	Control com- mand
0	0	0
0	1	1
1	0	1
1	1	1


**NOTE**

Parameters 502-504 deal with stop functions - see examples regarding 502 (coasting) below. Active stop command "0".

Parameter 502 = *Logic and*

Digital input	Bus	Control command
0	0	1 Coasting
0	1	0 Motor running
1	0	0 Motor running
1	1	0 Motor running

Parameter 502 = *Logic or*

Digital input	Bus	Control command
0	0	1 Coasting
0	1	1 Motor running
1	0	1 Motor running
1	1	0 Motor running

**506 Reversing  
(REVERSING SELECT)**
**Value:**

- ★ Digital input (DIGITAL INPUT) [0]
- Bus (SERIAL PORT) [1]
- Logic and (LOGIC AND) [2]
- Logic or (LOGIC OR) [3]

**Function:**

See description under parameter 502.

**Description of choice:**

See description under parameter 502.

**509 Bus jog 1**
**(BUS JOG 1 FREQ.)**
**Value:**

0.0 - parameter 202 ★ 10.0 Hz

**Function:**

This is where to set a fixed speed (jog) that is activated via the serial communication port.

This function is the same as in parameter 213.

**Description of choice:**

The jog frequency  $f_{JOG}$  can be selected in the range between  $f_{MIN}$  (parameter 201) and  $f_{MAX}$  (parameter 202).

**510 Bus jog 2**
**(BUS JOG 2 FREQ.)**
**Value:**

0.0 - parameter 202 ★ 10.0 Hz

**Function:**

This is where to set a fixed speed (jog) that is activated via the serial communication port.

This function is the same as in parameter 213.

**Description of choice:**

The jog frequency  $f_{JOG}$  can be selected in the range between  $f_{MIN}$  (parameter 201) and  $f_{MAX}$  (parameter 202).

**512 Telegram profile**
**(TELEGRAM PROFILE)**
**Value:**

- Fieldbus profile (FIELDDBUS PROFILE) [0]
- ★ FC Drive (FC DRIVE) [1]

**Function:**

There is a choice of two different control word profiles.

**Description of choice:**

Select the desired control word profile.

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

See the dedicated fieldbus manuals for further details.

**513 Bus time interval****(BUS TIMEOUT TIME)****Value:**1 - 99 sec.  1 sec.**Function:**

This parameter sets the maximum time expected to pass between the receipt of two consecutive telegrams. If this time is exceeded, the serial communication is assumed to have stopped and the desired reaction is set in parameter 514.

**Description of choice:**

Set the desired time.

Stop (STOP) [2]

Jogging (JOGGING) [3]

Max. speed (MAX SPEED) [4]

Stop and trip (STOP AND TRIP) [5]

**Function:**

This parameter selects the desired reaction of the adjustable frequency drive when the set time for bus timeout (parameter 513) has been exceeded.

If choices [1] to [5] are activated, relay 01 and relay 04 will be de-activated.

If more time-outs occur at the same time the adjustable frequency drive will give the following priority to the time-out function:

1. Parameter 318 *Function after time out*
2. Parameter 346 *Function after encoder loss*
3. Parameter 514 *Bus time interval function*.

**514 Bus time interval function****(BUS TIMEOUT FUNC)****Value:**

Off (OFF) [0]

Freeze output (FREEZE OUTPUT) [1]

**Description of choice:**

The output frequency of the adjustable frequency drive can: be frozen at the present value, be frozen at the reference, go to stop, go to jogging frequency (parameter 213), go to max. output frequency (parameter 202) or stop and activate a trip.

<b>Parameter no.</b>	<b>Description</b>	<b>Display text</b>	<b>Unit</b>	<b>Updating interval</b>
515	Reference %	(REFERENCE)	%	80 msec.
516	Reference Unit	(REFERENCE [UNIT])	Hz, Nm or rpm	80 msec.
517	Feedback	(FEEDBACK)	To be selected via par. 416	80 msec.
518	Frequency	(FREQUENCY)	Hz	80 msec.
519	Frequency x Scaling	(FREQUENCY X SCALE)	-	80 msec.
520	Current	(MOTOR CURRENT)	Amp x 100	80 msec.
521	Torque	(TORQUE)	%	80 msec.
522	Power, kW	(POWER (KW))	kW	80 msec.
523	Power, HP	(POWER (HP))	HP (US)	80 msec.
524	Motor voltage	(MOTOR VOLTAGE)	V	80 msec.
525	DC link voltage	(DC LNK VOLTAGE)	V	80 msec.
526	Motor temp.	(MOTOR THERMAL)	%	80 msec.
527	VLT temp.	(VLT THERMAL)	%	80 msec.
528	Digital input	(DIGITAL INPUT)	Binary code	2 msec.
529	Terminal 53, analogue input	(ANALOG INPUT 53)	V	20 msec.
530	Terminal 54, analogue input	(ANALOG INPUT 54)	V	20 msec.
531	Terminal 60, analogue input	(ANALOG INPUT 60)	mA	20 msec.
532	Pulse reference	(PULSE REFERENCE)	Hz	20 msec.
533	External reference %	(EXT. REFERENCE)		20 msec.
534	Status word	(STATUS WORD [HEX])	Hex code	20 msec.
535	Brake power/2 min.	(BR. ENERGY/2 MIN)	kW	
536	Brake power/sec.	(BRAKE ENERGY/S)	kW	
537	Heat sink temperature	(HEATSINK TEMP.)	°C	1.2 sec.
538	Alarm word	(ALARM WORD [HEX])	Hex code	20 msec.
539	VLT control word	(CONTROLWORD [HEX])	Hex code	2 msec.
540	Warning word, 1	(WARN. WORD 1)	Hex code	20 msec.
541	Extended status word Hex	(EXT. STATUS WORD)	Hex code	20 msec.
557	Motor RPM	(MOTOR RPM)	RPM	80 msec.
558	Motor RPM x scaling	(MOTOR RPM X SCALE)	-	80 msec.

**Function:**

These parameters can be read out via the serial communication port and via the display in Display mode, see also parameters 009 - 012.

parameter 100 (Hz, Nm or rpm) or in parameter 416. See also parameters 205 and 416, if required.

**Feedback, parameter 517:**

Indicates the status value of terminals 33/53/60 at the unit/scale selected in parameters 414, 416 and 416.

**Frequency, parameter 518:**

The value shown corresponds to the actual motor frequency  $f_M$  (without resonance dampening).

**Frequency x scale, parameter 519:**

The value shown corresponds to the actual motor frequency  $f_M$  (without resonance dampening) multiplied by a factor (scaling) set in parameter 008.

**Description of choice:**
**Reference %, parameter 515:**

The value shown corresponds to the total reference (sum of digital/analog/preset/bus/freeze ref./catch-up and slow-down).

**Reference Unit, parameter 516:**

Gives the present value of terminals 17/29/53/54/60 in the unit resulting from the choice of configuration in

**Motor current, parameter 520:**

The value shown corresponds to the given motor current measured as a mean value  $I_{RMS}$ .

The value is filtered, which means that approx. 1.3 seconds may pass from an input value changes until the data read-out changes values.

**Torque, parameter 521:**

The value shown is the torque, with sign, supplied to the motor shaft. The value is given as a percentage of the rated torque.

There is not exact linearity between 160% motor current and torque in relation to the rated torque. Some motors supply more torque than that. Consequently, the min. value and the max. value will depend on the max. motor current as well as the motor used.

The value is filtered, which means that approx. 1.3 seconds may pass from an input changes value until the data read-out changes values.

**NOTE**

If the setting of the motor parameters does not match the motor applied, the read-out values will be inaccurate and may become negative, even if the motor is not running or is producing a positive torque.

**Power, (kW), parameter 522:**

The value shown is calculated on the basis of the actual motor voltage and motor current.

The value is filtered, which means that it may take approx. 1.3 seconds from an input value changes until the data read-out changes values.

**Power (HP), parameter 523:**

The value shown is calculated on the basis of the actual motor voltage and motor current.

The value is indicated in the form of HP.

The value is filtered, which means that approx. 1.3 seconds may pass from an input value changes until the data read-out changes values.

**Motor voltage, parameter 524:**

The value shown is a calculated value used for controlling the motor.

**DC link voltage, parameter 525:**

The value shown is a measured value.

The value is filtered, which means that approx. 1.3 seconds may pass from an input value changes until the data read-out changes values.

**Motor temp., parameter 526:****VLT temp., parameter 527:**

Only whole numbers are displayed.

**Digital input, parameter 528:**

The value shown indicates the signal status from the 8 digital terminals (16, 17, 18, 19, 27, 29, 32 and 33). The read-out is binary and the digit at the extreme left gives the status of terminal 16, while the digit at the extreme right gives the status of terminal 33.

**Terminal 53, analogue input, parameter 529:**

The value shown indicates the signal value on terminal 53.

The scaling (parameters 309 and 310) does not influence the read-out. Min. and max. are determined by the offset and gain adjustment of the AD-converter.

**Terminal 54, analogue input, parameter 530:**

The value shown indicates the signal value on terminal 54.

The scaling (parameters 312 and 313) does not influence the read-out. Min. and max. are determined by the offset and gain adjustment of the AD-converter.

**Terminal 60, analogue input, parameter 531:**

The value shown indicates the signal value on terminal 60.

The scaling (parameters 315 and 316) does not influence the read-out. Min. and max. are determined by the offset and gain adjustment of the AD-converter.

**Pulse reference, parameter 532:**

The value shown indicates any pulse reference in Hz connected to one of the digital inputs.

**External reference %, parameter 533:**

The value stated gives, as a percentage, the sum of external references (sum of analogue/bus/pulse).

**Status word, parameter 534:**

Indicates the status word transmitted via the serial communication port in Hex code from the frequency converter. See the Design Guide.

**Brake power/2min., parameter 535:**

Indicates the brake power transmitted to an external brake resistor. The mean power is calculated on an ongoing basis for the latest 120 sec.

**Brake power/sec., parameter 536:**

Indicates the given brake power transmitted to an external brake resistor. Stated as an instantaneous value.

**Heat sink temperature, parameter 537:**  
States the given heat sink temperature of the frequency converter. The cut-out limit is  $90 \pm 5^\circ\text{C}$ , while the unit cuts back in at  $60 \pm 5^\circ\text{C}$ .

**Alarm word, parameter 538:**  
States in Hex format whether there is an alarm on the frequency converter. See section *Warning word 1, Extended status word and Alarm word for further information*.

**VLT control word, parameter 539:**  
Gives the control word sent via the serial communication port in Hex code to the frequency converter. See the *Design Guide* for further information.

**Warning word, 1, parameter 540:**  
States in Hex format whether there is a warning on the frequency converter. See section *Warning word 1, Extended status word and Alarm word for further information*.

**Extended status word Hex, parameter 541:**  
States in Hex format whether there is a warning on the frequency converter.

See section *Warning word 1, Extended status word and Alarm word for further information*.

**Motor RPM, parameter 557:**  
The displayed value corresponds to the actual motor RPM. In open loop or closed loop process control, the motor RPM is estimated. In speed closed loop modes, it is measured.

**Motor RPM x scaling, parameter 558:**  
The displayed value corresponds to the actual motor RPM multiplied by a factor (scaling) set in parameter 008.

<b>561</b>	<b>Protocol</b>
<b>(PROTOCOL)</b>	

**Value:**  
 ★ FC protocol (FC PROTOKOL) [0]  
 Modbus RTU [3]

**Function:**  
There is a choice of two different protocols.

**Description of choice:**  
Select the required control word protocol.

For further information about using the Modbus RTU, see MG10SX.

<b>570</b>	<b>Modbus parity and message framing</b>
<b>(M.BUS PAR./FRAME)</b>	

**Value:**  
 (EVEN/1 STOPBIT) [0]  
 (ODD/1 STOPBIT) [1]  
 ★ (NO PARITY/1 STOPBIT) [2]  
 (NO PARITY/2 STOPBIT) [3]

**Function:**  
This parameter sets up the drive's Modbus RTU interface to communicate properly with the master controller. The parity (EVEN, ODD, or NO PARITY) must be set to match the setting of the master controller.

**Description of choice:**  
Select the parity that matches the setting for the Modbus master controller. Even or odd parity is sometimes used to allow a transmitted word to be checked for errors. Because Modbus RTU uses the more efficient CRC (Cyclic Redundancy Check) method of checking for errors, parity checking is seldom used in Modbus RTU networks.

<b>571</b>	<b>Modbus communications timeout</b>
<b>(M.BUS COM.TIME.)</b>	

**Value:**  
 10 ms - 2000 ms  
 ★ 100 ms

**Function:**  
This parameter determines the maximum amount of time that the drive's Modbus RTU will wait between characters that are sent by the master controller. When this amount of time expires, the drive's Modbus RTU interface will assume that it has received the entire message.

**Description of choice:**  
Generally, the value of 100 ms is sufficient for Modbus RTU networks, although some Modbus RTU networks may operate on a timeout value as short as 35 ms. If this value is set too short, the drive's Modbus RTU interface may miss a part of the message. Since the CRC check will not be valid, the drive will ignore the

★ = factory setting, () = display text, [] = value for use in communication via serial communication port



---

## VLT® 5000 Series

---

message. The resulting retransmissions of messages will slow communications on the network.

If this value is set too long, the drive will wait longer than necessary to determine that the message is completed. This will delay the drive's response to the message and possibly cause the master controller to time out. The resulting retransmissions of messages will slow communications on the network.

---

■ **LCP procedure for entering text**

After selecting *Display Text* in parameter 009 and 010, select display line parameter (553 or 554) and press the **CHANGE DATA** key. Enter text directly into the selected line by using **UP, DN & LEFT, RIGHT** arrow keys on the LCP. The UP and DN arrow keys scroll through the available characters. The Left and Right arrow keys move the cursor through the line of text.

To lock in the text, press the **OK** key when the line of text is completed. The **CANCEL** key will cancel the text.

The available characters are:

A B C D E F G H I J K L M N O P Q R S T U V W X Y  
Z Å Ø Ä Ö É Í Ù è ./ - () 0 1 2 3 4 5 6 7 8 9 'space'

'space' is the default value of parameter 553 & 554. To erase a character that has been entered, it must be replaced with 'space'.


**553      Display text 1**  
**(DISPLAY TEXT ARRAY 1)**

**Value:**

Max. 20 characters [XXXXXXXXXXXXXXXXXXXXXX]

**Function:**

Here, a text of max. 20 characters can be written that will be shown in display line 1, provided *LCP display text* [27] has been selected in parameter 010 *Display line 1.1*. Example of display text:



**Description of choice:**

The required text can be written via serial communication or by means of the arrow keypads on the LCP.

**554      Display text 2**

**(DISPLAY TEXT ARRAY 2)**

**Value:**

Max. 8 characters [XXXXXXXX]

**Function:**

Here, a text of max. 8 characters can be written that will be shown in display line 2, provided *LCP Display Text* [29] has been selected in parameter 009 *Display line 2*.

**Description of choice:**

The required text can be written via serial communication or by means of the arrow keypads on the LCP.

**580–582 Defined parameters**  
**(DEFINED PARAM.)**

**Value:**

Read only

**Function:**

The three parameters contain a list of all parameters defined in the VLT. Each parameter contains up to 116 elements (parameter numbers). The number of parameters that are in use (580, 581, 582) depends on the respective VLT configuration. When a 0 is used as a parameter number, the list ends.

**Description of choice:**

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

**■ Parameters - Technical functions and diagnostics**

Parameter no.	Description	Display text	Unit	Range
Operating data				
600	Operating hours	(OPERATING HOURS)	Hours	0 - 130,000.0
601	Hours run	(RUNNING HOURS)	Hours	0 - 130,000.0
602	kWh counter	(KWH COUNTER)	kWh	0 - 9999
603	No. of cut-ins	(POWER UP's)	Nos.	0 - 9999
604	No. of overtemps	(OVER TEMP's)	Nos.	0 - 9999
605	No. of overvoltages	(OVER VOLT'S)	Nos.	0 - 9999

**Function:**

These parameters can be read out via the serial communication port and via the display in the parameters.

**Description of choice:**
**Operating hours , parameter 600:**

Indicates the number of hours in which the adjustable frequency drive has been in operation.

The value is updated in the adjustable frequency drive every hour and saved when the unit is turned off.

**Hours run, parameter 601:**

Indicates the number of hours in which the adjustable frequency drive has been in operation since reset in parameter 619.

The value is updated in the adjustable frequency drive every hour and saved when the unit is turned off.

**kWh counter , parameter 602:**

States the kW consumption of the motor as a mean value over one hour, since the reset in parameter 618.

**No. of cut-ins, parameter 603:**

States the number of power-ups of the supply voltage to the adjustable frequency drive.

**No. of overtemps, parameter 604:**

States the number of temperature faults there has been on the adjustable frequency drive.

**No. of overvoltages, parameter 605:**

States the number of overvoltages there has been on the adjustable frequency drive.

Parameter no.	Description	Display text	Unit	Range
Data log				
606	Digital inputs	(LOG: DIGITAL INP)	Decimal	0 - 255
607	Control word	(LOG: CONTROL WORD)	Decimal	0 - 65535
608	Status word	(LOG: BUS STAT WD)	Decimal	0 - 65535
609	Reference	(LOG: REFERENCE)	%	0 - 100
610	Feedback	(LOG: FEEDBACK)	Par. 416	999,999.99 999,999.99
611	Output frequency	(LOG: MOTOR FREQ.)	Hz.	0.0 - 999.9
612	Output voltage	(LOG: MOTOR VOLT)	Volt	50 - 1000
613	Output current	(LOG: MOTOR CURR.)	Amp	0.0 - 999.9
614	DC link voltage	(LOG: DC LINK VOLT)	Volt	0.0 - 999.9

**Function:**

Via this parameter it is possible to see up to 20 data-logs, where [0] is the latest log and [19] the oldest.

Each data-log is made every 160 ms as long as a start signal has been given. If a stop signal is given, the latest 20 data-logs will be saved and the values will be available on the display. This is useful, e.g. when carrying out service after a trip.

This parameter can be read out via the serial communication port or via the display.

**Description of choice:**

The data-log number is stated in square brackets: [1]. Data-logs are frozen if there is a trip and released when the adjustable frequency drive is subsequently reset.

Data-logging is active while the motor is running.


★ = factory setting, () = display text, [] = value for use in communication via serial communication port

Free a data-log if there is a trip and release it when resetting the adjustable frequency drive. Data-logging is active when the motor is running.

#### **Digital inputs, parameter 606:**

The value for the digital inputs is given as a decimal figure within the range of 0-255.

The data-log number is stated in square brackets: [1]



#### **Control word, parameter 607:**

The value for the control word is given as a decimal figure within the range of 0-65535.

#### **Status word, parameter 608:**

The value for the bus status word is given as a decimal figure within the range of 0-65535.

#### **Reference, parameter 609:**

The value of the reference is stated as a % in the interval 0 - 100%.

#### **Feedback, parameter 610:**

The value is stated as the parameterised feedback.

#### **Output frequency, parameter 611:**

The value of the motor frequency is stated as a frequency in the interval 0.0 - 999.9 Hz.

#### **Output voltage, parameter 612:**

The value of the motor voltage is stated as Volts in the interval 50 - 1000 V.

#### **Output current, parameter 613:**

The value for the motor current is stated as Amps in the interval 0.0 - 999.9 A.

#### **DC link voltage, parameter 614:**

The value of the DC link voltage is stated as Volts in the interval 0.0 - 999.9 V.

#### **615 Fault log: Error code**

(F.LOG: ERROR COD)

##### **Value:**

[Index 1 - 10]

Error code 0 - 44

#### **Function:**

This parameter makes it possible to see the reason why a trip occurs.

10 (0-10) log values are stored.

The lowest log number (1) contains the latest/most recently saved data value; the highest log number (10) contains the oldest data value.

#### **Description of choice:**

Given as a number code in which the trip number refers to an alarm code that can be seen in the table in section *Warnings and Alarms*.

Reset the fault log after manual initialization.

#### **616 Fault log: Time**

(F.LOG: TIME)

##### **Value:**

[Index 1 - 10]

#### **Function:**

This parameter makes it possible to see the total number of operating hours before the trip occurred. 10 (0-10) log values are stored.

The lowest log number [1] contains the latest/most recently saved data value, while the highest log number [10] contains the oldest data value.

#### **Description of choice:**

Read out as an option.

Indication range: 0.0 - 9999.9.

Reset the fault log after manual initialisation.

#### **617 Fault log: Value**

(F.LOG: VALUE)

##### **Value:**

[Index 1 - 10]

#### **Function:**

This parameter makes it possible to see at what current or voltage a given trip occurred.

#### **Description of choice:**

Read out as one value.

Indication range: 0.0 - 999.9.

Reset the fault log after manual initialisation.

**618 Reset of kWh counter**
**(RESET KWH COUNT)**
**Value:**

- |                         |     |
|-------------------------|-----|
| No reset (DO NOT RESET) | [0] |
| Reset (RESET COUNTER)   | [1] |

**Function:**

Reset to zero of kWh hour counter (parameter 602).

**Description of choice:**

If Reset [1] has been selected and when the [OK] key is pressed, the kWh counter of the adjustable frequency drive is reset. This parameter cannot be selected via the serial port, RS 485.


**NOTE**

When the [OK] key has been activated, the reset has been carried out.

**619 Reset of hours-run counter**
**(RESET RUN. HOUR)**
**Value:**

- |                         |     |
|-------------------------|-----|
| No reset (DO NOT RESET) | [0] |
| Reset (RESET COUNTER)   | [1] |

**Function:**

Reset to zero of hours-run counter (parameter 601).

**Description of choice:**

If Reset [1] has been selected and when the [OK] key is pressed, the hours-run counter of the frequency converter is reset. This parameter cannot be selected via the serial port, RS 485.


**NOTE**

When the [OK] key has been activated, the reset has been carried out.

**620 Operating mode  
(OPERATION MODE)**
**Value:**

- |  |     |
|--|-----|
| ★ Normal function (NORMAL OPERATION)                       | [0] |
| Function with de-activated inverter (OPER. W/INVERT.DISAB) | [1] |
| Control card test (CONTROL CARD TEST)                      | [2] |
| Initialisation (INITIALIZE)                                | [3] |

**Function:**

In addition to its normal function, this parameter can be used for two different tests.

Also, all parameters (except parameters 603-605) can be initialised.


**NOTE**

This function will not become active until the mains supply to the adjustable frequency drive has been turned off and then turned on again.

**Description of choice:**

*Normal function* [0] is selected for normal operation with the motor in the selected application.

*Function with deactivated inverter* [1] is selected if control is desired over the influence of the control signal over the control card and its functions - without the inverter driving the motor.

*Control card test* [2] is selected if control of the analog and digital inputs, as well as the analog, digital relay outputs and the +10 V control voltage is desired. A test connector with internal connections is required for this test.

Use the following procedure for the control card test:


1. Select *Control card test*.
2. Cut off the mains supply and wait for the light in the display to go out.
3. Insert the test plug (see below).
4. Connect to mains.
5. The adjustable frequency drive expects the [OK] key to be pressed (if no LCP, set to *Normal operation*, when the adjustable frequency drive will start up as usual).
6. Carry out various tests.

★ = factory setting, () = display text, [] = value for use in communication via serial communication port

7. Press the [OK] key.
8. Parameter 620 is automatically set to *Normal operation*.

If a test fails, the adjustable frequency drive will move into an infinite loop. Replace control card.

Test plugs:



*Initialisation [3]* is selected if the factory setting of the unit is desired without resetting parameters 500, 501 + 600 - 605 + 615 - 617.

Procedure for initializing:

1. Select Initialisation.
2. Press the [OK] key.
3. Cut off the mains supply and wait for the light in the display to go out.
4. Connect to mains.

Manual initialisation can be carried out by holding down three keys at the same time as the mains voltage is connected. Manual initialisation sets all parameters to the factory setting, except 600-605. The procedure for manual initialisation is as follows:

1. Disconnect the mains voltage and wait for the light in the display to disappear.
2. Hold down [DISPLAY/STATUS]+[MENU]+[OK] while at the same time connecting the mains supply. The display will now read **MANUAL INITIALIZE**.
3. When the display reads **UNIT READY**, the adjustable frequency drive has been initialized.



#### NOTE

The motor must be stopped before initialisation can be carried out.

Parameter no.	Description Nameplate	Display text
621	VLT type	(VLT TYPE)
622	Power section	(POWER SECTION)
623	VLT ordering number	(VLT ORDERING NO)
624	Software version number	(SOFTWARE VERSION)
625	LCP identification number	(LCP ID NO)
626	Database identification number	(PARAM DB ID)
627	Power section identification number	(POWER UNIT DB ID)
628	Application option type	(APP. OPTION)
629	Application option ordering number	(APP. ORDER NO)
630	Communication option type	(COM. OPTION)
631	Communication option ordering number	(COM. ORDER NO)

#### Function:

The key data of the unit can be read out via the display or the serial communication port.

VLT Type indicates the unit size and basic function concerned.

For example: VLT 5008 380-500 V.

#### Power section, parameter 622:

The power section states the given power section being used.

For example: Extended with brake.

#### Description of choice:

VLT type , parameter 621:



---

## VLT® 5000 Series

---

**VLT ordering number , parameter 623:**

Ordering number gives the ordering number of the VLT type in question.

For example: 175Z0072.

**Software version number, parameter 624:**

Software version gives the version number.

For example: V 3,10.

**LCP identification number, parameter 625:**

The key data of the unit can be read out via the display or the serial communication port.

For example: ID 1,42 2 kB.

**Database identification number, parameter 626:**

The key data of the unit can be read out via the display or the serial communication port.

For example: ID 1,14.

**Power section identification number, parameter 627:**

The key data of the unit can be read out via the display or the serial communication port.

For example: ID 1,15.

**Application option type, parameter 628:**

This gives the type of application options fitted with the adjustable frequency drive.

**Application option ordering number, parameter 629:**

This gives the ordering number for the application option.

**Communication option type, parameter 630:**

This gives the type of communication options fitted with the adjustable frequency drive.

**Communication option ordering number, parameter 631:**

This gives the ordering number for the communication option.


**NOTE**

Parameters 700-711 for the relay card are only activated if a relay option card is installed in the VLT 5000.

<b>700</b>	<b>Relay 6, function</b> <b>(RELAY6 FUNCTION)</b>
<b>703</b>	<b>Relay 7, function</b> <b>(RELAY7 FUNCTION)</b>
<b>706</b>	<b>Relay 8, function</b> <b>(RELAY8 FUNCTION)</b>
<b>709</b>	<b>Relay 9, function</b> <b>(RELAY9 FUNCTION)</b>

**Function:**

This output activates a relay switch. Relay outputs 6/7/8/9 can be used for showing status and warnings. The relay is activated when the conditions for the relevant data values have been fulfilled. Activation/deactivation can be programmed in parameters 701/704/707/710 Relay 6/7/8/9, ON delay and parameters 702/705/708/711 Relay 6/7/8/9, OFF delay.

**Description of choice:**

For data choice and connections see parameter 319 - 326.

<b>701</b>	<b>Relay 6, ON delay</b> <b>(RELAY6 ON DELAY)</b>
<b>704</b>	<b>Relay 7, ON delay</b> <b>(RELAY7 ON DELAY)</b>
<b>707</b>	<b>Relay 8, ON delay</b> <b>(RELAY8 ON DELAY)</b>
<b>710</b>	<b>Relay 9, ON delay</b> <b>(RELAY9 ON DELAY)</b>

**Value:**

0 - 600 sec.      0 sec.

**Function:**

This parameter allows a delay of the cut-in time of relays 6/7/8/9 (terminals 1-2).

**Description of choice:**

Enter the required value.

<b>702</b>	<b>Relay 6, OFF delay</b> <b>(RELAY6 OFF DELAY)</b>
<b>705</b>	<b>Relay 7, OFF delay</b> <b>(RELAY7 OFF DELAY)</b>
<b>708</b>	<b>Relay 8, OFF delay</b> <b>(RELAY8 OFF DELAY)</b>
<b>711</b>	<b>Relay 9, OFF delay</b> <b>(RELAY9 OFF DELAY)</b>

**Value:**

0 - 600 sec.      0 sec.

**Function:**

This parameter is used to delay the cut-out time of relays 6/7/8/9 (terminals 1-2).

**Description of choice:**



Enter the required value.

**■ Electrical installation of the relay card**


The relays are connected as shown below.

Relay 6-9:

A-B make, A-C break  
Max. 240 V AC, 2 Amp.



To achieve double isolation, the plastic foil must be mounted as shown in the drawing below.



175H475.10

= factory setting, () = display text, [] = value for use in communication via serial communication port

## VLT® 5000 Series

Outputs	terminal no.	Relay 06 700	Relay 07 703	Relay 08 09 706	Relay 09 709
<b>Value:</b>					
No function	(NO OPERATION)	[0]	[0]	[0]	[0]
Control ready	(CONTROL READY)	[1]	[1]	[1]	[1]
Ready signal	(UNIT READY)	[2]	[2]	[2]	[2]
Ready - remote control	(UNIT READY/REM CTRL)	[3]	[3]	[3]	[3]
Enable, no warning	(ENABLE/NO WARNING)	[4]	[4]	[4]	[4]
Running	(VLT RUNNING)	[5]	[5]	[5]	[5]
Running, no warning	(RUNNING/NO WARNING)	[6]	[6]	[6]	[6]
Running within range, no warning	(RUN IN RANGE/NO WARN)	[7]	[7]	[7]	[7]
Running at reference value, no warning	(RUN ON REF/NO WARN)	[8]	[8]	[8]	[8]
Fault	(ALARM)	[9]	[9]	[9]	[9]
Fault or warning	(ALARM OR WARNING)	[10]	[10]	[10]	[10]
Torque limit	(TORQUE LIMIT)	[11]	[11]	[11]	[11]
Out of current range	(OUT OF CURRENT RANGE)	[12]	[12]	[12]	[12]
Over I low	(ABOVE CURRENT, LOW)	[13]	[13]	[13]	[13]
Under I high	(BELOW CURRENT, HIGH)	[14]	[14]	[14]	[14]
Out of frequency range	(OUT OF FREQ RANGE)	[15]	[15]	[15]	[15]
Over f low	(ABOVE FREQUENCY LOW)	[16]	[16]	[16]	[16]
Under f high	(BELOW FREQUENCY HIGH)	[17]	[17]	[17]	[17]
Out of feedback range	(OUT OF FDBK RANGE)	[18]	[18]	[18]	[18]
Over feedback low	(ABOVE FDBK, LOW)	[19]	[19]	[19]	[19]
Under feedback high	(BELOW FDBK, HIGH)	[20]	[20]	[20]	[20]
Thermal warning	(THERMAL WARNING)	[21]	[21]	[21]	[21]
Ready - no thermal warning	(READY &NOTHERM WARN)	[22]	[22]	[22]	[22]
Ready - remote control - no therm. warn. (REM RDY&NO THERMWAR)	[23]	[23]	[23]	[23]	
Ready - mains voltage within range	(RDY NO OVER/UNDERVOL)	[24]	[24]	[24]	[24]
Reversing	(REVERSE)	[25]	[25]	[25]	[25]
Bus ok	(BUS OK)	[26]	[26]	[26]	[26]
Torque limit and stop	(TORQUE LIMIT AND STOP)	[27]	[27]	[27]	[27]
Brake, no brake warning	(BRAKE NO WARNING)	[28]	[28]	[28]	[28]
Brake ready, no fault	(BRAKE RDY (NO FAULT))	[29]	[29]	[29]	[29]
Brake fault	(BRAKE FAULT (IGBT))	[30]	[30]	[30]	[30]
Relay 123	(RELAY 123)	[31]	[31]	[31]	[31]
Mechanical brake control	(MECH. BRAKE CONTROL)	[32]	[32]	[32]	[32]
Control word bit 11/12	(CTRL WORD BIT 11/12)	[33]	[33]	[33]	[33]
Mains ON	(MAINS ON)	[50]	[50]	[50]	[50]
Motor running	(MOTOR RUNNING)	[51]	[51]	[51]	[51]

### Function:

#### Description of choice:

For description of choice please see parameter 319.

Mains ON [50], has the same logical function as *Running* [5].


*Motor running* [51], has the same logical function as *Mechanical brake control* [32]

**■ Trouble-shooting**

Symptom	How to handle
1. Motor runs unevenly	If the motor runs unevenly, but no fault is given, this may be because the frequency converter has been wrongly set. Adjust the motor data settings. Contact Danfoss if the new setting does not make the motor run evenly.
2. Motor does not run	Check if there is a backlight in the display. If there is a backlight, please check if a fault message is displayed. If yes, please consult the <i>Warnings-section</i> , if no, please refer to symptom 5. If there is no backlight, check if the frequency converter is connected to mains supply. If yes, please refer to symptom 4.
3. Motor does not brake	Please refer to <i>Control with brake function</i> .
4. No message or backlight in display	Check if the prefuses for the frequency converter have blown. If yes, call Danfoss for assistance. If no, check if the control card is overloaded. If so, disconnect all control signal plugs on the control card and check if the fault disappears. If yes, make sure that the 24 V supply is not short-circuited. If no, call Danfoss for assistance.
5. Motor stopped, light in display, but no fault report	Start the frequency converter by pressing [START] on the control panel. Check if the display is frozen, ie. the display cannot be changed or is indefinable. If yes, check if screened cables have been used and are connected correctly. If no, check that the motor is connected and that all motor phases are OK. The frequency converter must be set to run using local references: Parameter 002 = Local operation Parameter 003 = desired reference value Connect 24 V DC to terminal 27. The reference is changed by pressing '+' or '-'. Is the motor running? If yes, check whether control signals to the control card are OK. If no, call Danfoss for assistance.

#### ■ Display - Status messages

Status messages appear in the 4th line of the display, see the below example. The status message will be on the display for approx. 3 seconds.



##### **Start clockwise/anti-clockwise (START FORW./REV):**

Input on digital inputs and parameter data are in conflict.

##### **Slow-down (SLOW DOWN):**

The output frequency of the adjustable frequency drive is reduced by the percentage value chosen in parameter 219.

##### **Catch-up (CATCH UP):**

The output frequency of the adjustable frequency drive is increased by the percentage value chosen in parameter 219.

##### **Feedback high (FEEDBACK HIGH):**

The FB value is higher than the value set in parameter 228. This message is only shown when the motor is running.

##### **Feedback low (FEEDBACK LOW):**

The FB value is lower than the value set in parameter 227. This message is only shown when the motor is running.

##### **Output frequency high (FREQUENCY HIGH):**

The output frequency is higher than the value set in parameter 226. This message is only shown when the motor is running.

##### **Output frequency low (FREQUENCY LOW):**

The output frequency is lower than the value set in parameter 225. This message is only shown when the motor is running.

#### **Output current high (CURRENT HIGH):**

The output current is higher than the value set in parameter 224. This message is only shown when the motor is running.

#### **Output current low (CURRENT LOW):**

The output current is lower than the value set in parameter 223. This message is only shown when the motor is running.

#### **Braking max. (BRAKING MAX):**

The brake is functioning.

Optimum braking is effected when the value in parameter 402 *Braking power limit, KW* is exceeded.

#### **Braking (BRAKING):**

The brake is functioning.

#### **Ramp operation (REM/ RAMPING):**

*Remote* has been selected in parameter 002 and the output frequency is changed in accordance with the ramps set.

#### **Ramp operation (LOCAL/ RAMPING):**

*Local* has been selected in parameter 002 and the output frequency is changed in accordance with the ramps set.

#### **Running, local control (LOCAL/RUN OK):**

Local control has been selected in parameter 002 and a start command is given on either terminal 18 (START or LATCHED START in parameter 302) or terminal 19 (START REVERSE parameter 303).

#### **Running, remote control (REM/RUN OK):**

Remote control has been selected in parameter 002 and a start command is given on either terminal 18 (START or LATCHED START in parameter 302), terminal 19 (START REVERSE parameter 303) or via the serial bus.

#### **VLT ready, remote control (REM/UNIT READY):**

*Remote control* has been selected in parameter 002 and *Coasting stop inverse* in parameter 304, and there is 0 V on terminal 27.

#### **VLT ready, local control (LOCAL/ UNIT READY):**

*Local* has been selected in parameter 002 and *Coasting inverse* in parameter 304, and there is 0 V on terminal 27.

**Quick-stop, remote control (REM/QSTOP):**

*Remote control* has been selected in parameter 002 and the adjustable frequency drive has stopped via a quick-stop signal on terminal 27 (or possibly via the serial communication port).

**Quick-stop, local (LOCAL/ QSTOP):**

*Local* has been selected in parameter 002 and the adjustable frequency drive has stopped via a quick-stop signal on terminal 27 (or possibly via the serial communication port).

**DC stop, remote control (REM/DC STOP):**

*Remote control* has been selected in parameter 002 and the adjustable frequency drive has stopped via a DC stop signal on a digital input (or possibly via the serial communication port).

**DC braking, local (LOCAL/ DC STOP):**

*Local* has been selected in parameter 002 and the adjustable frequency drive has stopped via a DC braking signal on terminal 27 (or possibly via the serial communication port).

**Stop, remote controlled (REM/STOP):**

*Remote control* has been selected in parameter 002 and the adjustable frequency drive has stopped via the control panel or a digital input (or possibly via the serial communication port).

**Stop, local (LOCAL/ STOP):**

*Local* has been selected in parameter 002 and the adjustable frequency drive has stopped via the control panel or the digital input (or possibly via the serial communication port).

**LCP stop, remote (REM/LCP STOP):**

*Remote* has been selected in parameter 002 and the adjustable frequency drive has stopped via the control panel. The coast signal on terminal 27 is high.

**LCP stop, local (LOCAL/LCP STOP):**

*Local* has been selected in parameter 002 and the adjustable frequency drive has stopped via the control panel. The coast signal on terminal 27 is high.

**Stand by (STAND BY):**

Remote control has been selected in parameter 002. The adjustable frequency drive will start when it receives a start signal via a digital input (or the serial communication port).

**Freeze output (FREEZE OUTPUT):**

*Remote control* has been selected in parameter 002 together with *Freeze reference* in parameter 300, 301,

305, 306 or 307, and the terminal in question (16, 17, 29, 32 or 33) has been activated (or possibly via the serial communication port).

**Jog operation, remote controlled****(REM/RUN JOG):**

*Remote control* has been selected in parameter 002 and *Jog* in parameter 300, 301, 305, 306 or 307, and the terminal in question (16, 17, 29, 32 or 33) has been activated (or possibly via the serial communication port).

**Jog operation, local (LOCAL/ RUN JOG):**

*Local* has been selected in parameter 002 and *Jog* in parameter 300, 301, 305, 306 or 307, and the terminal in question (16, 17, 29, 32 or 33) has been activated (or possibly via the serial communication port).

**Oversupply control (OVER VOLTAGE CONTROL):**

The intermediate circuit voltage of the adjustable frequency drive is too high. The adjustable frequency drive is trying to avoid a trip by increasing the output frequency.

This function is activated in parameter 400.

**Automatic Motor Adaptation (AUTO MOTOR ADAPT):**

Automatic Motor adaptation is running.

**Brake check finished (BRAKECHECK OK):**

Brake check of brake resistor and brake transistor tested successfully.

**Quick Discharge finished (QUICK DISCHARGE OK):**

Quick discharge has been completed successfully.

**Exceptions XXXX (EXCEPTIONS XXXX):**

The microprocessor of the control card has stopped and the adjustable frequency drive is out of operation. The cause may be noise on the mains, motor or control cables, leading to a stop of the control card microprocessor.

Check for EMC-correct connection of these cables.

**Ramp stop in fieldbus mode (OFF1):**

OFF1 means that the drive is stopped by ramp down. The command to stop has been given over a fieldbus or the RS485 serial port (select fieldbus in parameter 512).

**Coast stop in fieldbus mode (OFF2):**

OFF2 means that the drive is stopped by coast. The command to stop has been given over a fieldbus or the RS485 serial port (select fieldbus in parameter 512).

**Quick stop in fieldbus mode (OFF3):**

OFF3 means that the drive is stopped by quick stop. The command to stop has been given over a fieldbus or the RS485 serial port (select fieldbus in parameter 512).

**Start not possible (START INHIBIT):**

The drive is in fieldbus profile mode. OFF1, OFF2 or OFF3 have been activated. OFF1 must be toggled to be able to start (OFF1 set from 1 to 0 to 1).

**Not ready for operation (UNIT NOT READY):**

The drive is in Fieldbus profile mode (parameter 512). The drive is not ready for operation as bit 00, 01 or 02 in the control word is "0", the drive has tripped or there is no mains supply (only seen on units with 24 V DC supply).

**Ready for operation (CONTROL READY):**

The drive is ready for operation. For extended units supplied with a 24 V DC supply the message also comes up when there is not mains supply.

**Bus jog, remote controlled (REM/RUN BUS JOG1):**

Remote control has been selected in parameter 002 and the Fieldbus has been selected in parameter 512. Bus Jog has been selected by the fieldbus or serial bus.

**Bus jog, remote controlled (REM/RUN BUS JOG2):**

Remote control has been selected in parameter 002 and Fieldbus has been selected in parameter 512. Bus Jog has been selected by the fieldbus or serial bus.

### ■ Warnings and alarms

The table gives the different warnings and alarms and indicates whether the fault locks the adjustable frequency drive. After Trip locked, the mains supply must be cut and the fault must be corrected. Reconnect the mains supply and reset the adjustable frequency drive before being ready. Wherever a cross is placed under both Warning and Alarm, this can mean that a warning

precedes the alarm. It can also mean that it is possible to program whether a given fault is to result in a warning or an alarm. This is possible, e.g. in parameter 404 *Brake check*. After a trip, alarm and warning will flash, but if the fault is removed, only alarm will flash. After a reset, the adjustable frequency drive will be ready to start operation again.

No.	Description	Warning	Alarm	Trip locked
1	10 Volts low (10 VOLT LOW)	X		
2	Live zero fault (LIVE ZERO ERROR)	X	X	
3	No motor (NO MOTOR)	X		
4	Phase fault (MAINS PHASE LOSS)	X	X	X
5	Voltage warning high (DC LINK VOLTAGE HIGH)	X		
6	Voltage warning low (DC LINK VOLTAGE LOW)	X		
7	Oversupply (DC LINK OVERVOLT)	X	X	
8	Undervoltage (DC LINK UNDERVOLT)	X	X	
9	Inverter overloaded (INVERTER TIME)	X	X	
10	Motor overloaded (MOTOR TIME)	X	X	
11	Motor thermistor (MOTOR THERMISTOR)	X	X	
12	Torque limit (TORQUE LIMIT)	X	X	
13	Overcurrent (OVERCURRENT)	X	X	X
14	Earth fault (EARTH FAULT)	X	X	
15	Switch mode fault (SWITCH MODE FAULT)	X	X	
16	Short-circuit (CURR.SHORT CIRCUIT)	X	X	
17	Standard bus timeout (STD BUS TIMEOUT)	X	X	
18	HPFB bus timeout (HPFB TIMEOUT)	X	X	
19	Fault in EEprom on power card (EE ERROR POWER CARD)	X		
20	Fault in EEprom on control card (EE ERROR CTRL. CARD)	X		
21	Auto-optimisation OK (AUTO MOTOR ADAPT OK)		X	
22	Auto-optimisation not OK (AUTO MOT ADAPT FAIL)		X	
23	Brake test failed (BRAKE TEST FAILED)	X	X	
25	Brake resistor short-circuited (BRAKE RESISTOR FAULT)	X		
26	Brake resistor power 100% (BRAKE POWER 100%)	X	X	
27	Brake transistor short-circuited (BRAKE IGBT FAULT)	X		
29	Heat-sink temperature too high (HEAT SINK OVER TEMP.)		X	X
30	Motor phase U missing (MISSING MOT.PHASE U)		X	
31	Motor phase V missing (MISSING MOT.PHASE V)		X	
32	Motor phase W missing (MISSING MOT.PHASE W)		X	
33	Quick discharge not OK (QUICK DISCHARGE FAIL)		X	X
34	Profibus communication fault (PROFIBUS COMM. FAULT)	X	X	
35	Out of frequency range (OUT FREQ RNG/ROT LIM)	X		
36	Mains failure (MAINS FAILURE)	X	X	
37	Inverter fault (INVERTER FAULT)		X	X
39	Check parameters 104 and 106 (CHECK P.104 & P.106)	X		
40	Check parameters 103 and 105 (CHECK P.103 & P.105)	X		
41	Motor too big (Motor too big)	X		
42	Motor too small (Motor too small)	X		
43	Brake fault (BRAKE FAULT)		X	X
44	Encoder loss (ENCODER FAULT)	X	X	

## ■ Warnings

The display flashes between normal state and warning. A warning comes up on the first and second line of the display. See examples below. If parameter 027 is set to line 3/4, the warning will be shown in these lines if the display is in read-out state 1-3.



### WARNING 1

#### **Under 10 Volts (10 VOLT LOW):**

The 10 Volts voltage from terminal 50 on the control card is below 10 Volts.

Remove some of the load from terminal 50, as the 10 Volts supply is overloaded. Max. 17 mA/min. 590 Ω.

### WARNING/ALARM 2

#### **Live zero fault (LIVE ZERO ERROR):**

The current signal on terminal 60 is less than 50% of the value set in parameter 315 Terminal 60,min. scaling.

### WARNING/ALARM 3

#### **No motor (NO MOTOR):**

The motor check function (see parameter 122) indicates that no motor has been connected to the output of the frequency converter.

### WARNING/ALARM 4

#### **Phase fault (MAINS PHASE LOSS):**

A phase is missing on the supply side or the mains voltage imbalance is too high.

This message can also appear if there is a fault in the input rectifier on the frequency converter.

Check the supply voltage and supply currents to the frequency converter.

### WARNING 5

#### **Voltage warning high**

#### **(DC LINK VOLTAGE HIGH):**

The intermediate circuit voltage (DC) is higher than the overvoltage limit of the control SYSTEM. The frequency converter is still active.

## Alarm messages

The alarm comes up in the 2. and 3. line of the display, see example below:



Messages

### WARNING 6

#### **Voltage warning low (DC LINK VOLTAGE LOW):**

The intermediate circuit voltage (DC) is below the undervoltage limit of the control SYSTEM. The frequency converter is still active.

### WARNING/ALARM 7

#### **Oversupply (DC LINK OVERVOLT):**

If the intermediate circuit voltage (DC) exceeds the inverter overvoltage limit (see table), the frequency converter will trip after the time set in parameter 410 has passed.

Furthermore, the voltage will be stated in the display. The fault can be eliminated by connecting a brake resistor (if the frequency converter has an integral brake chopper, EB or SB) or by extending the time chosen in parameter 410. In addition, *Brake function/oversupply control* can be activated in parameter 400.

**Alarm/warning limits:**

VLT 5000 Series	3 x 200 - 240 V [VDC]	3 x 380 - 500 V [VDC]	3 x 525 - 600 V [VDC]	3 X 525 - 690 v [VDC]
Undervoltage	211	402	557	553
Voltage warning low	222	423	585	585
Voltage warning high (w/o brake - w/brake)	384/405	801/840 <sup>1)</sup>	943/965	1084/1109
Overvoltage	425	855	975	1130

The voltages stated are the intermediate circuit voltage of the frequency converter with a tolerance of  $\pm 5\%$ . The corresponding mains voltage is the intermediate circuit voltage divided by 1.35

1) VLT 5122 - VLT 5552: 817/828 VDC.

**WARNING/ALARM 8**
**Undervoltage (DC LINK UNDERVOLT):**

If the intermediate circuit voltage (DC) drops below the inverter lower voltage limit (see table on previous page), it will be checked whether 24 V power supply is connected.

If no 24 V power supply is connected, the frequency converter will trip after a given time that depends on the unit.

Furthermore, the voltage will be stated in the display. Check whether the supply voltage matches the frequency converter, see technical data.

**WARNING/ALARM 9**
**Inverter overload (INVERTER TIME):**

The electronic, thermal inverter protection reports that the frequency converter is about to cut out because of an overload (too high current for too long). The counter for electronic, thermal inverter protection gives a warning at 98% and trips at 100%, while giving an alarm. The frequency converter cannot be reset until the counter is below 90%.

The fault is that the frequency converter is overloaded by more than 100% for too long.

**WARNING/ALARM 10**
**Motor overtemperature (MOTOR TIME):**

According to the electronic thermal protection (ETR), the motor is too hot. Parameter 128 allows a choice of whether the frequency converter is to give a warning or an alarm when the counter reaches 100%. The fault is that the motor is overloaded by more than 100% for too long. Check that motor parameters 102-106 have been set correctly.

**WARNING/ALARM 11**
**Motor thermistor (MOTOR THERMISTOR):**

The thermistor or the thermistor connection has been disconnected. Parameter 128 allows a choice of whether the frequency converter is to give a warning or an alarm. Check that the thermistor has been correctly connected between terminal 53 or 54 (analogue voltage input) and terminal 50 (+ 10 Volts supply).

**WARNING/ALARM 12**
**Torque limit (TORQUE LIMIT):**

The torque is higher than the value in parameter 221 (in motor operation) or the torque is higher than the value in parameter 222 (in regenerative operation).

**WARNING/ALARM 13**
**Overcurrent (OVERCURRENT):**

The inverter peak current limit (approx. 200% of the rated current) has been exceeded. The warning will last approx. 1-2 seconds, following which the frequency converter will trip, while giving an alarm. Turn off the frequency converter and check whether the motor shaft can be turned and whether the motor size matches the frequency converter.

If extended mechanical brake control is selected, trip can be reset externally.

**ALARM: 14**
**Earth fault (Earth fault):**

There is a discharge from the output phases to earth, either in the cable between the frequency converter and the motor or in the motor itself.

Turn off the frequency converter and remove the earth fault.

**ALARM: 15**
**Switch mode fault (SWITCH MODE FAULT):**

Fault in the switch mode power supply (internal  $\pm 15\text{ V}$  supply).

Contact your Danfoss supplier.

**ALARM: 16****Short-circuiting (CURR.SHORT CIRCUIT):**

There is short-circuiting on the motor terminals or in the motor itself.

Turn off the frequency converter and remove the short-circuit.

**WARNING/ALARM 17****Standard bus timeout (STD BUS TIMEOUT)**

There is no communication to the frequency converter.

The warning will only be active when parameter 514 has been set to another value than *OFF*.

If parameter 514 has been set to *Stop and trip*, it will first give a warning and then ramp down until it trips, while giving an alarm.

Parameter 513 *Bus time interval* could possibly be increased.

**WARNING/ALARM 18****HPFB bus timeout (HPFB BUS TIMEOUT)**

There is no communication with the frequency converter.

The warning will only be active when parameter 804 has been set to another value than *OFF*.

If parameter 804 has been set to *Stop and trip*, it will first give a warning and then ramp down until it trips, while giving an alarm.

Parameter 803 *Bus time interval* could possibly be increased.

**WARNING 19****Fault in the EEPROM on the power card****(EE ERROR POWER CARD)**

There is a fault on the power card EEPROM. The frequency converter will continue to function, but is likely to fail at the next power-up. Contact your Danfoss supplier.

**WARNING 20****Fault in the EEPROM on the control card****(EE ERROR CTRL CARD)**

There is a fault in the EEPROM on the control card. The frequency converter will continue to function, but is likely to fail at the next power-up. Contact your Danfoss supplier.

**ALARM 21****Auto-optimisation OK****(AUTO MOTOR ADAPT OK)**

The automatic motor tuning is OK and the frequency converter is now ready for operation.

**ALARM: 22****Auto-optimisation not OK****(AUTO MOT ADAPT FAIL)**

A fault has been found during automatic motor adaptation. The text shown in the display indicates a fault message. The figure after the text is the error code, which can be seen in the fault log in parameter 615.

**CHECK P.103,105 [0]**

See section *Automatic motor adaptation, AMA*.

**LOW P.105 [1]**

See section *Automatic motor adaptation, AMA*.

**ASYMMETRICAL IMPEDANCE [2]**

See section *Automatic motor adaptation, AMA*.

**MOTOR TOO BIG [3]**

See section *Automatic motor adaptation, AMA*.

**MOTOR TOO SMALL [4]**

See section *Automatic motor adaptation, AMA*.

**TIME OUT [5]**

See section *Automatic motor adaptation, AMA*.

**INTERRUPTED BY USER [6]**

See section *Automatic motor adaptation, AMA*.

**INTERNAL FAULT [7]**

See section *Automatic motor adaptation, AMA*.

**LIMIT VALUE FAULT [8]**

See section *Automatic motor adaptation, AMA*.

**MOTOR ROTATES [9]**

See section *Automatic motor adaptation, AMA*.

**NOTE**

 AMA can only be carried out if there are no alarms during tuning.

**WARNING/ALARM 23****Fault during brake test (BRAKE TEST FAILED):**

The brake test is only run after power-up. If *Warning* has been selected in parameter 404, the warning will come when the brake test finds a fault.

If *Trip* has been selected in parameter 404, the frequency converter will trip when the brake test finds a fault.

The brake test may fail for the following reasons:

No brake resistor connected or fault in the connections; defective brake resistor or defective brake transistor. A warning or alarm will mean that the brake function is still active.

**WARNING 25****Brake resistor fault****(BRAKE RESISTOR FAULT):**

The brake resistor is monitored during operation and if it short-circuits, the brake function is disconnected and the warning comes up. The frequency converter will still be able to work, although without the brake function. Turn off the frequency converter and replace the brake resistor.

**ALARM/WARNING 26****Brake resistor power 100%****(BRAKE PWR WARN 100%):**

The power transmitted to the brake resistor is calculated as a percentage, as a mean value over the last 120 sec., on the basis of the resistance value of the brake resistor (parameter 401) and the intermediate circuit voltage. The warning is active when the dissipated braking power is higher than 100%. If *Trip [2]* has been selected in parameter 403, the frequency converter will cut out while giving this alarm.

**WARNING 27****Brake transistor fault****(BRAKE IGBT FAULT):**

The brake transistor is monitored during operation and if it short-circuits, the brake function is disconnected and the warning comes up. The frequency converter will still be able to run, but since the brake transistor has short-circuited, substantial power will be transmitted to the brake resistor, even if it is inactive.

Turn off the frequency converter and remove the brake resistor.



Warning: There is a risk of substantial power being transmitted to the brake resistor if the brake transistor has short-circuited.

**ALARM: 29****Heat sink temperature too high****(HEAT SINK OVER TEMP.):**

If the enclosure is IP 00 or IP 20/NEMA 1, the cut-out temperature of the heat-sink is 90°C. If IP 54 is used, the cut-out temperature is 80°C.

The tolerance is  $\pm 5^\circ\text{C}$ . The temperature fault cannot be reset, until the temperature of the heat-sink is below 60°C.

The fault could be the following:

- Ambient temperature too high
- Too long motor cable

- Too high switching frequency.

**ALARM: 30****Motor phase U missing****(MISSING MOT.PHASE U):**

Motor phase U between frequency converter and motor is missing.

Turn off the frequency converter and check motor phase U.

**ALARM: 31****Motor phase V missing****(MISSING MOT.PHASE V):**

Motor phase V between frequency converter and motor is missing.

Turn off the frequency converter and check motor phase V.

**ALARM: 32****Motor phase W missing****(MISSING MOT.PHASE W):**

Motor phase W between frequency converter and motor is missing.

Turn off the frequency converter and check motor phase W.

**ALARM: 33****Quick discharge not OK****(QUICK DISCHARGE NOT OK):**

Check whether a 24 Volt external DC supply has been connected and that an external brake/discharge resistor has been fitted.

**WARNING/ALARM: 34****Fieldbus communication fault****(FIELDBUS COMMUNICATION FAULT):**

The fieldbus on the communication option card is not working.

**WARNING: 35****Out of frequency range****(OUT OF FREQUENCY RANGE):**

This warning is active if the output frequency has reached its *Output frequency low limit* (parameter 201) or *Output frequency high limit* (parameter 202). If the frequency converter is in *Process control, closed loop* (parameter 100), the warning will be active in the display. If the frequency converter is in another mode than *Process control, closed loop*, bit 008000 *Out of frequency range* in extended status word will be active, while there will be no warning in the display.

**WARNING/ALARM: 36****Mains failure (MAINS FAILURE):**

This warning/alarm is only active if the supply voltage to the frequency converter is lost and if parameter 407 *Mains fault* has been set to another value than *OFF*. If parameter 407 has been set to *Contr. ramp-down trip* [2], the frequency converter will first give a warning and then ramp down and trip, while giving an alarm. Check the fuses to the frequency converter.

**ALARM: 37****Inverter fault (Inverter fault):**

IGBT or the power card is defective. Contact your Danfoss supplier.

**Auto-optimisation warnings**

Automatic motor adaptation has stopped, since some parameters have probably been set wrongly, or the motor used is too big/small for AMA to be carried out. A choice must thus be made by pressing [CHANGE DATA] and choosing 'Continue' + [OK] or 'Stop' + [OK].

If parameters need to be changed, select 'Stop'; start up AMA all over.

**WARNING: 39****CHECK P.104,106**

The setting of parameter 102, 104 or 106 is probably wrong. Check the setting and choose 'Continue' or 'Stop'.

**WARNING: 40****CHECK P.103,105**

The setting of parameter 102, 103 or 105 is probably wrong. Check the setting and choose 'Continue' or 'Stop'.

**WARNING: 41****MOTOR TOO BIG**

The motor used is probably too big for AMA to be carried out. The setting in parameter 102 may not match the motor. Check the motor and choose 'Continue' or 'Stop'.

**WARNING: 42****MOTOR TOO SMALL**

The motor used is probably too small for AMA to be carried out. The setting in parameter 102 may not match the motor. Check the motor and choose 'Continue' or 'Stop'.

**ALARM: 43****Brake fault (BRAKE FAULT)**

A fault has arisen on the brake. The text shown in the display indicates a fault message. The figure after the text is the fault code that can be seen in the fault log, parameter 615.

**Brake check failed (BRAKE CHECK FAILED) [0]**

The brake check carried out during power-up indicates that the brake has been disconnected. Check whether the brake has been connected correctly and that it has not been disconnected.

**Brake resistor short-circuited****(BRAKE RESISTOR FAULT) [1]**

The brake output has short-circuited. Replace the brake resistor.

**Brake IGBT short-circuited****(BRAKE IGBT FAULT) [2]**

The brake IGBT has short-circuited. This fault means that the unit is not able to stop the brake and that, consequently, the resistor is constant being energized.

**WARNING/ALARM: 44****Encoder loss (ENCODER FAULT)**

The encoder signal is interrupted from terminal 32 or 33. Check the connections.

**WARNING/ALARM: 57****Overcurrent (OVERCURRENT)**

As warning/alarm 13, but in this case the warning/alarm occurs together with a quick stop.

**ALARM: 60****Safety stop (EXTERNAL FAULT)**

Terminal 27 (parameter 304 Digital Inputs) has been programmed for a safety interlock [3] and is a logic '0'.

■ **Warning word 1, Extended status word and Alarm word**

The **warning word 1, extended status word** and the **alarm word** return the different status, warning and alarm messages of the adjustable frequency drive as hexdecimal value. If there are more than one warning or alarm, a sum of all warnings or alarms will be shown. Warning word 1, extended status word and alarm word can also be displayed using the serial bus in parameter 540, 541 and 538.

Bit (Hex)	Warning word 1 (parameter 540)
000001	Fault during brake test
000002	EE-prom power card fault
000004	EE-prom control card
000008	HPFP bus timeout
000010	Standard bus timeout
000020	Overcurrent
000040	Torque limit
000080	Motor thermistor
000100	Motor overload
000200	Inverter overload
000400	Undervoltage
000800	Oversupply
001000	Voltage warning low
002000	Voltage warning high
004000	Phase fault
008000	No motor
010000	Live zero fault (4-20 mA current signal low)
020000	10 Volts low
040000	
080000	Brake resistor power 100%
100000	Brake resistor fault
200000	Brake transistor fault
400000	Out of frequency range
800000	Fieldbus communication fault
1000000	
2000000	Mains failure
4000000	Motor too small
8000000	Motor too big
10000000	Check P. 103 and P. 105
20000000	Check P. 104 and P. 106
40000000	Encoder loss

Bit (Hex)	Extended status word (parameter 541)
000001	Ramping
000002	Automatic motor tuning
000004	Start clockwise/anti-clockwise
000008	Slow down
000010	Catch-up
000020	Feedback high
000040	Feedback low
000080	Output current high
000100	Output current low
000200	Output frequency high
000400	Output frequency low
000800	Brake test ok
001000	Braking max.
002000	Braking
004000	Quick discharge OK
008000	Out of frequency range




## VLT® 5000 Series

Messages

Bit (Hex)	Alarm word 1 (parameter 538)
000001	Brake test failed
000002	Trip locked
000004	AMA tuning not OK
000008	AMA tuning OK
000010	Power-up fault
000020	ASIC fault
000040	HPFP bus timeout
000080	Standard bus timeout
000100	Short-circuiting
000200	Switchmode fault
000400	Earth fault
000800	Overcurrent
001000	Torque limit
002000	Motor thermistor
004000	Motor overload
008000	Inverter overload
010000	Undervoltage
020000	Oversupply
040000	Phase fault
080000	Live zero fault (4 - 20 mA current signal low)
100000	Heat sink temperature too high
200000	Motor phase W missing
400000	Motor phase V missing
800000	Motor phase U missing
1000000	Quick discharge not ok
2000000	Fieldbus communication fault
4000000	Mains failure
8000000	Inverter fault
10000000	Brake power fault
20000000	Encoder loss
40000000	Safety interlock
80000000	Reserved

### ■ Conveyor belt



The following must be programmed in order shown:



Function:	Parameter:	Setting:	Data value:
Rotation, frequency/direction	200	Both directions, 0-132 Hz	[1]
Minimum reference	204	3-10 (Hz)	
Ramp-up time 1	207	10-20 sec.	
Ramp-down time 1	208	10-20 sec.	
Ramp-up time 2	209	10-20 sec.	
Ramp-down time 2	210	10-20 sec.	
Digital input, term. 16	300	Stop (inverse)	[2]
Digital input, term. 17	301	Freeze reference	[7]
Digital input, term. 18	302	Pulse start	[2]
Digital input, term. 19	303	Start reversing	[2]
Digital input, term. 27	304	Quick-stop (inverse)	[2]

All other settings are based on factory settings. However, motor data (nameplate data) must always be entered in parameters 102-106.

A conveyor belt is to be controlled using the digital inputs. Start the conveyor belt going to the right (clockwise) via switch 2 and to the left (anti-clockwise) via switch 3. The reference will increase as long as switch 5 (speed up) is active and will be reduced when switch 6 (speed down) is active.

A stop via the ramp can be activated by means of contact 1; quick-stop by means of switch 4.

1. Pulse stop (inverse)
2. Pulse start to the right
3. Pulse start to the left
4. Quick-stop
5. Speed up
6. Speed down

**■ Pump**


The following must be programmed in order shown:

Function:	Parameter:	Setting:	Data value:
Active Setup	004	Multi-Setup	[5]
Digital input, term. 16	300	Choice of Setup, lsb	[10]
Digital input, term. 32	306	Preset reference, lsb	[6]
Digital input, term. 33	307	Preset reference, msb	[6]
Setup copying	006	Copy to Setup 2 from #	[2]
Edit Setup	005	Setup 1	[1]
Maximum reference	205	60	
Preset reference 1	215	10%	
Preset reference 2	216	20%	
Preset reference 3	217	30%	
Preset reference 4	218	40%	
Edit Setup	005	Setup 2	[2]
Maximum reference	205	60	
Preset reference 5	215	70%	
Preset reference 6	216	100%	

All other settings are based on factory settings. However, motor data (nameplate data) must always be entered in parameters 102-106.

A pump is to run at six different speeds, determined by shifting between the preset references.

Switch no.:




1	3	4	
0	0	0	Preset reference 1
0	0	1	Preset reference 2
0	1	0	Preset reference 3
0	1	1	Preset reference 4
1	0	0	Preset reference 5
1	0	1	Preset reference 6

When switch 1 is active, a setup change to setup 2 is made.

Start/stop by means of switch 2

1. Choice of Setup, lsb
2. Start/stop
3. Preset reference, lsb
4. Preset reference, msb

Examples of use

**■ Gantry Crane**



The following must be programmed in order shown:

Function:	Parameter:	Setting:	Data value:
Torque characteristics	101	Normal/special motor character	[15]
Rotation, frequency/direction	200	Both directions, 0 - 132 Hz	[1]
Analog input, term. 53	308	Thermistor	[4]
Motor thermal protection	128	Thermistor warning/Thermistor trip	[1] or [2]
Analog input, term. 54	311	Reference	[1]
Terminal 18, digital input	302	Start	[1]
Terminal 27, digital input	304	Coasting stop inverse	[0]
Terminal 42, output	319	Torque limit and stop	[27]

All other settings are based on factory settings. However, motor data (nameplate data) must always be entered in parameters 102-106.

A portal gantry with two identical motors is controlled by an external 0-10 Volt signal. The direction of rotation (right or left) is controlled by means of switch 2, while start/stop is carried out using switch 1.

1. Start
2. Reversing
3. Speed reference signal

**■ Torque control, speed feedback**


The following must be programmed in order shown:

A winder winds material onto a roll or unwinds material from a roll at a constant tension.

A device measures the radius of the roll and adjusts the motor torque to ensure that the tension is constant. The measuring device must have a non-linear output signal.

Examples of use

Function:	Parameter:	Setting:	Data value:
Configuration	100	Torque control, speed feedback[5]	
Rotation, frequency/direction	200	Both directions, 0-132 Hz [1]	
Reference/feedback range	203	-Max. - +Max.	[1]
Minimum reference	204	Set to min. torque (Nm)	
Maximum reference	205	Set to max. torque (Nm)	
Reference function	214	Relative	[1]
Terminal 32, encoder input A	306	Encoder feedback, input A	[25]
Terminal 33, encoder input B	307	Encoder feedback, input B	[24]
Encoder feedback, pulses/rev.	329	Set to encoder pulses per rev.	
Terminal 53, analog input	308	Reference	[1]
Terminal 54, analog input	311	Relative reference	[4]
Speed PID lowpass filter	421	10 msec.	

**■ VLT 5000 controllers**

VLT 5000 has three inbuilt controllers: one for speed control, one for process control and one for torque control.

Speed control and process control are in the form of a PID controller that requires a feedback to an input. Torque control is in the form of a PI controller that does not require a feedback, since the torque is calculated by the adjustable frequency drive on the basis of the current measured.

**Setting of speed and process controller**

With respect to both PID controllers, there are a number of settings which are made in the same parameters; however, the choice of controller type will affect the choices to be made under the common parameters.

In parameter 100 *Configuration*, a choice is made of controller, *Speed control, closed loop* or *Process control, closed loop*.

**Feedback signal:**

A feedback range must be set for both controllers. This feedback range at the same time limits the possible reference range, which means that if the sum of all references is outside the feedback range, the reference will be limited to being within this range. The feedback range is set in the units that belong to the application (Hz, RPM, bar, °C, etc.). Setting is effected directly in a parameter for the individual input terminal, thereby deciding whether it should be used for feedback in connection with one of the controllers. Inputs that are not used can be disabled, which will ensure that they do not disturb control. If feedback has been selected on two terminals at the same time, these two signals will be added up.

**Reference:**

For both controllers, it is possible to set four preset references. These can be set between -100% and +100% of the maximum reference or the sum of the external references. External references can be analog signals, pulse signals and/or serial communication. All references will be added and the sum will be the reference for subsequent regulation.

It is possible to limit the reference range to a range smaller than the feedback range. This can be an advantage if it is to be avoided that an unintended change of an external reference makes the sum of references move too far away from the optimum reference. As

with the feedback range, the reference range is set in the units that belong to the applications in question.

**Speed control:**

This PID control has been optimized for use in applications with a need to maintain a given motor speed.

The parameters that are specific to the speed controller are parameters 417 to 421.

**PID for process control:**

This PID control has been optimized for process control. This controller does not have a feedforward facility, but a number of special features that are relevant to process control.

There is a choice of whether normal control is required, in which the speed is increased in the case of an error between the reference and the feedback, or whether inverse control is to be applied, in which the speed is reduced in the case of an error.

There is also a choice of whether the integrator is to continue integrating in the case of an error, even if VLT 5000 is at the minimum/maximum frequency or at the current limit. If VLT 5000 is in such a borderline situation, any attempt to change the motor speed will be restricted by this limit. The integrator comes from the works preset to stop integrating. Integration will be adjusted to a gain that corresponds to the given output frequency.

In certain applications, it is either difficult or completely impossible to measure such a factor as the level. In such cases, it can be necessary to allow the integrator to continue integrating on the fault, even if the motor speed cannot be changed. This will make the integrator work as a kind of counter, i.e. once the feedback indicates that the speed must be changed in a direction away from the borderline situation, the integration will give this change a delay that depends on the time for which the integrator has overcompensated for the previous error.

Furthermore, it is possible to program a starting frequency in which VLT 5000 will wait without activating the controller until this frequency has been reached. This makes it possible, for example, to quickly build up the necessary static pressure in a pumping system.

PID process control, continued:

The Proportional gain, Integration time and Differentiation time of the process controller are set in individual parameters, and the setting ranges are adapted to process control requirements.

As in speed control, it is possible to limit the influence of the differentiator in relation to swift changes in the error between the reference and the feedback signal.

Also available is a lowpass filter for the process controller. This can be set to remove a much greater share of the feedback signal oscillations than the lowpass filter of the speed controller does. This is because most fans and pump applications react relatively slowly, which is why it can be an advantage to feed as stable a signal as possible to the process controller.

The parameters that are specific to the process controller are parameters 437 to 444.

Setting of torque controller (open loop):

This control is selected if *Torque control, open loop* has been selected in 100 *Configuration*.


When this mode has been selected, the reference will use the Nm unit.

Control is in the form of a PI that requires no feedback, since the torque is calculated on the basis of the current measurement of VLT 5000. The proportional gain is set as a percentage in parameter 433 *Torque proportional gain* and the integration time is set in parameter 434 *Torque integration time*. However, both these have been set at the works and normally require no modification.

Examples of use

### ■ PID for process control

The following is an example of a process controller used in a ventilation system.



The following must be programmed in order shown - see explanation of settings in the Operating Instructions:

Function:	Parameter no.	Setting	Data value no.
Activation of process controller	100	Process control, closed loop	[3]
Feedback signal	314	Feedback signal	[2]
Terminal 60, min. scale	315	4 mA	
Terminal 60, max. scale	316	20 mA (factory setting)	
Minimum feedback	414	-10°C	
Maximum feedback	415	40°C	
Process units	416	°C	[10]
Reference	308	Reference (factory setting)	[1]
Terminal 53, min. scale	309	0 Volt (factory setting)	
Terminal 53, max. scale	310	10 Volt (factory setting)	
Minimum reference	204	-5°C	
Maximum reference	205	35°C	
Inverse control	437	Inverse	[1]
Min. frequency	201	10 Hz	
Max. frequency	202	50 Hz	
Proportional gain	440	Application-dependent (e.g. 1.0)	
Integration time	441	Application-dependent (e.g. 5 sec.)	

In a ventilation system, the temperature is to be settable from - 5 - 35°C with a potentiometer of 0-10 Volt. The set temperature must be kept constant, for which purpose the integrated process controller is to be used.

The control is of the inverse type, which means that when the temperature increases, the ventilation speed is increased as well, so as to generate more air. When the temperature drops, the speed is reduced.

The transmitter used is a temperature sensor with a working range of -10-40°C, 4-20 mA.

Min./Max. speed 10/50 Hz.



#### NOTE

The example shows a two-wire transmitter.

1. Start/Stop
2. Temperature reference -5-35°C, 0-10 V (set-point)
3. Temperature transmitter -10-40°C, 4-20 mA (feedback).

### ■ PID for speed control

Below are given a couple of examples of programming of VLT 5000 PID speed control.



175ZA451.10

The following must be programmed in order shown - see explanation of settings in the Operating Instructions:

Function:	Parameter no.	Setting	Data value no.
Activation of process controller	100	Speed control, closed loop	[1]
Feedback signal	314	Feedback signal	[2]
Terminal 32	306	Encoder feedback, input B	[24]
Terminal 33	307	Encoder feedback, input A	[25]
Minimum feedback	414	0 rpm	
Maximum feedback	415	1650 rpm (max. ref. + 10%)	
Reference	308	Reference (factory setting)	[1]
Terminal 53, min. scale	309	0 Volt (factory setting)	
Terminal 53, max. scale	310	10 Volt (factory setting)	
Minimum reference	204	0 rpm	
Maximum reference	205	1500 rpm	
Min. speed	201	0 Hz	
Max. speed	202	75 Hz	
Proportional gain	417	Application-dependent	
Integration time	418	Application-dependent	
Differentiation time	419	Application-dependent	

A conveyor belt that carries heavy items must be maintained at a regular speed, which is set by means of a potentiometer within the range of 0-1500 rpm, 0-10 Volts. The speed selected must be kept constant and the integrated PID speed controller is to be applied. This is a case of normal control, which means that when the load increases, the power supplied to the conveyor belt motor increases in order to keep the speed constant. Correspondingly, when the load falls, the power is reduced.


The feedback used is an encoder with a resolution of 1024 pulses/rev. push-pull.

1. Start/Stop
2. Speed reference 0-1500 rpm, 0-10 Volts
3. Encoder 1024 pulses/rev. push-pull.

Examples of use

■ **PID for torque controller (open loop)**

Below is given an example of programming of VLT 5000 torque controller.



The following must be programmed in order shown:

Function:	Parameter no.	Setting	Data value no.
Activation of process controller	100	Torque control, open loop	[4]
Torque proportional gain	433	100% (factory setting)	
Torque integration time	434	0.02 sec (factory setting)	
Reference	308	Reference (factory setting)	[1]
Terminal 53, min. scale	309	0 volt (factory setting)	
Terminal 53, max. scale	310	10 volt (factory setting)	
Min. speed	201	0 Hz	
Max. speed	202	50 Hz	

A conveyor belt is used for carrying bales forward to a shredder at constant force, regardless of the conveyor belt speed. If there is a space between bales, the conveyor belt must move the next bale to the shredder as quickly as possible.

1. Start/stop.
2. Reference [Nm]

Optimisation of the torque controller

The basic settings have now been made and the factory setting has been optimised for most processes. It is rarely necessary to optimize the *torque proportional gain* in parameter 433 and the *torque integration time* in parameter 434.

In the cases where the factory setting has to be changed, it is recommended to change this setting by a maximum factor of +/- 2.

Feedback

The feedback signal is an estimated torque, calculated by the adjustable frequency drive on the basis of the current values measured.

Reference

The reference is always in Nm.

A minimum and a maximum reference can be set (204 and 205) which limit the sum of all references. The reference range cannot go beyond the feedback range.

## ■ CE labelling

### What is CE labelling?

The purpose of CE labelling is to avoid technical obstacles to trade within EFTA and the EU. The EU has introduced the CE label as a simple way of showing whether a product complies with the relevant EU directives. The CE label says nothing about the specifications or quality of the product. Adjustable frequency drives are regulated by three EU directives:

#### •The machinery directive (98/37/EEC)

All machines with critical moving parts are covered by the machinery directive, which came into force on 1 January 1995. Since an adjustable frequency drive is largely electrical, it does not fall under the machinery directive. However, if an adjustable frequency drive is supplied for use in a machine, we provide information on safety aspects relating to the adjustable frequency drive. We do this by means of a manufacturer's declaration.

#### •The low-voltage directive (73/23/EEC)

Adjustable frequency drives must be CE labelled in accordance with the low-voltage directive, which came into force on 1 January 1997. The directive applies to all electrical equipment and appliances used in the 50 - 1000 Volt AC and the 75 - 1500 Volt DC voltage ranges. Danfoss CE labels in accordance with the directive and issues a declaration of conformity upon request.

#### •The EMC directive (89/336/EEC)

EMC is short for electromagnetic compatibility. The presence of electromagnetic compatibility means that the mutual interference between different components/appliances is so small that the functioning of the appliances is not affected.

The EMC directive came into force on 1 January 1996. Danfoss CE labels in accordance with the directive and issues a declaration of conformity upon request. In order that EMC-correct installation can be carried out, this manual gives detailed instructions for installation. In addition, we specify the standards which our different products comply with. We offer the filters that can be seen from the specifications and provide other types of assistance to ensure the optimum EMC result.

In the great majority of cases, the adjustable frequency drive is used by professionals of the trade as a complex component forming part of a larger appliance, system or installation. It must be noted that the responsibility for the final EMC properties of the appliance, system or installation rests with the installer.

## ■ Danfoss VLT adjustable frequency drive and CE labeling

CE labelling is a positive feature when used for its original purpose, i.e. to facilitate trade within the EU and EFTA.

However, CE labelling may cover many different specifications. This means that it has to be checked what a given CE label specifically covers.

The specifications covered can in fact be widely different. That is why a CE label can give the installer a false feeling of security when using an adjustable frequency drive as a component in a system or an appliance.

We CE label our adjustable frequency drives in accordance with the low-voltage directive. This means that as long as the adjustable frequency drive is installed correctly, we guarantee that it complies with the low-voltage directive. We issue a declaration of conformity that confirms our CE labelling in accordance with the low-voltage directive.

The CE label also applies to the EMC directive, on condition that the instructions given in these Operating Instructions for EMC-correct installation and filtering have been followed. On this basis, a declaration of conformity in accordance with the EMC directive is issued.

The Operating Instructions give detailed instructions for installation to ensure that your installation is EMC-correct. Furthermore, we specify which norms that are complied with by our different products.

We offer the filters that can be seen from the specifications and gladly provide other types of assistance that can help you obtain the best EMC result.

EC/EMC

## ■ Compliance with EMC directive 89/336/EEC

In the great majority of cases, the VLT adjustable frequency drive is used by professionals of the trade as a complex component forming part of a larger appliance, system or installation. It must be noted that the responsibility for the final EMC properties of the appliance, system or installation rests with the installer. As an aid to the installer, Danfoss has prepared EMC installation guidelines for the Power Drive System. The



---

## VLT® 5000 Series

---

standards and test levels stated for Power Drive Systems are complied with, provided the right EMC-correct instructions for installation have been followed, see *electrical installation*.

---

### ■ General aspects of EMC emissions


Electrical interference at frequencies in the range 150 kHz to 30 MHz are usually conducted. Airborne interference from the drive SYSTEM in the range 30 MHz to 1 GHz is generated from the inverter, the motor cable and the motor.

As the sketch below shows, capacitive currents in the motor cable together with a high dV/dt from the motor voltage generate leakage currents.

The use of a screened motor cable increases the leakage current (see figure below). This is because screened cables have higher capacitance to earth than unscreened cables. If the leakage current is not filtered, it will cause greater interference on the mains in the radio frequency range below approx. 5 MHz. Since the leakage current ( $I_1$ ) is carried back to the unit through the screen ( $I_3$ ), there will in principle only be a small electro-magnetic field ( $I_4$ ) from the screened motor cable according to the below figure.

The screen reduces the radiated interference, but increases the low-frequency interference on the mains. The motor cable screen must be connected to the VLT enclosure as well as on the motor enclosure. The best way of doing this is by using integrated screen clamps so as to avoid twisted screen ends (pigtails). These increase the screen impedance at higher frequencies, which reduces the screen effect and increases the leakage current ( $I_4$ ).

If a screened cable is used for Profibus, standard bus, relay, control cable, signal interface and brake, the screen must be mounted on the enclosure at both ends. In some situations, however, it will be necessary to break the screen to avoid current loops.



In the cases when the screen is to be placed on a mounting plate for the VLT frequency converter, the mounting plate must be made of metal, because the screen currents are to be conveyed back to the unit. It is also important to ensure good electrical contact from the mounting plate through the mounting screws to the VLT frequency converter chassis.

With respect to installation, it is generally less complicated to use unscreened cables than screened ones.

although the immunity requirements are complied with.

In order to reduce the interference level from the system overall (unit + installation) as far as possible, it is important to make motor and brake cables as short as possible. Cables with a sensitive signal level must not be alongside motor and brake cables. Radio interference higher than 50 MHz (airborne) will be generated especially by the control electronics.



#### NOTE

Please note, however, that when unscreened cables are used, some emission requirements are not complied with,



## VLT® 5000 Series

EMC Test Results (Emission, Immunity)  
The following test results have been obtained using a system with a VLT adjustable frequency drive (with options if relevant), a screened control cable, a control box with potentiometer, as well as a motor and motor cable.

		Emission				Industrial environment				Housing trades and light industries					
		Environment		EN 55011 Class A1		Conducted 150 kHz-30 MHz		Radiated 30 MHz- GHz		EN 55011 Class B1		Conducted 150 kHz-30 MHz		Radiated 30 MHz- 1 GHz	
Setup	Environment	Basic standard	Motor cable	300 m unscreened/unarmoured	50 m br. screened/armoured (Bookstyle 20m)	150 m br. screened/armoured	Yes <sup>3)</sup>	Yes	No	No	Yes <sup>2)</sup>	Yes <sup>2)</sup>	No	No	
VLT 5000 with RFI filter option															
VLT 5000 with RFI filter option (+ LC filter)				300 m unscreened/unarmoured	50 m br. screened/armoured	150 m br. screened/armoured	Yes <sup>1)</sup>	Yes <sup>1)</sup>	No	No	No	No	No	No	
VLT 5011/380-500 V and VLT 5006/200-240 V this is only complied with if a maximum braided screened/armoured cable of 100 m is used.															
1) For VLT 5011/380-500 V and VLT 5006/200-240 V this is only complied with if a maximum braided screened/armoured cable of 100 m is used.															
2) Does not apply to 5011/380-500 V and 5006/200-240 V															
3) Depending on installation conditions															
VLT 5016-555/380-500 V															
VLT 5008-505/200-240 V															
VLT 5042-505/25-600 V															
Setup															
VLT 5000 without RFI filter option 4/5)				300 m unscreened/unarmoured	150 m br. screened/armoured	300 m unscreened/unarmoured	Yes <sup>6)</sup>	No	Yes <sup>6)</sup>	No	Yes <sup>6)</sup>	No	No	No	
VLT 5000 with RFI filter option				50 m br. screened/armoured	150 m br. screened/armoured	50 m br. screened/armoured	Yes <sup>6)</sup>	Yes <sup>6)</sup>	Yes <sup>6)</sup>	Yes <sup>6)</sup>	Yes <sup>6)</sup>	Yes <sup>6)</sup>	No	No	

1) Does not apply to VLT 5122-555/2 / 380-500 V.

2) Depending on installation conditions.

3) VLT 5032-505/2 / 200-240 V with external filter.

4) VLT 5122-555/2, 380-500 V, fulfills class A at 150 m screened cable without RFI filter (typecode R0).

5) VLT 5042-555/2, 325-600 V, fulfills class A2 at 150 m screened cable without RFI filter (R0), and class A1 at 30 m screened cable with RFI filter (R0).

6) Does not apply to VLT 5042-560/2, 325-600 V.

In order to minimise the conducted noise to the mains supply and the radiated noise from the frequency converter system, the motor cables should be as short as possible and the screen ends should be made in accordance with the section on electrical install

**■ Electrical Installation****■ Electrical installation - EMC precautions**

The following is a guideline to good engineering practice, when installing drives. Following these guidelines is advised, where compliance with EN 61000-6-3, EN 61000-6-4, EN 55011 or EN 61800-3 *First environment* is required. If the installation is in EN 61800-3 *Second environment*, i.e. industrial networks or in an installation that has its own transformer, it is acceptable to deviate from these guidelines. It is however not recommended. See also *CE labelling, Emission and EMC test results* under special conditions in the Design Guide for further details.

**Good engineering practice to ensure EMC-correct electrical installation:**


- Use only braided screened/armoured motor cables and braided screened/armoured control cables. The screen should provide a minimum coverage of 80%. The screen material must be metal, not limited to but typically copper, aluminium, steel or lead. There are no special requirements for the mains cable.
- Installations using rigid metal conduits are not required to use screened cable, but the motor cable must be installed in conduit separate from the control and mains cables. Full connection of the conduit from the drive to the motor is required. The EMC performance of flexible conduits varies a lot and information from the manufacturer must be obtained.
- Connect the screen/armour/conduit to earth at both ends for motor cables as well as for control cables. In some cases, it is not possible to connect the screen in both ends. In these cases, it is important to connect the screen at the frequency converter. See also *Earthing of braided screened/armoured control cables*.
- Avoid terminating the screen/armour with twisted ends (pigtails). Such a termination increases the high frequency impedance of the


screen, which reduces its effectiveness at high frequencies. Use low impedance cable clamps or EMC cable glands instead.

- It is important to ensure good electrical contact between the mounting plate on which the frequency converter is installed and the metal chassis of the frequency converter. However, this does not apply to IP 54 units as they are designed for wall-mounting and VLT 5122-5552 380-500 V, 5042-5602 525-690 V and VLT 5032-5052 200-240 V in IP20/NEMA 1 enclosure and IP 54/NEMA 12 enclosure.
- Use starwashers and galvanically conductive installation plates to secure good electrical connections for IP00 and IP20 installations.
- Avoid using unscreened/unarmoured motor or control cables inside cabinets housing the drive(s), whenever this can be avoided.
- An uninterrupted high frequency connection between the frequency converter and the motor units is required for IP54 units.

The illustration shows an example of an EMC-correct electrical installation of an IP 20 frequency converter; the frequency converter has been fitted in an installation cabinet with an output contactor and connected to a PLC, which in this example is installed in a separate cabinet. In IP 54 units and VLT 5032-5052, 200-240 V in IP20/IP21/NEMA 1 enclosure screened cables are connected by using EMC conduits to ensure proper EMC performance. See illustration. Other ways of making the installation may have as good an EMC performance, provided the above guide lines to engineering practice are followed.

Please note, that when the installation is not carried through according to the guideline as well as when unscreened cables and control wires are used, some emission requirements are not complied with, although the immunity requirements are fulfilled. See the section *EMC test results* in the Design Guide for further details.





**EC/EMC**

**■ Electrical installation, selection of EMC-correct cables**

Braided screened/armoured cables are recommended to optimise EMC immunity of the control cables and the EMC emission from the motor cables.

The ability of a cable to reduce the in- and outgoing radiation of electric noise depends on the transfer impedance ( $Z_T$ ). The screen of a cable is normally designed to reduce the transfer of electric noise; however, a screen with a lower transfer impedance ( $Z_T$ ) value is more effective than a screen with a higher transfer impedance ( $Z_T$ ).



Transfer impedance ( $Z_T$ ) is rarely stated by cable manufacturers, but it is often possible to estimate transfer impedance ( $Z_T$ ) by assessing the physical design of the cable.

Transfer impedance ( $Z_T$ ) can be assessed on the basis of the following factors:

- The conductivity of the screen material.
- The contact resistance between the individual screen conductors.
- The screen coverage, i.e. the physical area of the cable covered by the screen - often stated as a percentage value.
- Screen type, i.e. braided or twisted pattern.

Aluminium-clad with copper wire.

Twisted copper wire or armoured steel wire cable.

Single-layer braided copper wire with varying percentage screen coverage.

This is the typical Danfoss reference cable.

Double-layer braided copper wire.

Twin layer of braided copper wire with a magnetic, screened/armoured intermediate layer.

Cable that runs in copper tube or steel tube.

Lead cable with 1.1 mm wall thickness.

### ■ Application configuration

Using this parameter enables the choice of a configuration (setting) of the adjustable frequency drive that fits the application in which the adjustable frequency drive is to be active.



#### NOTE

First, the motor nameplate date must be set in parameters 102-106.

- Speed control, open loop
- Speed control, closed loop
- Process control, closed loop
- Torque control, open loop
- Torque control, speed feedback

The selection of special motor characteristics can be combined with any application configuration.

There is a choice of the following configurations:

### ■ Setting of parameters

Select *Speed control, open loop* if a normal speed adjustment without external feedback signals is required

Speed control, open loop:		
Parameter:	Setting:	Data value:
100 Configuration	Speed control, open loop	[0]
200 Output frequency range/direction		
201 Output frequency low limit	Only if [0] or [2] in par. 200	
202 Output frequency high limit		
203 Reference/feedback range		
204 Minimum reference	Only if [0] in par. 203	
205 Maximum reference		

Select *Speed control, closed loop* if the application has a feedback signal and the accuracy in *Speed control, open loop* is not sufficient or a full holding torque is required.

(the internal slip compensation is operating) from motor or unit.

Set the following parameters in order shown:

Speed control, closed loop (PID):		
Parameter:	Setting:	Data value:
100 Configuration	Speed control, closed loop	[1]
200 Output frequency range/direction	Output frequency low limit	
201 Output frequency low limit		
202 Output frequency high limit		
203 Reference/feedback range		
414 Minimum feedback	Only if [0] or [2] in par. 200	
415 Maximum feedback		
204 Minimum reference	Only if [0] in par. 203	
205 Maximum reference		
417 Speed PID proportional gain		
418 Speed PID integration time		
419 Speed PID differentiation time		
420 Speed PID diff. gain limit		
421 Speed PID lowpass filter time		

Please be aware that the encoder loss function (parameter 346) will be active when parameter 100 is set to *Speed control, closed loop*.

Select *Process control, closed loop* if the application has a feedback signal that is not directly related to motor speed (rpm/Hz), but some other unit, such as tem-

perature, pressure, etc. Set the following parameters in the order shown:

Process control, closed loop (Process PID):

Parameter:	Setting:	Data value:
100 Configuration	Process control, closed loop	[3]
200 Output frequency range/direction		
201 Output frequency low limit		
202 Output frequency high limit		
203 Reference/feedback range		
414 Minimum feedback	Only if [0] or [2] in par. 200	
415 Maximum feedback		
204 Minimum reference	Only if [0] in par. 203	
205 Maximum reference		
416 Process units		
437 Process PID normal/inverse		
438 Process PID anti-windup		
439 Process PID start frequency		
440 Process PID proportional gain		
441 Process PID integration time		
442 Process PID differentiation time		
443 Process PID diff. gain limit		
444 Process PID lowpass filter		

Select *Torque control, open loop* if PI control is required, to change the motor frequency in order to maintain the torque reference (Nm).

This is relevant for winding and extrusion applications.

*Torque control, open loop*, is to be selected if the speed direction is not to be changed during operation; this

means that either a positive or a negative torque reference is used at all times.

Set the following parameters in order shown:

Torque control, open loop:

Parameter:	Setting:	Data value:
100 Configuration	Torque control, open loop	[4]
200 Output frequency range/direction		
201 Output frequency low limit		
202 Output frequency high limit		
203 Reference/feedback range		
204 Minimum reference	Only if [0] in par. 203	
205 Maximum reference		
414 Minimum feedback		
415 Maximum feedback		
433 Torque proportional gain		
434 Torque integration time		

Select *Torque control, speed feedback*, if an encoder feedback signal is to be generated. This is relevant in winder and extruder applications.

*Torque control, speed feedback*, is selected if it is to be possible to change the speed direction, while at the same time maintaining the torque reference.

Set the following parameters in order shown:

Torque control, speed feedback:		
Parameter:	Setting:	Data value:
100 Configuration	Torque control, speed feedback	[5]
200 Output frequency, range/direction		
201 Output frequency, low limit		
202 Output frequency, high limit		
203 Reference/feedback range		
204 Minimum reference	Only if [0] in par. 203	
205 Maximum reference		
414 Minimum feedback		
415 Maximum feedback		
306 Encoder feedback, input B		[24]
307 Encoder feedback, input A		[25]
329 Encoder feedback, pulse/rev		
421 Speed PID low-pass filter time		
448 Gear ratio		
447 Torque regulation, speed feed-back		
449 Friction loss		

After *Torque control, speed feedback*, has been selected, the adjustable frequency drive should be calibrated to ensure that the current torque equals the torque of the adjustable frequency drive. For this to be ensured, a torque gauge must be fitted to the shaft so as to enable accurate adjustment of parameter 447, *Torque compensation*, and parameter 449, *Friction loss*. It is recommended to run an AMA before torque calibration. Proceed as follows before beginning to use the system:

1. Fit a torque gauge to the shaft.
2. Start the motor with a positive torque reference and a positive direction of rotation.  
Read the torque gauge.
3. Using the same torque reference, change the direction of rotation from positive to negative.

Read the torque and adjust it to the same level as for the positive torque reference and direction of rotation. This can be done by means of parameter 449, *Friction loss*.

4. Using a warm motor and approx. 50% load, set parameter 447, *Torque compensation*, to match the torque gauge. The adjustable frequency drive is now ready for operation.

Select *Special motor characteristics* if the adjustable frequency drive is to be adapted to a synchronous motor, parallel motor operation or if slip-compensation is not required.

Set the following parameters in order shown:

Special motor characteristics:		
Parameter:	Setting:	Data value:
101 Torque characteristics	Special motor characteristics	[5] or [15]
432 + 431 F5 frequency/U5 voltage		
430 + 429 F4 frequency/U4 voltage		
428 + 427 F3 frequency/U3 voltage		
426 + 425 F2 frequency/U2 voltage		
424 + 423 F1 frequency/U1 voltage		
422 U0 voltage		

**■ Local and remote control**

The adjustable frequency drive can be operated manually or remotely. The following is a list of the functions/

commands given via the control panel, the digital inputs or the serial communication port in the two situations (modes).

If parameter 002 is set to Local [1]:

On the LCP, the following keys can be used for local control:

Key:	Parameter:	Data value:
[STOP]	014	[1] Enable
[JOG]	015	[1] Enable
[RESET]	017	[1] Enable
[FWD/REV]	016	[1] Enable

Set parameter 013 for LCP control and open loop [1] or LCP control as parameter 100 [3]:

1. Local reference is set in parameter 003; can be changed via the "+/-" keys.
2. Reversing can be effected by means of the [FWD/REV] key.

Set parameter 013 for LCP digital control and open loop [2] or LCP digital control as parameter 100 [4]:

For the above parameter setting, it is now possible to control the adjustable frequency drive as follows:

Digital inputs:

1. Local reference set in parameter 003 can be changed via the "+/-" keys.
2. Reset via digital terminal 16, 17, 29, 32 or 33.
3. Stop inverse via digital terminal 16, 17, 27, 29, 32 or 33.
4. Choice of Setup, lsb via digital terminal 16, 29 or 32.
5. Choice of Setup, msb via digital terminal 17, 29 or 33.
6. Ramp 2 via digital terminal 16, 17, 29, 32 or 33.
7. Quick-stop via digital terminal 27.
8. DC braking via digital terminal 27.

9. Reset and motor coasting stop via digital terminal 27.

10. Motor coasting stop via digital terminal 27.
11. Reversing via digital terminal 19.
12. Choice of Setup, msb/speed up via digital terminal 32.
13. Choice of Setup, lsb/speed down via digital terminal 33.

The serial communication port:

1. Ramp 2
2. Reset
3. Choice of Setup, lsb
4. Choice of Setup, msb
5. Relay 01
6. Relay 04

If parameter 002 is set to Remote control [0]:

Key:	Parameter:	Data value:
[STOP]	014	[1]
[JOG]	015	[1]
[RESET]	017	[1]

### ■ Control with brake function

The function of the brake is to limit the voltage in the intermediate circuit when the motor is acting as a generator. This occurs, for example, when the load drives the motor and the power enters the intermediate circuit. The brake is built up in the form of a chopper circuit with the connection of an external brake resistor. Placing the brake resistor externally offers the following advantages:

- The brake resistor can be selected on the basis of the application in question.
- The brake energy is dissipated outside the control panel, i.e. where the energy can be utilized.
- The electronics of the adjustable frequency drive will not be overheated if the brake resistor is overloaded.

The brake is protected against short-circuiting of the brake resistor, and the brake transistor is monitored to ensure that short-circuiting of the transistor is detected. By using a relay/digital output, the latter can be used for protecting the brake resistor against overloading in connection with a fault in the adjustable frequency drive.

In addition, the brake makes it possible to read out the momentary power and the mean power for the latest 120 seconds, as well as to monitor that the power energizing does not exceed a monitoring limit selected via parameter 402. In parameter 403 select the function to be carried out when the power transmitted to the brake resistor exceeds the limit set in parameter 402.



#### NOTE

Monitoring of the brake power is not a safety function; a thermal switch is required for that purpose. The brake resistor circuit is not earth leakage protected.

### ■ Selection of Brake Resistor


In order to select the right brake resistor, information on how often to brake and by the level power braking is effected must be available.

The resistor ED is an indication of the duty cycle at which the resistor is working.

The resistor ED is calculated as follows:

$$ED \text{ (duty cycle)} = \frac{tb}{T \text{ cycle}}$$

where tb is the braking time in seconds and T cycle is the total cycle time.



The maximum permissible load on the brake resistor is stated as a peak power at a given ED. The following example and formula apply to VLT 5000 only. The peak power can be calculated on the basis of the highest brake resistance required for braking:

$$P_{PEAK} = P_{MOTOR} \times M_{BR}(\%) \times \bullet_{MOTOR} \times \bullet_{VLT} [W]$$

where  $M_{BR}(\%)$  is a percentage of the rated torque.

The brake resistance is calculated as follows:

$$R_{REC} = \frac{U^2 \cdot DC}{P_{PEAK}} [\Omega]$$

The brake resistance depends on the intermediate circuit voltage (UDC).

The brake will be active at the following voltages:

- 3 x 200-220 V: 397 V
- 3 x 380-500 V: 822 V
- 3 x 525-600 V: 943 V
- 3 x 525-690 V: 1084 V



#### NOTE

The brake resistor used must be rated to 430 Volts, 850 Volts, 960 Volts or 1100 Volts, unless Danfoss brake resistors are used.

$R_{REC}$  is the resistance recommended by Danfoss, i.e., one that guarantees the user that the adjustable frequency drive is able to brake at the highest braking torque ( $M_{br}$ ) of 160%.

$\bullet_{MOTOR}$  is typically at 0.90, while  $\bullet_{VLT}$  is typically at 0.98.  $R_{REC}$  at 160% braking torque can be written as:

$$R_{REC} = \frac{111.684}{P_{MOTOR}} [\Omega] \text{ at } 200 \text{ V}$$

$$R_{REC} = \frac{478.801}{P_{MOTOR}} [\Omega] \text{ at } 500 \text{ V}$$

$$R_{REC} = \frac{630.137}{P_{MOTOR}} [\Omega] \text{ at } 600 \text{ V}$$

$$R_{REC} = \frac{855.868}{P_{MOTOR}} [\Omega] \text{ at } 690 \text{ V}$$

P motor in kW.



#### NOTE

The max. brake resistance selected should have an ohmic value max. 10% lower than that recommended by Danfoss. If a brake resistor with a higher ohmic value is selected, the 160% braking



torque will not be achieved and there is a risk that the adjustable frequency drive will cut out for safety reasons. For further information, please consult Brake Resistor Instruction MI.90.FX.YY.

#### NOTE

If a short circuit in the brake transistor occurs, power dissipation in the brake resistor can only be prevented by using a line power switch or contactor to disconnect the power for the adjustable frequency drive. (The contactor can be controlled by the adjustable frequency drive).

#### ■ References - single references

Using a single reference, only one active reference signal is connected, either in the form of an external or in the form of a preset (internal) reference.

The external reference can be voltage, current, frequency (pulse) or binary via the serial port. Two examples are given below of the way the single references are handled by VLT 5000 Series.


#### Example 1:

External reference signal = 1 V (min) - 5 V (max)

Reference = 5 Hz - 50 Hz

Configuration (parameter 100) - Speed control, open loop.

	U/f on terminal 53, 54 or 60. f (pulse) on terminal 17 or 29 binary (serial port).
/ External	
\ Preset references (par.215-218)	




Setting: Parameter:	Setting: Speed control, open loop	Data value: [0]
100 Configuration	Reference	[1]
308 Funct. of analog input	Min.	1 V
309 Min. reference signal	Max.	5 V
310 Max. reference signal	Reference range	Min - Max [0]
203 Reference range	Min. reference	5 (Hz)
204 Minimum reference	Max. reference	50 (Hz)
205 Maximum reference		
The following can be used:	<ul style="list-style-type: none"> <li>- Catch-up/slow-down via digital input terminals 16,17, 29, 32 or 33</li> <li>- Freeze reference via digital input terminals 16,17, 29, 32 or 33.</li> </ul>	

**Example 2:**

External reference signal = 0 V (min) - 10 V (max)

Reference = -50 Hz ccw - 50 Hz cw

Configuration (parameter 100) = Speed control, open loop.



Setting:	Parameter:	Setting:	Data value:
100	Configuration	Speed control, open loop	[0]
308	Funct. of analog input	Reference	[1]
309	Min. reference signal	Min.	0 V
310	Max. reference signal	Max.	10 V
203	Reference range	Reference range	- Max - + Max [1]
205	Max. reference		100 Hz
214	Reference type	Sum	[0]
215	Preset reference		-50%
200	Output frequency range/direction	Both directions, 0-132 Hz	[1]

The following can be used:

- Catch-up/slow-down via digital input terminals 16,17, 29, 32 or 33
- Freeze reference via digital input terminals 16,17, 29, 32 or 33.





### ■ References - multi-references


If the multi-reference is used, two or more reference signals are connected, either in the form of external or preset reference signals. Via parameter 214 these can be combined in three different ways:

- / Sum
- Multi-ref. – Relative
- \ External/preset

In the following, each reference type (sum, relative and external/preset) is shown:


#### SUM




**RELATIVE**


List of functions

## EXTERNAL/PRESET



## References



List of functions

### ■ Automatic Motor Adaptation, AMA

Automatic motor adaptation is a test algorithm that measures the electrical motor parameters at a motor standstill. This means that AMA itself does not supply any torque.

AMA is useful when commissioning systems, where the user wants to optimise the adjustment of the frequency converter to the motor applied. This feature is used in particular where the factory setting does not adequately cover the motor in question.

There are two motor parameters that are of primary significance in automatic motor adaptation: the stator resistance,  $R_s$ , and the reactance at normal magnetising level,  $X_s$ . Parameter 107 allows a choice of automatic motor adaptation, with determination of both  $R_s$  and  $X_s$ , or reduced automatic motor adaptation with determination of only  $R_s$ .

The duration of a total automatic motor adaptation varies from a few minutes on small motors to more than 10 minutes on large motors.

#### Limitations and preconditions:

- For AMA to be able to determine the motor parameters optimally, the correct nameplate data for the motor connected to the frequency converter must be entered in parameters 102 to 106.
- For the best adjustment of the frequency converter, it is recommended to carry out AMA on a cold motor. Repeated AMA runs may lead to a heating of the motor that will result in an increase of the stator resistance,  $R_s$ .
- AMA can only be carried out if the rated motor current is minimum 35% of the rated output current of the frequency converter. AMA can be carried out up to one oversize motor.
- If a LC filter is inserted between the frequency converter and the motor, it will only be possible to carry out a reduced test. If an overall setting is required, remove the LC filter while running a total AMA. After completion of the AMA reinsert the LC filter.
- If motors are coupled in parallel only use reduced AMA if any.
- When using synchronous motors it is only possible to make a reduced AMA.

- Long motor cables can have an effect on the implementation of the AMA function if their resistance is bigger than the stator resistance of the motor.

#### How to perform an AMA

1. Press the [STOP/RESET] key
2. Set motor nameplate data in parameters 102 to 106
3. Select whether a total [ENABLE (RS,XS)] or a reduced [ENABLE RS] AMA is required in parameter 107
4. Connect terminal 12 (24 VDC) to terminal 27 on the control card
5. Press the [START] key or connect terminal 18 (start) to terminal 12 (24 VDC) to start the automatic motor adaptation.

Now the automatic motor adaptation goes through four tests (for reduced AMA only the first two tests). The different tests can be followed in the display as dots after the text **WORKING** in parameter 107:

1. Initial error check where nameplate data and physical errors are checked. Display shows **WORKING**.
2. DC test where the stator resistance is estimated. Display shows **WORKING..**
3. Transient test where the leakage inductance is estimated. Display shows **WORKING...**
4. AC test where the stator reactance is estimated. Display shows **WORKING....**



#### NOTE

AMA can only be carried out if there are no alarms during tuning.

#### Discontinue AMA

If the automatic motor adaptation is to be discontinued, press the [STOP/RESET] key or disconnect terminal 18 from terminal 12.

The automatic motor adaptation ends up with one of the following messages after the test:

**Warnings and alarm messages****ALARM 21****Auto-optimisation OK**

Press the [STOP/RESET] key or disconnect terminal 18 from terminal 12. This alarm indicates that the AMA is OK and that the drive is correctly adapted to the motor.

**ALARM 22****Auto-optimisation not OK****[AUTO MOTOR ADAPT OK]**

A fault has been found during automatic motor adaptation. Press the [STOP/RESET] key or disconnect terminal 18 from terminal 12. Check the possible cause to the fault related to the alarm message given. The figure after the text is the error code, which can be seen in the fault log in parameter 615. Automatic motor adaptation does not update parameters. You may choose to run a reduced automatic motor adaptation.

**CHECK P.103,105 [0]**

**[AUTO MOT ADAPT FAIL]** Parameter 102, 103 or 105 has a wrong setting. Correct the setting and start AMA all over.

**LOW P.105 [1]**

The motor is too small for AMA to be carried out. If AMA is to be enabled, the rated motor current (parameter 105) must be higher than 35% of the rated output current of the frequency converter.

**ASYMMETRICAL IMPEDANCE [2]**

AMA has detected an asymmetrical impedance in the motor connected to the system. The motor could be defective.

**MOTOR TOO BIG [3]**

The motor connected to the system is too big for AMA to be carried out. The setting in parameter 102 does not match the motor used.

**MOTOR TOO SMALL [4]**

The motor connected to the system is too small for AMA to be carried out. The setting in parameter 102 does not match the motor used.

**TIME OUT [5]**

AMA fails because of noisy measuring signals. Try to start AMA all over a number of times, until AMA is carried out. Please note that repeated AMA runs may heat the motor to a level where the stator resistance RS is increased. In most cases, however, this is not critical.

**INTERRUPTED BY USER [6]**

AMA has been interrupted by the user.

**INTERNAL FAULT [7]**

An internal fault has occurred in the frequency converter. Contact your Danfoss supplier.

**LIMIT VALUE FAULT [8]**

The parameter values found for the motor are outside the acceptable range within which the frequency converter is able to work.

**MOTOR ROTATES [9]**

The motor shaft rotates. Make sure that the load is not able to make the motor shaft rotate. Then start AMA all over.

**WARNING 39 - 42**

A fault have been encountered during automatic motor adaptation. Check the possible fault causes in accordance with the warning message. Press the [CHANGE DATA key and select "CONTINUE" if AMA is to continue despite the warning or press the [STOP/RESET] key or disconnect terminal 18 from terminal 12 to discontinue AMA.

**WARNING: 39****CHECK P.104,106**

The setting of parameter 102, 104 or 106 is probably wrong. Check the setting and choose 'Continue' or 'Stop'.

**WARNING: 40****CHECK P.103,105**

The setting of parameter 102, 103 or 105 is probably wrong. Check the setting and choose 'Continue' or 'Stop'.

**WARNING: 41****MOTOR TOO BIG**

The motor used is probably too big for AMA to be carried out. The setting in parameter 102 may not match the motor. Check the motor and choose 'Continue' or 'Stop'.

**WARNING: 42****MOTOR TOO SMALL**

The motor used is probably too small for AMA to be carried out. The setting in parameter 102 may not match the motor. Check the motor and choose 'Continue' or 'Stop'.

### ■ Mechanical brake control

For hoisting applications, it is necessary to be able to control an electro-magnetic brake.

For controlling the brake, a relay output (01 or 04) is required. This output must be kept closed (voltage-free) during the time when the adjustable frequency drive is not able to 'hold' the motor, due to a load that is too large, for example. In parameter 323 or 326 (relay outputs 01, 04), select *Mechanical brake control* [32] or *Extended mechanical brake control* [34] for applications with an electro-magnetic brake.

During start/stop and ramp-down, the output current is monitored. If *Mechanical brake control* [32] is selected and the current is below the level selected in parameter 223 *Warning: Low current*, the mechanical brake is closed (voltage-free).

As a point of departure, a current can be selected which is approx. 70% of the magnetizing current. Parameter 225 *Warning: Low frequency* states the frequency during ramp-down at which the mechanical brake is to close again.

If Extended mechanical brake control [34] is selected the mechanical brake is closed (voltage-free) during

start until the output current is above the level selected in parameter 223 *Warning: Low Current*.

During stop mechanical brake is released until the frequency is below the level selected in parameter 225 *Warning: Low frequency*.

Notice by *Extended mechanical brake control* [34] that the brake does not close if the output current falls under parameter 223 *Warning: Low current*.

Nor does a current low level warning appear.

In extended mechanical brake mode, an overcurrent trip (alarm 13) can be reset by an external reset.

If the adjustable frequency drive is brought into an alarm condition or an overcurrent or overvoltage situation, the mechanical brake will immediately cut in.



### NOTE

The application shown is only for hoisting without counterweight.


#### Control of mechanical brake:

Parameter:	Setting:	Data value:
323 Relay 01 or par. 326 relay 04	Mechanical brake control	[32]
323 Relay 01 or par. 326 relay 04	Extended mechanical brake control	[34]
223 Warning: Low current	approx. 70% of magnetizing current <sup>1)</sup>	
225 Warning: Low frequency	3-5 Hz <sup>2)</sup>	
122 Function at stop	Pre-magnetization	[3]
120 Start delay time	0.1-0.3 sec	
121 Start function	Start frequency/voltage clockwise <sup>3)</sup>	[3]
130 Start frequency	Set to slip frequency	
131 Initial voltage	The voltage must correspond to the frequency that has been set in parameter 130.	

1. During start and stop, the current limit in parameter 223 determines the switching level.
2. This value indicates the frequency during ramp-down at which the mechanical brake is to be closed again. This assumes that a stop signal has been given.
3. It must be ensured that the motor starts clockwise (hoist), since otherwise the adjustable frequency drive may drop the load. Switch U, V, W connections, if required.


## Mechanical brake control

1757A253.11



## Extended mechanical brake control

List of functions



$t_2-t_1$  and  $t_6-t_5$  = reaction time of mech. brake  
 $t_3-t_4$  = motor current below current low level

## ■ PID for process control

### Feedback

The feedback signal must be connected to a terminal on the adjustable frequency drive. Use the list below to decide which terminal is to be used and which parameters are to be programmed.

Feedback type	Terminal	Parameters
Pulse	33	307
Voltage	53	308, 309, 310
Current	60	314, 315, 316

Furthermore, the minimum and maximum feedback (parameters 414 and 415) must be set to a value in the process unit that corresponds to the minimum and maximum value on the terminal.

Select process unit in parameter 416.

### Reference

A minimum and a maximum reference can be set (204 and 205), which limit the sum of all references. The reference range cannot exceed the feedback range. If one or several setpoint references are required, the simplest way is to set such reference directly in parameters 215 to 218. Select between the preset references by connecting terminals 16, 17, 29, 32 and/or 33 to terminal 12. Which terminals that are used depends on the choice made in the parameters of the various terminals (parameters 300, 301, 305, 306 and/or 307). Use the table below when selecting preset references.

	Preset ref. msb	Preset ref. lsb
Preset ref. 1 (par. 215)	0	0
Preset ref. 2 (par. 216)	0	1
Preset ref. 3 (par. 217)	1	0
Preset ref. 4 (par. 218)	1	1

If an external reference is required, this can either be an analog or a pulse reference. If current is used as a feedback signal, only voltage can be used as an analog reference. Use the following list to decide which terminal to use and which parameters to program.

Reference type	Terminal	Parameters
Pulse	17 or 29	301 or 305
Voltage	53 or 54	308, 309, 310 or 311, 312, 313
Current	60	314, 315, 316

Relative references can be programmed. A relative reference is a percentage value (Y) of the sum of the external references (X). This percentage value is added to the sum of the external references, which produces the active reference ( $X + XY$ ). See section *Handling of multi references*.

If relative references are to be used, parameter 214 is to be set to *Relative* [1]. This makes the preset references relative. Furthermore, *Relative reference* [4] can be programmed on terminal 54 and/or 60. If an external relative reference is selected, the signal on the input will be a percentage value of the full range of the terminal. The relative references are added with signs.



### **NOTE**

Terminals that are not in use should preferably be set to *No function* [0].

### Inverse control

If the drive has to react with increasing speed on and increasing feedback, *Inverse* must be selected in parameter 437. Normal control means that the motor speed decreases when the feedback signal increases.

### Anti Windup

The process controller comes with the anti windup function in active position. This function ensures that when either a frequency limit or a torque limit is reached, the integrator will be set to a gain that corresponds to the actual frequency. This avoids integrating on an error that cannot in any case be compensated for by means of a speed change. This function can be disabled in parameter 438.

### Start-up conditions

In some applications, optimum setting of the process controller will mean that it takes an excessive time for the desired process value to be reached. In such applications it might be an advantage to fix a motor frequency to which the adjustable frequency drive is to bring the motor before the process controller is activated. This is done by programming a *Process PID start frequency* in parameter 439.

#### Differentiator gain limit

If there are quick changes in reference or feedback in a given application - which means that the error changes swiftly - the differentiator may soon become too dominant. This is because it reacts to changes in the error. The quicker the error changes, the stronger the differentiator gain is. The differentiator gain can thus be limited to allow setting of the reasonable differentiation time for slow changes and a suitably quick gain for quick changes. This is done in parameter 443, *Process PID Differentiator gain limit*.

#### Lowpass filter

If there are oscillations of the current/voltage feedback signal, these can be damped by means of a lowpass filter. Set a suitable lowpass filter time constant. This time constant represents the limitfrequency of the ripples occurring on the feedback signal. If the lowpass filter has been set to 0.1s, the limit frequency will be 10 RAD/sec., corresponding to  $(10/2 \times \pi) = 1.6$  Hz. This will mean that all currents/voltages that vary by more than 1.6 oscillations per second will be removed by the filter. In other words, control will only be carried out on a feedback signal that varies by a frequency of less than 1.6 Hz. Choose a suitable time constant in parameter 444, *Process PID Lowpass filter*.

#### Optimisation of the process controller

The basic settings have now been made; all that needs to be done is to optimise the proportional gain, the integration time and the differentiation time (parameters 440, 441, 442). In most processes, this can be done by following the guidelines given below.

1. Start the motor
2. Set parameter 440 (proportional gain) to 0.3 and increase it until the feedback signal again begins to vary continuously. Then reduce the value until the feedback signal has stabilised. Now lower the proportional gain by 40-60%.
3. Set parameter 441 (integration time) to 20s and reduce the value until the feedback signal again begins to vary continuously. Increase the integration time until the feedback signal stabilises, followed by an increase of 15-50%.
4. Only use parameter 442 for very fast-acting systems only (differentiation time). The typical value is four times the set integration time.

The differentiator should only be used when the setting of the proportional gain and the integration time has been fully optimised.

#### **NOTE**

If necessary, start/stop can be activated a number of times in order to provoke a variation of the feedback signal.

### ■ PID for speed control

#### Feedback

Use the list below to decide which terminal to use for the feedback signal and which parameters to program.

Feedback type	Terminal	Parameters
Pulse	32	306
Pulse	33	307
Feedback pulse/rev.		329
Voltage	53	308, 309, 310
Current	60	314, 315, 316

Furthermore, the minimum and maximum feedback (parameters 414 and 415) are to be set to values in the process unit that correspond to the actual minimum and maximum process feedback values and units. The minimum feedback cannot be set to a value lower than 0. Choose unit in parameter 416.

#### Reference

A minimum and a maximum reference can be set (204 and 205) which limit the sum of all references. The reference range cannot exceed the feedback range. If one or several preset references are required, the simplest way of doing this is by setting such references directly in parameters 215 to 218. Choose between the preset references by connecting terminals 16,17,29,32 and/or 33 to terminal 12. Which of them that are to be used depends on the choice in the parameters of the terminals in question (parameters 300, 301, 305, 306 and/or 307). The table below can be used to select the preset references.

	Preset ref. msb	Preset ref. lsb
Preset ref. 1 (par. 215)	0	0
Preset ref. 2 (par. 216)	0	1
Preset ref. 3 (par. 217)	1	0
Preset ref. 4 (par. 218)	1	1

If an external reference is required, this can either by an analog reference or a pulse reference. If current is used as a feedback signal, voltage can be used as an analog reference. Use the list below to decide which terminal to use and which parameters to program.

Reference type	Terminal	Parameters
Pulse	17 or 29	301 or 305
Voltage	53 or 54	308, 309, 310 or 311, 312, 313
Current	60	314, 315, 316

Relative references can be programmed. A relative reference is a percentage value (Y) of the sum of the external references (X). This percentage value is added to the sum of the external references, which produces the active reference (X + XY). See drawing on pages 62 and 63.

If relative references are to be used, parameter 214 is to be set to *Relative* [1]. This makes the preset references relative. Furthermore, *Relative reference* [4] can be programmed on terminal 54 and/or 60. If an external relative reference is selected, the signal on the input will be a percentage value of the full range of the terminal. The relative references are added with signs.



#### NOTE

Terminals that are not in use should preferably be set to *No function* [0].

#### Differentiator gain limit

If there are quick changes in reference or feedback in a given application - which means that the error changes swiftly - the differentiator may soon become too dominant. This is because it reacts to changes in the error. The quicker the error changes, the stronger the differentiator gain is. The differentiator gain can thus be limited to allow setting of the reasonable differentiation time for slow changes and a suitably quick gain for quick changes. This is done in parameter 420, *Speed PID Differentiator gain limit*.

#### Lowpass filter

If are oscillations of the current/voltage on the feedback signal, these can be damped by means of a lowpass filter. Set a suitable lowpass filter time constant. This time constant represents the limit frequency of the ripples occurring on the feedback signal. If the lowpass filter has been set to 0.1s, the break frequency will be 10 RAD/sec., corresponding to  $(10/2 \times \pi) = 1.6$  Hz. This will mean that all currents/voltages that vary by more than 1.6 oscillations per second will be removed by the filter.

In other words, control will only be carried out on a feedback signal that varies by a frequency of less than 1.6 Hz. Choose a suitable time constant in parameter 421, *Speed PID Lowpass filter*.

#### ■ Quick discharge

This function is only available in EB units (extended with brake) of the following type:

- VLT 5001-5052, 200-240 V
- VLT 5001-5102, 380-500 V
- 5001-5062, 525-600 V

This function is used for discharging the capacitors in the intermediate circuit after the mains supply has been interrupted. This is a useful function for servicing the adjustable frequency drive and/or the motor installation. The motor must be stopped before quick discharge is activated. If the motor acts as a generator, quick discharge is not possible.

The quick discharge function can be selected via parameter 408. The function starts when the intermediate circuit voltage has dropped to a given value and the rectifier has stopped.

In order to obtain the possibility of a quick discharge, the adjustable frequency drive requires an external 24 V DC supply to terminals 35 and 36, as well as a suitable brake resistor on terminals 81 and 82.

For sizing of the discharge resistor for quick discharge, see Brake Instructions MI.50.DX.XX.



#### NOTE

Quick discharge is only possible if the adjustable frequency drive has 24 Volts external DC supply and if an external brake/discharge resistor has been connected.




Before servicing the installation (adjustable frequency drive + motor), it must be checked that the intermediate circuit voltage is below 60 V DC. This is done by measuring terminals 88 and 89, load-sharing.



#### NOTE

The power dissipation during quick discharge does not form part of the power monitoring function, parameter 403. When sizing resistors, this fact should be taken into consideration.



#### ■ Mains failure/quick discharge with mains failure inverse

The first column in the table shows *Mains failure*, which is selected in parameter 407. If no function is selected, the mains failure procedure will not be carried out. If *Controlled ramp-down* [1] is selected, the frequency converter will take the motor down to 0 Hz. If *Enable* [1] has been selected in parameter 408, a quick discharge of the intermediate circuit voltage will be carried out after the motor has stopped.

Using a digital input, it is possible to activate mains failure and/or quick discharge. This is done by select-

ing *Mains failure inverse* on one of the control terminals (16, 17, 29, 32, 33). *Mains failure inverse* is active in the logical '0' situation.



#### NOTE

The frequency converter can be completely damaged if the Quick-discharge function is repeated, using the digital input while mains voltage is on.

Mains failure par. 407	Quick discharge par. 408	Mains failure inverse digital in- put	Function
No function [0]	Disable [0]	Logical '0'	1
No function [0]	Disable [0]	Logical '1'	2
No function [0]	Enable [1]	Logical '0'	3
No function [0]	Enable [1]	Logical '1'	4
[1]-[4]	Disable [0]	Logical '0'	5
[1]-[4]	Disable [0]	Logical '1'	6
[1]-[4]	Enable [1]	Logical '0'	7
[1]-[4]	Enable [1]	Logical '1'	8

Function no. 1	Function no. 3
Mains failure and quick discharge are not active.	The digital input activates the quick discharge function, regardless of the intermediate circuit voltage level and regardless of whether the motor is running.
Function no. 2	

Mains failure and quick discharge are not active.

#### Function no. 4

Quick discharge is activated when the intermediate circuit voltage has dropped to a given value and the inverters have stopped. See procedure on previous page.

#### Function no. 5

The digital input activates the mains failure function, regardless of whether the unit receives any supply voltage. See the different functions in parameter 407.

#### Function no. 6

The mains failure function is activated when the intermediate circuit voltage has dropped to a given value. The selected function in case of mains failure is selected in parameter 407.

#### Function no. 7

The digital input activates both the quick discharge and the mains failure function, regardless of the intermediate circuit voltage level and regardless of whether the motor is running. First the mains failure function will be active; subsequently there will be a quick discharge.

#### Function no. 8

Quick discharge and mains failure function are activated when the intermediate circuit level drops to a given level.

First the mains failure function will be active; subsequently there will be a quick discharge.


### ■ Flying start

This function makes it possible to "catch" a motor that is spinning freely and for the frequency converter to take control of the motor speed. This function can be enabled or disabled via parameter 445.


If *flying start* has been selected, there will be four situations in which the function is activated:

1. After a coast has been given via terminal 27.
2. After power-up.
3. If the frequency converter is in a trip state and a reset signal has been given.
4. If the frequency converter releases the motor because of a fault state and the fault disappears before a trip, the frequency converter will catch the motor and go back to the reference.

#### 1. Flying start is active.




#### 2. Flying start is active.




The search sequence for the spinning motor depends on *Rotation, frequency/direction* (parameter 200). If only *clockwise* is selected, the frequency converter will start looking from *Maximum frequency* (parameter 202) down to 0 Hz. If the frequency converter does not find the spinning motor during the search sequence, it will carry out a DC braking so as to try to bring the speed of the spinning motor down to 0 rpm. This requires that the DC brake is active via parameters 125 and 126. If *Both directions* is selected, the frequency converter will first find out in which direction the motor rotates and then search for the frequency. If the motor is not found, the system assumes that the motor is at a standstill or is rotating at a low speed, and the frequency converter will start the motor in the normal way after searching.

3. The frequency converter trips and *Flying start* is active.



4. The frequency converter momentarily releases the motor. *Flying start* is activated and catches the motor again.



List of functions

### ■ Normal/high overload torque control, open loop

This function enables the adjustable frequency drive to perform a constant 100% torque, using an oversize motor.

The choice between a normal or a high overload torque characteristic is made in parameter 101.

This is also where to choose between a high/normal constant torque characteristic (CT) or a high/normal VT torque characteristic.

If a *high torque characteristic* is chosen, a rated motor with the adjustable frequency drive obtains up to 160% torque for 1 min. in both CT and VT. If a *normal torque characteristic* is chosen, an oversize motor allows up to 110% torque performance for up to 1 min. in both CT and VT. This function is used mainly for pumps and fans, since these applications do not require an overload torque.

The advantage of choosing a normal torque characteristic for an oversize motor is that the adjustable frequency drive will be able constantly to yield 100% torque, without derating as a result of a bigger motor.



#### NOTE

This function cannot be chosen for VLT 5001-5006, 200-240 Volts, and VLT 5001-5011, 380-500 Volts.

### ■ Internal current regulator

The VLT 5000 features an integral current limit regulator which is activated when the motor current, and thus the torque, is higher than the torque limits set in parameter 221 and 222.

When VLT 5000 Series is at the current limit during motor operation or regenerative operation, the adjustable frequency drive will try to get below the preset torque limits as quickly as possible without losing control of the motor.

While the current regulator is active, the adjustable frequency drive can *only* be stopped by means of terminal 27 if set to *Coasting stop, inverse [0]* or *Reset and coasting stop, inverse [1]*. A signal on terminals 16-33 will *not* be active until the adjustable frequency drive has moved away from the current limit.

Please note that the motor will not use the ramp-down time, since terminal 27 must be programmed for *Coasting stop, inverse [0]* or *Reset and coasting stop, inverse [1]*.

### ■ Programming of Torque limit and stop

In applications with an external electro-mechanical brake, such as hoisting applications, it is possible to stop the adjustable frequency drive via a 'standard' stop command, while at the same time activating the external electro-mechanical brake.


The example given below illustrates the programming of adjustable frequency drive connections.

The external brake can be connected to relay 01 or 04, see Control of mechanical brake on page 66. Program terminal 27 to *Coasting stop, inverse [0]* or *Reset and coasting stop, inverse [1]*, as well as terminal 42 to *Torque limit and stop [27]*.

#### Description:

If a stop command is active via terminal 18 and the adjustable frequency drive is not at the torque limit, the motor will ramp down to 0 Hz.

If the adjustable frequency drive is at the torque limit and a stop command is activated, terminal 42 *Output* (programmed to *Torque limit and stop [27]*) will be activated. The signal to terminal 27 will change from 'logic 1' to 'logic 0' and the motor will start coasting.



- Start/stop via terminal 18.  
Parameter 302 = *Start [1]*.
- Quickstop via terminal 27.  
Parameter 304 = *Coasting stop, inverse [0]*.
- Terminal 42 Output  
Parameter 319 = *Torque limit and stop [27]*.
- Terminal 01 Relay output  
Parameter 323 = *Mechanical brake control [32]*.

### ■ Galvanic Isolation (PELV)

PELV offers protection by way of extra low voltage. Protection against electric shock is considered to be ensured when the electrical supply is of the PELV type and the installation is made as described in local/national regulations on PELV supplies.

All control terminals and relay terminals 01-03 comply with PELV (Protective Extra Low Voltage) (Does not apply to 525-600 V units).


Galvanic (ensured) isolation is obtained by fulfilling requirements concerning higher isolation and by providing the relevant creepage/clearance distances. These requirements are described in the EN 50178 standard.

The components that make up the electrical isolation, as described below, also comply with the requirements concerning higher isolation and the relevant test as described in EN 50178.

The galvanic isolation can be shown in five locations (see drawing below), namely:

1. Power supply (SMPS) incl. signal isolation of U<sub>DC</sub>, indicating the intermediate current voltage.
2. Gate drive that runs the IGBTs (trigger transformers/opto-couplers).
3. Current transducers (Hall effect current transducers).
4. Opto-coupler, brake module.
5. Opto-coupler, 24 V external supply.

Galvanic isolation



### ■ Earth leakage current

Earth leakage current is primarily caused by the capacitance between motor phases and the motor cable screen. When an RFI filter is used, this contributes additional leakage current, as the filter circuit is connected to earth through capacitors.

The size of the leakage current to the ground depends on the following factors, in order of priority:

1. Length of motor cable
2. Motor cable with or without screen
3. Switching frequency
4. RFI filter used or not
5. Motor grounded on site or not

The leakage current is of importance to safety during handling/operation of the adjustable frequency drive if (by mistake) the adjustable frequency drive has not been earthed.



#### NOTE

Since the leakage current is >3.5 mA, reinforced earthing must be established, which is required if EN 50178 is to be complied with. For 3-phased adjustable frequency drives, only fault current relays which are suitable for protection against DC currents (Din VDE 0664) are to be used. RCD fault current relays type B comply with these requirements according to the norm IEC 755-2.



---

## VLT® 5000 Series

---

The following requirements must be complied with:

- Suitable for protecting equipment with a direct current content (DC) in the fault current (3-phase rectifier)
- Suitable for power-up with short pulse-shaped charging current to earth
- Suitable for a high leakage current.

**■ Extreme Running Conditions**Short circuit

The adjustable frequency drive is protected against short circuits by means of current measurement in each of the three motor phases. A short circuit between two output phases will cause an overcurrent in the inverter. However, each transistor of the inverter will be turned off individually when the short circuit current exceeds the permitted value.

After 5-10 µs the driver card turns off the inverter and the adjustable frequency drive will display a fault code, although depending on impedance and motor frequency.

Earth fault

The inverter cuts out within a few µs in case of an earth fault on a motor phase, although depending on impedance and motor frequency.

Switching on the output

Switching on the output between the motor and the adjustable frequency drive is fully permitted. It is not possible to damage VLT 5000 Series in any way by switching on the output. However, fault messages may appear.

Motor-generated overvoltage

The voltage in the intermediate circuit is increased when the motor acts as a generator. This occurs in two cases:

1. The load drives the motor (at constant output frequency from the adjustable frequency drive), ie. the load generates energy.

2. During deceleration ("ramp-down") if the moment of inertia is high, the load is low and the ramp-down time is too short for the energy to be dissipated as a loss in the adjustable frequency drive, the motor and the installation.

The control unit attempts to correct the ramp if possible.

The inverter turns off to protect the transistors and the intermediate circuit capacitors when a certain voltage level is reached.

Mains drop-out

During a mains drop-out, the adjustable frequency drive continues until the intermediate circuit voltage drops below the minimum stop level, which is typically 15% below the adjustable frequency drive's lowest rated supply voltage.

The time before the inverter stops depends on the mains voltage before the drop-out and on the motor load.

Static overload

When the adjustable frequency drive is overloaded (the torque limit in parameter 221/222 has been reached), the controls will reduce the output frequency in an attempt to reduce the load.

If the overload is excessive, a current may occur that makes the adjustable frequency drive cut out after approx. 1.5 sec.

Operation within the torque limit can be limited in time (0-60 s) in parameter 409.

## VLT® 5000 Series

### ■ Peak voltage on motor

When a transistor in the inverter is opened, the voltage across the motor increases by a dU/dt ratio that depends on:

- the motor cable (type, cross-section, length, shielded or unshielded)
- inductance

The natural induction causes an overshoot  $U_{PEAK}$  in the motor voltage before it stabilizes itself at a level which depends on the voltage in the intermediate circuit. The rise time and the peak voltage  $U_{PEAK}$  affect the service life of the motor. If the peak voltage is too high, motors without phase coil insulation are the ones that will primarily be affected. If the motor cable is short (by a few yards), the rise time and peak voltage are lower.

If the motor cable is long (328 ft [100 m]), the rise time and peak voltage will increase.

If very small motors without phase coil insulation are used, it is recommended that an LC filter be fitted after the adjustable frequency drive.

Typical values for the rise time and peak voltage  $U_{PEAK}$  are measured on the motor terminals between two phases.

To obtain approximate values for cable lengths and voltages not mentioned below, use the following rules of thumb:

1. Rise time increases/decreases proportionally with cable length.
2.  $U_{PEAK} = \text{DC link voltage} \times 1.9$   
(DC link voltage = Line voltage  $\times 1.35$ ).

$$3. \frac{dU}{dt} = \frac{0.5 \times U_{PEAK}}{\text{Rise time}}$$

Data are measured according to IEC 60034-17.

### VLT 5001-5011 / 380-500 V

Cable length	AC line voltage	Rise time	Peak voltage	dU/dt
164 ft [50 m]	500 V	0.5 sec	1230 V	1968 V/sec
492 ft [150 m]	500 V	1 sec	1270 V	1270 V/sec
164 ft [50 m]	380 V	0.6 sec	1000 V	1333 V/sec
492 ft [150 m]	380 V	1.33 sec	1000 V	602 V/sec

### VLT 5016-5102 / 380-500 V

Cable length	AC line voltage	Rise time	Peak voltage	dU/dt
105 ft [32 m]	380 V	0.27 sec	950 V	2794 V/sec
230 ft [70 m]	380 V	0.60 sec	950 V	1267 V/sec
433 ft [132 m]	380 V	1.11 sec	950 V	685 V/sec

### VLT 5122-5302 / 380-500 V

Cable length	AC line voltage	Rise time	Peak voltage	dU/dt
230 ft [70 m]	400 V	0.34 sec	1040 V	2447 V/sec

### VLT 5352-5552 / 380-500 V

Cable length	AC line voltage	Rise time	Peak voltage	dU/dt
95 ft [29 m]	500 V	0.71 sec	1165 V	1389 V/sec
95 ft [29 m]	400 V	0.61 sec	942 V	1233 V/sec

### VLT 5001-5011 / 525-600 V

Cable length	AC line			dU/dt
	volt-	Rise time	Peak voltage	
115 ft [35 m]	600 V	0.36 sec	1360 V	3022 V/sec

### VLT 5016-5062 / 525-600 V

Cable length	AC line voltage	Rise time	Peak voltage	dU/dt
115 ft [35 m]	575 V	0.38 sec	1430 V	3011 V/sec

### VLT 5042-5352 / 525-690 V

Cable length	AC line voltage	Rise time	Peak voltage	dU/dt
82 ft [25 m]	690 V	0.59 sec	1425	1983 V/sec
82 ft [25 m]	575 V	0.66 sec	1159	1428 V/sec
82 ft [25 m]	690 V <sup>1)</sup>	1.72 sec	1329	640 V/sec

1) With Danfoss dU/dt filter.

### VLT 5402-5602 / 525-690 V

Cable length	AC line voltage	Rise time	Peak voltage	dU/dt
82 ft [25 m]	690 V	0.57 sec	1540	2.230 V/sec
82 ft [25 m]	575 V	0.25 sec		2.510 V/sec
82 ft [25 m]	690 V <sup>1)</sup>	1.13 sec	1629	1.150 V/sec

1) With Danfoss dU/dt filter.

### ■ Switching on the input

Switching on the input depends on the AC line voltage in question and on whether quick discharge of the intermediate capacitor has been selected. The table below states the waiting time between cut-ins.

AC line voltage	380 V	415 V	460 V	500 V	690 V
Without quick discharge	48 s	65 s	89 s	117 s	120 s
With quick discharge	74 s	95 s	123 s	158 s	

**VLT 5016-5062 / 525 - 600 V**

IP 20 / NEMA 1 units: 66 dB(A)

**VLT 5042-5352 / 525 - 690 V**

IP 21/NEMA 1 units: 74 dB(A)  
IP 54 units: 74 dB(A)

**VLT 5402 / 525 - 690 V**

All enclosure types: 80 dB(A)

**VLT 5502-5602 / 525 - 690 V**

All enclosure types: 83 dB(A)

Measured 1 meter from the unit at full load.

### ■ Acoustic noise

The acoustic interference from the adjustable frequency drive comes from two sources:

1. DC intermediate circuit coils.
2. Integral fan.

Below are the typical values measured at a distance of 1 m from the unit at full load:

**VLT 5001-5006 200 - 240 V, VLT 5001-5011 380 - 500 V**

IP 20 / NEMA 1 units: 50 dB(A)  
IP 54 / NEMA 12 units: 62 dB(A)

**VLT 5008-5027 200 - 240 V, VLT 5016-5102 380 - 500 V**

IP 20 / NEMA 1 units: 61 dB(A)  
IP 20 / NEMA 1 unit (VLT 5062-5102):  
IP 54 / NEMA 12 units: 66 dB(A)

**VLT 5032-5052 / 200 - 240 V**

IP 20 / NEMA 1 units: 70 dB(A)  
IP 54 / NEMA 12 units: 65 dB(A)

**VLT 5122-5302 / 380 - 500 V**

IP 21 / NEMA 1 units: 73 dB(A)  
IP 54 / NEMA 12 units: 73 dB(A)

**VLT 5352 / 380 - 500 V**

IP 00 and IP 21/ NEMA 1 units:  
IP 54 / NEMA 12 units: 80 dB(A)

**VLT 5452-5552 / 380 - 500 V**

All enclosure types: 83 dB(A)


**VLT 5001-5011 / 525 - 600 V**

IP 20 / NEMA 1 units: 62 dB(A)

### ■ Derating for ambient temperature

The ambient temperature ( $T_{AMB,MAX}$ ) is the maximum temperature allowed. The average ( $T_{AMB,AVG}$ ) measured over 24 hours must be at least 5°C lower.

If the adjustable frequency drive is operated at temperatures above 45 °C, a derating of the continuous output current is necessary.



- The current of VLT 5122-5552, 380-500 V and VLT 5042-5352, 525-690 V, is to be derated 1% / °C above 45°C maximum (160% overload) and 40°C maximum (110% overload). Max. temperature is 55° C.
- The current of VLT 5402-5602, 525-690 V, is to be derated 1.5% / °C above 45°C maximum (160% overload) and 40°C maximum (110% overload). Max. temperature is 55° C.

### ■ Derating for Air Pressure




At altitudes above 6,600 feet [2000 m], please contact Danfoss Drives regarding PELV.

Below an altitude of 3280 ft. [1000 m], no derating is necessary.

Above 3280 ft. [1000 m], the ambient temperature ( $T_{AMB}$ ) or max. output current ( $I_{VLT, MAX}$ ) must be derated in accordance with the diagram below:

- Derating of output current versus altitude at  $T_{AMB} = \text{max. } 113^{\circ} \text{ F } [45^{\circ} \text{ C}]$
- Derating of max.  $T_{AMB}$  versus altitude at 100% output current.



#### ■ Derating for Running at Low Speed

When a motor is connected to an adjustable frequency drive, it is necessary to check whether the cooling of the motor is adequate.

At low RPM values, the motor fan is not able to supply the required volume of air for cooling. This problem occurs when the load torque is constant (e.g. a conveyor belt) across the regulating range. The reduced ventilation available decides the size of the torque that can be permitted under a continuous load. If the motor is to run continuously at an RPM value lower than half the rated value, the motor must be supplied with additional air for cooling.

Instead of such extra cooling, the load level of the motor can be reduced. This can be done by choosing a bigger motor. However, the design of the adjustable

frequency drive sets limits as to the size of motor that can be connected to it.

#### ■ Derating for Installing Long Motor Cables or Cables with Larger Cross-section

The adjustable frequency drive has been tested using 300 m unscreened cable and 150 m screened cable.

The adjustable frequency drive has been designed to work using a motor cable with a rated cross-section. If a cable with a larger cross-section is to be used, it is recommended to reduce the output current by 5% for every step the cross-section is increased.

(Increased cable cross-section leads to increased capacity to earth, and thus an increased earth leakage current).

#### ■ Derating for high switching frequency


A higher switching frequency (to be set in parameter 411) leads to higher losses in the electronics of the adjustable frequency drive.

If SFAVM has been selected in parameter 446, the adjustable frequency drive will automatically derate the rated output current  $I_{VLT,N}$  when the switching frequency exceeds 3.0 kHz.

If 60°AVM is selected, the adjustable frequency drive will automatically derate when the switching frequency exceeds 4.5 kHz. In both cases, the reduction is carried out linearly, down to 60% of  $I_{VLT,N}$ . The table gives the min., max. and factory-set switching frequencies for adjustable frequency drive. The switching pattern can be changed in parameter 446 and the switching frequency in parameter 411.


	SFAVM			60 deg. AVM		
	Min. [kHz]	Max. [kHz]	Fac. [kHz]	Min. [kHz]	Max. [kHz]	Fac. [kHz]
VLT 5001-5006, 200 V	3.0	5.0	3.0	3.0	10.0	4.5
VLT 5008-5027, 200 V	3.0	10.0	3.0	3.0	14.0	4.5
VLT 5032-5052, 200 V	3.0	4.5	3.0	3.0	4.5	4.5
VLT 5001-5011, 500 V	3.0	5.0	3.0	3.0	10.0	4.5
VLT 5016-5052, 500 V	3.0	10.0	3.0	3.0	14.0	4.5
VLT 5062-5102, 500 V	3.0	4.5	3.0	3.0	4.5	4.5
VLT 5122-5302, 500 V	3.0	8.0	3.0	2.0	10.0	4.5
VLT 5352-5552, 600 V	1.5	2.0	2.0	1.5	3.0	3.0
VLT 5001-5011, 600 V	3.0	5.0	3.0	4.5	7.0	4.5
VLT 5016-5027, 600 V	3.0	10.0	3.0	3.0	14.0	4.5
VLT 5032-5052, 600 V	3.0	7.0	3.0	3.0	10.0	4.5
VLT 5062, 600 V	3.0	4.5	3.0	3.0	4.5	4.5
VLT 5042-5302, 690 V	1.5	2.0	2.0	1.5	3.0	3.0
VLT 5352-5602, 690 V	1.5	1.5	1.5	1.5	2.0	2.0

## VLT® 5000 Series



#### ■ Motor thermal protection

The motor temperature is calculated on the basis of motor current, output frequency and time. See parameter 128 in the Operating Instructions.



1752AO52.11

#### ■ Vibration and Shock

The adjustable frequency drive has been tested according to a procedure based on the following standards:

- IEC 68-2-6: Vibration (sinusoidal) - 1970
- IEC 68-2-34: Random vibration broad-band  
- general requirements
- IEC 68-2-35: Random vibration broad-band  
- high reproducibility
- IEC 68-2-36: Random vibration broad-band  
- medium reproducibility

The adjustable frequency drive complies with requirements that correspond to conditions when the unit is mounted on the walls and floors of production premises, as well as in panels bolted to walls or floors.

#### ■ Air Humidity

The adjustable frequency drive has been designed to meet the IEC 68-2-3 standard, EN 50178 pkt. 9.4.2.2/DIN 40040, class E, at 40°C.

List of functions

**■ Aggressive environments**

In common with all electronic equipment, an adjustable frequency drive contains a large number of mechanical and electronic components, all of which are vulnerable to environmental effects to some extent.



The adjustable frequency drive should not therefore be installed in environments with airborne liquids, particles or gases capable of affecting and damaging the electronic components. Failure to take the necessary protective measures increases the risk of stoppages, thus reducing the life of the adjustable frequency drive.

Liquids can be carried through the air and condense in the adjustable frequency drive. In addition to this, liquids may cause corrosion of components and metal parts. Steam, oil and salt water may cause corrosion of components and metal parts. In such environments, equipment with enclosure rating IP 54 is recommended. As an extra protection, coated printet circuit boards can be ordered as an option.

Airborne Particles such as dust particles may cause mechanical, electrical or thermal failure in the adjustable frequency drive. A typical indicator of excessive levels of airborne particles is dust particles around the adjustable frequency drive fan. In very dusty environments, equipment with enclosure rating IP 54 or a cabinet for IP 00/IP 20/Nema 1 equipment is recommended.

In environments with high temperatures and humidity, corrosive gases such as sulphur, nitrogen and chlorine compounds will cause chemical processes on the frequency converter components.

Such chemical reactions will rapidly affect and damage the electronic components. In such environments, it is recommended that equipment is mounted in a cabinet with fresh air ventilation, keeping aggressive gases away from the frequency converter.

An extra protection in such areas a conformal coating of the printed circuit boards can be ordered as an option.

**NOTE**

Mounting adjustable frequency drives in aggressive environments will increase the risk of stoppages and furthermore considerably reduce the life of the drive.


Before the installation of the adjustable frequency drive, the ambient air should be checked for liquids, particles and gases. This may be done by observing existing installations in this environment. Typical indicators of harmful airborne liquids are water or oil on metal parts, or corrosion of metal parts.

Excessive dust particle levels are often found on installation cabinets and existing electrical installations. One indicator of aggressive airborne gases is blackening of copper rails and cable ends on existing installations.

See also Instruction MN.90.IX.YY

### ■ Efficiency

To reduce energy consumption it is very important to optimize the efficiency of a system. The efficiency of each single element in the system should be as high as possible.



#### Efficiency of VLT 5000 Series ( $\eta_{VLT}$ )

The load on the frequency converter has little effect on its efficiency. In general, the efficiency is the same at the rated motor frequency  $f_{M,N}$ , regardless of whether the motor supplies 100% of the rated shaft torque or only 75%, i.e. in case of part loads.

This also means that the efficiency of the frequency converter does not change even if other U/f characteristics are chosen.

However, the U/f characteristics influence the efficiency of the motor.

The efficiency declines a little when the switching frequency is set to a value of above 4 kHz (3 kHz for VLT 5005) (parameter 411). The rate of efficiency will also be slightly reduced if the mains voltage is 500 V, or if the motor cable is longer than 30 m.

#### Efficiency of the motor ( $\eta_{MOTOR}$ )

The efficiency of a motor connected to the frequency converter depends on the sine shape of the current. In general, the efficiency is just as good as with mains operation. The efficiency of the motor depends on the type of motor.

In the range of 75-100% of the rated torque, the efficiency of the motor is practically constant, both when it is controlled by the frequency converter and when it runs directly on mains.

In small motors, the influence from the U/f characteristic on efficiency is marginal; however, in motors from 11 kW and up, the advantages are significant.

In general, the switching frequency does not affect the efficiency of small motors. Motors from 11 kW and up have their efficiency improved (1-2%). This is because

the sine shape of the motor current is almost perfect at high switching frequency.



---

## VLT® 5000 Series

---

### Efficiency of the system ( $\eta_{SYSTEM}$ )

To calculate the system efficiency, the efficiency of VLT 5000 Series ( $\eta_{VLT}$ ) is multiplied by the efficiency of the motor ( $\eta_{MOTOR}$ ):

$$\eta_{SYSTEM} = \eta_{VLT} \times \eta_{MOTOR}$$

Based on the graph on this page, it is possible to calculate the efficiency of the system at different loads.

---

### ■ Interference, Power factor


### ■ Mains Supply Interference/Harmonics

A frequency converter takes up a non-sinusoidal current from mains, which increases the input current  $I_{RMS}$ . A non-sinusoidal current can be transformed by means of a Fourier analysis and split up into sine wave currents with different frequencies, i.e. different harmonic currents  $I_N$  with 50 Hz as the basic frequency:

Harmonic currents	$I_1$	$I_5$	$I_7$
Hz	50 Hz	250 Hz	350 Hz

The harmonics do not affect the power consumption directly, but increase the heat losses in the installation (transformer, cables). Consequently, in plants with a rather high percentage of rectifier load, it is important to maintain harmonic currents at a low level to avoid overload of the transformer and high temperature in the cables.

Some of the harmonic currents might disturb communication equipment connected to the same transformer or cause resonance in connection with power-factor correction batteries.



175HA34.00

Harmonic currents compared to the RMS input current:

	Input current
$I_{RMS}$	1.0
$I_1$	0.9
$I_5$	0.4
$I_7$	0.2
$I_{11-49}$	< 0.1

To ensure low, harmonic currents, the frequency converter has intermediate circuit coils as standard. This normally reduces the input current  $I_{RMS}$  by 40%.

The voltage distortion on the mains supply depends on the size of the harmonic currents multiplied by the mains impedance for the frequency in question. The total voltage distortion THD is calculated on the basis of the individual voltage harmonics using the following formula:

$$THD\% = \frac{\sqrt{U_5^2 + U_7^2 + \dots + U_N^2}}{U_1} (U_N \% \text{ of } U)$$

See also Application Note MN.90.FX.02.

### ■ Power Factor

The power factor is the relation between  $I_1$  and  $I_{RMS}$ .

The power factor for 3-phase control:

$$\text{Power factor} = \frac{\sqrt{3} \times U \times I_1 \times \cos\varphi_1}{\sqrt{3} \times U \times I_{RMS}}$$

$$\frac{I_1 \times \cos\varphi_1}{I_{RMS}} = \frac{I_1}{I_{RMS}} \text{ since } \cos \varphi = 1$$

The power factor indicates the extent to which the adjustable frequency drive imposes a load on the line supply.

The lower the power factor, the higher the  $I_{RMS}$  for the same kW performance.

In addition, a high power factor indicates that the different harmonic currents are low.

$$I_{RMS} = \sqrt{I_1^2 + I_5^2 + I_7^2 + \dots + I_n^2}$$

**■ Factory Settings**

PNU	Parameter # description	Factory setting	Range	Changes during operation	4-Setup	Conversion index	Data type
001	Language	English		Yes	No	0	5
002	Local/remote control	Remote control		Yes	Yes	0	5
003	Local reference	000.000		Yes	Yes	-3	4
004	Active setup	Setup 1		Yes	No	0	5
005	Programming setup	Active setup		Yes	No	0	5
006	Copying of setups	No copying		No	No	0	5
007	LCP copy	No copying		No	No	0	5
008	Display scaling of motor frequency	1	0.01 - 500.00	Yes	Yes	-2	6
009	Display line 2	Frequency [Hz]		Yes	Yes	0	5
010	Display line 1.1	Reference [%]		Yes	Yes	0	5
011	Display line 1.2	Motor current [A]		Yes	Yes	0	5
012	Display line 1.3	Power [kW]		Yes	Yes	0	5
013	Local control/configura	LCP digital control/as par.100		Yes	Yes	0	5
014	Local stop	Possible		Yes	Yes	0	5
015	Local jog	Not possible		Yes	Yes	0	5
016	Local reversing	Not possible		Yes	Yes	0	5
017	Local reset of trip	Possible		Yes	Yes	0	5
018	Lock for data change	Not locked		Yes	Yes	0	5
019	Operating state at power-up, local control	Forced stop, use saved ref.		Yes	Yes	0	5
027	Warning readout	Warning in line 1/2		Yes	No	0	5

Changes during operation:

"Yes" means that the parameter can be changed, while the adjustable frequency drive is in operation.

"No" means that the adjustable frequency drive must be stopped before a change can be made.

4-Setup:

"Yes" means that the parameter can be programmed individually in each of the four setups, i.e. the same parameter can have four different data values. "No" means that the data value will be the same in all four setups.

Conversion index:

This number refers to a conversion figure to be used when writing or reading by means of an adjustable frequency drive.

Conversion index	Conversion factor
74	0.1
2	100
1	10
0	1
-1	0.1
-2	0.01
-3	0.001
-4	0.0001

Data type:

Data type shows the type and length of the telegram.

Data type	Description
3	Integer 16
4	Integer 32
5	Unsigned 8
6	Unsigned 16
7	Unsigned 32
9	Text string



## VLT® 5000 Series

PNU #	Parameter description	Factory setting	Range	Change s during operation	4-Setup	Conversion index	Data type
100	Configuration	Speed control, open loop		No	Yes	0	5
101	Torque characteristics	High - constant torque		Yes	Yes	0	5
102	Motor power	Depends on the unit	0.18-600 kW	No	Yes	1	6
103	Motor voltage	Depends on the unit	200 - 600 V	No	Yes	0	6
104	Motor frequency	50 Hz / 60 Hz		No	Yes	0	6
105	Motor current	Depends on the unit	0.01-I <sub>VLT,MAX</sub>	No	Yes	-2	7
106	Rated motor speed	Depends on the unit	100-60000 rpm	No	Yes	0	6
107	Automatic motor adaptation, AMA	Adaptation off		No	No	0	5
108	Stator resistor	Depends on the unit		No	Yes	-4	7
109	Stator reactance	Depends on the unit		No	Yes	-2	7
110	Motor magnetizing, 0 rpm	100 %	0 - 300 %	Yes	Yes	0	6
111	Min. frequency normal magnetizing	1.0 Hz	0.1 - 10.0 Hz	Yes	Yes	-1	6
112							
113	Load compensation at low speed	100 %	0 - 300 %	Yes	Yes	0	6
114	Load compensation at high speed	100 %	0 - 300 %	Yes	Yes	0	6
115	Slip compensation	100 %	-500 - 500 %	Yes	Yes	0	3
116	Slip compensation time constant	0.50 s	0.05 - 1.00 s	Yes	Yes	-2	6
117	Resonance dampening	100 %	0 - 500 %	Yes	Yes	0	6
118	Resonance dampening time constant	5 ms	5 - 50 ms	Yes	Yes	-3	6
119	High starting torque	0.0 sec.	0.0 - 0.5 s	Yes	Yes	-1	5
120	Start delay	0.0 sec.	0.0 - 10.0 s	Yes	Yes	-1	5
121	Start function	Coasting in start delay time		Yes	Yes	0	5
122	Function at stop	Coasting		Yes	Yes	0	5
123	Min. frequency for activating function at stop	0.0 Hz	0.0 - 10.0 Hz	Yes	Yes	-1	5
124	DC holding current	50 %	0 - 100 %	Yes	Yes	0	6
125	DC braking current	50 %	0 - 100 %	Yes	Yes	0	6
126	DC braking time	10.0 sec.	0.0 - 60.0 sec.	Yes	Yes	-1	6
127	DC brake cut-in frequency	Off	0.0-par. 202	Yes	Yes	-1	6
128	Motor thermal protection	No protection		Yes	Yes	0	5
129	External motor fan	No		Yes	Yes	0	5
130	Start frequency	0.0 Hz	0.0-10.0 Hz	Yes	Yes	-1	5
131	Initial voltage	0.0 V	0.0-par. 103	Yes	Yes	-1	6
145	Minimum DC brake time	0 sec.	0 - 10 sec.	Yes	Yes	-1	6

Parameters



## VLT® 5000 Series

PNU #	Parameter description	Factory setting	Range	Changes during operation	4-Setup	Conversion index	Data type
200	Output frequency range/direction	Only clockwise, 0-132 Hz		No	Yes	0	5
201	Output frequency low limit	0.0 Hz	0.0 - f <sub>MAX</sub>	Yes	Yes	-1	6
202	Output frequency high limit	66 / 132 Hz	f <sub>MIN</sub> - par. 200	Yes	Yes	-1	6
203	Reference/feedback area	Min - max		Yes	Yes	0	5
204	Minimum reference	0.000	-100,000.000-Ref <sub>MAX</sub>	Yes	Yes	-3	4
205	Maximum reference	50.000	Ref <sub>MIN</sub> -100,000.000	Yes	Yes	-3	4
206	Ramp type	Linear		Yes	Yes	0	5
207	Ramp-up time 1	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
208	Ramp-down time 1	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
209	Ramp-up time 2	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
210	Ramp-down time 2	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
211	Jog ramp time	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
212	Quick stop ramp-down time	Depends on unit	0.05 - 3600	Yes	Yes	-2	7
213	Jog frequency	10.0 Hz	0.0 - par. 202	Yes	Yes	-1	6
214	Reference function	Sum		Yes	Yes	0	5
215	Preset reference 1	0.00 %	- 100.00 - 100.00 %	Yes	Yes	-2	3
216	Preset reference 2	0.00 %	- 100.00 - 100.00 %	Yes	Yes	-2	3
217	Preset reference 3	0.00 %	- 100.00 - 100.00 %	Yes	Yes	-2	3
218	Preset reference 4	0.00 %	- 100.00 - 100.00 %	Yes	Yes	-2	3
219	Catch up/slow down value	0.00 %	0.00 - 100 %	Yes	Yes	-2	6
220							
221	Torque limit for motor mode	160 %	0.0 % - xxx %	Yes	Yes	-1	6
222	Torque limit for regenerative operation	160 %	0.0 % - xxx %	Yes	Yes	-1	6
223	Warning: Low current	0.0 A	0.0 - par. 224	Yes	Yes	-1	6
224	Warning: High current	I <sub>VLT,MAX</sub>	Par. 223 - I <sub>VLT,MAX</sub>	Yes	Yes	-1	6
225	Warning: Low frequency	0.0 Hz	0.0 - par. 226	Yes	Yes	-1	6
226	Warning: High frequency	132.0 Hz	Par. 225 - par. 202	Yes	Yes	-1	6
227	Warning: Low feedback	-4000.000	-100,000.000 - par. 228	Yes		-3	4
228	Warning: High feedback	4000.000	Par. 227 - 100,000.000	Yes		-3	4
229	Frequency bypass, bandwidth	OFF	0 - 100 %	Yes	Yes	0	6
230	Frequency bypass 1	0.0 Hz	0.0 - par. 200	Yes	Yes	-1	6
231	Frequency bypass 2	0.0 Hz	0.0 - par. 200	Yes	Yes	-1	6
232	Frequency bypass 3	0.0 Hz	0.0 - par. 200	Yes	Yes	-1	6
233	Frequency bypass 4	0.0 Hz	0.0 - par. 200	Yes	Yes	-1	6
234	Motor phase monitor	Enable		Yes	Yes	0	5



## VLT® 5000 Series

PN U #	Parameter description	Factory setting	Range	Changes during operation	4-Setup	Conversion index	Data type
300	Terminal 16, input	Reset		Yes	Yes	0	5
301	Terminal 17, input	Freeze reference		Yes	Yes	0	5
302	Terminal 18 Start, input	Start		Yes	Yes	0	5
303	Terminal 19, input	Reversing		Yes	Yes	0	5
304	Terminal 27, input	Coasting stop, inverse		Yes	Yes	0	5
305	Terminal 29, input	Jog		Yes	Yes	0	5
306	Terminal 32, input	Choice of setup, msb/speed up		Yes	Yes	0	5
307	Terminal 33, input	Choice of setup, lsb/speed down		Yes	Yes	0	5
308	Terminal 53, analogue input voltage	Reference		Yes	Yes	0	5
309	Terminal 53, min. scaling	0.0 V	0.0 - 10.0 V	Yes	Yes	-1	5
310	Terminal 53, max. scaling	10.0 V	0.0 - 10.0 V	Yes	Yes	-1	5
311	Terminal 54, analogue input voltage	No operation		Yes	Yes	0	5
312	Terminal 54, min. scaling	0.0 V	0.0 - 10.0 V	Yes	Yes	-1	5
313	Terminal 54, max. scaling	10.0 V	0.0 - 10.0 V	Yes	Yes	-1	5
314	Terminal 60, analogue input current	Reference		Yes	Yes	0	5
315	Terminal 60, min. scaling	0.0 mA	0.0 - 20.0 mA	Yes	Yes	-4	5
316	Terminal 60, max. scaling	20.0 mA	0.0 - 20.0 mA	Yes	Yes	-4	5
317	Time out	10 sec.	1 - 99 sec.	Yes	Yes	0	5
318	Function after time out	Off		Yes	Yes	0	5
319	Terminal 42, output	0 - I <sub>MAX</sub> P 0-20 mA		Yes	Yes	0	5
320	Terminal 42, output, pulse scaling	5000 Hz	1 - 32000 Hz	Yes	Yes	0	6
321	Terminal 45, output	0 - f <sub>MAX</sub> P 0-20 mA		Yes	Yes	0	5
322	Terminal 45, output, pulse scaling	5000 Hz	1 - 32000 Hz	Yes	Yes	0	6
323	Relay 01, output	Ready - no thermal warning		Yes	Yes	0	5
324	Relay 01, ON delay	0.00 sec.	0.00 - 600 sec.	Yes	Yes	-2	6
325	Relay 01, OFF delay	0.00 sec.	0.00 - 600 sec.	Yes	Yes	-2	6
326	Relay 04, output	Ready - remote control		Yes	Yes	0	5
327	Pulse reference, max. frequency	5000 Hz		Yes	Yes	0	6
328	Pulse feedback, max. frequency	25000 Hz		Yes	Yes	0	6
329	Encoder feedback pulse/rev.	1024 pulses/rev.	1 - 4096 pulses/rev.	Yes	Yes	0	6
330	Freeze reference/output function	No operation		Yes	No	0	5
345	Encoder loss timeout	1 sec.	0 - 60 sec	Yes	Yes	-1	6
346	Encoder loss function	OFF		Yes	Yes	0	5
357	Terminal 42, Output minimum scaling	0 %	000 - 100%	Yes	Yes	0	6
358	Terminal 42, Output maximum scaling	100%	000 - 500%	Yes	Yes	0	6
359	Terminal 45, Output minimum scaling	0 %	000 - 100%	Yes	Yes	0	6
360	Terminal 45, Output maximum scaling	100%	000 - 500%	Yes	Yes	0	6
361	Encoder loss threshold	300%	000 - 600 %	Yes	Yes	0	6

Parameters



## VLT® 5000 Series

PN U #	Parameter description	Factory setting	Range	Change s up during operation	4-Set- up	Conver- sion index	Data type
400	Brake function/overvoltage control	Off		Yes	No.	0	5
401	Brake resistor, ohm	Depends on the unit		Yes	No.	-1	6
402	Braking energy limit, kW	Depends on the unit		Yes	No.	2	6
403	Power monitoring	On		Yes	No.	0	5
404	Brake check	Off		Yes	No.	0	5
405	Reset function	Manual reset		Yes	Yes	0	5
406	Automatic restart time	5 sec	0-10 sec	Yes	Yes	0	5
407	Line Failure	No function		Yes	Yes	0	5
408	Quick discharge	Not possible		Yes	Yes	0	5
409	Trip delay torque	Off	0-60 sec	Yes	Yes	0	5
410	Trip delay inverter	Depends on type of unit	0-35 sec	Yes	Yes	0	5
411	Switching frequency	Depends on type of unit	1.5-14 kHz	Yes	Yes	2	6
412	Output frequency dependent switching frequency	Not possible		Yes	Yes	0	5
413	Overmodulation function	On		Yes	Yes	-1	5
414	Minimum feedback	0.000	-100,000.000 - FB <sub>HIGH</sub>	Yes	Yes	-3	4
415	Maximum feedback	1500.000	FB <sub>LOW</sub> - 100,000.000	Yes	Yes	-3	4
416	Process unit	%		Yes	Yes	0	5
417	Speed PID proportional gain	0.015	0.000 - 0.150	Yes	Yes	-3	6
418	Speed PID integration time	8 ms	2.00 - 999.99 ms	Yes	Yes	-4	7
419	Speed PID differentiation time	30 ms	0.00 - 200.00 ms	Yes	Yes	-4	6
420	Speed PID diff. gain ratio	5.0	5.0 - 50.0	Yes	Yes	-1	6
421	Speed PID low-pass filter	10 ms	5 - 200 ms	Yes	Yes	-4	6
422	U 0 voltage at 0 Hz	20.0 V	0.0 - parameter 103	Yes	Yes	-1	6
423	U 1 voltage	parameter 103	0.0 - UVLT, MAX	Yes	Yes	-1	6
424	F 1 frequency	parameter 104	0.0 - parameter 426	Yes	Yes	-1	6
425	U 2 voltage	parameter 103	0.0 - UVLT, MAX	Yes	Yes	-1	6
426	F 2 frequency	parameter 104	par. 424 - par. 428	Yes	Yes	-1	6
427	U 3 voltage	parameter 103	0.0 - UVLT, MAX	Yes	Yes	-1	6
428	F 3 frequency	parameter 104	par. 426 - par. 430	Yes	Yes	-1	6
429	U 4 voltage	parameter 103	0.0 - UVLT, MAX	Yes	Yes	-1	6



## VLT® 5000 Series

PN U #	Parameter description	Factory setting	Range	Change s during operation	4-Setup	Conver- sion index	Data type
430 F 4	frequency	parameter 104	par.426-par.432	Yes	Yes	-1	6
431 U 5	voltage	parameter 103	.0 - U <sub>VLT, MAX</sub>	Yes	Yes	-1	6
432 F 5	frequency	parameter 104	par.426 - 1000 Hz	Yes	Yes	-1	6
433 Torque proportional gain	100%	0 (Off) - 500%		Yes	Yes	0	6
434 Torque integral time	0.02 sec.	0.002 - 2.000 sec.		Yes	Yes	-3	7
437 Process PID Normal/inverse control	Normal			Yes	Yes	0	5
438 Process PID anti windup	On			Yes	Yes	0	5
439 Process PID start frequency	parameter 201	f <sub>min</sub> - f <sub>max</sub>		Yes	Yes	-1	6
440 Process PID proportional gain	0.01	0.00 - 10.00		Yes	Yes	-2	6
441 Process PID integral time	9999.99 sec. (OFF)	0.01 - 9999.99 sec.		Yes	Yes	-2	7
442 Process PID differentiation time	0.00 sec. (OFF)	0.00 - 10.00 sec.		Yes	Yes	-2	6
443 Process PID diff. gain limit	5.0	5.0 - 50.0		Yes	Yes	-1	6
444 Process PID lowpass filter time	0.01	0.01 - 10.00		Yes	Yes	-2	6
445 Flying start	Disable			Yes	Yes	0	5
446 Switching pattern	SFAVM			Yes	Yes	0	5
447 Torque compensation	100%	-100 - +100%		Yes	Yes	0	3
448 Gear ratio	1	0.001 - 100.000		No	Yes	-2	4
449 Friction loss	0%	0 - 50%		No	Yes	-2	6
450 Mains voltage at mains fault	Depends on unit	Depends on unit		Yes	Yes	0	6
453 Speed closed loop gear ratio	1	0.01-100		No	Yes	0	4
454 Dead time compensation	On			No	No	0	5
455 Frequency range monitor	Enable					0	5
457 Phase loss function	Trip			Yes	Yes	0	5
483 Dynamic DC Link compensation	On			No	No	0	5

Parameters



## VLT® 5000 Series

PNU #	Parameter description	Factory setting	Range	Changes during operation	4-Set-up	Conversion index	Data type
500	Address	1	0 - 126	Yes	No.	0	6
501	Baud rate	9600 baud		Yes	No.	0	5
502	Coasting	Logic or		Yes	Yes	0	5
503	Quick stop	Logic or		Yes	Yes	0	5
504	DC-brake	Logic or		Yes	Yes	0	5
505	Start	Logic or		Yes	Yes	0	5
506	Reversing	Logic or		Yes	Yes	0	5
507	Selection of set-up	Logic or		Yes	Yes	0	5
508	Selection of speed	Logic or		Yes	Yes	0	5
509	Bus jog 1	10.0 Hz	0.0 - parameter 202	Yes	Yes	-1	6
510	Bus jog 2	10.0 Hz	0.0 - parameter 202	Yes	Yes	-1	6
511							
512	Telegram profile	FC Drive		No.	Yes	0	5
513	Bus time interval	1 sec	1 - 99 s	Yes	Yes	0	5
514	Bus time interval function	Off		Yes	Yes	0	5
515	Data readout: Reference %			No.	No.	-1	3
516	Data readout: Reference unit			No.	No.	-3	4
517	Data readout: Feedback			No.	No.	-3	4
518	Data readout: Frequency			No.	No.	-1	6
519	Data readout: Frequency x Scaling			No.	No.	-2	7
520	Data readout: Current			No.	No.	-2	7
521	Data readout: Torque			No.	No.	-1	3
522	Data readout: Power, kW			No.	No.	1	7
523	Data readout: Power, HP			No.	No.	-2	7
524	Data readout: Motor voltage			No.	No.	-1	6
525	Data readout: DC link voltage			No.	No.	0	6
526	Data readout: Motor temp.			No.	No.	0	5
527	Data readout: VLT temp.			No.	No.	0	5
528	Data readout: Digital input			No.	No.	0	5
529	Data readout: Terminal 53, analog input			No.	No.	-2	3
530	Data readout: Terminal 54, analog input			No.	No.	-2	3
531	Data readout: Terminal 60, analog input			No.	No.	-5	3
532	Data readout: Pulse reference			No.	No.	-1	7
533	Data readout: External reference %			No.	No.	-1	3
534	Data readout: Status word, binary			No.	No.	0	6
535	Data readout: Braking energy/2 min.			No.	No.	2	6
536	Data readout: braking energy/sec			No.	No.	2	6
537	Data readout: Heatsink temperature			No.	No.	0	5
538	Data readout: Alarm word, binary			No.	No.	0	7
539	Data readout: VLT Control word, binary			No.	No.	0	6
540	Data readout: Warning word, 1			No.	No.	0	7
541	Data readout: Extended Status word			No.	No.	0	7
553	Display text 1			No.	No.	0	9
554	Display text 2			No.	No.	0	9
557	Data readout: Motor RPM			No.	No.	0	4
558	Data readout: Motor RPM x scaling			No.	No.	-2	4
580	Defined parameter			No.	No.	0	6
581	Defined parameter			No.	No.	0	6
582	Defined parameter			No.	No.	0	6



## VLT® 5000 Series

PNU #	Parameter description	Factory setting	Range	Changes during operation	4-Setup	Conversion index	DataType
600	Operating data: Operating hours			No	No	74	7
601	Operating data: Hours run			No	No	74	7
602	Operating data: kWh counter			No	No	1	7
603	Operating data: Number of power-up's			No	No	0	6
604	Operating data: Number of overtemperatures			No	No	0	6
605	Operating data: Number of overvoltages			No	No	0	6
606	Data log: Digital input			No	No	0	5
607	Data log: Bus commands			No	No	0	6
608	Data log: Bus Status word			No	No	0	6
609	Data log: Reference			No	No	-1	3
610	Data log: Feedback			No	No	-3	4
611	Data log: Motor frequency			No	No	-1	3
612	Data log: Motor voltage			No	No	-1	6
613	Data log: Motor current			No	No	-2	3
614	Data log: DC link voltage			No	No	0	6
615	Fault log: Error code			No	No	0	5
616	Fault log: Time			No	No	-1	7
617	Fault log: Value			No	No	0	3
618	Reset of kWh counter	No reset		Yes	No	0	5
619	Reset of hours-run counter	No reset		Yes	No	0	5
620	Operating mode Normal function	Normal function		No	No	0	5
621	Nameplate: VLT type			No	No	0	9
622	Nameplate: Power section			No	No	0	9
623	Nameplate: VLT ordering number			No	No	0	9
624	Nameplate: Software version no.			No	No	0	9
625	Nameplate: LCP identification no.			No	No	0	9
626	Nameplate: Database identification no.			No	No	-2	9
627	Nameplate: Power section identification no.			No	No	0	9
628	Nameplate: Application option type			No	No	0	9
629	Nameplate: Application option ordering no.			No	No	0	9
630	Nameplate: Communication option type			No	No	0	9
631	Nameplate: Communication option ordering no.			No	No	0	9

Parameters



## VLT® 5000 Series

PNU	Parameter #	Parameter description	Factory setting	Range	Change s	4-Set-up during operation	Conversion index	Data type
700	Relay 6, function	Ready signal			Yes	Yes	0	5
701	Relay 6, ON delay	0 sec	0.00-600 sec		Yes	Yes	-2	6
702	Relay 6, OFF delay	0 sec	0.00-600 sec		Yes	Yes	-2	6
703	Relay 7, function	Motor running			Yes	Yes	0	5
704	Relay 7, ON delay	0 sec	0.00-600 sec		Yes	Yes	-2	6
705	Relay 7, OFF delay	0 sec	0.00-600 sec		Yes	Yes	-2	6
706	Relay 8, function	Line Supply ON			Yes	Yes	0	5
707	Relay 8, ON delay	0 sec	0.00-600 sec		Yes	Yes	-2	6
708	Relay 8, OFF delay	0 sec	0.00-600 sec		Yes	Yes	-2	6
709	Relay 9, function	Fault			Yes	Yes	0	5
710	Relay 9, ON delay	0 sec	0.00-600 sec		Yes	Yes	-2	6
711	Relay 9, OFF delay	0 sec	0.00-600 sec		Yes	Yes	-2	6

**■ Definitions**
**VLT:**
 $I_{VLT,MAX}$ 

The maximum output current.

 $I_{VLT,N}$ 

The rated output current supplied by the adjustable frequency drive.

 $U_{VLT\ MAX}$ 

The maximum output voltage.

**Output:**
 $I_M$ 

The current transmitted to the motor.

 $U_M$ 

The voltage transmitted to the motor.

 $f_M$ 

The frequency transmitted to the motor.

 $f_{JOG}$ 


The frequency transmitted to the motor when the jog function is activated (via digital terminals or the keypad).

 $f_{MIN}$ 

The minimum frequency transmitted to the motor.

 $f_{MAX}$ 

The maximum frequency transmitted to the motor.

**Break-away torque:**

 $\eta_{VLT}$ 

The efficiency of the adjustable frequency drive is defined as the ratio between the power output and the power input.

**Input:**
**Control command:**

By means of LCP and the digital inputs, it is possible to start and stop the connected motor.

Functions are divided into two groups, with the following priorities:

Group 1

Reset, Coasting stop, Reset and Coasting stop, Quick-stop, DC braking, Stop and the "Stop" key.

Group 2

Start, Pulse start, Reversing, Start reversing, Jog and Freeze output

Group 1 functions are called start-disable commands. The difference between group 1 and group 2 is that in group 1 all stop signals must be cancelled for the motor to start. The motor can then be started by means of a single start signal in group 2.

A stop command given as a group 1 command results in the display indication STOP.

A missing stop command given as a group 2 command results in the display indication STAND BY.

**Start-disable command:**

A stop command that belongs to group 1 of the control commands - see this group.

**Stop command:**

See Control commands.

**Motor:**
 $I_{M,N}$ 

The rated motor current (nameplate data).

 $f_{M,N}$ 

The rated motor frequency (nameplate data).

 $U_{M,N}$ 

The rated motor voltage (nameplate data).

 $P_{M,N}$ 

The rated power delivered by the motor (nameplate data).

 $n_{M,N}$ 

The rated motor speed (nameplate data).

 $T_{M,N}$ 

The rated torque (motor).

**References:**
**preset ref.**

A firmly defined reference which can be set from -100% to +100% of the reference range. There are four preset references, which can be selected via the digital terminals.

**analog ref.**

A signal transmitted to input 53, 54 or 60. Can be voltage or current.

**pulse ref.**

A signal transmitted to the digital inputs (terminal 17 or 29).

**binary ref.**

A signal transmitted to the serial communication port.

**Ref<sub>MIN</sub>**

The smallest value which the reference signal may have. Set in parameter 204.

**Ref<sub>MAX</sub>**

The maximum value which the reference signal may have. Set in parameter 205.

**Miscellaneous:****GLCB:**

Ground Leakage Circuit Breaker.

**lsb:**

Least significant bit.

Used in serial communication.

**msb**

Most significant bit.

Used in serial communication.

**PID:**

The PID regulator maintains the desired speed (pressure, temperature, etc.) by adjusting the output frequency to match the varying load.

**Trip:**

A state which occurs in different situations, e.g., if the adjustable frequency drive is subjected to an overtemperature. A trip can be cancelled by pressing reset or, in some cases, automatically.

**Trip-locked:**

A state which occurs in different situations, e.g., if the adjustable frequency drive is subject to an overtemperature. A locked trip can be cancelled by cutting off line power and restarting the adjustable frequency drive.

**Initializing:**

If initializing is carried out, the adjustable frequency drive returns to the factory setting.

**Set-up:**

There are four set-ups, in which it is possible to save parameter settings. It is possible to change between the four parameter set-ups and to edit one set-up, while another set-up is active.

**LCP:**

The control panel, which makes up a complete interface for control and programming of VLT 5000 Series. The control panel is detachable and may, as an alternative, be installed up to 9.8 ft (3 meters) away from the adjustable frequency drive, i.e., in a front panel, by means of the installation kit option.

**VVC plus**

If compared with standard voltage/frequency ratio control, VVC<sup>plus</sup> improves the dynamics and the stability, both when the speed reference is changed and in relation to the load torque.

**Slip compensation:**

Normally, the motor speed will be affected by the load, but this load dependence is unwanted. The adjustable frequency drive compensates for the slip by giving the frequency a supplement that follows the measured effective current.

**Thermistor:**

A temperature-dependent resistor placed where the temperature is to be monitored (adjustable frequency drive or motor).

**Analog inputs:**

The analog inputs can be used for controlling various functions of the adjustable frequency drive.

There are two types of analog inputs:

Current input, 0-20 mA

Voltage input, 0-10 V DC.

**Analog outputs:**

There are two analog outputs, which are able to supply a signal of 0-20 mA, 4-20 mA or a digital signal.

**Digital inputs:**

The digital inputs can be used for controlling various functions of the adjustable frequency drive.

**Digital outputs:**

There are four digital outputs, two of which activate a relay switch. The outputs are able to supply a 24 V DC (max. 40 mA) signal.

**Brake resistor:**

The brake resistor is a module capable of absorbing the braking energy that is generated in regenerative braking. This regenerative braking energy increases the intermediate circuit voltage, while a brake chopper ensures that the energy is transmitted to the brake resistor.

Pulse encoder:

An external, digital pulse transmitter used for feeding back information on motor speed. The encoder is used in applications where great accuracy in speed control is required.

AWG:

Means American Wire Gauge, i.e., the American measuring unit for cable cross-section.

Manual initialization:

Press the [CHANGE DATA] + [MENU] + [OK] keys at the same time to carry out manual initialization.

60° AVM

Switching pattern called 60° Asynchronous Vector Modulation.

SFAVM

Switching pattern called Stator Flux-oriented Asynchronous Vector Modulation.

Automatic motor adjustment, AMA:

Automatic motor adjustment algorithm, which determines the electrical parameters for the connected motor, at standstill.

On-line/off-line parameters:

On-line parameters are activated immediately after the data value is changed. Off-line parameters are not activated until OK has been entered on the control unit.

VT characteristics:

Variable torque characteristics, used for pumps and fans.

CT characteristics:

Constant torque characteristics, used for all applications, such as conveyor belts and cranes. CT characteristics are not used for pumps and fans.

MCM:

Stands for Mille Circular Mil, an American measuring unit for cable cross-section. 1 MCM • 0.5067 mm<sup>2</sup>.

**■ Index**
**6**

60° AVM ..... 137

**A**

AC Line fault	138
AC line supply (L1, L2, L3):	6
acceleration time	102
Accuracy of display readout (parameters 009-012)	10
Address	141
Aggressive environments	216
Air Humidity	215
Alarm messages	161
Alarm word	166
Alarms	160
AMA	91
AMA	196
Analog input current	115
Analog input voltage	115
analog inputs	113
Application configuration	185
Application option	153
Automatic motor adaptation	91
Automatic Motor Adaptation, AMA	196
Automatic reset	127

**B**

Baudrate	141
Brake function	189
Brake resistor	9
Brake resistors	35
Braking time	189
Bus time interval	143

**C**

cable clamps	181
Cable lengths, cross-sections and connectors:	10
Catch up	105
Catch up	105
Catch-up/Slow-down	111
CE labelling	177
Change of group of numeric data values	76
Changing a text value	76
Changing data	75
Coasting	141
Coasting stop	110
Communication option	153
Configuration	87
Connection of motor	62
control cables	181
Control card test	151
Control card, 24 V DC supply	8
Control card, analog inputs	7
Control card, digital inputs:	7
Control card, digital/pulse and analog outputs	8
Control card, pulse/encoder input	8
Control card, RS 485 serial communication	9
Control characteristics	10

Control key functions	72
Control panel - control keys	72
Control panel - display	71
Control panel - display read-outs	73
Control panel - LEDs	72
Control panel (LCP)	71
Cooling	44
copy parameter value(s)	81
Current reference with speed feedback	70

**D**

Data change	85
Data change lock	112
Data value, step-by-step	76
data-logs	149
DC brake	96
DC braking	110
DC holding	96
DC-brake	141
deceleration time	102
Definitions	229
Derating for Air Pressure	212
Derating for ambient temperature	212
Derating for Running at Low Speed	213
Digital speed up/down	69
DIP Switches 1-4	65
Direction	100
direction of motor rotation	62
Direction of motor rotation	62
Display	82
Display - Status messages	157
Display mode	73
Display mode - selection of read-outstate	73

**E**

Earth leakage current	207
Electrical installation	47
Electrical installation	67
Electrical installation - 24 Volt external DC supply	63
Electrical installation - brake cable	63
Electrical installation - brake resistor temperature switch	64
Electrical installation - bus connection	64
Electrical installation - EMC precautions	181
Electrical installation - mains supply	58
Electrical installation - relay outputs	63
Electrical installation, power cables	48
Electrical installation, power cables	55
Electrical installation, power cables	56
Electrical installation, selection of EMC-correct cables	184
EMC Test Results	180
Encoder connection	70
Encoder feedback	112
Encoder feedback	122
Encoder loss	123
ETR	97
Extended mechanical brake control	198
External 24 V DC supply	9
External 24 V DC supply	63
External motor fan	98



## **VLT® 5000 Series**

Externals	10
<b>F</b>	
Factory Settings	220
Fan Supply	64
Fault log	150
Fault log: Time	150
Fault log: Value	150
Feedback	130
Feedback	130
Feedback signal	101
Feedback signal	114
Flying start	137
Flying start	204
Freeze output	111
Freeze reference	111
Freeze reference/output	122
Frequency bypass	107
Fuses	33
<b>G</b>	
Galvanic Isolation (PELV)	207
Galvanically isolated	65
General technical data	6
General technical data	6
<b>H</b>	
Harmonic filter	140
Harmonic filters	39
High current	106
High feedback	107
High frequency	107
High voltage test	58
<b>I</b>	
Indexed parameters	76
Infinitely variable change of numericdata value	76
Installation of control cables	65
Installation of mechanical brake	5
Installation of motor cables	62
Internal current regulator	206
IT mains	58
<b>J</b>	
Jog	111
<b>K</b>	
kWh counter	149
KWh counter	151
<b>L</b>	
Language	79
Language 001	79
Latched start	110
LCP copy	81
LCP identification	153
Load sharing	63
<b>M</b>	
Local and remote control	84
Local jog	84
Local reversing	84
Local stop	84
Low current	106
Low feedback	107
Low frequency	106
<b>N</b>	
Mains failure	112
Mains failure	127
Mains failure/quick discharge with mains failure inverse	203
Mains supply	13
Mains Supply Interference/Harmonics	219
Manual initialization	77
Manual reset	127
Max. imbalance of supply voltage:	6
Mechanical brake control	198
Mechanical dimensions	41
Mechanical installation	44
Menu mode	75
Menu structure	78
Motor cables	181
motor phases.	108
Motor protection	58
Motor thermal protection	58
Motor thermal protection	97
<b>O</b>	
Normal/high overload torque control,open loop	206
<b>P</b>	
Operating hours	149
Output data	6
Output frequency	100
Outputs	117
Overvoltage control	125
<b>R</b>	
Parallel coupling of motors	62
Parameter selection	75
Parameter selection	75
Parameter Setup	74
Peak voltage	210
PID for process control	200
PID for speed control	201
Potentiometer reference	70
Power Factor	219
Power up	85
Pre-heat	96
Preset reference,	111
Preset references	104
Process control, closed loop	87
Process PID	135
Programming of Torque limit and stop	206
Programming Setup	80
proportional gain	131
Protocol	146
Pulse feedback	112

Index

Pulse reference	121
Pulse reference	112
Pulse start/stop	69
 <b>Q</b>	
Quick discharge	202
Quick Setup	75
Quick-stop	110
Quick-stop	141
 <b>R</b>	
Ramp type	102
Ramp-down time	102
Ramp-up time	102
Read out via the serial communication	144
Reference	79
Reference function	103
Reference signal	101
Reference.	114
Reference/feedback unit	130
References - multi-references	192
References - single references	190
Relative reference	114
Relay	121
Relay	121
Relay outputs:	9
Relay outputs:	9
Reset	127
Reset	110
Resistor brake	125
Reversing	110
Reversing	142
RFI switch	58
Rise time	210
RS-485	65
 <b>S</b>	
Safety grounding	58
Safety interlock	112
Safety regulations	5
Selection of Setup	141
Selection of Setup,	111
Selection of speed	141
Setting of parameters	185
Setup	80
Setup change	69
SFAVM	137
single references.	115
single references.	116
Slow down	105
Software version	153
Speed control, closed loop	87
Speed control, open loop	87
Speed down	111
Speed PID	131
Speed up	111
Start	110
Start	141
Start anti-clockwise only	110
Start clockwise only	110
stator resistance	91
status word	166
Stop	110
Switching frequency	129
Switching pattern	137
 <b>T</b>	
Telegram profile	142
Thermistor	97
Thermistor.	114
Tightening-up torques and screw sizes	57
Time out	116
Torque characteristics	87
Torque characteristics:	6
Torque control, open loop	87
Torque control, speed feedback	87
Torque limit	105
Torque limit	105
Torque limit.	114
Trip locked	160
Trouble-shooting	156
Two wire start/stop	69
Two-wire transmitter	70
 <b>U</b>	
U/f characteristic	133
Unintended start	5
 <b>V</b>	
Vibration and Shock	215
VLT 5000 Series protection:	12
VLT 5000 Series protection:	12
VLT ordering number	153
Vlt output data (u, v, w):	6
VLT type	152
Voltage level	138
 <b>W</b>	
Warning against unintended start	5
Warning word	166
Warnings	160
Warnings	161
Warnings and alarms	160



[www.danfoss.com/drives](http://www.danfoss.com/drives)

---

Danfoss shall not be responsible for any errors in catalogs, brochures or other printed material. Danfoss reserves the right to alter its products at any time without notice, provided that alterations to products already on order shall not require material changes in specifications previously agreed upon by Danfoss and the Purchaser.  
All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logo type are trademarks of Danfoss A/S. All rights reserved.

---

For: Industrial Sales, Application Engineering

### Danfoss Drives

**Division of Danfoss Inc.**  
4401 N. Bell School Road  
Loves Park, IL, 61111  
Toll free: 800/432-6367  
Telephone: 815/639-8600  
Fax: 815/639-8000  
[www.namc.danfoss.com](http://www.namc.danfoss.com)



