2016




Remotely Accessing raspberry pi




Author: Rajatha B

- First the ip address of raspberry pi is taken by the command hostname I.
- Later from the system where u wants to remotely access install putty software.
- In putty command prompt, first it will ask login id.
- Give it as pi.
- Later passwords give it as raspberry.
- Next follow the following commands:
- sudo apt-get update
- sudo apt-get upgrade
- sudo apt-get install tightvncserver
- tightvncserver
- After typing tightvncserver u will get number for raspberry pi
- The following screen shots will display all these commands.




9/3, 2nd floor, SreeLaksmi Complex, opp, to Vivekananda Park, Girinagar, Bangalore - 560085,




- Note down that
- Later install vnc server from website <u>www.realvnc.com</u>
- After downloading run vnc
- It will display following two dialogue box:






- Give prefer on for encryption and type raspberry pi ip address along with the number.
- Later the following dialogue box will display. For that give continue




 ${\it \# 9/3, 2} {\it nd floor, SreeLaksmi Complex, opp, to Vivekananda Park, Girinagar, Bangalore - 560085,}$

Now raspberry pi can be remotely accessed by another computer.



TENET Technetronics

#9/3, 2nd floor, SreeLaksmi Complex, opp, to Vivekananda Park, Girinagar, Bangalore - 560085,



 $\#\ 9/3, 2nd\ floor, Sree Laksmi\ Complex,\ opp,\ to\ Vivekananda\ Park,\ Girinagar,\ Bangalore\ -\ 560085,$