<u>Command Reference</u> > <u>SCPI Command Reference</u> > [<u>SENSe:</u>] <u>Commands</u> > [<u>SENSe:</u>] <u>CORRection...</u> > [SENSe:]CORRection:COLLect:FIXTure:LMParameter[:STATe] |

[<u>SENSe:</u>]CORRection:COLLect:FIXTure:LMParameter[:STATe] |

Selects an Auto Length (and Loss) calculation or a Direct Compensation.

## Parameters:

<Boolean> 1 - Auto Length (and Loss), depending on the last

[SENSe<Ch>:]

CORRection:COLLect:FIXTure:LMParameter:LOSS

[:STATe] setting

0 - Direct Compensation

\*RST:

**Example:** See [SENSe<Ch>:]CORRection:COLLect:FIXTure[:

ACQuire]

Manual operation: See <u>"Fixture Compensation"</u>

Top