

Maintenance manual

UNIMOG 435

Mercedes Benz
service

UKD 30 400 26 41

General 0

	page
1 Pictorial representation of the vehicle	1 - 1
2 Outline drawing with main dimensions	2 - 1
3 Marking points	3 - 1
4 Technical specifications	4 - 1
5 Operating materials and fill quantities	5 - 1
6 Operation of the vehicle	6 - 1
7 Towing the vehicle	7 - 1
Emergency release of the spring accumulator	7 - 2
Switch the group shift lever	7 - 4
8 Maintenance, general	8 - 1
Maintenance work 00 to 99	

Table of Contents

Maintenance work (BW vehicles)	Type or aggregate	Deadline plan					Note page
		E1	F1	F2	F3	F4	

01, 03, 05, 24 engine mechanics

Removing and installing cylinder head cover	Type 435.115 engine 353.961	x					01-1 / 1
Check and adjust valve clearance		x				x	05-1 / 1
Remove rocker arm brackets		x					05-2 / 1
Retighten the cylinder head nuts		x					05-3 / 1

07, 09, 14, 47, 49 engine combustion

Bleed the fuel system	Type 435.115 engine 353.961				x	x	07-1 / 1
Check the function of the hand pump					x	x	07-2 / 1
Clean the prefilter				x	x	x	07-3 / 1
Clean the step filter					x	x	07-4 / 1
Exhaust system tightness test		x					49-1 / 1
Renew air filter element						x	09-1 / 1

13 air compressor / V-belt

Checking tightness of cylinder head bolts Air compressor		Type 435.115 engine 353.961	x					13-1 / 1
Air compressor tightness test			x					13-2 / 1
Tension the V-belt or replace	Coolant pump generator		x		x	x	x	13-3 / 1
	Power steering pump		x		x	x	x	13-3 / 4
	Air compressor		x		x	x	x	13-3 / 5
	Intermediate drive fan		x		x	x	x	13-3 / 6
	Fan drive		x		x	x	x	13-3 / 7

Table of Contents

Maintenance work	Type or aggregate	Deadline					Note page
		E1	F1	F2	F3	F4	

18 Engine lubrication

Check the oil level in the engine	Type 435.115 Engine 359.961	x		x	x	x	18-1 / 1
Oil change in the engine		x			x	x	18-2 / 1
Oil filter care		x			x	x	18-3 / 1
Renew oil separator with control valve (Crankcase ventilation)						x	18-4 / 1

20/50/83 Cooling system, heating

Check coolant level, correct	Type 435.115 Engine 353.961						50-1 / 1
Checking tightness of cooling system				x	x	x	50-2 / 1

25 Clutch

Check the lining thickness on the drive plate	Type 435.115			x	x	x	25-1 / 1
--	--------------	--	--	---	---	---	----------

26 Gearbox / PTO gearbox

Check the oil level in the main transmission	Type 435.115 gear 717.901			x	x	x	26-1 / 1
Check the oil level in the PTO gearbox				x	x	x	26-2 / 1
Oil change in the main transmission		x				x	26-3 / 1
Oil change in the PTO gearbox						x	26-4 / 1
Check the condition of the sleeve on the shift cylinder				x	x	x	

29 Foot control

Fluid level clutch actuation	Type 435.115				x	x	29-1 / 1
Fluid in clutch actuation replace						x	29-2 / 1

30 Regulation

	Type 435.115			x	x	x	30-1 / 1
--	--------------	--	--	---	---	---	----------

8th
Joints from foot controls
lubricate

Table of Contents

Maintenance work (BW vehicles)	Type or aggregate	Deadline					Note page
		E1	F1	F2 nd	F3	F4	
31 frame / trailer coupling							
Lubricate the towbar	Type 435.115			x	x	x	31-1 / 1
Plug pin on towing coupling lubricate				x	x	x	31-1 / 1
Fixed wheel test for spare wheel				x	x	x	31-2 / 1
Frame on loose screw and Check welded connection						x	-
32 springs, shock absorbers							
Fixed arm test for wishbones	Type 435.115	x					31-1 / 1
33 front axle							
Lubricate the steering knuckle bearing	Type 435.115 VA 737.111	x		x	x	x	33-1 / 1
Check oil level				x			33-2 / 1
O i l c h a n g e		x			x	x	33-3 / 1
Check axle ventilation				x	x	x	33-4 / 1
Differential gear lock care					x	x	33-5 / 1
Front axle tightness test		x					33-6 / 1
Check the condition of the rubber boot on the axle push tube					x	x	x
35 rear axle							
Check oil level	Type 435.115 HA 747.111			x			33-2 / 1
Oil change		x			x	x	33-3 / 1
Check axle ventilation				X	x	x	35-1 / 1
Differential gear lock care		x			x	x	33-5 / 1
Checking tightness on the rear axle		x					33-6 / 1
Rubber sleeve on the axle push tube check for condition					x	x	x

Table of Contents

Maintenance work (BW vehicles)	Type or aggregate	Deadline					Hinweis page
		E1	F1	F2	F3	F4	
40 Wheels and tyres							
Four-wheel drive and differential gear Check lock for function	Type 435.115						40-1 / 1
Wheel fastening nuts on tight fit check		x		x	x	x	40-2 / 1
41 PTO shaft							
Drive shaft between clutch and lubricate the gearbox	Type 435.115	x		x	x	x	41-1 / 1
42 Brake system							
Check the brake system	Type 435.115	x					42-1 / 1
Brake pads on front axle on condition check, replace if necessary				x	x	x	42-2 / 1
Brake pads on the rear axle are in good condition check, replace if necessary				x	x	x	42-3 / 1
Functional test of spring-loaded quick release device					x	x	42-4 / 1
Change brake fluid					x		42-5 / 1
43 compressed air system							
Check condition of central ventilation	Type 435.115			x	x	x	43-1 / 1
Clean the ventilation system filter				x	x	x	43-2 / 1
46 steering system							
Check oil level	Type 435.115 steering 765,601			x	x	x	46-1 / 1
Oil change with filter care		x				x	46-2 / 1
Check and adjust the track					x	x	46-4 / 1
Condition check of the steering linkage		x		x	x	x	46-3 / 1
Steering gear tightness test		x			x	x	46-5 / 1
15,54,82 electrical system							
Battery care	Type 435.115			x	x	x	54-1 / 1
Check sockets					x	x	54-2 / 1

Table of Contents

Maintenance time (BW vehicles)	Type respectively. Aggregate	Deadline plan					Note page
		EI	F1	F2	F3	F4	
Headlights: Check setting	Type 435.115				x	x	82-1 / 1

55 PTO shafts

Wait the PTO	Type 435.115			x	x	x	55-1 / 1
--------------	--------------	--	--	---	---	---	----------

56 Winch

Check oil level	Type 435.115			x			56-1 / 1
Oil change					x	x	56-1 / 1
Winding device and guide roller lubricate				x	x	x	56-1 / 1

60 Cab / platform

Lubricate the door catcher	Fhs 425.820 Pr. 435.611 Typ 435.115 435			x	x	x	60-1 / 1
Lubricate door lock, locking plate				x	x	x	60-1 / 1
Driver seat guide rails lubricate					x	x	60-1 / 1
Lubricate bolt locks				x	x	x	60-2 / 1
Fixed seating test in the driver's cab					x	x	60-3 / 1 60-4 / 1
Raise and lower the cab		x					60-6 / 1
Remove lifting device with the cab raised							60-7 / 1
Fixed seat test of the flatbed		x			x	x	60-5 / 1
Hinges (accessories, equipment and Lubricate battery box)				x	x	x	-
Cavity conservation (once after a year)					(x)		60-8 / 1

Table of Contents

Maintenance work (civil vehicles)	Type or aggrega	Maintenance				Zusatzarbeit zu jedem 2. Wtg.-Dienst	Note page
		1D	2D	Wtg.	Pl.		

01, 03, 05, 24 engine mechanics

Remove cylinder head cover	Type 435. 115 Engine 352	•		•			01-1 / 1
Check and adjust valve clearance		•		•			05-1 / 1
Remove rocker arm brackets		•					05-2 / 1
Retighten the cylinder head nuts		•					05-3 / 1
Fixed seating test engine mounting		•	•				24-1 / 1

07, 09, 14, 47, 49 engine combustion

Bleed the fuel system	Type 435.115 Engine 352					0	07-1 / 1
Clean the prefilter				0			07-3 / 1
Clean the step filter						0	07-4 / 1
Check air filter system, clean filter only according to maintenance indicator			●	0	0		0 9 1/1
Renew air filter element		every 2 years 0					09-1 / 1
Visually inspect the pipes on the fuel system for condition and tightness		●	●	0	0		

13 air compressor / V-belt

Checking tightness of cylinder head screws on air compressor		Type 435.115 Engine 352	•	•				13-1 / 1
Tension the V-belt or replace	Coolant pump generator		•	•	0	0		13-3 / 1
	hydraulic pump		•	•	0	0		13-3 / 3
	Power steering pump		•	•	0	0		13-3 / 4
	Air compressor		•	•	0	0		13-3 / 5
	Intermediate drive fan		•	•	0	0		13-3 / 6
	Fan drive		•	•	0	0		13-3 / 7

18 Engine lubrication

Check oil level	Type 435.115 Engine 352	●	●	0	0		18-1/1
Oil change		●	●	0	0		18-2/1
Oil filter care		●	●	0	0		18-3/1
Renew oil separator with control valve (crankcase ventilation)		every 2 years					18-4 / 1

Table of Contents

Maintenance work (civil vehicles)	Type or aggrega	Maintenance				Zusatzarbeit zu jedem 2. Wtg.-Dienst	Note page
		1D	2D	Wtg.	Pf !		

20,50,83, cooling system, heating

Pipelines and hoses on condition and check tightness	Type 435.115 Engine 352	●	●	O	O		50-2 / 1
--	----------------------------	---	---	---	---	--	----------

26 Gearbox / PTO gearbox

Check the oil level in the main transmission	Type 435.115 gear 717.901		•		0		26-1 / 1
Check the oil level in the PTO gearbox					0		26-2 / 1
Oil change in the main transmission		•				0	26-3 / 1
Oil change in the PTO gearbox			•			0	26-4 / 1
Gearbox suspension tightness test		•	•				26-5 / 1

29 foot control

Fluid level clutch actuation	Type 435.115	●	●	O	O		29-1 / 1
Fluid in clutch actuation replace		annually •					29-2 / 1

31 frame / trailer coupling

Lubricate the towbar	Type 435.115		●	O	O		31-1 / 1
----------------------	--------------	--	---	---	---	--	----------

32 springs, shock absorbers

Fixed arm test for wishbones	Type 435.115	●	●				32-1 / 1
------------------------------	--------------	---	---	--	--	--	----------

33 front axle

	Type 435.115 VA 737.111	•	•	0	0		33-1 / 1
Check oil level			•		0		33-2 / 1
Oil change		•				0	33-3 / 1

Table of Contents

Maintenance work (civil vehicles)	Type or aggregat	Maintenance				Zusatzarbeit zu jedem 2. Wtg.-Dienst	Note page
		1D	2D	Wtg.	Pl.		
35 Rear axle							
Check oil level	Type 435.115 HA 747.111		•		0		33-2 / 1
Oil change		•				0	33-3 / 1
40 Wheels and tyres							
Checking tightness of wheel fastening nuts	Type 435.115	•	•	•	0		40-2 / 1
Check tires for wear			•	0	0		
41 PTO shaft							
Lubricate the PTO shaft between the clutch and gearbox	Type 435.115		●	0	0		41-1 / 1
42 brake system							
Visually check the brake system for leaks	Type 435.115		●	●	0		42-1 / 2
Pipelines for condition and tightness visually inspect		●	●	0	0		
Check the brake fluid level		●	●	0	0		42-1 / 1
Change brake fluid		annually •					42-5 / 1
Check the brake pads for condition			●	●	0		42-2 / 1 42-3 / 1
46 steering system							
Check oil level	Type 435.115 steering 765,601		0	0	0		46-1 / 1
Oil change		●	after and all 2,600 op. Hours				46-2 / 1
Filter maintenance		●					46-2 / 1
Pipelines for condition and tightness visually inspect		●	●	0	0		
Steering linkage for condition and wear check		●	●				46-3 / 1 46-6 / 1
Fixing screws of the Retighten the steering			●				46-5 / 1
15,54,82 electrical system							
Battery care	Type 435.115		•	0	0		54-1 / 1
Check headlight setting			•			•	82-1 / 1

Table of Contents

Maintenance work (civil vehicles)	Type or aggrega	Maintenance				Zusatzarbeit zu jedem 2. Wtg.-Dienst	Note page
		1D	2 n	Wtg.	Pl.		

55 special installations

Wait the PTO	Type 435.115		•	0	0		55-1 / 1
Check the oil level in the hydraulic system			•				55-2 / 1
Oil change in hydraulic system			•			0	55-3 / 1
Filter maintenance			•			0	55-3 / 1
Pipelines on hydraulic system on condition and check tightness	-	•	•	0	0		